



CTD Data RV Heincke HE471

Data Processing Report

Contents

1	Introduction	1
2	Workflow	1
3	Cruise details	3
4	Sensor Layout	3
5	Processing	3
6	Results	5

Contact:

Gerd Rohardt

Alfred-Wegener-Institute

Am Handelshafen 12, D-27570 Bremerhaven, GERMANY

Mail: info@awi.de

Processing Agency:

FIELAX

Schleusenstr. 14, D-27568 Bremerhaven, GERMANY

Mail: info@fielax.de

Ref.: CTD-HE4/1-report.pdf	Vers.: 1	Date: 2016/09/28	Status: final
----------------------------	----------	------------------	---------------



1 Introduction

This report describes the processing of CTD raw data acquired by Seabird SBE 911plus CTD on board RV Heincke during expedition HE471.

2 Workflow

The different steps of processing and validation are visualized in Figure 1. The CTD raw data are delivered from Gerd Rohardt (AWI). The station book of the RV Heincke cruise is extracted from the DAVIS SHIP data base (https://dship.awi.de). The first CTD station and cast is processed manually in SBE Data Processing to configure the *.psa Seabird routines Data Conversion, Wild Edit, Bottle Summary, Split, Translate, Cell Thermal Mass, Loop Edit and Bin Average. The Seabird routines are then run in a batch job CTDjob in ManageCTD to process the complete CTD data set. The downcast of each CTD station/cast is used for further processing. In CTDjob the start record and the lowest altimeter point of the downcast is selected. With the *Utilities* → *Dship Ebook* function of ManageCTD the DAVIS SHIP station book extraction is used for getting the header information of all CTD stations/casts of the cruise. ManageCTD *Utilities* \rightarrow *Find Profile* function compares station times of the header with the entries in the station book to find out the correct naming of the stations and casts. In CTDheader in ManageCTD the header information of each CTD station/cast is displayed, controlled and corrected if necessary. CTDdespike in ManageCTD is used for a visual check of the data and to erase/interpolate spikes in the data if necessary. Additionally, a sensor pair (Temp1/Sal1 or Temp2/Sal2) is chosen for each station/cast of the RV Heincke cruise in CTDdespike.

ManageCTD *Utilities* \rightarrow *CheckDoubleSensors* controls the quality of temperature and conductivity sensors. For this purpose outliers of too high sensor pair differences could be removed. The data is then converted to spreadsheet format with dsp2odv for visualization of the data in Ocean Data View (ODV). The second visual inspection of the CTD data allows a comparison with data from other CTD casts from close-by stations to verify the oxygen sensor data. Therefore, potential reference cruise data is downloaded from PANGAEA (http://www.PANGAEA.de). The reference data is converted to *.mat format. In the ManageCTD Final Processing the CTD data is displayed together with the reference data. Bad data points, sensors or casts are interpolated or erased from the data set and filters are applied if necessary. The processed CTD data are written to text files and imported to PANGAEA (http://www.PANGAEA.de) for publication.






Figure 1: CTD data Processing Workflow



3 Cruise details

Vessel name RV Heincke

Cruise name HE471

Cruise start 06.09.2016 Bremerhaven
Cruise end 21.09.2016 Bremerhaven

Cruise duration 16 days

No. of CTD casts 27

4 Sensor Layout

This chapter describes the CTD sensors mounted during this cruise: SBE 911plus CTD (SN: 1015), SBE Instrument Configuration Version 7.23.0.1.

ID	Sensor Name	Serial No.	Calibration Date
55	TemperatureSensor	5354	19-Jan-16
3	ConductivitySensor	3810	08-Dec-15
45	PressureSensor	1015	05-Oct-10
55	TemperatureSensor	5375	19-Jan-16
3	ConductivitySensor	2470	08-Dec-15
0	AltimeterSensor	46466	23-Mar-09
71	WET_LabsCStar	1348DR	28-Jan-2016
20	FluoroWetlabECO_AFL_FL_Sensor	1365	15-Jan-2016
38	OxygenSensor	1597	25-May-16

5 Processing

Details of processing procedures and processing parameters are described in *CTD Processing Log-book of RV Heincke* (hdl:10013/epic.47427).

Density Inversions and Manual Validation

Obvius outliers were removed manually. For the visual check density inversions > 0.005 kg/m^3 and > 0.01 kg/m^3 were flagged differently for display but removed automatically. Decisions whether the flagged values were manually removed or not are based on the description in *CTD Processing Logbook of RV Heincke* (hdl:10013/epic.47427).



Sensor Differences




Figure 2: Data accuracy of sensor pairs HE471



6 Results

A complete processing overview for each sensor at each station is summarized in the table in the Appendix (Figure 3).

Double Sensor Check

In Figure 2, the absolute residuals between the two sensorpairs are shown for the measured parameters *Temperature* and *Conductivity* and the derived parameter *Salinity*. Measurements in shallow water depths < 15 m (blue crosses) and gradients between two datapoints exceeding a defined threshold (red crosses) were omitted for accuracy calculation.

	Accuracy	Measurements re-	Remaining measure-				
		moved	ments				
Parameter	given by manufacturer	Surface 0-15m + gradi-	within accuracy specifi-				
		ent filter	cations				
Temperature	$\pm 0.001^{\circ}C$	53.97%	55.88%				
Conductivity	$\pm 0.003mS/cm$	54.11%	77.13%				
Salinity	$\pm 0.0015 PSU$	53.29%	57.92%				

Comments

- 27 CTD/RO "on ground" entries in DShip station book
- 26 CTD raw data sets delivered
- 0 CTD casts were invalid or tests
- 0 CTD casts were made twice on a station
- 2 files had no matching station book entries (076-2.hex, 090.hex)
- 3 station book entries had no matching CTD casts
- 24 CTD casts processed and uploaded
- of these 24 processed CTD casts:
 - 0 oxygen profiles deleted (spiky and not matching to reference casts)
 - 1 data points interpolated
 - 105 data points erased



Result files

Text File (HE471_phys_oce.tab):

The format is a plain text (tab-delimited values) file.

Column separator	Tabulator "\t"
Column 1	Event label
Column 2	Date/Time of event
Column 3	Latitude of event
Column 4	Longitude of event
Column 5	Elevation of event
Column 6	DEPTH, water [m]
Column 7	Pressure, water [dbar]
Column 8	Temperature, water [°C]
Column 9	Conductivity [mS/cm]
Column 10	Salinity [PSU]
Column 11	Temperature, water, potential [°C]
Column 12	Density, sigma-theta [kg/m³]
Column 13	Oxygen [μ mol/l]
Column 14	Oxygen, saturation [%]
Column 15	Attenuation, optical beam transmission
Column 16	Chlorophyll Fluorometer [V]
Column 17	Number of observations

Processing Report (CTD-HE471-report.pdf):

This PDF document.



_																					_	_	_	_							_
	COMMENTS	all transmission data deleted	several salinity data of sensor 2 deleted	no data available			no data available			no data available				no DSHIP entry				no DSHIP entry, no btl-file	no btl-file	no btl-file	no btl-file	no btl-file	no btl-file	no btl-file	no btl-file	no btl-file				several salinity data of sensor 2 deleted	
	Offset	8.0	8.0		6.0	6.0		1.0	6.0		0.3	0.4	0.5		0.3	8.0	8.0		0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7	0.7	П
referenc	ist. (km	10.04	9:95		39.99	40.01		20.76	20.52		0.39	2.97	4.94		5.64	4.41	4.16		1.16	1.36	1.54	1.74	1.92	2.10	2.28	2.49	5.69	1.63	4.43	1.73	
Oxygen reference	interp erased cruise/sss-cc dist. (km Offset	HE453/41-1	HE453/41-1		HE453/13-1	HE453/13-1		HE453/30-1	HE453/30-1		HE470/091-1	HE470/118-1	HE453/78-1		HE453/78-1	HE452/37-1	HE452/14-1		HE452/37-1	HE452/37-1	HE452/37-1	HE452/37-1	HE452/37-1	HE452/37-1	HE452/37-1	HE452/37-1	HE452/37-1	HE452/37-1	HE452/37-1	HE452/37-1	
lete	erased	45	0	0	0	2		10	10	0	10	10	0	0	2	15	0	0	0	0	0	70	0	5	0	0	10	5	0	0	150
complete	interp	0	0	0	1	0		0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	П
_						1		2	2		2	2			1	3						4		1			2	1			12
Oxy	interp																														٥
llyhdi	interp erased interp erased interp erased interp erased interp erased					1		2	2		2	2			1	3						4		1			2	1			21
Chlorophyll	interp																														•
su	erased	45				1		2	2		2	2			1	3						4		1			2	1			99
Trans	interp				1																										П
	erased					1		2	2		2	2			1	3						4		1			2	1			21
Sal	interp																														°
ם	erased					1		2	2		2	2			1	3						4		1			2	1			21
Temp	interp																														-
Sensor	pair	1	1		1	1		1	1		1	1			1	1	1		1	1	1	1	1	1	1	1	1	1	1	1	П
111.474	rile nc4/1_	003	100		014	023		032	041		048	061	920	076_2	082	980	880	060	960	097	099	101	103	105	107	109	111	117	120	122	
Depth	Ξ	44.1	44.3	27.6	27.2	27.2	32.7	32.9	33.3	25.3	24.7	26.4	21.4		21.5	25.8	21.8		23.3	23.6	25.8	26.4	26.6	26.5	27.4	27.3	27.9	27	25.3	29	
Position	Longitude	004° 44.98' E	004° 44.90' E	006° 11.09′ E	N 006° 13.88′ E	006° 13.78′ E	007° 21.44' E	007° 21.44' E	007° 21.53' E	007° 22.74' E	007° 25.57' E	007° 21.13' E	007° 57.69' E		007° 57.70' E	008° 01.12' E	008° 01.54′ 目		007° 57.99′ ∄	007° 58.17' E	007° 58.34' E	007° 58.52' E	007° 58.68' E	007° 58.85' E	007° 59.03' E	007° 59.21' E	007° 59.38' E	007° 58.48' E	008° 01.11' E	007° 58.55' E	
Position	Latitude	55° 15.50' N	55° 15.58' N	53° 59.03' N		z	54° 05.41' N	z	5:55 54° 05.52' N	54° 27.37' N	6:11 54° 26.37' N	54° 28.47' N	54° 10.32' N		54° 10.88' N	z	z		z	z	z	z	z	z	z	54° 02.91' N	54° 02.87' N	6:03 54° 03.09' N	54° 03.89' N	54° 03.04' N	
ï	Ē	6:20	00:9	23:54	6:16	5:50	6:04	6:19	5:55	11:22	6:11	6:05	11:37		60:9	10:11	90:9		6:26	6:42	7:00	7:14	7:27	7:41	8:42	9:01	10:06	6:03	1:55	2:32	
1	Date	07.09.2016	08.09.2016	08.09.2016 23:54 53° 59.03	09.09.2016 6:16 53° 59.38	10.09.2016 5:50 53° 59.42	10.09.2016 6:04 54° 05.4	12.09.2016 6:19 54° 05.40	13.09.2016	13.09.2016	14.09.2016	15.09.2016	16.09.2016 11:37 54° 10.32		17.09.2016 6:09 54° 10.88'	17.09.2016 10:11 54° 03.76	18.09.2016 6:06 54° 04.03		19.09.2016 6:26 54° 03.09	19.09.2016 6:42 54° 03.05	19.09.2016 7:00 54° 03.03	19.09.2016 7:14 54° 03.00	19.09.2016 7:27 54° 02.97	19.09.2016 7:41 54° 02.95	19.09.2016	19.09.2016	19.09.2016 10:06 54° 02.87	20.09.2016	21.09.2016 1:55 54° 03.89	21.09.2016	
, A.P. P.	Gear Appr.	CTD-R	CTD/RO	CTD/RO	CTD-R	CTD/RO	CTD/RO	CTD/RO	CTD/RO	CTD/RO/MIC	CTD/RO	CTD/RO	CTD/RO		CTD/RO	CTD/RO	CTD/RO		CTD/RO	CTD/RO	CTD/RO	CTD/RO	CTD/RO	CTD/RO	CTD/RO	CTD/RO	CTD/RO	CTD/RO	CTD/RO	CTD/RO	
Station	HE471/	0003-1	0010-1	0012-1	0014-1	0023-1	0032-1	0032-1	0041-1	0043-1	0048-1	1-1900	0076-1		0082-1	0086-1	0088-1		0095-1	0097-1	0099-1	0101-1	0103-1	0105-1	0107-1	0109-1	0111-1	0117-1	0120-1	0122-1	

Figure 3: CTD data Processing Summary HE471 Page 7 of 8






Figure 4: ODV Screenshot of HE471 CTD data Page 8 of 8