

NAS8-35591
NASA CR-

(NASA-CR-16-1970) AUTOMATED LONGWALL GUIDANCE AND CONTROL VERTICAL CONTROL SUBSYSTEM, VOLUME 2 Final Report (Foster-Miller Associates, Inc., Waltham, Mass.) 204 p HC A18/MF A01 CSCL ORI 93/83 09157 N82-18-59 Unclass

**AUTOMATED LONGWALL GUIDANCE AND CONTROL
VERTICAL CONTROL SUBSYSTEM**

VOLUME II

**W.R. Griffiths, M. Smirlock, J. Aplin,
R. Fish, D. Fish
Foster-Miller Associates, Inc.**

January 1982

Prepared for:

**NATIONAL AERONAUTICS AND SPACE ADMINISTRATION
George C. Marshall Space Flight Center
Marshall Space Flight Center, AL**



REPORT DOCUMENTATION PAGE

1. Report No. NASA CR-	2.	3. Recipient's Accession No.	
4. Title and Subtitle Automated Longwall Guidance and Control Vertical Control Subsystem		5. Report Date 31 January 1982	6.
7. Author(s) W. Ronald Griffiths, Martin Smirlock, James Aplin, Roger E. Fish, David Fish		8. Performing Organization Report No. NAS7946	
9. Performing Organization Name and Address Foster-Miller Associates, Inc. 350 Second Avenue Waltham, MA 02254		10. Project/Task/Work Unit No.	11. Contract or Grant No. NAS8-33591
12. Sponsoring Organization Name and Address National Aeronautics and Space Administration Geo. C. Marshall Space Flight Center Marshall Space Flight Center, AL 35812		13. Type of Report Contractor Report	
15. Supplementary Notes			
<p>16. Abstract</p> <p>A design fabrication and implementation of a horizon control of a longwall shearer has been performed. This equipment was tested and demonstrated aboveground at the Department of Energy's surface test facility in Bruceton, PA. This hardware was also installed on a longwall face in the Herrin No. 6 seam in southern Illinois. The feasibility of providing horizon control for a shearer was demonstrated aboveground. The feasibility of retrofitting the necessary sensors in a survivable manner was demonstrated underground. Subsequent tests of a specific component, the natural background sensor, at a western location demonstrated the particular usefulness of this device on a wider application basis.</p>			
17. Originator's Key Words Horizon control Underground mining Longwall shearer control Coal interface detection		18. Availability Statement	
19. U.S. Security Classif. of the Report Unclassified	20. U.S. Security Classif. of This Page Unclassified	21. No. of Pages 573	22. Price

LIST OF APPENDICES

	Page
APPENDIX A - SOFTWARE DOCUMENTATION	151
APPENDIX B - PROGRAM LISTING	365

APPENDIX A
SOFTWARE DOCUMENTATION

· VERTICAL CONTROL SYSTEM

NAS-7946

SOFTWARE DOCUMENTATION


January 1982

Roger Fish

VERTICAL CONTROL SYSTEM

PROGRAM INTRODUCTION

VCS PROGRAM STRUCTURE



PROGRAM CAPABILITY

- SENSOR RANGE ERROR CHECKING
- MULTIPLE RUN MODES (CONTROL LAWS)
- MASK CONTROL OF I/O AND OPERATIONS
- NOT DYNAMICALLY SELF PROGRAMMING
- INTERACTIVE INITIALIZATION
- INTERACTIVE DEBUG OF I/O, MEMORY

OPERATIONAL FEATURES

DUAL MODE:

- RUN MODE (AUTOMATIC)
- DEBUG MODE (INTERACTIVE)

SYSTEM INITIALIZATION:

- PARAMETER SET FROM RAM
 - CLEAR RAM BUFFERS
 - SET UP POINTERS AND DEFAULT FLAGS
 - OPERATOR INTERACTION
- MENU BASED MODIFICATIONS PROMPT FOR CLASS AND
ELEMENT CHANGE FLAGS, VARIABLES

OPERATIONAL FEATURES (CONTINUED)


RUN:

- INPUT SENSORS (RANGE CHECK)
- CONTROL FUNCTION COMPUTATION
- OUTPUT CONTROL/DATA
- ERROR TEST
- SYNCHRONIZE TO CLOCK

DEBUG:


- INTERACTIVE SENSOR TEST
- OUTPUT TEST
- MEMORY CHECK/DUMP
- RESTART/INITIALIZE

NORMAL VCS
PROGRAM FLOW





VCS OLD BEN CONTROL ALGORITHM "MODE II"


DELAYED SENSORS
NO PICK AVERAGE




LCX = DELAYED
(LCF + FDRUM * GAIN;











IN DATA (AUTO START)




SUBROUTINE CALL CHAIN




VCS [DEUCETON/KLF
OLD-BEN] HARDWARE

VCS DATA INPUT/CONVERSION


1) INPUT:




2) CONVERSION:



3) RANGE CHECK:





VCS - SYSTEM HARDWARE

VCS MEMORY ALLOCATION

	LOC	
MONITOR CODE	0000H 9FFH	CPU ROM
DATA TABLES (DEFAULT) MESSAGE CODES	A00H 1FFFH	
VARIABLE SPACE COMMUNICATION BUFFERS	2000H	CPU RAM
STACK SPACE	2FFFH	
NOT AVAILABLE	3000H 3FFFH	-
VCS PROGRAM ● EXECUTIVE ● SUPERVISORS ● EXECUTION MODULES ● UTILITY FUNCTIONS ● I/O DRIVERS ● FORTRAN RTL ● MISCELLANEOUS	4000H 67FFH	ROM
SENSOR DATA SPECIAL VARIABLES	7000H 9000H	CMOS RAM

VCS MEMORY ALLOCATION

LOW ROM

MONITOR	0000H 9FF	} 8k
DEFAULT AND TABLES	0A00 0C00	
UNUSED AVAILABLE FOR DIAGNOSTICS, ETC.	0C01 1FFF	

LOW RAM

MONITOR SPACE	2000 20FF	} 4k
VARIABLES ~3 Kb	2100 27FF	
CONTAB, SENBUF	2800	
STACK	2FFF	

I/O PORT NUMBERS

Tape Recorder

	08	OUT	RECHI	; Recorder Data HI byte
	09	OUT	RECLC	; Recorder Data LO byte
	0A	OUT	RECCTL	; Recorder Control
	0B	IN	RECSTA	; Recorder Status

Picks	10	OUT	PICC1	; Pick Control 1
	11	IN	PICS1	; Pick Status 1
	12	OUT	PICC2	
	13	IN	PICS2	
	14	OUT	PICC3	These may not be required.
	15	IN	PICS3	
	16	OUT	PICC4	
	17	IN	PICS4	

Clock	20	Unit 0
	21	Unit 1
	22	Unit 2
	23	Control Port
	24	Counter Output Bit Port (3 bits)
	25	Gate Port

NBS	30
	31
	32
	33
	34

A/D Converter

80	OUT	MROUT	; Multiplexer out reg.
81	IN	MSRIN	; Multiplexer Status Port
82	OUT	MROUTC	; Multiplexer Out Control Port
83	OUT	MSRINC	; Multiplexer Control Port
84	IN	DATA1	; Data Port, MSB
85	IN	DATA 2	; Data Port, LSB

Keyboard Display Card

D0	IN	KDSW	; Keyboard/Display Switch Port
D0	OUT	KDDATA	; Keyboard/Display Data Port
D1	OUT	KDCNTL	; Keyboard/Display Control Port
DC	IN/OUT	CDATA	; EPROM/UART Console Data Port
DD	IN/OUT	CSTAT	; Console Status Port
DE	OUT	SCNTL	; System Control Port
03	OUT	ARMS	Arm Control
04	IN	SWTCH 1	; Front Panel Switches
05	IN	SWTCH 2	; Front Panel Switches
06	OUT	STAT1	; Front Panel Indicators
07	OUT	STAT2	; Front Panel Indicators

LINKAGE OF ASSEMBLY ROUTINES

ORG	Absolute origin
ASEG	Absolute segment
CSEG	Relocatable code segment
DSEG	Relocatable data segment
PUBLIC	Define symbols as public for use by other programs
EXTRN	Symbols from other programs

LINKAGE

Call name (A, B)

REG BC = Address (A)

DE = Address (B)

See INTEL FORTRAN User's Guide

VCS COMMON BLOCKS

/CLOCK/		CLOCK FLAG + COUNTERS
/COMBUF/		COMMUNICATION BUFFERS
/CONTAB/		CONVERSION TABLES
/CNTVEC/		CONTROL VECTORS
/CPANEL/		CONTROL PANEL ARRAY
/DEBUG/		DEBUG MASKS
/DEFAULT/	ROM	DEFAULT DATA
/DEFOPS/		
/DEFTAB/	ROM	DEFAULT DATA
/DEFMOS/		
/ERRFLG/		ERROR FLAG ARRAY
/ERRBUF/		
/IOFVEC/		I/O MASK VECTOR
/MESTAB/	ROM	MESSAGE TABLES I
/MESTB2/	ROM	MESSAGE TABLES II
/MESTB3/	ROM	MESSAGE TABLES III
/OPPARM/		OPERATION PARAMETERS
/OPSPNT/		OPERATION POINTERS
/OPSVEC/		OPERATION VECTOR
/PARAMS/		PARAMETER STORAGE
/PIKBUF/		PICK DATA STORAGE
/SENBUF/		SENSOR INPUT, DATA BUFFER
/SENDEL/		SENSOR DELAY LINES
/SENMEM/	CMOS	NONVOLATILE STORAGE
/SENPNP/		
/SAVER/		
/WORK/		G.P. WORK SPACE
/OPPARM/		
NMAX (1)	=	NMXSEN
NMAX (2)	=	NMXERR
NMAX (3)	=	NMXSIR
NMAX (4)	=	NMXIPM
NMAX (5)	=	NMXOUT
NMAX (6)	=	NMXDSP
NMAX (7)	=	NMXIOF
NMAX (8)	=	NMXCNM,CTV
NMAX (9)	=	NMXDBG
NMAX (10)	=	NMXCBF

/OPPARM/

NMAX (11) = NMXTAP
NMAX (12) = NMXKIB
NMAX (13) = NMXPRM
NMAX (14) = NMXOPS
NMAX (15) = NMXPNT

/IOFVEC/

IOFVEC (1) = IOFSEN
IOFVEC (2) = IOFDED
IOFVEC (3) = IOFPCF
IOFVEC (4) = IOFLCF
IOFVEC (5) = IOFLAP
IOFVEC (6) = IOFRAP
IOFVEC (7) = IOFCID
IOFVEC (8) = IOFPRF
IOFVEC (9) = IOFPRR
IOFVEC (10) = IOFVCF
IOFVEC (11) = IOFVCR
IOFVEC (12) = IOFVOT
IOFVEC (13) = IOFDSP
IOFVEC (14) = IOFKEY
IOFVEC (15) = IOFCAS
IOFVEC (16) = IOFCRT
IOFVEC (17) = IOFCDU

/CNTVEC/

CNTVEC (1)	=	CTVCID	CID
CNTVEC (2)	=	CTVLCF	LAST CUT
CNTVEC (3)	=	CTVPRF	PICK F
CNTVEC (4)	=	CTVPRR	PICK R
CNTVEC (5)	=	CTVPCF	PAST CUT
CNTVEC (6)	=	CTVVCF	VALVE F
CNTVEC (7)	=	CTVVCR	VALVE R
CNTVEC (8)	=	CTVFRT	FRONT CNTL
CNTVEC (9)	=	CTVRER	REAR CNTL
CNTVEC (10)	=	CTVOUT	CNTL OUTPUT

/PARAMS/

DMAX - DRUM MAY
DMIN - DRUM MIN
ERRLMT - MAX# ERRORS FOR TRIP
SEAM - SEAM HEIGHT
PIKAVE - PICK AVERAGE #
PKSTEP - PICK STEP VALUE
DEDEBF - FRONT DEAD BAND
DEDEBR - REAR DEAD BAND
ARMLNG - ARM LENGTH POT GAIN = 1

/PARAMS/

DRMRAD - DRUM RADIUS
LCPOS - LCF MOUNTING POS (DFD UNITS)
PCPOS - PCF MOUNTING POS (DFD UNITS)
CIDPOS - CID MOUNTING POS (DFD UNITS)
STRLOC - FRONT TO REAR DIST. (DFD UNITS)
DFDFCT - DFD GAIN FACTOR = 1
SNDSTP - CMOS STEP UPDATE DISTANCE
DBIASF - BIAS FRONT
DBIASR - BIAS REAR
SRKVAL - SENSOR RATE LIMIT VALUE
TRGFCT - TRIG COMPENSATION FACTOR

/OPSVVEC/

OPMODE - OPERATION MODE
MODECT - CONTROL MODE
RNGMSK - RANGE CHECK FLAG
OPSENR - SENSOR DELAY FLAG
RATECK - RATE CHECK FLAG
STAT - SYSTEM STATUS
FDVGN - FRONT CONTROL GAIN
FDCAL - FRONT TRIG FACTOR
RDVGN - REAR CONTROL GAIN
RDCAL - REAR TRIG FACTOR

PROGRAM OPERATION PARAMETERS

/OPPARM/ ICMPTNT(10), NMXVEC(16), NMXIPX(6)

ICMPTNT(1)	7	CID MAP CONTRU SET INTO MESSAGE VECTOR
(2)	4	LCF
(3)	8	PKF
(4)	9	PKR
(5)	3	PCF
(6)	10	VCF
(7)	11	VCR
(8)	18	FRT
(9)	19	RER
(10)	20	OUT

NMXVEC(1)	8	NMXSEN
(2)	8	NMXERR
(3)	0	NMXSIR
(4)	6	NMXIPM
(5)	0	NMXOUT
(6)	8	NMXDSP

NMXVEC (7)	20	NMXIOF
(8)	10	NMXCNM, CTV
(9)	9	NMXDBG
(10)	8	NMXCBF
(11)	128	NMXTAP
(12)	8	NMXKTB
(13)	20	NMXPRM
(14)	0	NMXOPS
(15)	8	NMXPNT
(16)	0	DUMMY

NMXIPX (1)	17	I/O	NUMBER OF PROMPTS TO ASK
(2)	10	CONTROL	FOR EACH TYPE
(3)	4	OPERATION	
(4)	10	PARAMETERS	
(5)	1	CMOS MEM TABLE	
(6)	32	SENSOR TABLES	

ASCII TABLES

/MESTAB/
ERRMES: CHARACTER*4 (20)

1	\$SEN
	\$DPD
	\$PCF
	\$LCF
5	\$LAP
	\$RAP
	\$CID
	\$PKF
	\$PKR
10	\$VCF
	\$VCR
	\$VOT
	\$DSP
	\$KEY
15	\$CAS
	\$CRT
	\$CDU
	\$FRT
	\$RER
20	\$COT

DBGMES: CHARACTER*4 (20)

1	@DBG
	OUT?
	INP?
	DAT?
5	ITZ?
	TAP?
	I/O?
	CLK?
	MEM?
10	DUMP
	END?
	@SYS
	PORT
	CHNL
15	UP
	DOWN
	MAN
	MODE
	WRIT
20	ADR?

RUNMES: CHARACTER*4 (20)

1	?I/O
	?CNT
	?OPS
	?VRB
5,6	*RUN-OK*
7,8	*DEBUG *
9,10	?CALBRAT
	?PAUSE ?
	MASK
	PARM
15	ERR
	?-STOP-?
	-EXIT-
20	##

DSPCODE: CHARACTER*1 (10)

1:	\$ * # & ?
6:	@ ? = /

PARAMETER MESSAGE TABLE

PARMES (20)

CHARACTER*4

/MESTB2/

1	DMAX
2	DMIN
3	ERLM
4	SEAM
5	PAVE
6	PKSP
7	DBDF
8	DBDR
9	LENG
10	DRAD
11	LCPS
12	PCPS
13	CDPS
14	FLOC
15	DFCT
16	DSTP
17	FBAS
18	RBAS
19	SKRV
20	TRGF

/MESTB3/

OPSMES: CHARACTER*4 (10)

1: OPER
MODE
RANG
OSDL
5: RATE
STAT
FDVG
FCAL
RDVG
RCAL

OPERATION VARIABLE VALUES

OPMODE:	-1	REBOOT
	0	STOP
	1	RUN
	2	DEBUG
	3	HALT
	4	MANUAL
	5	CALIBRATE
MODECT:	0	NO CONTROL
	1	MODE II
	2,4	MODE I
	3	REAR SLAVE
RANG:	0	NO CHECK
	1	RANGE CHECK
OPSENR:	0	DIRECT
	1	DELAYED (PREVIEW)
RATECK:	0	NO CHECK
	1	RATE CHECK
STATUS:	0	SYSTEM COLD START
	1	RUNNING

SENSOR INDEX POINTER

SINPNT:		
	1	DFD
	2	PCF
	3	LCF
	4	LAP
	5	RAP
	6	CID
	7	PKF
	8	PKR

USED FOR CONTROL OF A/D AND CONVERSION AND RANGE
CHECK TABLE ENTRIES

POINTS INTO SIB OR SDB ENTRIES FOR APPROPRIATE VALUE

VCS ERROR CODES

ERROR (1) = I (SINPNT) FOR SENSOR INPUT RANGE ERROR POSITIVE
I + 10 FOR NEGATIVE

ERROR (2) = 1 IF 39 VOLT FAILURE

ERROR (3) = 1 CAL SWITCH $\overline{\text{RUN}}$ FROM RUN MODE

ERROR (4) RATE CHECKING
= 1 LCF ERROR
= 10 PCF
= 11 BOTH

ERROR (5) = N; CASSETTE ERROR (DUMMY (2))
ERROR FLAG BYTE = STATUS FROM CASSETTE

ERROR (6) CMOS DATA NOT READY MODE I MODECT = 2 or 4

PROGRAM MODULES

VCS SUPERVISOR PROGRAM

Main program: VCSSUP

Main program calls supervisor routines based on flags and of modes.

Inputs: Control information buffers

Outputs: Nothing

Calls: SUPINP, SUPOUT, SUPCNT, SUPDEG, SUPITZ, SUPCAL,
SUPERR, SUPEXT, SUPHLT

Destroys: Nothing


Modifies: Nothing


Language: FORTRAN 80


L-V-A: Version 1, Level 1
Roger B. Fish


MODULE: VCSPRG

VCSPRG is the main program executive module of the VCS software. The main program supervises operation of the VCS by calling the appropriate supervisor routines to perform the required operations. VCSPRG continuously monitors operation parameters (OPMODE, ERROR(I)) and calls the relevant routines to handle the condition. (For example, DEBUG, RUN, INITIALIZE, ERROR PROCESSING.) Communication between modules in the VCS software, except for certain I/O drivers, is via global COMMON blocks. VCS operates by continuously scanning the mode and status data and looping through its test code. The routine first inputs all sensor and control variables and then tests for supervisor routines to be called. Unless the supervisor causes a program termination, the system outputs are then updated and the process repeats.









SUPERVISOR SUBROUTINES

SUPINP	Input supervisor (sensors)
SUPOUT	Output supervisor
SUPCNT	Control supervisor
SUPDBG	Debug supervisor
SUPITZ	Initialization routine
SUPERR	Error handler
SUPEXT	Exit routine
SUPCAL	Calibration routines (restart)
SUPHLT	Program hard pause

SUPERVISOR CONTROL ROUTINE

SUBROUTINE: SUPINP

SUPINP Control input to the VCS

Inputs: I/O control buffer

Outputs: Nothing

Calls: SENINP, INPCDU, CONVRT

Destroys: Nothing


Modifies: Sensor input buffer


Language: FORTRAN 80


L-V-A: Version 1, Level 1
Roger B. Fish

MODULE: SUPINP

SUPINP is the supervisor routine which inputs sensor and control data to the VCS. The routine reads the operator control panel switches and then tests if sensor I/O is enabled by an I/O flag. If the flag, IOFSEN, is true, the sensor input routines SENINP for LCF, PCF, etc. is called. The sensor conversion routine CONVRT is called to convert the raw sensor data into appropriate engineering units.







SUPERVISOR CONTROL ROUTINE

Subroutine: SUPOUT

 SUPOUT controls outputs from the VCS

Inputs: I/O control vector

Outputs: Nothing

Calls: CNTOUT, SAVDAT, FORMAT, CLOCK, INTREN,
 OUTDSP, OUTPUT

Destroys: Nothing

Modifies: Nothing


Language: FORTRAN 80


L-V-A: Version 1, Level 1
 Roger B. Fish


MODULE: SUPOUT

SUPOUT is the supervisor routine which outputs data from the VCS to the various control devices, control indicators, and operator control panel.

The operation mode value (OPMODE) is tested and an appropriate message is displayed on the display panel, and appropriate output routines are called. Display information for the control display is formatted and output. Finally, CLOCK is called for system synchronization.







SUPERVISOR CONTROL ROUTINE

Subroutine: SUPCNT

SUPCNT controls VCS control algorithm use and signal generation.

Inputs: Operation control vectors

Outputs: Nothing

Calls: CNTRFD, CNTRRD

Destroys: Nothing


Modifies: Nothing

Language: FORTRAN 80

L-V-A Version 1, Level 1
 Roger B. Fish

MODULE: SUPCNT

SUPCNT is the VCS control algorithm supervisor routine. This routine tests the control operation flags and control words and calls the appropriate routine to control the front, rear, or output the valve control signals.



SUPERVISOR CCNTROL ROUTINE

Subroutine: SUPDBG

SUPDBG is the debug operation routine

Inputs: Debug control vector

Outputs: None

Calls: DBUGCI, DBUGCO, DBUGIN, DBUGOT, DBUGTP,
ITZINP, DBUGCK, DBUGME, DBUGIO, INTRDS

Destroys: Nothing


Modifies: Nothing


Language: FORTRAN 80

L-V-A: Version 1, Level 1
Roger B. Fish

MODULE: SUPDBG

SUPDBG is the debug interaction supervisor. SUPDBG is called by *MAIN* when OPMODE is set to the debug value. SUPDBG then calls the debug control input routine DBUGCI which prompts the user for the appropriate control input to select one of the debug options. When debug is complete, the routine returns to *MAIN*. SUPDBG can also call the interactive initialization routine ITZINP if the operator wishes to modify any variables.





SUPERVISOR CONTROL ROUTINE

Subroutine: SUPITZ

SUPITZ initializes the program variables buffers and control variables.

Inputs: None

Outputs: System initialized

Calls: INTRDS, INTRCN, OUTDSP, AIOITZ, ITZINP,
 INPCDU, RESTRT, TAPITZ

Destroys: Nothing

Modifies: Input buffers, parameters, interrupts,
 control information


Language: FORTRAN 80


L-V-A: Version 1, Level 1
 Roger B. Fish


MODULE: SUPITZ


SUPITZ is the program initialization routine. SUPITZ takes care of initializing I/O interfaces via AIOITZ, clears I/O buffers to zero, and loads common blocks from the default ROM areas. The default values are copied into RAM memory so that the values can be modified via routine ITZINP.

SUPITZ also calls INTRDS to disable system interrupts.









SUPERVISOR CONTROL ROUTINE

Subroutine: SUPERR

 SUPERR processes error condition flags and outputs message.

Inputs: Error flag vector

Outputs: D/C error message


Calls: OUTDSP, INPCDU, FORMAT


Destroys: Error flags

Modifies: Nothing

Language: FORTRAN 80

L-V-A: Version 1, Level 1
 Roger B. Fish





SUPERVISOR CONTROL ROUTINE

Subroutine: SUEXT

SUEXT exits from the VCS program after closing data base.

Inputs: None

Outputs: None


Calls: CLOCK, INTRDS, INPCDU, OUTDSP, CNTOUT,
 INTREN


Destroys: S1B, SDB, ERRORS


Modifies: Pointers, control words


Language: FORTRAN 80

L-V-A: Version 1, Level 1
 Roger B. Fish









SUPERVISOR CONTROL ROUTINE

Subroutine: SUPCAL

SUPCAL calls the system restart (warm start) routine.

Inputs: None

Outputs: OPMODE


Calls: RESTRT, INPCDU, OUTDSP


Destroys: Nothing

Modifies: OPSVEC, DOB

Language: FORTRAN 80

L-V-A: Version 1, Level 1
 Roger B. Fish





SUPERVISOR CONTROL MODULE

SUBROUTINE: SUPHLT

SUPHLT stops VCS program operation by stopping clock interrupts and blocks program flow.

Inputs: None

Outputs: OPMODE


Calls: INTREN, INTRDS, INPCDU, OUTDSP


Destroys: DOB


Modifies: OPSVEC

Language: FORTRAN 80

L-V-A: Version 1, Level 1
 Roger B. Fish







SUPERVISOR EXECUTION MODULES:

SENINP	-	Sensor input
CONVRT	-	Sensor conversion
CNTOUT	-	Control signal output
ITZINP	-	Initialization routine
RESTRT	-	Reset system, cold start

SUPERVISOR EXECUTION MODULE

Subroutine: SENINP

 SENINP calls sensor input routines under I/O mask control.

Inputs: I/O mask buffer

Outputs: None


Calls: AIOADC, SENRLM, INPCID, INPPKS, ADCITZ


Destroys: Nothing

Modifies: Sensor input buffer

Language: FORTRAN 80

L-V-A: Version 1, Level 1
 Roger B. Fish





SUPERVISOR EXECUTION MODULE

Subroutine: CONVRT

CONVRT converts sensor input data to engineering units,
and does range checking.

Inputs: Sensor input data

Outputs: None


Calls: CONFNC


Destroys: Nothing

Modifies: Nothing

Language: FORTRAN 80

L-V-A: Version 1, Level 1
 Roger B. Fish





SUPERVISOR EXECUTION MODULE

Subroutine: CNTOUT

CNTOUT is the controller output routine. This calls the appropriate output routines as per the I/O controls.

Inputs: I/O control vectors, controller outputs

Outputs: None


Calls: AIOVOT


Destroys: Nothing


Modifies: Nothing

Language: FORTRAN 80

L-V-A: Version 1, Level 1
Roger B. Fish







SUPERVISOR EXECUTION MODULE

Subroutine: ITZINP

ITZINP prompts the user and updates the value of some variables in the program.

Inputs: None

Outputs: None


Calls: OUTDSP, INPCDU, INTRDS, INPHEX, OUTPUT


Destroys: CMOS (Optional)


Modifies: Variable input by user


Language: FORTRAN 80


L-V-A: Version 1, Level 1
 Roger B. Fish











SUPERVISOR EXECUTION MODULE

Subroutine: RESTRT

RESTRT initializes and clears data which is run dependent
for restart.

Inputs: None

Outputs: None


Calls: TAPITZ


Destroys: SENPTR(I), ERRBUF(I), TFLAG(I), PKBUFS,
SENDEL(I)

Modifies: Status, pointers, OPMODE

Language: FORTRAN

L-V-A: Version 1, Level 1
Roger B. Fish





SUPERVISOR EXECUTION MODULE:

Control Routines

CNTREFD - Front drum control

CNTRRD - Rear drum control

SUPERVISOR EXECUTION MODULE

Subroutine: CNTRFD

 CNTRFD computes the front drum control signal. Algorithm
 is controlled by inputs and mode control.

Inputs: Sensor data, control information

Outputs: Front drum control signal


Calls: Nothing


Destroys: Nothing


Modifies: Control output, front (VOB)


Language: FORTRAN 80


L-V-A: Version 1, Level 1
 Roger B. Fish














SUPERVISOR EXECUTION MODULE

Subroutine: CNTRRD

 CNTRRD computes the rear drum control signal. Algorithm
 is controlled by inputs and mode control.

Inputs: Sensor data, control information

Outputs: Front drum control signal


Calls: Nothing


Destroys: Nothing


Modifies: Control output, rear (VOB)


Language: FORTRAN 80

L-V-A: Version 1, Level 1
 Roger B. Fish









SUPERVISOR EXECUTION MODULES:

Debugger Routines

DEBUGCI	-	Input control
DEBUGCO	-	Output
DEBUGIN	-	Sensor scan
DEBUGOT	-	Output (valve)
DEBUGIO	-	I/O channel test
DEBUGTP	-	Tape check
DEBUGCK	-	Clock test
DEBUGME	-	Memory display/modify

SUPERVISOR EXECUTION MODULE

Subroutine: **DEBUGCI**

DEBUGCI reads debug control information from control/
display panel.

Inputs: **Debug control vector**

Outputs: **None**


Calls: **INPCDU, OUTDSP, PAUSE**


Destroys: **Nothing**

Modifies: **Debug control vector**

Language: **FORTRAN 80**

L-V-A: **Version 1, Level 1**
 Roger B. Fish





SUPERVISOR EXECUTION MODULE

Subroutine: DEBUGCO

 DEBUGCO outputs debug information to control/display panel.

Inputs: Debug control vector

Outputs: Debug messages


Calls: OUTDSP, CLOCK


Destroys: Nothing

Modifies: Nothing

Language: FORTRAN 80

L-V-A: Version 1, Level 1
 Roger B. Fish





"@DBG"

SUPERVISOR EXECUTION MODULE

Subroutine: DEBUGIN (FLAG)

 DEBUGIN reads sensor data via I/O routines as per input.

Inputs: Sensor buffer, control vector

Outputs: None


Calls: SENINP, PAUSE, OUTDSP, FORMAT, INPCDU,
 CONVRT


Destroys: Nothing


Modifies: Sensor input data (SDB)

Language: FORTRAN 80

L-V-A: Version 1, Level 1
 Roger B. Fish







SUPERVISOR EXECUTION MODULE

Subroutine: DEUGOT

DEUGOT outputs debug control signals to front and rear arms.

Inputs: Debug control vector

Outputs: Drum control signals


Calls: INPCDU, CNTOUT, OUTDSP


Destroys: Nothing

Modifies: Nothing

Language: FORTRAN 80

L-V-A: Version 1, Level 1
 Roger B. Fish





SUPERVISOR EXECUTION MODULE

Subroutine: DEBUGIO

 DEBUGIO reads an I/O channel or port and displays value.

Inputs: None

Outputs: None


Calls: FORMAT, OUTDSP, PAUSE, INPCDU, SENINP


Destroys: Nothing


Modifies: DOB

Language: FORTRAN

L-V-A: Version 1, Level 1
 Roger B. Fish







SUPERVISOR EXECUTION MODULE

Subroutine: DBUGTP

 DBUGTP checks tape cassette operation.

Inputs: None

Outputs: None


Calls: AIOCAS, MSEC2H, PAUSE, OUTDSP


Destroys: Nothing

Modifies: TOB, DOB

Language: FORTRAN

L-V-A: Version 1, Level 1
 Roger B. Fish





SUPERVISOR EXECUTION MODULE

Subroutine: DEBUGCK

 DEBUGCK checks the clock timer for VCS synchronization.

Inputs: None

Outputs: None


Calls: CLOCK, INTREN


Destroys: Nothing

Modifies: Nothing

Language: FORTRAN 80

L-V-A: Version 1, Level 1
 Roger B. Fish





SUPERVISOR EXECUTION MODULE

Subroutine: DDUGME

DDUGME displays memory to the operator via LEDS.

Inputs: None

Outputs: None


Calls: OUTDSP, INPCDU, AGETIT, INPHEX, FORMAT,
APUTIT


Destroys: Nothing

Modifies: DOB, memory location if "PUT"

Language: FORTRAN 80

L-V-A: Version 1, Level 1
Roger B. Fish






"ADR? U⁰⁴U"

GET ADDRESS

"ADR = #"



UTILITY ROUTINES

PAUSE	-	Wait at KEYPAD
CLOCK	-	Clock synchronizer
INPCDU	-	Read C/D panel
INPHEX	-	Input a HEX value
CONFNC	-	Convert sensor to data
RANGCK	-	Range check on sensors
SENRLM	-	Sensor rate limit test
INPCID	-	Input CID value
INPPKS	-	Input pick data
OUTCAS	-	Output data to cassette
OUTDSP	-	Display in LEDS
SAVDAT	-	Store data in CMOS and for cassette
TAPITZ	-	Initialize tape header.

I/O UTILITY ROUTINES

Subroutine: PAUSE

PAUSE waits for any key to be pressed on the display/
control.

Inputs: None

Outputs: None


Calls: INPCDU, OUTDSP


Destroys: Nothing

Modifies: DOB

Language: FORTRAN 80

L-V-A: Version 1, Level 1
Roger B. Fish





G.P. UTILITY ROUTINES

Subroutine: CLOCK

CLOCK synchronizes VCS timing by waiting for a timer interrupt (1 second), times out after 2 seconds.

Inputs: None

Outputs: None


Calls: Nothing

Destroys: Nothing

Modifies: Clears TFLAG (3) = 0

Language: FORTRAN 80

L-V-A: Version 1, Level 1
 Roger B. Fish



I/O UTILITY ROUTINES: INPUT

Subroutine: INPCDU

INPCDU inputs the data from the C/D via port 04.

Inputs: None

Outputs: C/D input in PIB


Calls: AIOCDU


Destroys: Nothing

Modifies: /WORK/, /CPANEL/, /ERRFLG/

Language: FORTRAN 80

L-V-A: Version 1, Level 1
Roger B. Fish





READ C/D
INPUTS

NEXT
ADJUST
RESET
MODE,
ETC.

I/O UTILITY ROUTINES: INPUT

Subroutine: INPHEX

INPHEX gets a HEX number from the C/D by prompting.

Inputs: None

Outputs: HEX value in TEMPIO


Calls: AIOC DU, OUTDSP, FORMAT


Destroys: Nothing


Modifies: /WORK/

Language: FORTRAN 80

L-V-A: Version 1, Level 1
Roger B. Fish







I/O UTILITY ROUTINES: CONVERSION

Subroutine: CONFNC

CONFNC is a table driver routine which is used to convert sensor inputs to engineering unit data.

Inputs: Sensor index SENPNT

Outputs: None


Calls: RANGCK (opt)


Destroys: Nothing

Modifies: TEMPIO

Language: FORTRAN 80

L-V-A: Version 1, Level 1
Roger B. Fish





I/O UTILITY ROUTINES: CONVERSION

Subroutine: RANGCK

RANGCK test converted sensor data against max and min
stored in table

Inputs: Sensor index pointer

Outputs: ERROR FLAG 1


Calls: Nothing

Destroys: Nothing

Modifies: SDB, ERROR (1)

Language: FORTRAN 80

L-V-A: Version 1, Level 1
Roger B. Fish



I/O UTILITY ROUTINES: SENRLM

Subroutine: SENRLM

SENRLM is the reasonableness check on the LCF, PCF data.

Inputs: SDB, LCF, PCF ; STATUS

Outputs: SDB, LCF, PCF, ERROR (4)


Calls: Nothing


Destroys: Nothing

Modifies: LCF, PCF, ERROR (4), STATUS

Language: FORTRAN 80

L-V-A: Version 1, Level 1
Roger B. Fish





I/O UTILITY ROUTINES: INPUT

Subroutine: INPCID

INPCID inputs the CID data via port 01, control via port 02

Inputs: None

Outputs: CID data in SIB


Calls: AIOCID


Destroys: Nothing

Modifies: SIB

Language: FORTRAN 80

L-V-A: Version 1, Level 1
Roger B. Fish





I/O UTILITY ROUTINES: INPUT

Subroutine: INPPKS

INPPKS inputs the front pick signal via port 10H

Inputs: None

Outputs: Pick (front and rear) data in SIB


Calls: INPUT (FORTRAN BYTE I/O)


Destroys: Nothing

Modifies: SIB

Language: FORTRAN 80

L-V-A: Version 1, Level 1
Roger B. Fish





I/O UTILITY ROUTINES: OUTPUT

Subroutine: OUTCAS

OUTCAS outputs the cassette output buffer to the digital cassette via port 08, 09, 0A, control port 0B.

Inputs: None

Outputs: TOB


Calls: AIOCAS


Destroys: Nothing

Modifies: Nothing

Language: FORTRAN 80

L-V-A: Version 1, Level 1
Roger B. Fish





I/O UTILITY ROUTINES: OUTPUT

Subroutine: OUTDSP

OUTDSP outputs an ASCII character string to the (7303) display.

Inputs: ASCII string in DOB

Outputs: None


Calls: AIODSP (DOB (1))


Destroys: Nothing

Modifies: Nothing

Language: FORTRAN 80

L-V-A: Version 1, Level 1
Roger B. Fish





SUPERVISOR EXECUTION MODULE

Subroutine: SAVDAT

SAVDAT stores sensor data into CASDAT buffer for tape
dump and DFD + LCF into SNDATA buffer (Mode 1).

Inputs: None

Outputs: None


Calls: None

Destroys: Nothing

Modifies: DATPNT, SNDATA BUFFER

Language: FORTRAN 80

L-V-A: Version 1, Level 1
 Roger B. Fish



I/O UTILITY ROUTINE: OUTPUT

Subroutine: TAPITZ

TAPITZ writes the data tape file header.

Inputs: None

Outputs: None


Calls: AIOCAS, OUTDSP, MSEC2H


Destroys: WORK/


Modifies: DOB


Language: FORTRAN 80


L-V-A Version 1, Level 1
Roger B. Fish











I/O DRIVERS + INTERRUPT ROUTINES

AIODSP	-	Display call to monitor
FORMAT	-	Format # into HEX
APUTIT	-	Put a BYTE into memory
AIOCID	-	CID I/O driver
AIOCAS	-	Cassette I/O driver
AIOVOT	-	Valve I/O driver
AIOITZ	-	I/O initializer routine
AIOADC	-	A/D I/O driver
AGETIT	-	Get a BYTE from memory
AIOCDD	-	C/D I/O driver
INTRPT	-	Interrupt handler (timer)
INTREN	-	Interrupt enable
INTRDS	-	Interrupt disable

I/O DRIVER ROUTINES:

Subroutine: AIODSP (DOB (1))

AIODSP writes ASCII data to the display unit (7303)
via the monitor from DOB

Inputs: Address of DOB (1) in BC

Outputs: None


Calls: MONITOR : OUTPT


Destroys: F/F's, A

Modifies: Nothing

Language: ASSEMBLER 8080/8085

L-V-A: Version 1, Level
Roger B. Fish





I/O UTILITY ROUTINES:

Subroutine: FORMAT (ADDR)

 FORMAT turns a HEX value in DOB (5,6) to ASCII code,
 in (BC 5, 6, 7, 8)

Inputs: None

Outputs: None


Calls: MONITOR: HEXASC


Destroys: A, F/F, BC, HL


Modifies: DOB

Language: ASSEMBLER 8080/8085

L-V-A: Version 1, Level 1
 Roger B. Fish







I/O UTILITY ROUTINES:

Subroutine: APUTIT (TEMPIO)

APUTIT stores a BYTE in memory complementary to AGETIT.

Inputs: Address in TEMPIO and BYTE @ TEMPIO + ±

Outputs: None


Calls: Nothing

Destroys: A, BC, F/F's, HL

Modifies: BYTE @ TEMPIO

Language: ASSEMBLER 8080/8085

L-V-A: Version 1, Level 1
 Roger B. Fish



I/O DRIVER ROUTINES:

Subroutine: AIOCID (I)

 AIOCID reads the CID data from port 01, into TEMP10

Inputs: None

Outputs: None


Calls: Nothing

Destroys: F/F's, A

Modifies: TEMP10

Language: ASSEMBLER 8080/8085

L-V-A: Version 1, Level 1
 Roger B. Fish



I/O DRIVER ROUTINES:

Subroutine: AIOCAS (BUF)

AIOCAS writes data from the cassette output buffer to
tape.

Inputs: None

Outputs: None


Calls: Nothing


Destroys: F/F's, A


Modifies: Nothing

Language: ASSEMBLER 8080/8085

L-V-A: Version 1, Level 1
 Roger B. Fish







I/O DRIVER ROUTINES:

Subroutine: AIOVOT

AIOVOT is the valve control I/O driver routine.

Inputs: CBYTE control word

Outputs: Valve control interface lines


Calls: Nothing

Destroys: A, F/F's, BC

Modifies: Valve control lines

Language: ASSEMBLER 8080/8085

L-V-A: Version 1, Level 1
 Roger B. Fish



I/O DRIVER ROUTINES:

Subroutine: AIOITZ

AIOITZ initializes I/O interfaces for operation at machine startup

Inputs: None

Outputs: None


Calls: ADCITZ, CLKITZ (local subroutines)

Destroys: A, F 'F's, BC, DE, HL

Modifies: Interface status

Language: ASSEMBLER 8080/8085

L-V-A: Version 1, Level 1
 Roger B. Fish



I/O DRIVER ROUTINES:

Subroutine: AIOADC (I, J)

AIOADC reads signals from the A/D converter into the
SIB

Inputs: Sensor index, output data

Outputs: Sensor data to TEMP10


Calls: Nothing

Destroys: F/F's

Modifies: TEMP10 = /WORK/

Language: ASSEMBLER 8080/8085

L-V-A: Version 1, Level 1
Roger B. Fish



G.P. UTILITY ROUTINES:

Subroutine: **AGETIT (I, J)**

AGETIT takes the HEX address of TEMPIO in BC loads
the value and puts it in address held in DE.

Inputs: **I = HEX**

Outputs: **J = HEX value**


Calls: **Nothing**

Destroys: **BC, DE**

Modifies: **DOB**

Language: **ASSEMBLY 8080/8085**

L-V-A: **Version 1, Level 1**
 Roger B. Fish



I/O DRIVER ROUTINES:

Subroutine: AIOCDU (BUF)

 AIOCDU reads data from the C/D panel port 04.

Inputs: (BC) points to work buffer

Outputs: None

Calls: None


Destroys: A, F/F's, DE, HL


Modifies: Work vector

Description: Generator 8 bytes of local data BUF

Language: ASSEMBLER 8080/8085

L-V-A: Version 1, Level 1
 Roger B. Fish





I/O UTILITY ROUTINES: INTERRUPT

Subroutine: INTRPT

INTRPT is the clock interrupt service routine.

Inputs: None

Outputs: None

Calls: OUTCAS

Destroys: Nothing

Modifies: Interrupt counters and flags in monitor code

Language: ASSEMBLER 8080/8085

I-V-A: Version 1, Level 1
 Roger B. Fish

CASSETTE INTERRUPT STRUCTURE

```
Monitor:          RST ~ 5.5
                  Call INTRPT
                  RET
                  :
                  :

INTRPT:           Read clock port
                  Test if 1 second
                  Test if 100 msec
                  Test if 1 msec

ONESEC:           Set flag BYTE (sec)
                  Add 1 to count (sec)
                  RET

HUNDRED:          Set flag BYTE (100 msec)
                  Call OUTCAS
                  RET

MILSEC:           Set flag BYTE (1 msec)
                  RET
```

Timer generates an interrupt every 1 msec, but only 100 msec and 1 sec are wired to CPU RST 5.5.

OUTCAS:

 If test mask

Then:

 IF OPPNTS (3) > = 100; OPPNTS (3) = 0, RET

 IF OPPNTS (2) > 0, then

 Call cassette output

 OPPNTS (2) = OPPNTS (2) -1

 OPPNTS (3) = OPPNTS (3) +1

 END IF

Else:

 If OPPNTS (3) > = 64

 OPPNTS (3) = 111

 RET

 END

AIOCAS:

 Get ARGS + ADDRESSES

 Test if write; go to write

 Test if F.FORWARD

 ENT

Write:


 Test status


 Error go to error


 Write 16 bits to ports

 Send write command 5 μ sec

 END







I/O UTILITY ROUTINES: INTERRUPT

Subroutine: INTREN

INTREN enables CPU interrupts.

Inputs: None

Outputs: None

Calls: Nothing

Destroys: Nothing

Modifies: CPU interrupt masks

Language: ASSEMBLER 8080/8085

L-V-A: Version 1, Level 1
Roger B. Fish

I/O UTILITY ROUTINES: INTERRUPT

Subroutine: INTRDS

INTRDS disables CPU interrupts.

Inputs: None

Outputs: None

Calls: Nothing

Destroys: Nothing

Modifies: CPU interrupt masks

Language: ASSEMBLER 8080/8085

L-V-A: Version 1, Level 1
 Roger B. Fish

APPENDIX B
PROGRAM LISTING

ISS-11 FORTRAN-90 V2.4 COMPILATION OF PROGRAM UNIT VCSFPG
 OBJECT MODULE PLACED IN :F1:VCSFPG.GPJ
 COMPILER INVOKED BY: FORTE0 :F1:VCSFPG.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      PROGRAM VCSFPG
      C VCS MAIN SUPERVISOR PROGRAM
      C
      C MAIN PROGRAM CALLS SUPERVISOR ROUTINES BASED ON
      C FLAG AND OPERATION MODE CONTROLS
      C
      C INPUTS: CONTROL INFORMATION BUFFERS
      C OUTPUTS: NONE
      C CALLS: SUPINP, SUPOUT, SUPCNT, SUPDEG, SUPITZ,
      C         SUPERR, SUPEXT, SUPCAL, SUPHLT
      C DESTROYS: NOTHING
      C MODIFIES: NOTHING
      C VERSION 1.0
      C
2      $INCLUDE('F1:VCSMEN.FOR')
      = *****
      = C
      = C VCS SYSTEM MEMORY ALLOCATION
      = C
3      =      IMPLICIT INTEGER*2(A-Z)
4      =      INTEGER*1  CID, KIB, DOB, TOB, PIB, PCB, VOB
5      =      INTEGER*1  PKFEUF, PKREUF, PKFSRV, PKRSRV
6      =      INTEGER*1  NIXIPX(6), TFLAG(6)
7      =      INTEGER*1  ERKEUF(8,10)
      = C
8      =      LOGICAL*1  IOFVEC(20), CNTVEC(16), SINT(8), SMSK(8), DEGM(8)
9      =      LOGICAL*1  DEFIOV(20), DEFCTV(16)
10     =      LOGICAL*1  NEXT, ADJUST, RESET, RUN, CALRT, FHRFAL, AUTO, MANUAL
      = C
11     =      CHARACTER*4  PARMES, MOSMES(10)
12     =      CHARACTER*1  DEPCOD(10)
13     =      CHARACTER*4  DOBC, DCCH, CPMES(10)
14     =      CHARACTER*4  ERRMES(20), DEGMES(20), RUNMES(20)
      = C
15     =      DIMENSION  DEFRM(20), DEFPNT(8)
      = C
      = C COMMON BLOCK ALLOCATIONS
      = C
16     =      COMMON/CPANEL/NEXT, ADJUST, RESET, AUTO, MANUAL, FHRFAL, RUN, CALRT
      = C
17     =      COMMON/NESTB2/ PARMES(20)
      = C
18     =      COMMON/NESTB3/CPMES
      = C
19     =      COMMON/MOSMES/MOSMES
      = C
20     =      COMMON/SENPNT/SENPTR(16)
      = C
21     =      COMMON/PIKEUF/PKFEUF(10), PKREUF(10), PKFSRV, PKRSRV
      = C
22     =      COMMON/CLOCK/TFLAG

```

```

23 = C      COMMON/DEEUG/DEEM
24 = C      COMMON/SEDEL/LODEL(48), FDEL(60), FFDEL(460)
25 = C      COMMON/IOFVEC/IOFVEC
26 = C      COMMON/INTVEC/INTVEC
27 = C      COMMON/OPSVEC/OPSVEC(10)
28 = C      COMMON/OFFPARM/ICHPNT(10), NMAX(16), NMAXPX
29 = C      COMMON/SENMEM/LSTAPS(3000), DECNL(16)
30 = C      COMMON/OPSPNT/OPSPNTS(8)
31 = C      COMMON/NCRK/TEMP10, DUMKY(19)
32 = C      COMMON/SAVER/SAVE(20)
33 = C      COMMON/PARAMS/ PARM(20)
34 = C      COMMON/ERRBUF/ERRBUF
35 = C      COMMON/ERRFLG/ ERROR(8)
36 = C      COMMON/COMBUF/CIB(80), KIB(8), DOB(8), TOB(120), PIB(2), FGB(2), VOB(2)
37 = C      COMMON/SENELF/SIB(10), SDB(10)
38 = C      COMMON/CONTAB/SENTAB(10, 2), RECDAT(10, 2)
39 = C      COMMON/NESTAB/ERRMES, DECHES, RUMES, DSFCO
40 = C      COMMON/DEFAULT/ DEF104, DEFPRM, DEFCTV, DEFINT
41 = C      COMMON/DEFTAB/ DEFPRG(10, 2), DEFCON(10, 2)
42 = C      COMMON/DEFOPS/DEFOPS(10)
43 = C      COMMON/DEFMOS/DEFMOS(16)
44 = C      SAVE /CPANEL/, /PIKEUF/, /SAVER/, /ERRBUF/, /SENDEL/
45 = C      SAVE /DEEUG/, /IOFVEC/, /INTVEC/, /OPSVEC/
46 = C      SAVE /OFFPARM/, /SENMEM/, /OPSPNT/, /CLOCK/, /NCRK/, /DEFTAB/
47 = C      SAVE /PARAMS/, /ERRFLG/, /COMBUF/, /SENBUF/, /CONTAB/, /NESTAB/, /DEFAULT/
48 = C      SAVE /SENHPNT/, /NESTB2/, /NESTB3/, /DEFOPS/
49 = C      SAVE /DEFMOS/
50 = C      EQUIVALENCE (DOB(1), DOBC), (DOB(5), DOBN)
51 = C      EQUIVALENCE (OPSVEC(1), OPNODE), (OPSVEC(2), MODECT), (OPSVEC(3), RNMEX)
52 = C      EQUIVALENCE (OPSVEC(4), OPSENR), (OPSVEC(5), RATECK)
53 = C      EQUIVALENCE (OPSVEC(6), STATUS), (TIME, TFLAG(4))
54 = C      EQUIVALENCE (NMAX(3), NMAXSIR), (NMAX(2), NMAXER)

```

ORIGINAL PAGE IS
OF POOR QUALITY.

```

C
C*****
55 100 CONTINUE
C PROGRAM INITIALIZATION ENTRY POINT
C
56 CALL SUPITZ
C
57 CALL SUPOUT
C
C NORMAL OPERATION LOOP ENTRY POINT
C
58 1000 CONTINUE
C SENSOR INPUT CALL
C
59 CALL SUPINP
C
C TEST OPERATION MODE AND CALL SUPERVISOR ROUTINE
C
C MODE = 0 EXIT
60 IF(OPMODE EQ 0) CALL SUFEXT
C
C OPMODE = -1 ; RESTART
61 IF(OPMODE EQ -1) GO TO 100
C
C OPMODE = 1 ; NORMAL
62 IF(OPMODE EQ 1) CALL SUPCNT
C
C OPMODE = 2 ; DEBUG MODE
63 IF(OPMODE EQ 2) CALL SUFDEG
C
C OPMODE = 4 ; MANUAL MODE
64 IF(OPMODE EQ 4) CALL SUFCNT
C
C OPMODE = 5 ; CALIBRATE
65 IF(OPMODE EQ 5) CALL SUPCAL
C
C OPMODE = 3 ; HALT PROCESS
66 IF(OPMODE EQ 3) CALL SUFHLT
C
67 OFFFFTS(7)=0
C
C BUFFER ERROR FLAGS FOR TEN SECONDS
C
68 DO 1010 I=L,NMAXERR
69 ERREUF(1,MOD(TIME,10)+1)=ERROR(I)
70 1010 CONTINUE
C
C TEST FOR PRESENT ERROR AND PROCESS THEM
C
71 DO 1020 I=L,NMAXERR
72 IF(ERROR(I),NE.0) THEN
73 TEMP10=I
C CALL ERROR PROCESSING ROUTINE
74 CALL SUFERR
75 END IF

```

ORIGINAL PAGE IS
OF POOR QUALITY

FORTRAN COMPILER

ORIGINAL PAGE IS
OF POOR QUALITY

```

      C
      C IF MODE CHANGE SKIP OUT
76      IF (OPMODE.EQ.0) GO TO 1000
      C
77      1020 CONTINUE
      C
      C OUTPUT ROUTINE
      C
78      CALL SUPOUT
      C
79      GO TO 1000
      C
80      END

```

MODULE INFORMATION:

```

CODE AREA SIZE   = 0112H   2740
VARIABLE AREA SIZE = 0014H   200
MAXIMUM STACK SIZE = 0002H   20
178 LINES READ

```

0 PROGRAM ERROR(S) IN PROGRAM UNIT YCSFRG

```

0 TOTAL PROGRAM ERROR(S)
END OF FORTRAN COMPILATION

```

1915-11 FORT90H-90 V2.1 COMPILATION OF PROGRAM UNIT SUPINP
 OBJECT MODULE PLACED IN :F1:VCSUP.OBJ
 COMPILER INVOKED BY: FORT90 :F1:VCSUP.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE SUPINP
      C
      C SUPINP CONTROLS INPUT TO THE VCS
      C
      C INPUTS: I/O CONTROL VECTORS
      C OUTPUTS: NOTHING
      C CALLS: SENINP, INPCDU, CONVRT
      C DESTROYS: NOTHING
      C MODIFIES: S. I. B., P. I. B.
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      LOGICAL*1 IOFVEC, IOFSEN
      C
4      COMMON/OPSVEC/OPMODE, ODUM(9)
      C
5      COMMON/IOFVEC/IOFVEC(20)
      C
6      EQUIVALENCE (IOFVEC(1), IOFSEN)
      C
7      SAVE /IOFVEC/, /OPSVEC/
      C
      C*****
      C
      C INPUT CONTROL PANEL INFORMATION
      C
8      CALL INPCDU
      C
      C EXIT IF HALT MODE
9      IF(OPMODE EQ 0) RETURN
      C
      C TEST SENSOR INPUT MASK AND CALL I/O ROUTINE IF TRUE
      C
10     IF(IOFSEN) THEN
      C
11     CALL SENINP
      C
12     CALL CONVRT
      C
13     END IF
      C
14     RETURN
15     END
    
```

MODULE INFORMATION:

CODE AREA SIZE = 001EH 300
 VARIABLE AREA SIZE = 0000H 00

FORTRAN CC.MLES

PAGE 2

MAXIMUM STACK SIZE = 0002H 20
44 LINES READ

0 PROGRAM ERRORS IN PROGRAM UNIT SUPINP

**ORIGINAL PAGE IS
OF POOR QUALITY**

ISIS-II FORTRAN-60 V2.1 COMPILATION OF PROGRAM UNIT SUPOUT
 OBJECT MODULE PLACED IN :F1:VCSUP.OBJ
 COMPILER INVOKED BY: FORT60 :F1:VCSUP FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE SUPOUT
      C
      C SUPOUT CONTROLS OUTPUTS FROM THE VCS
      C
      C INPUTS: I/O CONTROL VECTORS
      C OUTPUTS: NOTHING
      C CALLS: CNTOUT, OUTDSP, FORMAT, SAYDAT, INTREN, OUTPUT, CLOCK
      C DESTROYS: NOTHING
      C MODIFIES: NOTHING
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*1 TFLAG(6), BYTE, LEDS
4      INTEGER*1 CIB(80), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), VOB(2)
      C
5      CHARACTER*1 DSPCOD(18)
6      CHARACTER*4 DOBC, DOBN, ERRMES(20), DEGMES(20), RUNMES(20)
      C
7      LOGICAL*1 IOFVEC(20), IOFVOT, IOFCAS, CNTVEC(16), CHMPKF
      C
8      COMMON/OPSPNT/OPPNTS(8)
      C
9      COMMON/IOFVEC/IOFVEC
      C
10     COMMON/CLOCK/TFLAG
      C
11     COMMON/OPSVEC/OPMODE, MODECT, RANGCK, OPSENR, PATECK, OPSVEC(5)
      C
12     COMMON/MESTAB/ ERRMES, DEGMES, RUNMES, DSPCOD
      C
13     COMMON/CNTVEC/CNTVEC
      C
14     COMMON/COMBUF/ CIB, KIB, DOB, TOB, PIB, POB, VOB
      C
15     EQUIVALENCE (BYTE, TEMP), (LEDS, XTEHP)
16     EQUIVALENCE (DOBX, DOB(5)), (CHMPKF, CNTVEC(3))
17     EQUIVALENCE (IOFVEC(15), IOFCAS), (IOFVEC(12), IOFVOT)
18     EQUIVALENCE (TIME, TFLAG(4))
19     EQUIVALENCE (DOBC, DOB(1)), (DOBN, DOB(5))
      C
20     SAVE /CLOCK/, /CNTVEC/
21     SAVE /OPSPNT/, /IOFVEC/, /MESTAB/, /COMBUF/, /OPSVEC/
      C
      C *****
      C
      C TEST OUTPUT CONTROL MASK AND CALL IF TRUE
      C
      C IF AUTO RUN OR MANUAL RUN THEN DO THIS
      C
22     IF(OPMODE.EQ.1 OR CFMODE.EQ.4) THEN
    
```

ORIGINAL PAGE IS
OF POOR QUALITY

```

C
C IF AUTO RUN
23     IF(OPMODE.EQ.1) THEN
24         CALL CNTOUT
25         DOBC=RUNMES(5)
C
26     ELSE
C ELSE MANUAL MODE
27         DOBC=OBOMES(17)
28     END IF
C
C PUT TIME INTO DISPLAY
29     DOBX=TIME
30     CALL FORMAT(DOEN)
C
C *RUNXXXX OR OPERXXXX
C
31     CALL SAVDAT
32     CALL INTREN
33     GO TO 100
34     END IF
C
C DEBUG MODE
35     IF(OPMODE.EQ.2) THEN
36         DOBC=RUNMES(7)
37         DOBN=RUNMES(8)
C
C *DEBUG *
C
38     GO TO 100
39     END IF
C
C CALIBRATE MODE
40     IF(OPMODE.EQ.5) THEN
41         DOBC=RUNMES(9)
42         DOBN=RUNMES(10)
43         C(8(1))=#2PH
C
C *CALSRAT
C
44     END IF
C
45 100 CONTINUE
C
C IF ERROR PUT IN DISPLAY
46     IF(OPPNTS(7).EQ.1) DOBN=RUNMES(15)
47     CALL OUTDSP
C
C BUILD LED DISPLAY BYTE
C
48     IF(OPMODE.EQ.1) THEN
C AUTO MODE
49         IOP=2
50         XTEMP=#02H
51     ELSE
52     IF(OPMODE.EQ.4) THEN
C MANUAL MODE

```

ORIGINAL PAGE IS
OF POOR QUALITY

```

53      IOP=1
54      XTEMP=#01H
      C
55      ENDIF
56      ENDIF
      C
57      TEMP=0
58      TEMP=TEMP+IOP*54
59      TEMP=TEMP+MODECT*16
60      TEMP=TEMP+RANGCK*8
61      TEMP=TEMP+OPSENR*4
      C
      C ERROR BIT
62      IF(OPPNTS(7).EQ.1) THEN
63          TEMP=TEMP+1
64          XTEMP=XTEMP+4
65      END IF
      C
      C PICK CONTROL
66      IF(CNMPKG) TEMP=TEMP+2
      C
      C OUTPUT STATUS TO LEDS
67      CALL OUTPUT(#000H, BYTE)
      C
      C OUTPUT STATUS TO LEDS
      C INVERT BITS
68      XTEMP=-(XTEMP+1)
      C XTEMP UPPER 4 BITS MUST BE ZEROS
69      XTEMP=(XTEMP.AND.#0FH)
70      CALL OUTPUT(#000H, LEDS)
      C
      C SYNCHRONIZE SYSTEM TIMING
71      CALL CLOCK
      C
72      RETURN
73      END

```

MODULE INFORMATION:

```

CODE AREA SIZE      = 018CH   4440
VARIABLE AREA SIZE = 0000H    60
MAXIMUM STACK SIZE = 0000H   160
144 LINES READ

```

0 PROGRAM ERROR(S) IN PROGRAM UNIT SUPOUT

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT SUPCNT
OBJECT MODULE PLACED IN :F1:VCSUP. OBJ
COMPILER INVOKED BY: FORT90 :F1:VCSUP.FOR

```

1      SUBROUTINE SUPCNT
      C
      C SUPCNT CONTROLS VCS CONTROL ALGORITHM USE AND SIGNAL GENERATION
      C
      C INPUTS: OPERATION CONTROL VECTORS
      C OUTPUTS: NOTHING
      C CALLS: CNTRFD, CNTRRD
      C DESTROYS: NOTHING
      C MODIFIES: NOTHING
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      LOGICAL*1 CNTVEC(16), CNMOUT, CNMRR, CNMFRT
      C
4      COMMON/CNTVEC/CNTVEC
      C
5      EQUIVALENCE (CNTVEC(8), CNMFRT), (CNTVEC(9), CNMRR), (CNTVEC(10), CNMOUT)
      C
5      SAVE /CNTVEC/
      C
      C*****
      C
      C TEST FRONT CONTROL MASK
      C
7      IF(CNMFRT) CALL CNTRFD
      C
      C TEST REAR CONTROL MASK
      C
8      IF(CNMRR) CALL CNTRRD
      C
9      RETURN
10     END
    
```

MODULE INFORMATION:

CODE AREA SIZE = 0015H 21D
VARIABLE AREA SIZE = 0000H 00
MAXIMUM STACK SIZE = 0002H 2D
33 LINES READ

0 PROGRAM ERROR(S) IN PROGRAM UNIT SUPCNT

1955-11 FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT SUPDBG
 OBJECT MODULE PLACED IN FILE YOSSUP.OBJ
 COMPILER INVOKED BY: FORTR90.F91 YOSSUP.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

SUBROUTINE SUPDBG
C
C SUPDBG IS THE DEBUG OPERATION SUPERVISOR
C
C INPUTS: DEBUG CONTROL VECTOR
C OUTPUTS: NONE
C CALLS: DBUGCI, DBUGCO, DBUGIN, DEBUGT, INTRO5
C         DEBUGT, DBUGIO, DBUGCK, DEBUGE, ITZINP
C TESTS: NOTHING
C MODIFIES: NOTHING
C VERSION: 1.0
C
2      IMPLICIT INTEGER*2 (A-Z)
3      LOGICAL*4 (DBNCK)
4      COMMON/DEBUG/DBCN
5      COMMON/CPSEV/CPMODE, MODECT, RANGCK, ARRY(7)
6      COMMON/WORK/TEMP10, DUMMY(15)
7      SAVE /DEBUG/, /CPSEV/, /WORK/
C
C *****
C CALL INTERRUPT DISABLE
8      CALL INTRO5
9      CONTINUE
C INPUT DEBUG CONTROL FROM PANEL
C
10     CALL DBUGCI
C TEST DEBUG MODE AND CALL CORRECT ROUTINE
C
11     IF (TEMP10.EQ.0) THEN
12         C IF RESET SET TO EXIT MODE
13         CPMODE=0
14         RETURN
15     ELSE
16         IF (TEMP10.EQ.1) CALL DBUGOT
17         IF (TEMP10.EQ.2) CALL DBUGIN (0)
18         IF (TEMP10.EQ.3) CALL DBUGIN (1)
19         IF (TEMP10.EQ.4) CALL ITZINP
20         IF (TEMP10.EQ.5) CALL DEBUGT
    
```

PROGRAM LISTING

ORIGINAL PAGE IS
OF POOR QUALITY

```

10      IF TEMPID. EQ. 6) CALL DSUBS1
11      IF TEMPID. EQ. 7) CALL DSUBS1
12      IF TEMPID. EQ. 8) CALL DSUBS1
13      WRITE CONTROL PANEL AND WAIT FOR CONTINUE INPUT
14      CALL DSUBS1
15      GO TO 100
16      END
    
```

TABLE INFORMATION

CODE AREA SIZE = 0000H 1650
 VARIABLE AREA SIZE = 0002H 20
 MAXIMUM STACK SIZE = 0002H 20
 64 LINES READ

0 PROGRAM ERRORS. IN PROGRAM UNIT SUP050

ORIGINAL PAGE IS
OF POOR QUALITY

***** FORTRAN-90 VLSI DESCRIPTION OF PROGRAM UNIT SUFITE
 SEVERAL LINES PLACED IN FILE VCSUP.OBJ
 IN FILE IN CODE BY FORTRAN-90 VCSUP.FOR

```

1      ELECTRONIC SUFITE
      :
      : SUFITE INITIALIZES THE PROGRAM VARIABLES, BUFFERS, AND CONTROL VECTORS
      :
      :
      : INPUTS: NONE
      : OUTPUTS: INITIALIZED SYSTEM
      : FILES: INP00U, INTROS, AIOITE, INTREN, OUTDEP, ITZINF, AIOCRS, HSEC2H
      :        RESTRT
      : DESTROYS: NOTHING
      : MODIFIES: INPUT BUFFERS, PARAMETERS, INTERRUPTS, CONTROL INFORMATION
      : VERSION 1.0
      :
2      $INCLUDE('F1-VCSUP.FOR')
      = C
      = C
      = C VCS SYSTEM MEMORY ALLOCATION
      = C
3      =      IMPLICIT INTEGER*(A-Z)
4      =      INTEGER*4  CIB, KIB, IOS, TOP, PIB, POS, YOB
5      =      INTEGER*4  PKFBUF, PKFBUF, PKFSRV, PKRSRV
6      =      INTEGER*4  MMKIPK(6), TFLAG(6)
7      =      INTEGER*4  ERREUF(8, 10)
      = C
8      =      LOGICAL*4  IOFVEC(20), CNTVEC(16), SINT(8), EMER(8), DEBN(8)
9      =      LOGICAL*4  DEFION(10), DEFCTV(16)
10     =      LOGICAL*4  NEXT, ADJUST, RESET, RUN, CALRT, FUSFAL, AUTO, MANUAL
      = C
11     =      CHARACTER*4  PARNES, MOSNES(10)
12     =      CHARACTER*4  DSPOOD(10)
13     =      CHARACTER*4  DOBC, DOBN, OPENES(10)
14     =      CHARACTER*4  ERRMES(20), DEGMES(20), RUNMES(20)
      = C
15     =      DIMENSION DEFPRN(20), DEFINT(8)
      = C
      = C COMMON BLOCK ALLOCATIONS
      = C
16     =      COMMON/CPANEL/NEXT, ADJUST, RESET, AUTO, MANUAL, FUSFAL, RUN, CALRT
      = C
17     =      COMMON/MSSTB2/ PARNES(10)
      = C
18     =      COMMON/MSSTB3/ OPSMES
      = C
19     =      COMMON/MOSMES/MOSMES
      = C
20     =      COMMON/SENINT/SENINT(16)
      = C
21     =      COMMON/PIKBUF/PKFBUF(16), PKFBUF(10), PKFSRV, PKRSRV
      = C
22     =      COMMON/CLKK/TFLAG
      = C
23     =      COMMON/DEBUC/DEBN
  
```

ORIGINAL PAGE IS
OF POOR QUALITY

```

14 = : COMMON/SENDEL/SENEL(40), PDEL(60), PDEL(40)
15 = :
16 = : COMMON/IOFVEC/IOFVEC
17 = :
18 = : COMMON/CNTVEC/CNTVEC
19 = :
20 = : COMMON/OPSVEC/OPSVEC(10)
21 = :
22 = :
23 = : COMMON/OPPRM/ICMPNT(10), NMAX(15), NMXIPX
24 = :
25 = : COMMON/SENMEM/LSTPRM(3000), DSCNTL(15)
26 = :
27 = : COMMON/OPSPNT/OPSPNT(8)
28 = :
29 = : COMMON/WORK/TEMP10, DUMMY(19)
30 = :
31 = : COMMON/SAVER/SAVE(20)
32 = :
33 = : COMMON/PARAMS/ PARAM(20)
34 = :
35 = : COMMON/ERRBUF/ERRBUF
36 = :
37 = : COMMON/ERRFLG/ ERROR(8)
38 = :
39 = : COMMON/COMBUF/CIB(50), KIB(8), CIB(8), TIB(128), PIB(2), PCB(2), PCB(2)
40 = :
41 = : COMMON/SENBUF/SIB(10), SDB(10)
42 = :
43 = : COMMON/CONTRAB/SENTAB(10, 2), PGCAT(10, 2)
44 = :
45 = : COMMON/MESTAB/ERRMES, DBGMES, RUNMES, DSPCOD
46 = :
47 = : COMMON/DEFAULT/ DEFT04, DEFPRM, DEFCV, DEFPNT
48 = :
49 = : COMMON/DEFTAB/ DEFRNG(10, 2), DEFCON(10, 2)
50 = :
51 = : COMMON/DEFOPS/DEFOPS(10)
52 = :
53 = : COMMON/DEFMOS/DEFMOS(16)
54 = :
55 = : SAVE /CPANEL/, /PIKBUF/, /SAVER/, /ERRBUF/, /SENDEL/
56 = : SAVE /DEBUG/, /IOFVEC/, /CNTVEC/, /OPSVEC/
57 = : SAVE /OPPRM/, /SENMEM/, /OPSPNT/, /CLOCK/, /WORK/, /DEFTAB/
58 = : SAVE /PARAMS/, /ERRFLG/, /COMBUF/, /SENBUF/, /CONTRAB/, /MESTAB/, /DEFAULT/
59 = : SAVE /SENPNT/, /MESTB2/, /MESTB3/, /DEFOPS/
60 = : SAVE /DEFMOS/
61 = :
62 = : EQUIVALENCE (DOB(1), DGSC), (DOB(5), DOBN)
63 = : EQUIVALENCE (OPSVEC(1), OPMODE), (OPSVEC(2), MODECT), (OPSVEC(3), RMXMSE)
64 = : EQUIVALENCE (OPSVEC(4), OPSNR), (OPSVEC(5), RATECK)
65 = : EQUIVALENCE (OPSVEC(6), STATUS), (TIME, TFLAG(4))
66 = :
67 = :
68 = : EQUIVALENCE (NMXSIR, NMAX(3)), (NMXERR, NMAX(2))
69 = : 1 . (NMXIOF, NMAX(7)), (NMXPRM, NMAX(13)), (NMXCV, NMAX(15)),
70 = : 2 . (NMXDBG, NMAX(9)), (NMXPNT, NMAX(15)), (NMXSEN, NMAX(1))

```


ORIGINAL PAGE IS
OF POOR QUALITY

```

3 (NMXCEF, NMAX(5)), (NMXKIB, NMSEN(12)), (NMXTAP, NMAX(11)),
+ (NMXCF, NMAX(10)), (NMXCFE, NMAX(14))
:
55  EQUIVALENCE (NMXIFN, NMAX(4))
:
:
:
:
56  DISABLE INTERRUPTS
57  CALL INTRIS
C
C INITIALIZE I/O INTERFACES
57  CALL AIOITZ
C
C CLEAR ERROR FLAGS
C
58  DO 200 I=L, NMXERR
59  ERROR(I)=0
60  200  CONTINUE
C
C SET DEBUG MASKS
C
61  DO 600 I=L, NMNDBG
62  DDBG(I)=.TRUE.
63  600  CONTINUE
C
C CLEAR ALL I/O BUFFERS
C
64  DO 800 I=L, NMXSEN
65  SIB(I)=0
66  SDB(I)=0
67  800  CONTINUE
C
68  DO 900 I=L, NMXOSP
69  DOB(I)=0
70  900  CONTINUE
C
71  DO 1000 I=L, NMXKIB
72  KIB(I)=0
73  1000 CONTINUE
C
74  DO 1100 I=L, NMXTAP
75  TOB(I)=0
76  1100 CONTINUE
C
77  DO 1200 I=L, NMXCEF
78  CIB(I)=0
79  1200 CONTINUE
C
80  VOB(1)=0
81  VOB(2)=0
C
C TEST IF OVERRIDE OF PARAMETER BOOT (ONLY IF WARM RESTART IN CMOS)
82  DOBC=DBGMES(12)
83  DOBN=DBGMES(5)
C @SYSITZ?
84  CALL @PROMPT
85  IF(PESET) GO TO 4000

```

ORIGINAL PAGE IS
OF POOR QUALITY

```

C
C SET DEFAULT I/O MODES
C
97      DO 300 I=L,NMIOCF
97      IOFVEC(I)=DEFIOV(I)
98      300 CONTINUE
C
C SET DEFAULT PARAMETERS
C
89      DO 400 I=L,NMXPRI
90      PARPRM(I)=DEFPRM(I)
91      400 CONTINUE
C
C SET DEFAULT CONTROL VECTOR
C
92      DO 500 I=L,NMXCTV
93      CNTVEC(I)=DEFCTV(I)
94      500 CONTINUE
C
95      OPPTS(1)=1
C
96      DO 1400 I=L,NMXSEN
97      DO 1400 J=L,2
98      RSCCAT(I,J)=DEFPRG(I,J)
99      SENTAS(I,J)=DEFCON(I,J)
100     1400 CONTINUE
C
C INITIALIZE THE OPERATION VECTOR
C
101     DO 1500 I=L,NMXOPS
102     OPSVEC(I)=DEFOPS(I)
103     1500 CONTINUE
C
C SET CMOS CONTROL
C
104     DO 1600 I=1,16
105     DSCNTL(I)=DEFMOS(I)
106     1600 CONTINUE
C
C USE RESTRT CODE TO CLEAR OTHER ARRAYS I
107     CALL RESTRT
C
C DISPLAY TAPE MESSAGE
108     DGBG=DBGMES(12)
109     DGBH=DBGMES(6)
C @SYSTAP?
C
110     CALL PROMPT
C TEST IF BLOCK FORMAT PAUSE IF .NOT. RUN MODE
C SKIP IF RESET
111     IF(RESET) GO TO 3000
C IF CASSETTE ON, WRITE HEADER FILE
C
112     CALL TAPITZ
C
C CALL INTERACTIVE INITIALIZATION ROUTINE
C

```

```
113 3000 CONTINUE
114      CALL ITZINP
      C
115 4000 CONTINUE
      C
116      RETURN
117      END
```

**ORIGINAL PAGE IS
OF POOR QUALITY**

MODULE INFORMATION:

```
CODE AREA SIZE = 034CH 8440
VARIABLE AREA SIZE = 0016H 220
MAXIMUM STACK SIZE = 0000AH 100
229 LINES READ
```

0 PROGRAM ERROR(S) IN PROGRAM UNIT SUPITZ

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II FORTRAN 90 V2.1 COMPILATION OF PROGRAM UNIT SUPERR
OBJECT MODULE PLACED IN :F1:VCSUP.OBJ
COMPILER INVOKED BY: FORT90 :F1:VCSUP.FOR

```

1      SUBROUTINE SUPERR
      C
      C SUPERR PROCESSES ERROR CONDITION FLAGS AND OUTPUTS MESSAGE
      C
      C INPUTS: ERROR FLAG VECTOR
      C OUTPUTS: ERROR MESSAGE ON DISPLAY
      C CALLS: OUTDSP, INPCDU, FORMAT
      C DESTROYS: NOTHING
      C MODIFIES: NOTHING
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*1 ERRBUF(8,10)
4      INTEGER*1 DOB, KIB, DOB, TOB, PIB, POB, VOB
      C
5      CHARACTER*1 DSPCOD(10)
6      CHARACTER*4 DOBC
7      CHARACTER*4 ERRMES(20), DGBMES(20), RUNMES(20)
      C
8      COMMON/MESTAB/ERR: 'S', DGBMES, RUNMES, DSPCOD
      C
9      COMMON/COMBUF/COB(80), KIB(8), DOB(8), TOB(120), PIB(2), POB(2), VOB(2)
      C
10     COMMON/ERRBUF/ERRBUF
      C
11     COMMON/PARAMS/PARAM(20)
      C
12     COMMON/OPSEVC/OPMODE, ODUM(9)
      C
13     COMMON/ERRFLG/ERROR(8)
      C
14     COMMON/OPSPNT/OPPNTS(8)
      C
15     COMMON/WORK/TEMP10, DUMMY(19)
      C
16     SAVE /OPSPNT/, /ERRFLG/, /OPSEVC/, /PARAMS/, /ERRBUF/
17     SAVE /MESTAB/, /COMBUF/, /WORK/
      C
18     EQUIVALENCE (PARAM(2), EARLMT)
19     EQUIVALENCE (DOB(1), DOBC), (DOB(5), DOBN)
      C
      C*****
      C
      C LOAD ERROR MESSAGE TO DISPLAY BUFFER
      C
      C ERR
20     DOBC=RUNMES(15)
      C
      C PUT ERROR NUMBER IN DOBN
      C

```

```

21      TEMPX=TEMP10
22      CUSH=132*TEMP10+ERRPCR(TEMP10)
      )
      C  FORMAT AND DISPLAY
23      CALL FORMAT(DOBN)
24      DOB(5)=DOB(6)
25      DOB(6)=#ICH
      C  ERR H-XX ON DISPLAY
26      CALL OUTDSP
      C
      C  TEST FOR ERROR OVERFLOW
27      ETOT=0
28      DO 100 I=1,10
29      ETOT=ETOT+MIN(4,ERRBUF(TEMPX,I))
30  100 CONTINUE
      C
      C  TEST IF ERROR COUNT OVER LIMIT
31      IF(ETOT GT ERKLM) THEN
32      IF(COPMODE.EQ.1) OPMODE=4
33      END IF
      C
      C  PAUSE IF OAL ; ELSE RUN NO PAUSE
34      CALL INPCDU
      C
      C  SET ERROR FLAG
35      OPANTS(7)=1
36      ERROR(TEMPX)=0
      C
37      RETURN
38      END

```

ORIGINAL PAGE IS
OF POOR QUALITY

MODULE INFORMATION:

```

CODE AREA SIZE   = 006AH   106D
VARIABLE AREA SIZE = 0006H    6D
MAXIMUM STACK SIZE = 000AH   10D
81 LINES READ

```

0 PROGRAM ERROR(S) IN PROGRAM UNIT SUPER

ORIGINAL PAGE IS
OF POOR QUALITY

ISES-II FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT SUEPXT
OBJECT MODULE PLACED IN FL:VOSUP.OBJ
COMPILER INVOKED BY: FORT90 (FL:VOSUP.FOR)

```

1      SUBROUTINE SUEPXT
      C
      C SUEPXT STOPS THE VCS PROGRAM AFTER CLOSING DATA BASE
      C AND WAITS FOR OPERATOR INPUT AT THE C/D
      C
      C INPUTS: NONE
      C OUTPUTS: NONE
      C CALLS: OUTDSP, INTADS, CLOCK, INPCDU, INTREN, CNTOUT
      C DESTROYS: STB, SOB, ERRORS
      C MODIFIES: OPMODE
      C VERSION 1.0
      C
2      $INCLUDE( 'FL:VCSMEM.FOR' )
      = C*****
      = C
      = C VCS SYSTEM MEMORY ALLOCATION
      = C
3      = IMPLICIT INTEGER*(A-Z)
4      = INTEGER*4 C/D, K/D, DOB, TOB, P/D, POB, V/D
5      = INTEGER*4 PKFBUF, PKRBUF, PKFSAV, PKRSV
6      = INTEGER*4 NPKIPX(6), TFLAG(6)
7      = INTEGER*4 EKRBUF(8,10)
      = C
8      = LOGICAL*4 TOPVEC(20), CNTVEC(16), SINT(8), SMSK(8), DEGM(8)
9      = LOGICAL*4 DEFION(20), DEFCTY(16)
10     = LOGICAL*4 NEXT, ADJUST, RESET, RUN, CALBRT, PHRFAL, AUTO, MANUAL
      = C
11     = CHARACTER*4 PARNES, NOSMES(10)
12     = CHARACTER*4 DSPCDD(10)
13     = CHARACTER*4 DOBC, DOBN, OPSMES(10)
14     = CHARACTER*4 ERRMES(20), DEGMES(20), RUNMES(20)
      = C
15     = DIMENSION DEFRM(20), DEFPNT(8)
      = C
      = C COMMON BLOCK ALLOCATIONS
      = C
16     = COMMON/CPANEL, NEXT, ADJUST, RESET, AUTO, MANUAL, PHRFAL, RUN, CALERT
      = C
17     = COMMON/NESTB2, PARNES(20)
      = C
18     = COMMON/NESTB3, OPSMES
      = C
19     = COMMON/NOSMES, NOSMES
      = C
20     = COMMON/SENPNT, SENPTR(16)
      = C
21     = COMMON/PIKBUF, PKFBUF(10), PKRBUF(10), PKFSAV, PKRSV
      = C
22     = COMMON/CLOCK, TFLAG
      = C
23     = COMMON, DEBUG, DEGM

```

ORIGINAL PAGE IS
OF POOR QUALITY

```

= C
24 = COMMON/SENDEL/LODEL(40), FODEL(60), FORDDEL(400)
= C
25 = COMMON/IOFVEC/IOFVEC
= C
26 = COMMON/CNTVEC/CNTVEC
= C
27 = COMMON/OPSVEC/OPSVEC(10)
= C
28 = COMMON/OPPARM/ICHPNT(10), NMAX(16), NMAXPX
= C
29 = COMMON/SENMEM/LSTPAS(3000), DSCNTL(16)
= C
30 = COMMON/OPSPNT/OPSPNTS(8)
= C
31 = COMMON/WORK/TEMP10, DUMMY(19)
= C
32 = COMMON/SAVER/SAVE(20)
= C
33 = COMMON/PARAMS/ PARAM(20)
= C
34 = COMMON/ERRBUF/ERRBUF
= C
35 = COMMON/ERRFLG/ ERROR(8)
= C
36 = COMMON/COMBUF/CIB(80), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), WOB(2)
= C
37 = COMMON/SENBUF/SIB(10), SOB(10)
= C
38 = COMMON/CONTAB/SENTAB(10, 2), RGCDAT(10, 2)
= C
39 = COMMON/NESTAB/ERRNES, DBGNES, RUNNES, DSPCOD
= C
40 = COMMON/DEFAULT/ DEFIOV, DEFPRM, DEFCTV, DEFINT
= C
41 = COMMON/DEFTAB/ DEFRNG(10, 2), DEFCON(10, 2)
= C
42 = COMMON/DEFOPS/DEFOPS(10)
= C
43 = COMMON/DEFMOS/DEFMOS(16)
= C
44 = SAVE /CPANEL/, /PIKBUF/, /SAVER/, /ERRBUF/, /SENDEL/
45 = SAVE /DEBUG/, /IOFVEC/, /CNTVEC/, /OPSVEC/
46 = SAVE /OPPARM/, /SENMEM/, /OPSPNT/, /CLOCK/, /WORK/, /DEFTAB/
47 = SAVE /PARAMS/, /ERRFLG/, /COMBUF/, /SENBUF/, /CONTAB/, /NESTAB/, /DEFAULT/
48 = SAVE /SENINT/, /NESTB2/, /NESTB3/, /DEFOPS/
49 = SAVE /DEFMOS/
= C
50 = EQUIVALENCE (DOB(1), DOBC), (DOB(5), DOBN)
51 = EQUIVALENCE (OPSVEC(1), OPCODE), (OPSVEC(2), NODECT), (OPSVEC(3), PNGMSK)
52 = EQUIVALENCE (OPSVEC(4), OPSENR), (OPSVEC(5), RATECK)
53 = EQUIVALENCE (OPSVEC(6), STATUS), (TIME, TFLAG(4))
= C
54 = INTEGER*4 BITS(8)
= C
55 = LOGICAL*4 IOFCAS
= C

```

ORIGINAL PAGE IS
OF POOR QUALITY

```

56      EQUIVALENCE (IOFVECK(15), IOFCAS)
57      EQUIVALENCE (TEMPIO, BITS(1))
58      EQUIVALENCE (NMAX(1), NMAXEN), (NMAXPR, NMAX(2))
      C
      C *****
      C
59      DOBC=RUNMES(19)
60      DOBN=RUNMES(19)
61      CALL OUTDSP
      C %-EXIT-%
      C
      C CLEAR VALVE OUTPUTS
62      VOB(1)=0
63      VOB(2)=0
      C
64      CALL CNTOUT
      C
65      TFLAG(2)=0
      C WAIT FOR CASSETTE TO FINISH IF ON
66      IF(IOFCAS) THEN
67      CALL INTREN
68      10  CALL CLOCK
      C WAIT FOR END OF BLOCK
69      END IF
      C
      C DISABLE INTERRUPTS
      C
70      CALL INTFDS
      C
      C CLEAR ERRORS
      C
71      DO 500 I=1,8
72      DO 600 J=1,10
73      ERRSUF(I, J)=0
74      600  CONTINUE
75      ERROR(I)=0
76      500  CONTINUE
      C
      C LOAD STOP MESSAGE INTO DOB
77      DOBC=RUNMES(16)
78      DOBN=RUNMES(17)
      C %-STOP-%
      C
79      CALL OUTDSP
      C
      C LOOP ON CONTROL PANEL TILL ENTRY BY OPERATOR
80      1000 CONTINUE
81      CALL INPCDU
      C
      C IF CALIBRATE ON THEN TEST NEXT AND ADJUST
82      IF(CALART) THEN
      C
      C IF RESET REBOOT SYSTEM
83      IF(RESET) THEN
84      OPMODE=-1
85      GO TO 2000
86      END IF

```



```

      C
      C IF NEXT GO TO DEEUG
97      IF(NEXT) THEN
98          OPMODE=2
99          GO TO 2000
99      END IF
      C
      C IF ADJUST GO TO CALIBRATE
91      IF(ADJUST) THEN
92          OPMODE=5
93          GO TO 2000
94      END IF
      C
      C END CALIBRATE SWITCH ON SECTION
95      END IF
      C
      C IF RUN SWITCH ON
      C RESTART RUN MODE ,CONTINUE
96      IF(RUN) THEN
      C
      C IF MANUAL SWITCH
97      IF(MANUAL) THEN
98          OPMODE=4
99          GO TO 2000
100     END IF
      C
      C IF AUTOMATIC SWITCH
101     IF(AUTO) THEN
102         OPMODE=1
103         GO TO 2000
104     END IF
      C
      C END RUN SWITCH ON SECTION
105     END IF
106     GO TO 1000
      C
107     2000 CONTINUE
108     RETURN
109     END

```

ORIGINAL PAGE IS
OF POOR QUALITY.

MODULE INFORMATION:

```

CODE AREA SIZE      = 0130H    3040
VARIABLE AREA SIZE = 0014H    200
MAXIMUM STACK SIZE = 000AH    100
284 LINES READ

```

0 PROGRAM ERROR(S) IN PROGRAM UNIT SUPEXT

ORIGINAL PAGE IS
OF POOR QUALITY.

IS15-11 FORTRAN-50 V2.1 COMPILATION OF PROGRAM UNIT SUPCAL
OBJECT MODULE PLACED IN :F1:VCSUP.OBJ
COMPILER INVOKED BY: FORT80 :F1:VCSUP.FOR

```

1      SUBROUTINE SUPCAL
      C
      C SUPCAL IS THE CALIBRATION ROUTINE SUPERVISOR
      C
      C INPUTS: NONE
      C OUTPUTS: OPMODE AND RESET SYSTEM (HOT RESTART)
      C CALLS: RESTR7, PROMPT
      C DESTROYS: BUFFERS FOR DELAYS AND POINTERS
      C MODIFIES: OPMODE
      C VERSION: 1.0
      C
2      $INCLUDE(:F1:VCSMEM.FOR)
      = C*****
      = C
      = C VCS SYSTEM MEMORY ALLOCATION
      = C
3      =      IMPLICIT INTEGER*2(A-Z)
4      =      INTEGER*1  CIB, KIB, DOB, TOS, PIB, POB, VOB
5      =      INTEGER*1  PKFBUF, PKRBUF, PKFSAY, PKRSAY
6      =      INTEGER*1  MAXIPX(6), TFLAG(6)
7      =      INTEGER*1  ERRBUF(3,10)
      = C
8      =      LOGICAL*1  IOFVED(20), CNTVEC(16), SINT(8), SMSK(8), DEGM(8)
9      =      LOGICAL*1  DEF10V(20), DEFCTY(16)
10     =      LOGICAL*1  NEXT, ADJUST, RESET, RUN, CALBRT, PHRFAL, AUTO, MANUAL
      = C
11     =      CHARACTER*4  PARMES, NOSHES(10)
12     =      CHARACTER*1  DSPCOD(10)
13     =      CHARACTER*4  DOPC, DOBN, OPSMES(10)
14     =      CHARACTER*4  ERRMES(20), DEGMES(20), RUNMES(20)
      = C
15     =      DIMENSION DEFPRM(20), DEFPNT(8)
      = C
      = C COMMON BLOCK ALLOCATIONS
      = C
16     =      COMMON/CPANEL/NEXT, ADJUST, RESET, AUTO, MANUAL, PHRFAL, RUN, CALBRT
      = C
17     =      COMMON/NESTB2/ PARMES(20)
      = C
18     =      COMMON/NESTB3/ OPSMES
      = C
19     =      COMMON/MOSHES/MOSHES
      = C
20     =      COMMON/SENPNT/SENPTR(16)
      = C
21     =      COMMON/PIKBUF/PKFBUF(10), PKRBUF(10), PKFSAY, PKRSAY
      = C
22     =      COMMON/CLOCK/TFLAG
      = C
23     =      COMMON/DEBUG/DEGM
      = C

```

```

24 = COMMON/SENDEL/LODEL(40), PODEL(60), FODEL(400)
   = C
25 = COMMON/IOPVEC/IOPVEC
   = C
26 = COMMON/CNTVEC/CNTVEC
   = C
27 = COMMON/OPSVEC/OPSVEC(10)
   = C
28 = COMMON/OPPPRM/ICNPNT(10), NMAX(16), NMXIPX
   = C
29 = COMMON/SENMEM/LSTFAS(3000), DSCNTL(16)
   = C
30 = COMMON/OPSPNT/OPSPNT(8)
   = C
31 = COMMON/WORK/TEMP10, DUMMY(19)
   = C
32 = COMMON/SAVER/SAVE(20)
   = C
33 = COMMON/PARAMS/ PARAM(20)
   = C
34 = COMMON/ERRBUF/ERRBUF
   = C
35 = COMMON/ERRFLG/ ERROR(8)
   = C
36 = COMMON/COMBUF/CIB(80), KIB(8), OOB(8), TOB(128), FIB(2), POB(2), VOB(2)
   = C
37 = COMMON/SENBUF/SIB(10), SDB(10)
   = C
38 = COMMON/CONTAB/SENTAB(10, 2), RCGDAT(10, 2)
   = C
39 = COMMON/NESTAB/ERRNES, DBGNES, RUNNES, DEPCOD
   = C
40 = COMMON/DEFAULT/ DEF10V, DEFPRH, DEFCTV, DEFNT
   = C
41 = COMMON/DEFTAB/ DEFANG(10, 2), DEFCON(10, 2)
   = C
42 = COMMON/DEFOPS/DEFOPS(10)
   = C
43 = COMMON/DEFMOS/DEFMOS(16)
   = C
44 = SAVE /CPANEL/, /PIKBUF/, /SAVER/, /ERRBUF/, /SENDEL/
45 = SAVE /DEBUG/, /IOPVEC/, /CNTVEC/, /OPSVEC/
46 = SAVE /OPPPRM/, /SENMEM/, /OPSPNT/, /CLOCK/, /WORK/, /DEFTAB/
47 = SAVE /PARAMS/, /ERRFLG/, /COMBUF/, /SENBUF/, /CONTAB/, /NESTAB/, /DEFAULT/
48 = SAVE /SENPN1/, /NESTB2/, /NESTB3/, /DEFOPS/
49 = SAVE /DEFMOS/
   = C
50 = EQUIVALENCE (OOB(1), DOBC), (OOB(5), DOBN)
51 = EQUIVALENCE (OPSVEC(1), OPNODE), (OPSVEC(2), MODECT), (OPSVEC(3), PNGMSK)
52 = EQUIVALENCE (OPSVEC(4), OPSENR), (OPSVEC(5), RATECK)
53 = EQUIVALENCE (OPSVEC(6), STATUS), (TIME, TFLAG(4))
   = C
C*****
C
54 DOBC=RUNNES(5)
55 DOBN=DBGNES(5)
C *UNIT?

```

ORIGINAL PAGE IS OF POOR QUALITY

FORTRAN COMPILER

ORIGINAL PAGE IS
OF POOR QUALITY

```

53      CALL FROMAT
54      C
55      IF (ADJUST) THEN
56      C CLEAR WORK VARIABLES FOR RESTART
57      CALL RESTRT
58      END IF
59      GPMODE=0
60      C
61      RETURN
62      END

```

MODULE INFORMATION:

```

CODE AREA SIZE = 003AH 580
VARIABLE AREA SIZE = 0010H 160
MAXIMUM STACK SIZE = 0000H 100
118 LINES READ

```

0 PROGRAM ERROR(S) IN PROGRAM UNIT SUPCAL

ISIS-II FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT SUPHLT
 OBJECT MODULE PLACED IN :F1:VOSSUP.OBJ
 COMPILER INVOKED BY :FORT90 :F1:VOSSUP.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE SUPHLT
      C
      C SUPHLT WILL HALT EXECUTION IN A RECOVERABLE WAY
      C
      C INPUTS: NONE
      C OUTPUTS: MODE STATUS
      C CALLS: INTREN, INTRDS, OUTDSP, INPCDU
      C DESTROYS: NOTHING
      C MODIFIES: OPMODE
      C VERSION 1.0
      C
      C*****
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*4 CIB, KIB, DOB, TOB, PIB, POB, YOB
      C
4      LOGICAL*4 NEXT, ADJUST, RESET, RUN, CALEPT, PHRFAL, AUTO, MANUAL
      C
5      CHARACTER*4 DOBC, DOBN, OPSMES(10)
6      CHARACTER*4 ERRMES(20), DBGMES(20), RUNMES(20)
7      CHARACTER*4 DSPCOD(10)
      C
8      COMMON/COMBUF/CIB(80), KIB(8), DOB(8), TOB(120), PIB(2), POB(2), YOB(2)
      C
9      COMMON/OPSVED/OPMODE, ODUH(9)
      C
10     COMMON/CPANEL/NEXT, ADJUST, RESET, AUTO, MANUAL, PHRFAL, RUN, CALEPT
      C
11     COMMON/NESTAB/ERRMES, DBGMES, RUNMES, DSPCOD
      C
12     SAVE /OPSVED/, /CPANEL/, /COMBUF/, /NESTAB/
      C
12     EQUIVALENCE (DOBC, DOB(1)), (DOBN, DOB(5))
      C
      C*****
      C
14     CALL INTRDS
      C
15     DOBC=RUNMES(11)
16     DOBN=RUNMES(12)
17     CALL OUTDSP
      C
18     CALL INPCDU
      C
      C TEST IF MODE SWITCH IS IN RUN
19     IF(RUN) THEN
      C
20     IF(ADJUST) THEN
      C IF RUN AND ADJUST GO TO MANUAL MODE
21     OPMODE=4
    
```

ORIGINAL PAGE IS
OF POOR QUALITY

```

22          GO TO 100
23          END IF
          C
24          IF (NEXT) GO TO 100
          C IF RUN MODE AND NEXT JUST CONTINUE WHERE LEFT OFF
          C
          C ELSE IT IS IN CALIBRATE POSITION
25          ELSE
26          IF (RESET) THEN
          C IF CALL MODE AND RESET STOP PROGRAM
27          OPMODE=0
28          GO TO 100
29          END IF
          C
30          END IF
          C WAIT
31          GO TO 10
          C
32          100 CALL INTREN
33          RETURN
34          END

```

MODULE INFORMATION:

```

CODE AREA SIZE   = 006AH   100D
VARIABLE AREA SIZE = 0020H   40D
MAXIMUM STACK SIZE = 000AH   10D
72 LINES READ

```

0 PROGRAM ERROR(S) IN PROGRAM UNIT SUFHLT

0 TOTAL PROGRAM ERROR(S)
END OF FORTRAN COMPILATION

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT SENINP
OBJECT MODULE PLACED IN FLW0SEEM.OBJ
COMPILER INVOKED BY: FORT90 FLW0SEEM.FOR

```

1      SUBROUTINE SENINP
      C
      C SENINP CALLS SENSOR INPUT ROUTINES UNDER I/O MASK CONTROL
      C
      C INPUTS: I/O MASK BUFFER
      C OUTPUTS: NONE
      C CALLS: INPCID, INFPKS, AIOADC, SENRLM, ADCITZ
      C DESTROYS: NOTHING
      C MODIFIES: SENSOR INPUT BUFFER SIB
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-H, J-Z)
      C
3      IMPLICIT LOGICAL*1(I)
      C
4      DIMENSION DUMMY(5)
5      DIMENSION SIB(10), SOB(10)
      C
6      COMMON/IOFVEC/IOFVEC(5),
      1 IOFCID, IOFFKF, IOFFKR, IOFYCF, IOFYCR, IOFYOT, IOFDEP, IOFKEY,
      2 IOFCAS, IOFCRT, IOFCDU, IOUM(3)
      C
7      COMMON/OPSEEC/OPMODE, MODECT, RANGCK, OPSENR, RATECK, ODUM(5)
      C
8      COMMON/NORK/ TEMP10, SINPNT, WADUM(18)
      C
9      COMMON/SENSUF/ SIB, SOB
      C
10     SAVE /WORK/, /OPSEEC/
11     SAVE /IOFVEC/, /SENSUF/
      C
      C*****
      C INITIALIZE A/D EVERY TIME FOR SAFETYS SAKE
      C
12     CALL ADCITZ
      C
13     DO 100 J=1,5
      C TEST IF I/O FLAG ON (TRUE)
14     IF(IOFVEC(J+1)) THEN
15     SINPNT=J
      C CALL A/D DRIVER ROUTINE
16     CALL AIOADC (SINPNT, TEMP10)
17     SIB(SINPNT)=TEMP10
18     END IF
19 100 CONTINUE
      C
      C
      C TEST I/O FLAG FOR CID
      C
20     IF(IOFCID) CALL INPCID
      C

```

```
      C TEST I/O FLAG FOR PICKS
      C
21      IF(IOFFNE OR IOFFRY) CALL INFRS
      C
      C HARDWARE PATCH FOR A/D INPUT WIPES
22      DO 200 J=2,5
23      DUMMY(J)=SIB(J)
24      200 CONTINUE
      C
25      SIB(2)=DUMMY(4)
26      SIB(3)=DUMMY(5)
27      SIB(4)=DUMMY(2)
28      SIB(5)=DUMMY(3)
      C
      C IF RATE CHECKING ACTIVE CALL SENSOR LIMIT ROUTINE
      C
29      IF(RATECK EQ 1) CALL SENRLM
      C
30      RETURN
31      END
```

ORIGINAL PAGE IS
OF POOR QUALITY

MODULE INFORMATION:

```
CODE AREA SIZE   = 005EH   1900
VARIABLE AREA SIZE = 000CH   120
MAXIMUM STACK SIZE = 0002H    20
71 LINES READ
```

0 PROGRAM ERROR(S) IN PROGRAM UNIT SENINP

TS15-11 FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT CONVRT
 OBJECT MODULE PLACED IN :F1:YOSEMI.CBJ
 COMPILER INVOKED BY: FORT90 :F1:YOSEMI.FCR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE CONVRT
      C
      C CONVRT CONVERTS SENSOR INPUT DATA TO ENGINEERING UNITS, AND
      C     DOES OPTIONAL RANGE CHECK
      C
      C INPUTS: SENSOR INPUT DATA IN SIB
      C OUTPUTS: SENSOR DATA IN SDB
      C CALLS: CONFNC
      C DESTROYS: NOTHING
      C MODIFIES: SDB
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-H, J-Z)
      C
3      INTEGER*4 NMXIPX
      C
4      DIMENSION SIB(10), SDB(10)
      C
5      LOGICAL*4 IOFVEC(20)
      C
6      COMMON/OPPARM/IOFNT(10), NMXVEC(16), NMXIPX(6)
      C
7      COMMON/IOFVEC/ IOFVEC
      C
8      COMMON/SENBUF/ SIB, SDB
      C
9      COMMON/WORK/ TEMPID, SINFNT, DUMMY(18)
      C
10     EQUIVALENCE (NMXSEN, NMXVEC(1))
      C
11     SAVE /IOFVEC/, /SENBUF/, /OPPARM/, /WORK/
      C
      C*****
      C
12     DO 100 I=L, NMXSEN
      C TEST IF I/O FLAG ON (TRUE)
13         IF (IOFVEC(I+1)) THEN
14             SINFNT=I
15             TEMPID=SIB(I)
      C CALL DATA TO ENGINEERING UNITS CONVERSION
16             CALL CONFNC
17             SDB(I)=TEMPID
18         END IF
19     100 CONTINUE
      C
20     RETURN
21     END
    
```

MODULE INFORMATION:

CODE AREA SIZE = 0056H 66D
VARIABLE AREA SIZE = 0034H 40
MAXIMUM STACK SIZE = 0002H 2D
47 LINES READ

ORIGINAL PAGE IS
OF POOR QUALITY

0 PROGRAM ERROR(S) IN PROGRAM UNIT CONVET

ICS-11 FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT OUTPUT
 OBJECT MODULE PLACED IN: F140SEEM.OBJ
 COMPILER INVOKED BY: FORT90 F140SEEM.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE OUTPUT
      C
      C OUTPUT IS THE CONTROLLER OUTPUT ROUTINE. THIS CALLS THE
      C   APPROPRIATE OUTPUT ROUTINES AS PER THE I/O MASKS
      C
      C INPUTS: I/O MASKS
      C OUTPUTS: NONE
      C CALLS: AIOVOT
      C DESTROYS: NOTHING
      C MODIFIES: NOTHING
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-H, J-Z)
      C
3      IMPLICIT LOGICAL*4 (I)
      C
4      INTEGER*4 CIB(8), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), VOB(2)
      C
5      COMMON/COMBUF/CIB, KIB, DOB, TOB, PIB, POB, VOB
      C
6      COMMON/SENEUF/SIB(10), SDB(10)
      C
7      COMMON/PARAMS/DMAX, DMIN, PDUM(18)
      C
8      COMMON/IOFVEC/IOUM(9), IOFVCF, IOFVCR, IOFVOT, IBDUM(8)
      C
9      SAVE /IOFVEC/, /COMBUF/, /PARAMS/, /SENEUF/
      C
10     EQUIVALENCE (SDB(4), FDRUM), (SDB(5), RDRUM)
      C
      C*****
      C
      C VOB(1) = FRONT VALVE
      C VOB(2) = REAR VALVE
      C 1 = UP CONTROL
      C -1 = DOWN CONTROL
      C
      C OUTPUT FORMAT TO VALVE DRIVER
      C BIT 0 = FRONT UP
      C BIT 1 = FRONT DOWN
      C BIT 2 = REAR UP
      C BIT 3 = REAR DOWN
      C DRUMS ARE LIMITED TO DMAX UP AND DMIN DOWN
      C
11     CEYTE=0
      C FRONT VALVE ENABLE TEST
12     IF(IOFVCF) THEN
13     VTEST=0
14     VTEST=VOB(1)
      C TEST IF VALVE TO BE CONTROLLED
15     IF(VTEST.NE.0) THEN

```

FORTRAN COMPILER

ORIGINAL PAGE IS
OF POOR QUALITY

```

C TEST IF UP OR DOWN
15 IF(VTEST.EQ.1) THEN
17   IF(RDRUM.LT.DMAX) CBYTE=1
18   ELSE
19     IF(RDRUM.GT.DMIN) CBYTE=2
20   END IF
21 END IF
C END IOFVCF BLOCK
22 END IF
C
C REAR VALVE ENABLE
23 IF(IOFVCR) THEN
24   VTEST=3
25   VTEST=VDB(2)
C TEST IF VALVE TO BE CONTROLLED
26 IF(VTEST.NE.0) THEN
C
C TEST IF UP OR DOWN CONTROL
27 IF(VTEST.EQ.1) THEN
28   IF(RDRUM.LT.DMAX) CBYTE=CBYTE+4
29   ELSE
30     IF(RDRUM.GT.DMIN) CBYTE=CBYTE+8
31   END IF
32 END IF
C END IOFVCR BLOCK
33 END IF
C
C TEST IF VALVE OUTPUT ENABLED
34 IF(IOFVOT) THEN
35   CALL RIQVOT(CBYTE)
36 END IF
C
37 RETURN
38 END

```

MODULE INFORMATION:

CODE AREA SIZE	= 0000H	192D
VARIABLE AREA SIZE	= 0004H	4D
MAXIMUM STACK SIZE	= 0002H	2D
86 LINES READ		

0 PROGRAM ERROR(S) IN PROGRAM UNIT DINTAUT

ISIS-11 FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT ITZINP
 OBJECT MODULE PLACED IN :F1:VCSMEM.ORT
 COMPILER INVOKED BY: FORTE0 :F1:VCSMEM.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE ITZINP
      C
      C ITZINP PROMPTS THE USER AND UPDATES THE VALUE OF SOME VARIABLES IN COMMON
      C
      C INPUTS: NONE
      C OUTPUTS: NONE
      C CALLS: OUTDSP, INPCDU, INTRDS, INPHEX, OUTPUT
      C DESTROYS: NOTHING
      C MODIFIES: VARIABLES SELECTED BY USER
      C VERSION 1.0
      C
2      $INCLUDE(:F1:VCSMEM.FOR)
      = C*****
      = C
      = C VCS SYSTEM MEMORY ALLOCATION
      = C
3      =      IMPLICIT INTEGER*2(A-Z)
4      =      INTEGER*4  CIB, KIB, DOB, TOB, PIB, POB, VOB
5      =      INTEGER*4  PKFBUF, PKRBUF, PKFSAV, PKRSV
6      =      INTEGER*4  MNXIPX(6), TFLAG(6)
7      =      INTEGER*4  ERRBUF(8,10)
      = C
9      =      LOGICAL*4  IOFVEC(20), OMTVEC(16), SINT(8), SMEX(8), DBGM(8)
9      =      LOGICAL*4  DEFIOV(20), DEFCTV(16)
10     =      LOGICAL*4  NEXT, ADJUST, RESET, RUN, CALBRT, PWRPAL, AUTO, MANUAL
      = C
11     =      CHARACTER*4  PARMES, MOSMES(10)
12     =      CHARACTER*4  DSPCOD(10)
13     =      CHARACTER*4  DGBC, DGBM, OPSMES(10)
14     =      CHARACTER*4  ERRMES(20), DGBMES(20), RUNMES(20)
      = C
15     =      DIMENSION DEFPRM(20), DEFPNT(8)
      = C
      = C COMMON BLOCK ALLOCATIONS
      = C
16     =      COMMON/CPANEL/NEXT, ADJUST, RESET, AUTO, MANUAL, PWRPAL, RUN, CALBRT
      = C
17     =      COMMON/NESTB2/ PARMES(20)
      = C
18     =      COMMON/NESTB3/ OPSMES
      = C
19     =      COMMON/MOSMES/MOSMES
      = C
20     =      COMMON/SENFNT/SENPTR(16)
      = C
21     =      COMMON/PIKBUF/PKFBUF(10), PKRBUF(10), PKFSAV, PKRSV
      = C
22     =      COMMON/CLOCK/TFLAG
      = C
23     =      COMMON/DEBUG/DBGM
      = C

```

```

24 = COMMON/SENDEL/LODEL(40), PCDEL(60), FOPDEL(400)
   = C
25 = COMMON/IOFVEC/IOFVEC
   = C
26 = COMMON/CNTVEC/CNTVEC
   = C
27 = COMMON/OPSVEC/OPSVEC(10)
   = C
28 = COMMON/OPPARM/ICNPNT(10), NMAX(16), NMAXPX
   = C
29 = COMMON/SENMEM/LSTPARS(3000), DSCNTL(16)
   = C
30 = COMMON/OPSPNT/OPPNTS(8)
   = C
31 = COMMON/WORK/TEMP10, DUMMY(19)
   = C
32 = COMMON/SAVER/SAVE(20)
   = C
33 = COMMON/PARAMS/ PARAM(20)
   = C
34 = COMMON/ERRBUF/ERRBUF
   = C
35 = COMMON/ERRFLG/ ERROR(8)
   = C
36 = COMMON/COMBUF/CIB(80), KIB(8), DOB(8), TOB(120), PIB(2), POB(2), WOB(2)
   = C
37 = COMMON/SENBUF/SIB(10), SOB(10)
   = C
38 = COMMON/CONTAB/SENTAB(10, 2), RGCDAT(10, 2)
   = C
39 = COMMON/MESTAB/ERRMES, DBGMES, RUMMES, DSPCOD
   = C
40 = COMMON/DEFAULT/ DEFIOV, DEFPRN, DEFCTV, DEFPNT
   = C
41 = COMMON/DEFTAB/ DEFRNG(10, 2), DEFCON(10, 2)
   = C
42 = COMMON/DEFOPS/DEFOPS(10)
   = C
43 = COMMON/DEFMOS/DEFMOS(16)
   = C
44 = SAVE /CPANEL/, /PIVBUF/, /SAVER/, /ERRBUF/, /SENDEL/
45 = SAVE /DEBUG/, /IOFVEC/, /CNTVEC/, /OPSVEC/
46 = SAVE /OPPARM/, /SENMEM/, /OPSPNT/, /CLOCK/, /WORK/, /DEFTAB/
47 = SAVE /PARAMS/, /ERRFLG/, /COMBUF/, /SENBUF/, /CONTAB/, /MESTAB/, /DEFAULT/
48 = SAVE /SENPNT/, /MESTB2/, /MESTB3/, /DEFOPS/
49 = SAVE /DEFMOS/
   = C
50 = EQUIVALENCE (DOB(1), DOBC), (DOB(5), DOBN)
51 = EQUIVALENCE (OPSVEC(1), OPMODE), (OPSVEC(2), MODECT), (OPSVEC(3), PNGMSK)
52 = EQUIVALENCE (OPSVEC(4), OPSENR), (OPSVEC(5), RATECK)
53 = EQUIVALENCE (OPSVEC(6), STATUS), (TIME, TFLAG(4))
   = C
54 = INTEGER*1 BITS(8)
   = C
55 = CHARACTER*1 CDUM
   = C
56 = EQUIVALENCE (NMAXPX, NMAX(4))

```

ORIGINAL PAGE IS
OF FOUR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

```

57      EQUIVALENCE (TEMP10,BITS(1))
58      EQUIVALENCE (OPRNTS(1),DATPNT)
59      EQUIVALENCE (CDUM,DOB(1)),(DOB(5),DOBX)
      C
      C*****
      C
60      CALL INTRDS
      C
      C LOAD DOB WITH INITIALIZE CODE DISPLAY AND PAUSE
      C
61      DOBC=DEGMES(12)
62      DOBN=DEGMES(5)
      C @SYSITZ?
63  10  CALL OUTDSP
      C
64      CALL INPCDU
      C IF RUN SWITCH ON WAIT FOR RUN MODE FROM OPERATOR
      C BEGIN BLOCK = RUN
65      IF(RUN) THEN
      C TEST IF AUTOMATIC MODE SWITCH
66      IF(AUTO) THEN
67          OPMODE=1
68          GO TO 2000
69      END IF
      C TEST IF MANUAL MODE
70      IF(MANUAL) THEN
71          OPMODE=4
72          GO TO 2000
73      END IF
74          GO TO 10
75      END IF
      C END BLOCK = RUN
      C
      C ELSE CALIBRATE SWITCH
      C IF PST SKIP OUT OF ROUTINE
76      IF(RESET) GO TO 1000
      C
      C DATA INITIALIZATION BLOCK DO
      C BEGIN BLOCK = DATA
77      IF(ADJUST) THEN
      C
78      DO 100 I=L,NMXPIM
      C
      C LOAD DOB WITH FROMPT(I)
      C
      C LOAD MESSAGE FROM RUNMES TABLE TO CONTROL PROMPT TYPES
      C
      C PROMPTS
      C ?I/MASK
      C ?CHTMASK
      C ?OPSPARM
      C ?VRBPARM
      C DAT?ITZ?
      C ?SENPARM
      C ?MOSCHTL
      C
79      DOBC=RUNMES(I)

```

ORIGINAL PAGE IS
OF POOR QUALITY

```

90      DOBN=RUNMES(13)
      C
91      IF(I.GE.3) DOBN=RUNMES(14)
      C
92      IF(I.EQ.5) THEN
93          DOBC=DEGMES(4)
94          DOBN=DEGMES(5)
95      END IF
      C
96      IF(I.EQ.6) THEN
97          DOBC=ERRMES(1)
98          DOBN=RUNMES(14)
99          CDUM=DSPCOD(7)
99      END IF
      C
91      IF(I.EQ.7) THEN
92          DOBC=DEGMES(3)
93          DOBN=RUNMES(2)
94      END IF
      C
      C DISPLAY PROMPT
      C
95      CALL OUTDSP
      C
      C READ INPUT FROM C/D PANEL
      C
96      CALL INPCDU
      C
      C TEST IF MODIFY THIS SET OF VARIABLES
      C BEGIN BLOCK = MODIFY
97      IF(ADJUST) THEN
      C MODIFY THIS SET
      C
98      IF(I.EQ.5) GO TO 300
      C
99      NMXIPT=NMXIPX(I)
100     DO 200 J=L,NMXIPT
101     TEMP10=0
      C
      C LOAD DOB WITH PROMPT
      C
      C I/O FLAG RESET
102     IF(I.EQ.1) THEN
103     IF(IOFVEC(J)) TEMP10=TEMP10+255
104     DOBC=ERRMES(J)
105     GO TO 150
106     END IF
      C
      C CONTROL VECTOR RESET
107     IF(I.EQ.2) THEN
108     DOBC=ERRMES(ICNPNT(J))
109     IF(CNTVEC(J)) TEMP10=TEMP10+255
110     GO TO 150
111     END IF
      C
      C OPERATION VECTOR RESET
112     IF(I.EQ.3) THEN

```



```

113      DOBC=OPMES(J)
114      TEMP10=TEMP10+OPSVED(J+1)
115      GO TO 150
116      END IF
      C
      C PARAMETER RESET
117      IF(I EQ 4) THEN
118      DOBC=PARMES(J)
119      TEMP10=TEMP10+PARAM(J)
120      GO TO 150
121      END IF
      C
      C INPUT TABLE RESET
      C BEGIN BLOCK = TABLE
122      IF(I EQ 6) THEN
123      K=(J-1)/2+1
124      L=MOD(J-1,2)
      C
125      IF(J LE 16) THEN
126      TEMP10=SENTAB(K,L+1)
127      ELSE
128      TEMP10=RGCODAT(K-8,L+1)
129      END IF
130      IF(J LE 16) THEN
131      DOBC=ERRMES(K+1)
132      COUN=DSPCOD(5)
      C #
133      IF(L EQ 1) COUN=DSPCOD(2)
      C *
134      END IF
      C
135      IF(J GE 17) THEN
136      DOBC=ERRMES(K-7)
      C NXXX
137      DOB(1)=#4EH
      C XXXX
138      IF(L EQ 1) DOB(1)=#58H
139      END IF
140      GO TO 150
      C END BLOCK = TABLE
141      END IF
      C
142      IF(I EQ 7) THEN
143      DOBC=MOSMES(J)
144      TEMP10=TEMP10+OSCNL(J)
145      GO TO 150
146      END IF
      C
      C ##
147      DOBX=TEMP10
148      CALL FORMAT(DOBX)
      C DISPLAY MESSAGE
      C
149      CALL OUTDSP
      C
150      CALL INPCDU
      C IF RST SKIP OUT OF THIS SET

```

ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

```

151      IF(RESET) GO TO 100
      C
      C IF ADJ THEN DO . ELSE SKIP TO NEXT
      C BEGIN BLOCK = ADJUST
152      IF(ADJUST) THEN
153      CALL INPHEX
      C
      C BEGIN BLOCK = LOAD
154      IF(TEMP10.NE.0) THEN
      C LOAD DATA IN TEMP10+1 INTO DESTINATION
      C
      C I/O FLAG SET UP
      C
155      IF(I.EQ.1) THEN
156      IF(DUMMY(1).GE.1) THEN
157      IOFVEC(J)=.TRUE
158      ELSE
159      IOFVEC(J)=.FALSE
160      END IF
161      END IF
      C
      C CONTROL VECTOR SET UP
      C
162      IF(I.EQ.2) THEN
163      IF(DUMMY(1).GE.1) THEN
164      CNTVEC(J)=.TRUE
165      ELSE
166      CNTVEC(J)=.FALSE
167      END IF
168      END IF
      C
      C OPERATING CONTROL PARAMETER SET UP
      C
169      IF(I.EQ.3) OPSVEC(J+1)=DUMMY(1)
      C
      C PARAMETER SET UP
      C
170      IF(I.EQ.4) PARAM(J)=DUMMY(1)
      C
      C SENSOR TABLE RESET
      C
171      IF(I.EQ.6) THEN
      C
172      IF(J.LE.16) THEN
173      SENTAB(K,L+1)=DUMMY(1)
174      ELSE
175      RGCDAT(K-8,L+1)=DUMMY(1)
176      END IF
      C END SENSOR SET UP
177      END IF
      C
178      IF(I.EQ.7) DECNL(J)=DUMMY(1)
      C
      C END OF DATA LOAD SECTION
179      END IF
      C END BLOCK = LOAD
      C

```

ORIGINAL PAGE IS
OF POOR QUALITY

```

C END OF LOOP FOR SET
190   END IF
C END BLOCK = ADJUST
C
191   200 CONTINUE
C
C END OF SET OF VARIABLES
192   END IF
C END BLOCK = MODIFY
C
193   GO TO 450
C
C CLEAR CMOS AND SET DEFAULTS
194   300 DOBN=RUNMES(20)
195   DOB(4)=#41H
196   CALL OUTDSP
C
197   DO 400 I=L,3000
198   LSTRAS(I)=-32000
199   400 CONTINUE
C
C SET CMOS BUFFER POINTER AT START (OPPNTS(1))
199   DATPNT=1
C
191   450 CONTINUE
C
192   100 CONTINUE
C
C END OF DATA INITIALIZATION BLOCK
192   END IF
C END BLOCK = DATA
C
C *****
C TEST FOR DEBUG OR CALIBRATE MODES
C
194   DOBC=RUNMES(9)
195   DOBN=RUNMES(10)
C %CALERAT
196   CALL OUTDSP
C
197   CALL INPCDU
C IF ADJ PRESSED
198   IF(ADJUST) THEN
199   OPMODE=5
200   GO TO 1000
201   END IF
C IF RESET PRESSED
202   IF(RESET) GO TO 1000
C *****
C DEBUG
203   DOBC=RUNMES(7)
204   DOBN=DEGMES(12)
205   DOUN=DSFOOD(7)
C %DEB@S@S
206   CALL OUTDSP
C

```

```

207      CALL INPCD0
      C IF #0J PRESSED THEN DO
208          IF (#ADJUST) THEN
209              OFMODE=2
210              GO TO 1000
211          END IF
      C IF RESET SKIP OUT
212          IF (#RESET) GO TO 1000
      C
213      1000 CONTINUE
214          RETURN
      C
      C SYNCHRONIZE CLOCK TIMER
215      2000 CONTINUE
216          CALL OUTPUT(#25H,0)
217          CALL OUTPUT(#25H,#07H)
      C
218          RETURN
219          END

```

ORIGINAL PAGE IS
OF POOR QUALITY

MODULE INFORMATION:

```

CODE AREA SIZE      = 062EH   15820
VARIABLE AREA SIZE = 001EH    320
MAXIMUM STACK SIZE = 0009H    100
412 LINES READ

```

0 PROGRAM ERROR(S) IN PROGRAM UNIT ITZ1NP

IS15-II FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT PESTRT
 OBJECT MODULE PLACED IN :F1:VCSM31.OBJ
 COMPILER INVOKED BY: FORT90 :F1:VCSM31.FOR

**ORIGINAL PAGE IS
 OF POOR QUALITY.**

```

1      SUBROUTINE PESTRT
      C
      C RESTRT CLEARS APPROPRIATE DAT TO ALLOW WARM START OF VCS
      C
      C INPUTS: NONE
      C OUTPUTS: NONE
      C CALLS: NOTHING
      C DESTROYS: SENPNTS, ERREBUF, OPPNTS, CLOCK, PIKBUFS, SENDELS
      C MODIFIES: OPPNTS(1), STATUS
      C VERSION 1.0
      C
2      $INCLUDE(:F1:VCSM31.FOR)
      = C*****
      = C
      = C VCS SYSTEM MEMORY ALLOCATION
      = C
3      = IMPLICIT INTEGER*2(A-Z)
4      = INTEGER*4 CIB, KIB, DCB, TOB, PIB, POB, VOB
5      = INTEGER*4 PKFBUF, PKPBUF, PKFSAV, PKRSRV
6      = INTEGER*4 NMXIPX(6), TFLAG(6)
7      = INTEGER*4 ERREUF(8,10)
      = C
8      = LOGICAL*4 IOPVEC(20), CNTVEC(16), SINT(8), SMSK(8), DEGM(8)
9      = LOGICAL*4 DEFTDY(20), DEFCTY(16)
10     = LOGICAL*4 NEXT, ADJUST, RESET, RUN, CALBRT, PWRFAL, AUTO, MANUAL
      = C
11     = CHARACTER*4 PARMES, MOSMES(10)
12     = CHARACTER*4 DSPCOD(10)
13     = CHARACTER*4 DDEC, DDBN, OPSMES(10)
14     = CHARACTER*4 ERRMES(20), DBGMES(20), RUNMES(20)
      = C
15     = DIMENSION DEFRM(20), DEFPNT(8)
      = C
      = C COMMON BLOCK ALLOCATIONS
      = C
16     = COMMON/CPRMEL/NEXT, ADJUST, RESET, AUTO, MANUAL, PWRFAL, RUN, CALBRT
      = C
17     = COMMON/MESTB2/ PARMES(20)
      = C
18     = COMMON/MESTB3/OPSMES
      = C
19     = COMMON/MOSMES/MOSMES
      = C
20     = COMMON/SENPNT/SENPTR(16)
      = C
21     = COMMON/PIKBUF/PKFBUF(10), PKRBUF(10), PKFSAV, PKRSRV
      = C
22     = COMMON/CLOCK/TFLAG
      = C
23     = COMMON/DEBUG/DBGH
      = C
    
```

```

24 = COMMON/SENDEL/LCDEL(40), PCDEL(60), FORDL(400)
   = C
25 = COMMON/IOPVEC/IOPVEC
   = C
26 = COMMON/CNTVEC/CNTVEC
   = C
27 = COMMON/OPSVEC/OPSVEC(10)
   = C
29 = COMMON/OPPARM/ICHPNT(10), NMAX(16), NMAXP
   = C
29 = COMMON/SENMEM/LSTPAS(3000), DSCNTL(16)
   = C
30 = COMMON/OPSPNT/OPSPNTS(8)
   = C
31 = COMMON/WORK/TEMP10, DUMMY(19)
   = C
32 = COMMON/SAVER/SAVE(20)
   = C
33 = COMMON/PARAMS/ PARAM(20)
   = C
34 = COMMON/EPABUF/EPABUF
   = C
35 = COMMON/ERRFLG/ ERROR(8)
   = C
35 = COMMON/COMBUF/CIB(80), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), VOB(2)
   = C
37 = COMMON/SENBUF/SIB(10), SDB(10)
   = C
38 = COMMON/CONTAB/SENTAB(10, 2), RCODAT(10, 2)
   = C
39 = COMMON/MESTAB/ERMES, DBGMES, RUNMES, DEPCOD
   = C
40 = COMMON/DEFAULT/ DEFIOV, DEFPRN, DEFCTV, DEFINT
   = C
41 = COMMON/DEFTAB/ DEFRNG(10, 2), DEFCON(10, 2)
   = C
42 = COMMON/DEFOPS/DEFOPS(10)
   = C
43 = COMMON/DEFMOS/DEFMOS(16)
   = C
44 = SAVE /CPANEL/, /PIKBUF/, /SAVER/, /EPABUF/, /SENDEL/
45 = SAVE /DEBUG/, /IOPVEC/, /CNTVEC/, /OPSVEC/
46 = SAVE /OPPARM/, /SENMEM/, /OPSPNT/, /CLOCK/, /WORK/, /DEFTAB/
47 = SAVE /PARAMS/, /ERRFLG/, /COMBUF/, /SENBUF/, /CONTAB/, /MESTAB/, /DEFAULT/
48 = SAVE /SENINT/, /MESTB2/, /MESTB3/, /DEFOPS/
49 = SAVE /DEFMOS/
   = C
50 = EQUIVALENCE (DOB(1), DOBC), (DOB(5), DOBN)
51 = EQUIVALENCE (OPSVEC(1), OPMODE), (OPSVEC(2), MODECT), (OPSVEC(3), PNGMSK)
52 = EQUIVALENCE (OPSVEC(4), OPSENR), (OPSVEC(5), RATECK)
52 = EQUIVALENCE (OPSVEC(6), STATUS), (TIME, TFLAG(4))
   = C
   C
54 LOGICAL*4 IOFCAS
   C
55 DIMENSION SENDEL(500)
   C

```

ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

```

56      EQUIVALENCE (IOFVED(15), IOFCAS)
57      EQUIVALENCE (SENDEL(1), LODEL(1))
      C
      C*****
      C
58      STATUS=0
      C CLEAR DELAY POINTERS
59      DO 100 I=L 16
60      SENPTR(I)=0
61      100 CONTINUE
      C
      C CLEAR ERROR BUFFERS
62      DO 200 I=L 8
63      DO 200 J=L 10
64      ERBUF(I, J)=0
65      200 CONTINUE
      C
      C CLEAR OPERATION POINTERS
66      DO 300 I=L 8
67      OPPTS(I)=DEFPNT(I)
68      300 CONTINUE
69      OPPTS(1)=1
      C
      C CLEAR CLOCK ARRAY
70      DO 400 I=L 6
71      TFLAG(I)=0
72      400 CONTINUE
      C
      C CLEAR PICK DATA
73      DO 500 I=L 10
74      PKFBUF(I)=0
75      PKRBUF(I)=0
76      500 CONTINUE
      C
      C CLEAR DELAY LINES
77      DO 600 I=L 500
78      SENDEL(I)=0
79      600 CONTINUE
      C
80      IF(IOFCAS) CALL TAPITZ
      C IF CASSETTE ON WRITE TAPE HEADER
      C
      C CMOS POINTER RESET, LSTPNT
81 /    DSCNTL(6)=0
      C
82 |    RETURN
83      END

```

MODULE INFORMATION:

```

CODE AREA SIZE      = 0132H    3140
VARIABLE AREA SIZE = 0014H    200
MAXIMUM STACK SIZE = 0002H    20
155 LINES READ

```

FORTRAN COMPILER

ORIGINAL PAGE IS
OF POOR QUALITY

PAGE 1

0 PROGRAM ERROR(S) IN PROGRAM UNIT RESTRT

0 TOTAL PROGRAM ERROR(S)
END OF FORTRAN COMPILATION

IS15-11 FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT CNTRFD
 OBJECT MODULE PLACED IN FILEVSCNT.OBJ
 COMPILER INVOKED BY: FORT80 FILEVSCNT.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE CNTRFD
      C
      C CNTRFD IS THE FRONT DRUM CONTROL ALGORITHM
      C   THIS VERSION INCLUDES LCF, PICKS, HBS-CID, DEADEND, BIAS
      C
      C INPUTS: SENSOR DATA, CONTROL INFORMATION
      C OUTPUTS: FRONT DRUM CONTROL SIGNAL
      C CALLS: NOTHING
      C DESTROYS: NOTHING
      C MODIFIES: CONTROL OUTPUT FOR FRONT
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*1 CIB(80), KIB(8), DOB(6), TOB(128), PIB(2), POB(2), VOB(2)
4      INTEGER*1 PKFSAY, PKFBUF, PKRSAY, PKRBUF
      C
5      LOGICAL*1 IOFVCF
6      LOGICAL*1 CNMCID, CNMLCF, CNMPKF, CNMPKR, CNMPCF, CDUM(11), IOFVEC(38)
      C
7      COMMON/OPSPNT/OPPNTS(8)
      C
9      COMMON/CONBUF/ CIB, KIB, DOB, TOB, PIB, POB, VOB
      C
9      COMMON/SAVER/LCX, FCNTL, FCDEL, TEMPOR(17)
      C
10     COMMON/SENMEM/ LSTPAS(3000), DSCNTL(16)
      C
11     COMMON/SENFNT/FDRPNT, FDRCNT, LCPNT, LCNT, PCPNT, PCNT, DUMMY(10)
      C
12     COMMON/PIKBUF/PKFBUF(10), PKRBUF(10), PKFSAY, PKRSAY
      C
13     COMMON/SENBUF/SIB(10), SDB(10)
      C
14     COMMON/PARAMS/DMAX, DMIN, ERLMT, CDSTEP, PIKAVE, PKSTEP, DEDED,
1     DEDED, ARNLNG, DRHRAD, LCPOS, PCPOS, CIDPOS, FTRLOC, DFDFCT,
2     SINDSTP, DBIASF, DBIASR, ERKVAL, TRCFCT
      C
15     COMMON/CNTVEC/CNMCID, CNMLCF, CNMPKF, CNMPKR, CNMPCF, CDUM
      C
16     COMMON/OPSVEC/ OPMODE, MODECT, RHGMSK, OPSENR, RATECK, STAT,
1     FDVGN, FDCAL, ROYGN, RDCAL
      C
17     COMMON/SENDEL/LCDEL(40), PCDEL(60), FDRDEL(400)
      C
18     COMMON/IOFVEC/IOFVEC
      C
19     COMMON/ERRFLD/ERROR(8)
      C
20     SAVE .SENMEM/, /IOFVEC/
21     SAVE /OPSPNT/, /SENDEL/, /SAVER/, /PIKBUF/, /SENFNT/

```

ORIGINAL PAGE IS
OF POOR QUALITY

```

22     SAVE /CNTVEC/, /OPSVEC/, /SENEUF/, /PRRMS/, /CONSUF/
      C
23     EQUIVALENCE (SDB(1), DFD), (IOFVEC(10), IOFVCF)
24     EQUIVALENCE (SDB(6), CID), (SDB(2), LC), (SDB(4), FDRUM), (SDB(7), F.F)
25     EQUIVALENCE (DSCNTL(1), MAXSLT), (DSCNTL(2), STRTPT)
26     EQUIVALENCE (DSCNTL(3), STEPEZ), (DSCNTL(4), NEGMAX)
27     EQUIVALENCE (DSCNTL(5), POSMAX), (DSCNTL(6), LSTPNT)
28     EQUIVALENCE (DSCNTL(7), ISHND), (DSCNTL(8), ISNPOS)
29     EQUIVALENCE (DSCNTL(9), CIDMAX), (DSCNTL(10), CIDMIN)
      C
      C*****
      C
      C SENSOR SELECT SECTION
      C
      C TEST IF LCF DATA USED
      C BEGIN BLOCK = SENSOR
30     IF((MODECT.EQ.1).OR.(MODECT.EQ.3)) THEN
      C
31     LCX=(LC*(20-TRGFCT+((10*FDRUM)/FOCAL)))/20
      C
      C BEGIN BLOCK = DELAY
32     IF(OPSENR.EQ.1) THEN
      C
      C OPSENR = 1 FOR DELAYED SENSORS
      C
      C DELAYED LCF ROUTINE
33 10  CONTINUE
      C
      C IF DFD >= OLD DFD + 1 OR MORE STEPS
34     IF((DFD-LCCNT>DFDFCT).GT.DDFCFCT) THEN
35     LCDEL(MOD(LCPNT,LCPOS)+1)=LCX+((FDRUM+FDVGN)/10)*ARMLNG
36     LCPNT=LCPNT+1
37     LCCNT=LCCNT+1
38     GO TO 10
39     END IF
      C
      C TAKE LC FROM DELAYED BUFFER
40     LCX=LCDEL(MOD(LCPNT,LCPOS)+1)
      C
      C END SENSOR IF BLOCK
41     END IF
      C END BLOCK = DELAY
      C
      C *****
      C
      C ELSE NO LCF - RECORDED DATA MODE
42     ELSE
      C
43     IF((MODECT.EQ.2).OR.(MODECT.EQ.4)) THEN
      C LC DATA FROM CNDS BUFFER
44     INDEX=DFD+STRTPT
45     LCX=LSTPAS(INDEX)
      C IF NOT INITIALIZED
46     IF(LCX.EQ.(-32000)) THEN
47     LCX=0
      C ERROR 6 = NO LAST PASS DATA GOOD
48     ERROR(6)=1

```

```

49      END IF
      C
      C END STORED BLOCK
50      END IF
      C
51      END IF
      C END BLOCK = SENSOR
      C
      C *****
      C
      C BUFFER FRONT POSITION FOR SLAVE OF REAR (MODE 3)
52      CONTINUE
      C IF DFD >= OLD CFD + 1 OR MORE STEPS
53          IF((DFD-FDRCNT*(DFDCT).GT.DFDCT) THEN
54              FDRDEL(MOD(FDRPNT,FTRLOC)+1)=FORUM*ARMLNG
55              FDRPNT=FDRPNT+1
56              FDRCNT=FDRCNT+1
57              GO TO 20
58          END IF
      C
      C STOPE CID/PC IN CMOS
      C
59          INDEX=DFD+STRTPY-INSPOS
60          IF((INDEX.LE.POSMAX).AND.(INDEX.GE.NEGMAX)) THEN
      C OK IN RANGE
61          IF(INDEX.NE.LSTPNT) THEN
62              DO 50 I=LSTPNT+1,INDEX
63              LSTPAS(I)=SDB(INSIND)
64          50 CONTINUE
65              LSTPNT=INDEX
66          END IF
67          ELSE
68              ERROR(6)=10
69          END IF
      C
      C END SENSOR SEGMENT
      C
      C *****
      C
      C CONTROL ALGORITHM SECTION
      C
      C IF AUTO MODE DO CONTROL
      C BEGIN BLOCK = CONTROL
70          IF(OPMODE.EQ.1) THEN
      C
71          FCNTL=0
72          VOB(1)=0
      C
      C *****
      C
      C TEST IF PICK CONTROL
      C BEGIN BLOCK = PICKS
73          IF(CNMPKF) THEN
      C
      C TEST IF AVERAGE PICKS
74          IF(PIKAVE.GT.0) THEN
      C STORE PICK DATA FOR AVERAGING

```

ORIGINAL PAGE IS
OF POOR QUALITY.

```

75      I=MOD(QFNTS(5),PIKAVE)
76      PKFEUF(I+1)=PKF+10
77      J=0
      C AVERAGE PICK READINGS
78      DO 100 I=L,PIKAVE
79          J=J+PKFEUF(I)
80      100  CONTINUE
81          J=J/PIKAVE
      C
      C ELSE NO AVERAGING ON PICK DATA
82      ELSE
83          J=PKF+10
84      END IF
      C
      C TEST IF OVER OR UNDER THRESHOLDS FOR CHANGES
85      IF(J.GE.7) THEN
86          J=1
87          GO TO 200
88      END IF
      C
      C TEST IF COAL
89      IF(J.LE.3) THEN
90          J=-1
91          GO TO 200
92      END IF
      C
      C ELSE KEEP OLD VALUE
93      J=PKFSAY
      C
94      200  PKFSAY=J
      C
      C SHIFT LC DUE TO PICKS
95      LCX=LCX+PKSTEP*J
      C
96      END IF
      C END BLOCK = PICKS
      C
      C *****
      C
      C BEGIN BLOCK = CID
97      IF(CNMCID) THEN
      C
      C DO CID CONTROL AS PICKS ARE DONE
      C
      C IF CID .GT. SET POINT MOVE DRUM DOWN
98      IF(CID.GT.CIDMAX) LCX=LCX-CDSTEP
      C
      C IF CID .LT. MIN SET POINT MOVE DRUM UP
99      IF(CID.LT.CIDMIN) LCX=LCX+CDSTEP
      C
100     END IF
      C END BLOCK = CID
      C
      C *****
      C
      C BEGIN BLOCK = LCF
101     IF(CNMLCF) THEN

```

ORIGINAL PAGE IS
OF POOR QUALITY

ORIGINAL PAGE IS
OF POOR QUALITY

```

C
C TEST IF NULLING CONTROL
102   IF(NODECT.EQ.9) FCNTL=LCK
C
C TEST IF NORMAL REAL TIME CONTROL
103   IF((NODECT.EQ.1).OR.(NODECT.EQ.3)) FCNTL=LCK-FERUM*APPLNG
C
104   ELSE
C NO LCF DATA AVAILABLE DIRECTLY
C
C TEST IF STORED DATA (IN CMOS)
105   IF((NODECT.EQ.4).OR.(NODECT.EQ.2)) FCNTL=LCK-FERUM*APPLNG
C
C END LCF BLOCK
106   END IF
C
C *****
C
C CONTROL SIGNAL GENERATION SECTION
C
C TEST IF OUTPUT ENABLED
C BEGIN BLOCK = OUTPUT
107   IF(IOPVCF) THEN
C
C OUTPUT BIAS AND DEAD BAND
108   FCDEL=(FCNTL-OBIAF)
C
C TEST IF DEAD BAND ON OUTPUT
109   IF(DEDBF.GT.0) *ST
110   IF(IABS(FCDEL).LT.DEDEF) THEN
C IF CONTROL .LT. DEAD BAND SET TO 0
111   FCNTL=0
112   GO TO 500
113   END IF
114   END IF
C
C *****
C
C GENERATE VALVE CONTROL
115   IF(FCDEL.GT.0) THEN
116   VOB(1)=1
C DRUM LOW , GO UP
117   ELSE
118   VOB(1)=-1
C DRUM HIGH , GO DOWN
119   END IF
C
120   500 CONTINUE
C
121   END IF
C END BLOCK = OUTPUT
C
122   END IF
C END BLOCK = CONTROL
C
123   RETURN
124   END

```

MODULE INFORMATION

ORIGINAL PAGE IS
OF POOR QUALITY

CODE AREA SIZE = 010FH 8910
VARIABLE AREA SIZE = 000AH 100
MAXIMUM STACK SIZE = 0004H 40
279 LINES READ

0 PROGRAM ERROR(S) IN PROGRAM UNIT CNTRFD

ORIGINAL PAGE IS
OF POOR QUALITY

TS1E-11 FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT CNTRFD
OBJECT MODULE PLACED IN :F1:VCSCHT.OBJ
COMPILER INVOKED BY: FORT90 :F1:VCSCHT.FOR

```

1      SUBROUTINE CNTRFD
      C
      C CNTRFD COMPUTES THE REAR DRUM CONTROL SIGNAL. ALGORITHM IS
      C   CONTROLLED BY INPUTS AND MODE VECTOR
      C
      C INPUTS: SENSOR DATA, CONTROL INFORMATION
      C OUTPUTS: REAR DRUM CONTROL SIGNAL
      C CALLS: NOTHING
      C DESTROYS: NOTHING
      C MODIFIES: CONTROL OUTPUT FOR REAR
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*1 CIB(80), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), VOB(2)
      C
4      LOGICAL*1 IOFVEC(20), IOFYCR
5      LOGICAL*1 CNMCID, CNMLCF, CNMPKF, CNMPKR, CNMPCF, CNMYCF, CNMYCR, CDUM(9)
      C
6      COMMON/COMBUF/CIB, KIB, DOB, TOB, PIB, POB, VOB
      C
7      COMMON/SAVER/PCX, RCNTL, RCDLTL, TEMPOR(17)
      C
8      COMMON/SENMEM/ LSTPAS(3000), DSCNTL(16)
      C
9      COMMON/SENPHI/FDRPNT, FDRCNT, LCPNT, LCCHT, PCPNT, PCCNT, PDUM(10)
      C
10     COMMON/SENBUF/SID(10), SDB(10)
      C
11     COMMON/PARAMS/DMAX, DMIN, ERRANT, SEAR, PIKAVE, PKSTEP,
12     1 DEBDF, DEBDR, ARMLNG,
13     2 DRMRAD, LCPOS, PCPOS, CIDPOS, FTRLOC, DFDCT, SINDSTP,
14     3 OBIASF, DBIASR, SRKVAL, TRGFCT
      C
12     COMMON/CNTVEC/CNMCID, CNMLCF, CNMPKF, CNMPKR, CNMPCF, CNMYCF, CNMYCR, CDUM
      C
13     COMMON/OPSVEC/OPMODE, MODECT, RNMASK, OPSENR, RATECK, STAT,
14     1 FVGN, FDCAL, RYGN, RDCAL
      C
14     COMMON/SENDEL/LCDEL(40), PCDEL(60), FDEL(400)
      C
15     COMMON/IOFVEC/IOFVEC
      C
16     SAVE /OPSPNT/, /IOFVEC/
17     SAVE /SENDEL/, /SAVER/, /SENMEM/, /PIKBUF/, /SENPHI/
18     SAVE /CNTVEC/, /OPSVEC/, /SENBUF/, /PARAMS/, /COMBUF/
      C
19     EQUIVALENCE (SDB(1), OFD), (IOFVEC(11), IOFYCR)
20     EQUIVALENCE (SDB(2), PC), (SDB(8), PKR), (SDB(5), RDRUM)
      C
      C*****

```

ORIGINAL PAGE IS
OF POOR QUALITY

```

C
C SENSOR SELECT SECTION
C
C TEST IF PCF DATA USED
C BEGIN BLOCK = SENSOR
21 IF(MODECT.LE.1) THEN
C
22 PCX=(PC*(20-TRGFCT*((10+RDRUM)/RDCAL)))/20
C
C TEST IF DELAYED SENSOR
C
C BEGIN BLOCK = DELAY
23 IF(OPSENR.EQ.1) THEN
C
C PCF DELAY ROUTINE
24 10 CONTINUE
C IF (DFD )= OLD DFD + 1 (OR MORE STEPS
25 IF((DFD-PCCNT+(F*ST).GT.DDFDCT) THEN
26 PCDEL(MOD(PCPNT,PCPOS)+1)=PCX+((RDRUM+RDYGN)/10)*RPLING
27 PCPNT=PCPNT+1
28 PCCNT=PCCNT+1
29 GO TO 10
30 END IF
C
C TAKE PC DATA FROM DELAY BUFFER
31 PCX=PCDEL(MOD(PCPNT,PCPOS)+1)
C
C END BLOCK = DELAY
32 END IF
C
C *****
C
- C ELSE NO PCF - RECORDED DATA MODE
23 ELSE
C
C TEST IF STORED DATA
C IF((MODECT.EQ.2).OR.(MODECT.EQ.4)) PCX=PC
C
C TEST IF SLAVED DRUM
34 IF(MODECT.EQ.3) PCX=FDRDEL(MOD(FDRPNT,FTRLOC)+1)
C
C END BLOCK = SENSOR
35 END IF
C
C END SENSOR SEGMENT
C
C*****
C
C CONTROL ALGORITHM SECTION
C
C IF AUTO DO CONTROL
C BEGIN BLOCK = CONTROL
36 IF(OPMODE.EQ.1) THEN
C
37 RCNTL=0
38 VOB(2)=0
C

```



```

C TEST IF REAR PCF CONTROL
C BEGIN BLOCK = PCF
39     IF(CHMPCF) THEN
C
C TEST IF NULLING CONTROL
40     IF(MODECT.EQ.0) RCNTL=PCX
C
C TEST IF NORMAL REAL TIME CONTROL
41     IF((MODECT.EQ.1).OR.(MODECT.EQ.3)) RCNTL=PCX-ADRUM*ARMLNG
C
C *****
C
42     ELSE
C NO PCF DATA AVAILABLE
C
C TEST IF SLAVED DRUM CONTROL
43     IF(MODECT.EQ.3) RCNTL=PCX-ADRUM*ARMLNG
C
C TEST IF STORED DATA (CMOS)
C REAR IS SAME AS 1,3 FOR NON
44     IF((MODECT.EQ.4).OR.(MODECT.EQ.2)) RCNTL=PCX-ADRUM*ARMLNG
C
C END BLOCK = PCF
45     END IF
C
C *****
C
C CONTROL SIGNAL GENERATION SECTION
C
C TEST IF OUTPUT ENABLED FOR VALVE
C BEGIN BLOCK = OUTPUT
46     IF(DFVCR) THEN
C
C OUTPUT BIAS AND DEAD BAND
47     RDELTA=(RCNTL-DBIASR)
C
C DEAD BAND ON CONTROL OUTPUT
48     IF(DEDBDR.GT.0) THEN
49     IF(IABS(RDELTA).LT.DEDBDR) THEN
50     RCNTL=0
51     GO TO 500
52     END IF
53     END IF
C
C *****
C
C GENERATE VALVE CONTROL
54     IF(RDELTA.GT.0) THEN
C DRUM LOW , GO UP
55     VOB(2)=1
56     ELSE
C DRUM HIGH , GO DOWN
57     VOB(2)=-1
58     END IF
C
59     500 CONTINUE
C END SIGNAL BLOCK

```

ORIGINAL PAGE IS
OF POOR QUALITY

```
      C END BLOCK = OUTPUT  
60      END IF  
      C  
      C END CONTROL BLOCK  
      C END BLOCK = CONTROL  
61      END IF  
      C  
62      RETURN  
63      END
```

ORIGINAL PAGE IS
OF POOR QUALITY

MODULE INFORMATION:

```
CODE AREA SIZE    = 01F3H    4990  
VARIABLE AREA SIZE = 0000H    00  
MAXIMUM STACK SIZE = 0004H    40  
174 LINES READ
```

0 PROGRAM ERROR(S) IN PROGRAM UNIT CNTRD

ISIS-11 FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT SENRLM
 OBJECT MODULE PLACED IN :F1:VCSOBT.OBJ
 COMPILER INVOKED BY: FORT80 :F1:VCSOBT.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE SENRLM
      C
      C SENRLM IS THE SENSOR INPUT RATE LIMIT ERROR DETECTOR ROUTINE
      C
      C INPUTS: SDB
      C OUTPUTS: ERROR STATUS
      C CALLS: NOTHING
      C DESTROYS: NOTHING
      C MODIFIES: SIB, SDB, ERROR FLAG
      C VERSION: 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      COMMON/SENBUF/SIB(10), SDB(10)
      C
4      COMMON/OPSYEC/OPMODE, MODECT, RNGNSK, OPSENR, RATECK, STATUS, OOLM(4)
      C
5      COMMON/ERRFLG/ ERROR(8)
      C
6      COMMON/PARAMS/PDUM(18), SRKVAL, DUND
      C
7      SAVE /PARAMS/
8      SAVE /OPSYEC/, /ERRFLG/, /SENBUF/
      C
9      EQUIVALENCE (SDB(3), LCF), (SDB(2), PCF)
      C
      C*****
      C
      C IF OLD START INITIALIZE OLD VALUES
      C
10     IF(STATUS.EQ.0) THEN
11         LCOLD=LCF
12         PCOLD=PCF
13         STATUS=STATUS+1
14     END IF
      C
      C IF IN AUTOMATIC DO ERROR TEST
      C
15     IF(OPMODE.EQ.1) THEN
      C TEST IF RATE TOO LARGE ON INPUTS
      C ERROR 4 = INPUT SENSOR RATE OF CHANGE TOO HIGH
16         IF(ABS(LCF-LCOLD).GE.SRKVAL) ERROR(4)=1
      C
17         IF(ABS(PCF-PCOLD).GE.SRKVAL) ERROR(4)=ERROR(4)+10
      C
18     END IF
      C
19     IF(ERROR(4).NE.0) RETURN
      C
      C USE OLD VALUES IF ERROR
20     PCOLD=PCF
    
```

```
21      LOCLD=LCF
      C
22      RETURN
23      END
```

ORIGINAL PAGE IS
OF POOR QUALITY

MODULE INFORMATION:

```
CODE AREA SIZE   = 007FH   127D
VARIABLE AREA SIZE = 0004H   40
MAXIMUM STACK SIZE = 0002H   20
55 LINES READ
```

0 PROGRAM ERROR(S) IN PROGRAM UNIT SENRLM

0 TOTAL PROGRAM ERROR(S)
END OF FORTRAN COMPILATION

ORIGINAL PAGE IS
OF POOR QUALITY

F225-II FORTAN-90 V2.1 COMPILATION OF PROGRAM UNIT DEUGCI
OBJECT MODULE PLACED IN :F1:VCSDBG.OBJ
COMPILER INVOKED BY: FORT90 :F1:VCSDBG.FOR

```

1      SUBROUTINE DEUGCI
      C
      C DEUGCI READS DEBUG CONTROL INFORMATION FROM CONTROL/DISPLAY PANEL
      C
      C INPUTS: DEBUG CONTROL VECTOR
      C OUTPUTS: NONE
      C CALLS: INPCDU, OUTDSP, PAUSE
      C DESTROYS: NOTHING
      C MODIFIES: DEBUG CONTROL VECTOR
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      CHARACTER*1 DSFCOD(10)
4      CHARACTER*4 DOBC, DOBN
5      CHARACTER*4 ERRMES(20), DGMES(20), PUNMES(20)
      C
6      INTEGER*1 BITS(8)
7      INTEGER*1 CIB(80), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), YOB(2)
      C
8      LOGICAL*1 NEXT, ADJUST, RESET, AUTO, MANUAL, PHRFAL, RUN, CALERT
      C
9      COMMON/CPANEL/NEXT, ADJUST, RESET, AUTO, MANUAL, PHRFAL, RUN, CALERT
      C
10     COMMON/OPARM/NDUM(18), NMXDBG, MDUM(18)
      C
11     COMMON/COMBUF/ CIB, KIB, DOB, TOB, PIB, POB, YOB
      C
12     COMMON/MESTAB/ ERRMES, DGMES, RUNMES, DSFCOD
      C
13     COMMON/WORK/ TEMPIO, DUMMY(19)
      C
14     SAVE /COMBUF/, /MESTAB/, /WORK/, /CPANEL/, /OPARM/
      C
15     EQUIVALENCE (DOB(1), DOBC), (DOB(5), DOBN)
      C
16     EQUIVALENCE (TEMPIO, BITS(1))
      C
      C*****
      C
      C LOAD DOB WITH PROMPT
      C
      C *DEBUG!
17     DOBC=RUNMES(7)
18     DOBN=RUNMES(8)
      C
      C DISPLAY MESSAGE
      C
19     CALL OUTDSP
      C
20     CALL PAUSE
  
```

```

C
C PROMPT FOR NMYDBG DEBUG OPERATIONS
C
C LOAD DOBC WITH DEBUG CODE
C
C @DEGXXX
21     DOBC=DBGMES(1)
C
C M) FOR ALL DEBUG TYPES
22     DO 100 I=L,NMYDBG
C
C LOAD DOBN WITH SECOND HALF OF PROMPT
23     DOBN=DBGMES(I+1)
C
C DISPLAY AND WAIT FOR RESPONSE
C
24     CALL OUTDSP
25     CALL INPCDU
C
C TEST IF ADJ PRESSED
26     IF(ADJUST) THEN
27         TEMPIO=1
28         GO TO 1000
29     END IF
C
C IF RST ; EXIT
30     IF(RESET) THEN
31         TEMPIO=0
32         GO TO 1000
33     END IF
C
C ELSE IF HKT ; CONTINUE
34 100 CONTINUE
C
C DEFAULT EXIT
35     TEMPIO=0
C
36 1000 CONTINUE
37     RETURN
38     END

```

ORIGINAL PAGE IS
OF POOR QUALITY

MODULE INFORMATION:

```

CODE AREA SIZE   = 00A5H   165D
VARIABLE AREA SIZE = 0004H   4D
MAXIMUM STACK SIZE = 000AH   10D
91 LINES READ

```

0 PROGRAM ERROR(S) IN PROGRAM UNIT DEUGCI

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-11 FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT DEBUGO
OBJECT MODULE PLACED IN :F1:VCSDBG.OBJ
COMPILER INVOKED BY: FORT90 :F1:VCSDBG.FOR

```

1      SUBROUTINE DEBUGO
      C
      C DEBUGO OUTPUTS DEBUG INFORMATION TO CONTROL/DISPLAY PANEL
      C
      C INPUTS:  DEBUG CONTROL VECTOR
      C OUTPUTS:  DEBUG MESSAGES
      C CALLS:  OUTDSP, CLOCK
      C DESTROYS:  NOTHING
      C MODIFIES:  NOTHING
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      CHARACTER*1 DSPCCO(10)
4      CHARACTER*4 DOBC, DOBN
5      CHARACTER*4 ERRMES(20), DEGMES(20), RUNMES(20)
      C
6      INTEGER*1 CIB(80), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), VOB(2)
      C
7      COMMON/COMBUF/ CIB, KIB, DOB, TOB, PIB, POB, VOB
      C
8      COMMON/NESTAB/ ERRMES, DEGMES, RUNMES, DSPCCO
      C
9      SAVE /COMBUF/, /NESTAB/
      C
10     EQUIVALENCE (DOB(1), DOBC), (DOBN, DOB(5))
      C
      C*****
      C
      C LOAD DOB WITH PROMPT
      C
11     DOBC=DEGMES(1)
12     DOBN=RUNMES(6)
      C @DBG-OK*
      C
      C DISPLAY MESSAGE
      C
13     CALL OUTDSP
      C
      C USE TIME OUT FEATURE
14     CALL CLOCK
      C
15     RETURN
16     END

```

MODULE INFORMATION:

CODE AREA SIZE = 0020H 45D
VARIABLE AREA SIZE = 0000H 0D

FORTRAN COMPILER

**ORIGINAL PAGE IS
OF POOR QUALITY**

MAXIMUM STACK SIZE = 000AH 100
44 LINES READ

0 PROGRAM ERRORS IN PROGRAM UNIT DEUGCO

ORIGINAL PAGE IS
OF POOR QUALITY.

ISIS-II FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT DEBUGOT
OBJECT MODULE PLACED IN :F1:VCSDBG.OBJ
COMPILER INVOKED BY: FORT90 :F1:VCSDBG.FOR

```

1      SUBROUTINE DEBUGOT
      C
      C DEBUGOT OUTPUTS DEBUG CONTROL INFORMATION TO FRONT AND REAR DRUMS
      C
      C INPUTS: DEBUG CONTROL INFORMATION
      C OUTPUTS: DRUM CONTROL SIGNALS
      C CALLS: OUTDSP, INPCDU, CNTOUT
      C DESTROYS: NOTHING
      C MODIFIES: NOTHING
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*4 CIB(80), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), VOB(2)
      C
4      CHARACTER*1 DSPCOD(10), DOB4
5      CHARACTER*4 DOBC, DOBH
6      CHARACTER*4 ERRMES(20), DBGMES(20), RUNMES(20)
      C
7      LOGICAL*4 NEXT, ADJUST, RESET, AUTO, MANUAL, PARFAL, RUN, CALERT
8      LOGICAL*4 IOFVEC, IOFVOT
9      LOGICAL*4 CNTVEC(16), CNMFRT, CNMFER, CNMOUT, SAVVEC(40)
      C
10     COMMON/IOFVEC/IOFVEC(20)
      C
11     COMMON/NESTAB/ERRMES, DBGMES, RUNMES, DSPCOD
      C
12     COMMON/CPANEL/NEXT, ADJUST, RESET, AUTO, MANUAL, PARFAL, RUN, CALERT
      C
13     COMMON/COMBUF/CIB, KIB, DOB, TOB, PIB, POB, VOB
      C
14     COMMON/OPPARM/NDUN(17), NMXCNM, MDUM(11)
      C
15     COMMON/CNTVEC/CNTVEC
      C
16     COMMON/SAVER/SAVVEC
      C
17     SAVE /IOFVEC/, /SAVER/
18     SAVE /NESTAB/, /COMBUF/, /CNTVEC/, /OPPARM/, /CPANEL/
      C
19     EQUIVALENCE (IOFVOT, IOFVEC(12))
20     EQUIVALENCE (CNTVEC(8), CNMFRT), (CNTVEC(9), CNMFER), (CNTVEC(10), CNMOUT)
21     EQUIVALENCE (DOB(1), DOBC), (DOBH, DOB(5)), (DOB(4), DOB4)
      C
      C *****
      C
      C SAVE CONTROL MASK VECTOR AND FORCE ELEMENTS
      C
22     DO 100 I=1, NMXCNM
23     SAVVEC(I)=CNTVEC(I)
24     CNTVEC(I)= .TRUE.

```

ORIGINAL PAGE IS
OF POOR QUALITY

```

25 100 CONTINUE
    C
26     SAVVEC/(NINX(NM)+1)=ICFVOT
27     ICFVOT= TRUE.
    C
    C LOAD DISPLAY WITH PROMPT
    C
28 150 CONTINUE
29     DOBC=DBGMES(2)
30     DOB4=DSPCOD(9)
31     DOBN=ERRMES(12)
    C OUT=#V0!
    C
    C DISPLAY MESSAGE
    C
32     CALL OUTDSP
    C
    C WAIT FOR OPERATOR RESPONSE
    C
    C ADJUST = UP
    C NEXT = DOWN
    C RESET = STOP
    C
33     CALL INPCDU
34     IF(ADJUST) THEN
35         VOB(1)=1
36         VOB(2)=1
    C UP
37     DOBN=DBGMES(15)
38     ELSE
39     IF(NEXT) THEN
40         VOB(1)=-1
41         VOB(2)=-1
    C DOWN
42     DOBN=DBGMES(16)
43     ELSE
44         VOB(1)=0
45         VOB(2)=0
46     DOBN=DBGMES(11)
    C END
47     END IF
48     END IF
    C
    C
    C OUTPUT VALVE CONTROL SIGNALS
    C
49     CALL CNTOUT
    C
    C WAIT FOR OPERATOR RESPONSE
    C CALL OUTDSP
    C
    C OUT?END? OUT? UP OUT?DOWN
51     CALL INPCDU
    C
    C RESET VOB TO ZERO
    C
52     VOB(1)=0

```

```

53      VOB(2)=0
      C
      C OUTPUT VOB SIGNAL
      C
54      CALL CNTOUT
      C
55      IF (ADJUST) GO TO 150
      C
      C RESTORE CONTROL MASK VECTOR
      C
56      DO 200 I=L,NMXCNM
57      CNTVEC(I)=SAVVEC(I)
58      200 CONTINUE
59      IOFYOT=SAVVEC(NMXCNM+1)
      C
60      RETURN
61      END

```

ORIGINAL PAGE IS
OF POOR QUALITY

MODULE INFORMATION-

```

CODE AREA SIZE   = 0156H   342D
VARIABLE AREA SIZE = 0004H   4D
MAXIMUM STACK SIZE = 000AH   10D
125 LINES READ

```

0 PROGRAM ERROR(S) IN PROGRAM UNIT DEUGOT

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT DEBUGIN
OBJECT MODULE PLACED IN :F1:VCSDBG.OBJ
COMPILER INVOKED BY: FORT90 :F1:VCSDBG.FOR

```

1      SUBROUTINE DEBUGIN (FLAG)
      C
      C DEBUGIN READS SENSOR DATA VIA I/O ROUTINES AS PER INPUT
      C
      C INPUTS: SENSOR BUFFER, CONTROL VECTOR
      C OUTPUTS: NONE
      C CALLS: SENINP, PAUSE, OUTDSP, FORMAT, COMVRT, INPCDU
      C DESTROYS: NOTHING
      C MODIFIES: SENSOR INPUT DATA SIB, SDB
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*1 CBYTE
4      INTEGER*1 CIB(20), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), VOB(2)
      C
5      CHARACTER*1 DSEPCOD(10), DOB4
6      CHARACTER*4 DOBC, DOBB
7      CHARACTER*4 ERRMES(20), DEGMES(20), RUNMES(20)
      C
8      LOGICAL*1 NEXT, AUTO, RUN, RESET, ADJUST, MANUAL, PWRFFL, CALERT
9      LOGICAL*1 IOFVEC(20), SAVVEC(40)
      C
10     COMMON/CPANEL/NEXT, ADJUST, RESET, AUTO, MANUAL, PWRFFL, RUN, CALERT
      C
11     COMMON/SENBUF/SIB(10), SDB(10)
      C
12     COMMON/COMBUF/CIB, KIB, DOB, TOB, PIB, POB, VOB
      C
13     COMMON/IOFVEC/IOFVEC
      C
14     COMMON/OPARM/LDUM(10), NMKSEN, NDUM(5), NHXIOF, NDUM(12)
      C
15     COMMON/WORK/TEMP10, NDUM(3), ZDUM(16)
      C
16     COMMON/SAVER/SAVVEC
      C
17     COMMON/NESTAB/ERRMES, DEGMES, RUNMES, DSEPCOD
      C
18     SAVE /CPANEL/, /SAVER/, /OPARM/
19     SAVE /COMBUF/, /IOFVEC/, /NESTAB/, /WORK/, /SENBUF/
      C
20     EQUIVALENCE (DOB(5), DOBB), (DOB(4), DOB4)
21     EQUIVALENCE (DOB(1), DOBC), (DOB(5), DOBN)
      C
      C *****
      C
      C LOAD DOB WITH PROMPT FOR DISPLAY
      C
      C FLAG = 1 FOR DATA CONVERSION
22     IF (FLAG.NE.0) THEN

```

ORIGINAL PAGE IS
OF POOR QUALITY

```

22      DOB3=DOB3ES(4)
24      ELSE
25      DOB3=DOB3ES(3)
26      END IF
27      DOB8=RUNAMES(20)
29      DOB4=DEPCOD(9)
      C IMP= ##!
      C DISPLAY MESSAGE
      C
29      CALL OUTDSP
      C
      C WAIT FOR OPERATOR RESPONSE
      C
30      CALL PAUSE
      C
      C SAVE I/O MASK VECTOR AND SET TRUE
      C
31      DO 100 I=L,NMXIOF
32      SAVVEC(I)=IOFVEC(I)
33      IOFVEC(I)=.TRUE
34      100 CONTINUE
      C
      C CALL SENSOR INPUT ROUTINE
      C
35      150 CALL SENINP
      C
36      IF(FLAG.NE.0) CALL CONVRT
      C
      C DISPLAY VALUE READ IN FOR EACH I/O CHANNEL
      C
37      DO 200 I=L,NMXSEN
38      IF(FLAG.EQ.0) THEN
39      DOBN=SIB(I)
40      ELSE
41      DOBN=SDB(I)
42      END IF
43      DOB(3)=I+#30H
      C INX=ZZZZ
      C
      C FORMAT HEX VALUE INTO ASCII IN DOB
      C
44      CALL FORMAT(DOBN)
      C
45      CALL OUTDSP
      C
      C WAIT FOR OPERATOR RESPONSE
      C
46      CALL INPCDU
47      IF(RESET) GO TO 250
48      IF(ADJUST) GO TO 150
      C
49      200 CONTINUE
      C
      C RESTORE I/O MASK VECTOR
      C
50      250 DO 300 I=L,NMXIOF

```

FORTRAN COMPILER

```
51      IOFVEC(I)=SAWVEC(I)
52      200 CONTINUE
      C
53      RETURN
54      END
```

ORIGINAL PAGE IS
OF POOR QUALITY

MODULE INFORMATION:

```
CODE AREA SIZE   = 0162H   354D
VARIABLE AREA SIZE = 0007H    7D
MAXIMUM STACK SIZE = 000AH   10D
113 LINES READ
```

0 PROGRAM ERROR(S) IN PROGRAM UNIT DEUGIN

ISIS-II FORTPAN-80 V2.1 COMPILATION OF PROGRAM UNIT DEBUGCK
 OBJECT MODULE PLACED IN :F1:VCSDBG.OBJ
 COMPILER INVOKED BY: FORT80 :F1:VCSDBG.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE DEBUGCK
      C
      C DEBUGCK CHECKS THE CLOCK TIMER FOR VCS SYNCHRONIZATION
      C
      C INPUTS: NONE
      C OUTPUTS: NONE
      C CALLS: CLOCK, INTREN
      C DESTROYS: NOTHING
      C MODIFIES: DOB
      C VERSION 1.0
      L
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*4 TFLAG(6)
4      INTEGER*4 CIB(80), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), VOB(2)
      C
5      CHARACTER*4 DOBC, DOBN, ERRMES(20), DEGMES(20), RUNMES(20)
6      CHARACTER*1 DSPCOD(10)
      C
7      COMMON/COMBUF/CIB, KIB, DOB, TOB, PIB, POB, VOB
      C
8      COMMON/CLOCK/ TFLAG
      C
9      COMMON/MESTAB/ ERRMES, DEGMES, RUNMES, DSPCOD
      C
10     SAVE /COMBUF/, /MESTAB/, /CLOCK/
      C
11     EQUIVALENCE (DOB(1), DOBC), (DOB(5), DOBN)
      C
      C*****
      C
      C ENABLE CLOCK INTERRUPTS
      C
12     CALL INTREN
13     ISAV=IOFCAS
14     IOFCAS=0
15     DOBC=DEGMES(8)
16     DOBN=DEGMES(7)
      C CLK?I/O?
      C
17     CALL CLOCK
      C
18     IOFCAS=ISAV
      C
19     RETURN
20     END
    
```

MODULE INFORMATION:

FORTRAN COMPILER

ORIGINAL PAGE IS
OF POOR QUALITY

CODE AREA SIZE = 003FH 63D
VARIABLE AREA SIZE = 0004H 4D
MAXIMUM STACK SIZE = 000AH 10D
45 LINES READ

0 PROGRAM ERROR: IN PROGRAM UNIT DEUSCK

ISIS-II FORTPAN-90 V2.1 COMPILATION OF PROGRAM UNIT DEUGIO
 OBJECT MODULE PLACED IN F1:VCSDBG.OBJ
 COMPILER INVOKED BY: FORT90 F1:VCSDBG.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE DEUGIO
      C
      C DEUGIO READS AN I/O CHANNEL OR PORT AND DISPLAYS VALUE
      C
      C INPUTS: NONE
      C OUTPUTS: NONE
      C CALLS: OUTDSP, PAUSE, INPCIU, SENINP, FORMAT
      C DESTROYS: NOTHING
      C MODIFIES: DOB, TEMPIO
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*1 BITS(8)
4      INTEGER*1 CIB(80), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), VOB(2)
5      INTEGER*1 DSPCOD(10)
      C
6      LOGICAL*1 NEXT, ADJUST, RESET, AUTO, MANUAL, PWRFL, RUN, CALBRT
      C
7      CHARACTER*4 ERRMES(20), DBGMES(20), RUNMES(20), DOBC, DOBN
      C
8      COMMON/SENBUF/SIB(10), SDB(10)
      C
9      COMMON/CPANEL/NEXT, ADJUST, RESET, AUTO, MANUAL, PWRFL, RUN, CALBRT
      C
10     COMMON/WORK/ BITS, DUM(16)
      C
11     COMMON/COMBUF/ CIB, KIB, DOB, TOB, PIB, POB, VOB
      C
12     COMMON/NESTAB/ERRMES, DBGMES, RUNMES, DSPCOD
      C
13     SAVE /WORK/
14     SAVE /COMBUF/, /NESTAB/, /CPANEL/, /SENBUF/
      C
15     EQUIVALENCE (DOB(1), DOBC), (DOB(5), DOBN)
16     EQUIVALENCE (DOB(8), DOB(5))
      C
      C*****
      C
      C LOAD DOB WITH PROMPT
      C
17     DOBC=RUNMES(1)
18     DOBN=DBGMES(14)
      C ?I/OCHR!
      C
19     CALL OUTDSP
      C
20     CALL PAUSE
      C
21     NMXIOC=8
      C
    
```

```

22      GO 100 I=L NMX100
      C
      C LOAD DOB WITH PROMPTS
      C
23      DOBC=ERRMES(I+1)
24      DOB(1)=DEFDOB(E)
25      DOBN=RUNMES(20)
      C GXXX ##
      C
26      CALL OUTDSP
      C
27      CALL INPCDU
      C
      C TEST IF UPDATE
      C
      C IF EST EXIT
28      IF(RESET) GO TO 1000
      C TEST IF ADJ PRESSED
29      IF(ADJUST) THEN
      C
30      CALL SENINP
      C
31      TEMPIO=SIB(1)
      C
32      75 DOBX=TEMPIO
      C
      C FORMAT VALUE AND DISPLAY
33      CALL FORMAT(DOBX)
      C
34      CALL OUTDSP
      C
      C WAIT FOR OPERATOR
35      CALL INPCDU
      C
      C TEST IF NXT PRESSED CONTINUE LOOP
36      IF(NEXT) GO TO 100
      C
      C TEST IF RESET , EXIT
37      IF(RESET) GO TO 1000
      C ELSE ADJUST , READ AGAIN
38      GO TO 50
39      END IF
      C
40      100 CONTINUE
      C
      C ELSE NEXT, CONTINUE
41      1000 CONTINUE
42      RETURN
43      END

```

ORIGINAL PAGE IS
OF POOR QUALITY

MODULE INFORMATION:

CODE AREA SIZE	= 0007H	215D
VARIABLE AREA SIZE	= 0006H	20
MAXIMUM STACK SIZE	= 000AH	100

FORTRAN COMPILER

100 LINES READ

0 PROGRAM ERRORS IN PROGRAM UNIT DEBUG

ORIGINAL PAGE IS
OF POOR QUALITY

PAGE 15

ISIS-II FORTRAN-80 V2.1 COMPILATION OF PROGRAM UNIT DEUGTP
 OBJECT MODULE PLACED IN :F1:VCSDBG.OBJ
 COMPILER INVOKED BY: FORT80 :F1:VCSDBG.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE DEUGTP
      C
      C DEUGTP CHECKS OPERATION OF THE TAPE CASSETTE
      C
      C INPUTS: NONE
      C OUTPUTS: NONE
      C CALLS: AIOCRS, OUTDSP, MSEC2H, PAUSE
      C DESTROYS: NOTHING
      C MODIFIES: DOB, TOB
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*1 CIB(80), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), YOB(2)
4      INTEGER*1 CNTL(4)
      C
5      CHARACTER*1 DSPOOD(10)
6      CHARACTER*4 DOBC, DOBN, ERRMES(20), DGMES(20), RUNMES(20)
      C
7      COMMON/SENBUF/SIB(10), SDB(10)
      C
8      COMMON/COMBUF/CIB, KIB, DOB, TOB, PIB, POB, YOB
      C
9      COMMON/MESTAB/ ERRMES, DGMES, RUNMES, DSPOOD
      C
10     COMMON/WORK/ TEMP10, DUMMY(19)
      C
11     SAVE /MESTAB/, /COMBUF/, /WORK/
12     SAVE /SENBUF/
      C
13     EQUIVALENCE (DUMMY(1), CNTL(1))
14     EQUIVALENCE (DOB(1), DOBC), (DOB(5), DOBN)
      C
      C*****
      C
15     CNTL(2)=3
16     CNTL(1)=2
17     TEMP10=0
18     CALL AIOCRS(TEMP10)
19     CALL MSEC2H
20     IF (CNTL(2).NE.0) THEN
21     DOBC=ERRMES(15)
22     DOBN=RUNMES(15)
23     CALL OUTDSP
24     CALL PAUSE
25     END IF
26     RETURN
27     END
    
```

FORTRAN COMPILER

PAGE 17

ORIGINAL PAGE IS
OF POOR QUALITY

MODULE INFORMATION

CODE AREA SIZE = 0055H 850
VARIABLE AREA SIZE = 0000H 00
MAXIMUM STACK SIZE = 0000H 100
48 LINES REPO

0 PROGRAM ERROR(S) IN PROGRAM UNIT 06UGTP

IS15-11 FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT DEBUGME
 OBJECT MODULE PLACED IN :F1.VCSD60.OBJ
 COMPILER INVOKED BY: FORT90 :F1.VCSD60.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE DEBUGME
      C
      C DEBUGME DISPLAYS MEMORY TO THE OPERATOR VIA THE DISPLAY
      C
      C INPUTS: NONE
      C OUTPUTS: NONE
      C CALLS: OUTDSP, FORMAT, INPCDU, AGETIT, APUTIT, INPHEX
      C DESTROYS: NOTHING
      C MODIFIES: DOB, MEMORY
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*4 CIB(80), KIB(8), DOB(8), TOB(128), PIB(2), FOB(2), VOB(2)
4      INTEGER*4 BITS(8)
      C
5      LOGICAL*4 NEXT, ADJUST, RESET, AUTO, MANUAL, PWRPAL, PUN, CALERT
      C
6      CHARACTER*1 DSPCCO(10), DOB4
7      CHARACTER*4 DOBC, DOBN, ERRMES(20), DEGMES(20), RUNMES(20)
      C
8      COMMON/CPANEL/ NEXT, ADJUST, RESET, AUTO, MANUAL, PWRPAL, PUN, CALERT
      C
9      COMMON/COMBUF/ CIB, KIB, DOB, TOB, PIB, FOB, VOB
      C
10     COMMON/WORK/ TEMP10, DUMMY(19)
      C
11     COMMON/NESTAB/ ERRMES, DEGMES, RUNMES, DSPCCO
      C
12     SAVE /COMBUF/, /NESTAB/, /CPANEL/, /WORK/
      C
13     EQUIVALENCE (TEMP10, BITS(1))
14     EQUIVALENCE (DOB(1), DOBC), (DOB(5), DOBN)
15     EQUIVALENCE (DOB(5), DOBX), (DOB4, DOB(4))
16     EQUIVALENCE (DOB(2), DOBZ)
      C
      C*****
      C
      C LOAD DOB WITH MEMORY DUMP MESSAGE
      C
17     DOBC=DEGMES(9)
18     DOBN=DEGMES(10)
      C MEM?DUMP
      C
19     CALL OUTDSP
      C
20     CALL INPCDU
      C
      C LOAD DOB WITH MEMORY ADDRESS REQUEST
      C
21     100 DOBC=DEGMES(20)
    
```

ORIGINAL PAGE IS
OF POOR QUALITY

```

22      DOBN=FUNMES(20)
      C ADR? ##
      C
23      CALL OUTDSP
      C
      C INPUT HEX VALUE OF MEMORY BYTE TO DISPLAY
      C
24      CALL INPHEX
      C
      C SAVE TEMP10 ADDRESS FOR AUTO INCREMENT
25      TEMP10=DUMMY(1)
      C VALUE PASSED IN TEMP10+1 SLOT
26      200  ADRSAY=TEMP10
      C
      C CALL AGETIT TO RECOVER CONTENTS OF MEMORY REFERENCED IN TEMP10
27      210  CALL AGETIT(TEMP10,DOBX)
      C
      C DOBX WILL HAVE TWO CONSECUTIVE BYTES, FORMAT AND DISPLAY
      C
28      CALL FORMAT(DOBX)
29      DOB(8)=DOB(6)
30      DOB(7)=DOB(5)
31      DOB(6)=#3DH
32      DOBZ=TEMP10
33      CALL FORMAT(DOBZ)
      C
34      CALL OUTDSP
      C
      C INPUT CONTROL VALUE FOR AUTO INCREMENT OR END
35      CALL INPCDU
      C
      C IF AUTO INCREMENT RECOVER ADDRESS INC BY 1 AND LOOP
      C NXT KEY
36      IF(NEXT) THEN
37          TEMP10=ADRSAY+1
38          GO TO 200
39      END IF
      C
      C ADJUST PRESSED, GET NEW VALUE
40      IF(ADJUST) THEN
41          DOBC=DEGMES(20)
42          CALL INPHEX
      C DUMMY(1) = NEW BYTE
43          TEMP10=ADRSAY
44          CALL APUTIT(TEMP10)
45          GO TO 210
46      END IF
      C
      C ELSE RST , EXIT
47      RETURN
48      END

```

MODULE INFORMATION:

CODE AREA SIZE = 0004H 2120

VARIABLE AREA SIZE = 0002H 20
MAXIMUM STACK SIZE = 0000H 100
102 LINES READ

ORIGINAL PAGE IS
OF POOR QUALITY

0 PROGRAM ERROR(S) IN PROGRAM UNIT DEUSHE

0 TOTAL PROGRAM ERROR(S)
END OF FORTRAN COMPILATION

ISIS-II FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT PAUSE
 OBJECT MODULE PLACED IN F1:VCSIOU.OBJ
 COMPILER INVOKED BY FORT90 F1:VCSIOU.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE PAUSE
      C
      C PAUSE WAITS FOR THE USER TO PRESS ANY KEY ON THE INPUT C/D
      C
      C INPUTS: NONE
      C OUTPUTS: NONE
      C CALLS: INPCDU, OUTDSP
      C DESTROYS: NOTHING
      C MODIFIES: CPANEL
      C VERSION: 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*4 CIB(8), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), VOB(2)
4      INTEGER*4 BITS(8), DUMMY(32)
      C
5      LOGICAL*4 NEXT, ADJUST, RESET, AUTO, MANUAL, FUN, CALERT, FIREFL
      C
6      COMMON/CPANEL/ NEXT, ADJUST, RESET, AUTO, MANUAL, PRESSFL, FUN, CALERT
      C
7      COMMON/WORK/BITS, DUMMY
      C
8      COMMON/COMBUF/CIB, KIB, DOB, TOB, PIB, POB, VOB
      C
9      SAVE /COMBUF/, /CPANEL/, /WORK/
      C
      C*****
      C
      C XXXXXX!
10     DOB(8)=#21H
      C
11     CALL OUTDSP
      C
12     10 CONTINUE
      C
13     CALL INPCDU
      C
14     IF(RESET OR NEXT OR ADJUST) GO TO 500
      C
15     GO TO 10
16     500 CONTINUE
17     RETURN
18     END
    
```

MODULE INFORMATION:

CODE AREA SIZE	= 001FH	31D
VARIABLE AREA SIZE	= 0000H	0D
MAXIMUM STACK SIZE	= 0002H	2D

FORTRAN COMPILER

PAGE 2

43 LINES READ

0 PROGRAM ERROR(S) IN PROGRAM UNIT PHASE

ORIGINAL PAGE IS
OF POOR QUALITY

**ORIGINAL PAGE IS
OF POOR QUALITY**

ISIS-II FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT CLOCK
OBJECT MODULE PLACED IN :F1:YCSIOU.OBJ
COMPILER INVOKED BY: FORT90 :F1:YCSIOU.FOR

```

1      SUBROUTINE CLOCK
      C
      C CLOCK SYNCHRONIZES THE YCS TO THE TIMER UNIT
      C
      C INPUTS: NONE
      C OUTPUTS: NONE
      C CALLS: NOTHING
      C DESTROYS: NOTHING
      C MODIFIES: NOTHING
      C VERSION: 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*1 TFLAG(6)
      C
4      COMMON/CLOCK/TFLAG
      C
5      SAVE/CLOCK/
      C
      C*****
      C
6      I=0
      C TEST 1 SECOND FLAG BYTE FLAG FOR INTERRUPT PROCESS SYNC
7      100 IF(TFLAG(3).NE.0) GO TO 200
8      I=I+1
      C TIME OUT IF NO INTERRUPT
9      IF(I.GE.20000) GO TO 200
10     GO TO 100
11     200 CONTINUE
12     TFLAG(3)=0
      C
13     RETURN
14     END
    
```

MODULE INFORMATION:

```

CODE AREA SIZE      = 0015H    53D
VARIABLE AREA SIZE = 0062H    2D
MAXIMUM STACK SIZE = 0002H    2D
33 LINES READ
    
```

0 PROGRAM ERROR(S) IN PROGRAM UNIT CLOCK

ISIS-II FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT INPCDU
 OBJECT MODULE PLACED IN :F1:VCSIOU.OBJ
 COMPILER INVOKED BY: FORT90 :F1:VCSIOU.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE INPCDU
      C
      C INPCDU READS THE C/D PANEL AND RETURNS A LOGICAL ARRAY
      C
      C INPUTS: NONE
      C OUTPUTS: DATA IN /COMMON/
      C CALLS: AI0CCDU
      C DESTROYS: NOTHING
      C MODIFIES: CONTROL WORDS
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*1 BITS(8), DUMMY(22)
      C
4      LOGICAL*1 LBITS(8), NEXT, ADJUST, RESET, AUTO, MANUAL, RUN, CALRT, PWRFL
      C
5      COMMON/CPANEL/NEXT, ADJUST, RESET, AUTO, MANUAL, PWRFL, RUN, CALRT
      C
6      COMMON/WORK/BITS, DUMMY
      C
7      COMMON/OPSVEC/OPMODE, MODECT, ENGMASK, ARRAY(7)
      C
8      COMMON/ERRFLG/ ERROR(8)
      C
9      SAVE /WORK/, /OPSVEC/, /ERRFLG/, /CPANEL/
      C
10     EQUIVALENCE (LBITS(1), NEXT)
      C
      C*****
      C
      C BITS(1), NEXT, ACTIVE LOW, 0
      C BITS(2), ADJUST, ACTIVE LOW, 0
      C BITS(3), RUN/CAL RTN ACTIVE HIGH, 11111111B
      C           CAL ACTIVE LOW, 0
      C BITS(4), RESET, ACTIVE LOW, 0
      C BITS(5), AUTO, ACTIVE LOW, 0
      C BITS(6), MANUAL, ACTIVE HIGH, 11111111B
      C BITS(7), POWER FAIL, ACTIVE HIGH, 11111111B
      C
      C CLEAR WORK STORAGE AND READ C/D PANEL
      C
11     DO 100 I=1,8
12     BITS(I)=0
13     LBITS(I)=.FALSE.
14 100 CONTINUE *
      C
15     CALL AI0CCDU(BITS(1))
      C
      C TEST INPUTS AND RESET STATUS WORDS AS APPROPRIATE
      C

```

```

16     IF(BITS(1) EQ 0) THEN
17     C NEXT SWITCH PRESSED
18     NEXT= TRUE
19     END IF
20
21     C
22     IF(BITS(2) EQ 0) THEN
23     C ADJUST SWITCH PRESSED
24     ADJUST= TRUE
25     END IF
26
27     C
28     IF(BITS(3) EQ 0) THEN
29     C CALIBRATE MODE SWITCH SET
30     C IF IN RUN MODE NOW EXIT TO HALT
31     CALIBRY= TRUE
32     C IF IN AUTO OR MANUAL MODES
33     IF((OPMODE EQ 1). OR. (OPMODE EQ 4)) THEN
34     OPMODE=3
35     RETURN
36     END IF
37
38     C
39     END IF
40
41     C
42     IF(BITS(4) EQ 0) THEN
43     C RESET SWITCH PRESSED
44     RESET= TRUE
45     END IF
46
47     C
48     C IF RUN SWITCH ON
49     C
50     IF(BITS(3) NE 0) THEN
51     C
52     RUN= TRUE
53     IF(BITS(5) EQ 0) THEN
54     C AUTOMATIC MODE SWITCH PRESSED
55     AUTO= TRUE
56     OPMODE=1
57     C RESET TIME OUT ON CONTROL
58     ZERO=0
59     CALL AIOVOT(ZERO)
60     END IF
61
62     C
63     IF(BITS(6) NE 0) THEN
64     C MODE = MANUAL DISABLE SYSTEM
65     MANUAL= TRUE
66     OPMODE=4
67     END IF
68
69     C
70     END IF
71
72     C
73     IF(BITS(7) NE 0) THEN
74     C POWER FAILURE OR SHUT DOWN ON 39 VOLT CONTROL VOLTAGE
75     C HALT SYSTEM
76     PWRFAL= TRUE
77     OPMODE=0
78     ERROR(2)=1
79
80     C
81     END IF

```

ORIGINAL PAGE IS
OF POOR QUALITY

```
      C  
50     RETURN  
51     END
```

ORIGINAL PAGE IS
OF POOR QUALITY

MODULE INFORMATION:

```
CODE AREA SIZE      = 011CH    284D  
VARIABLE AREA SIZE = 0004H     4D  
MAXIMUM STACK SIZE = 0004H     4D  
111 LINES READ
```

0 PROGRAM ERROR(S) IN PROGRAM UNIT INPCDU

ISIS-II FORTAN-90 V2.1 COMPILATION OF PROGRAM UNIT INPHEX
 OBJECT MODULE PLACED IN :F1:VCS10U OBJ
 COMPILER INVOKED BY: FORT80 :F1:VCS10U.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE INPHEX
      C
      C INPHEX GETS A HEX NUMBER FROM THE C/D BY DYNAMIC PROMPTING
      C
      C INPUTS: NONE
      C OUTPUTS: HEX VALUE IN TEMP10
      C CALLS: A10C0U, OUTDSP, FORMAT
      C DESTROYS: NOTHING
      C MODIFIES: /WORK/, DOB
      C VERSION 1.0
      C
2      IMPLICIT INTEGER(2) (A-Z)
      C
3      INTEGER*4 WORK(8), XDUM(8)
4      INTEGER*4 CIB(80), TOB(128), PIB(2), POB(2), KIB(8), VOB(2)
      C
5      DIMENSION DNUM(4)
      C
6      CHARACTER*1 DOB(8)
      C
7      COMMON/WORK/TEMP10, DNUM, MAG, ICNT, ICOL, NUM, I, J, WORK, DUMMY(5)
      C
8      COMMON/COMBUF/CIB, KIB, DOB, TOB, PIB, POB, VOB
      C
9      SAVE /COMBUF/, /WORK/
      C
10     EQUIVALENCE (DOB(5), DOBX), (DOB(1), XDUM(1))
      C
      C *****
      C
      C INITIALIZE PARAMETERS AND CLEAR WORK AREA
      C
11     DO 100 I=1, 4
12     DNUM(I)=0
13     100 CONTINUE
      C
14     DOBX=0
15     MAG=1
16     NUM=0
17     ICOL=0
18     ICNT=0
19     GO TO 2150
      C
20     1000 CONTINUE
21     CALL A10C0U (WORK(1))
      C
      C TEST IF RESET (ENTER) KEY PRESSED
      C
22     IF(WORK(4) EQ 0) GO TO 3000
      C
      C TEST IF NEXT KEY PRESSED
    
```

ORIGINAL PAGE IS
OF POOR QUALITY

```

23     IF(WORK(1).EQ.0) THEN
24         DNUM=ICOL+1)*ICNT
25         ICOL=MOD(ICOL+L,4)
26         ICNT=0
27         MAG=16**ICOL
28         GO TO 2000
29     END IF

C
C TEST IF ADJUST KEY PRESSED
C
30     IF(WORK(2).EQ.0) THEN
31         ICNT=MOD(ICNT+L,16)
32         DNUM(ICOL+1)=ICNT
33         GO TO 2000
34     END IF

C
C BUILD VALUE FROM INPUTS
C
35 2000 DOBX=0
36         J=1
37         DO 2100 I=L,4
38             DOBX=DOBX+DNUM(I)*J
39             J=J*16
40 2100 CONTINUE
41 2150 CONTINUE

C
42     TEMP10=DOBX

C
43     CALL FORMAT(DOBX)

C
C # IN UNSET DIGITS
44     IF(ICOL.LT.3) THEN
45         J=3-ICOL
46         DO 2200 I=L,J
47             XDUM(I+4)=#23H
48 2200 CONTINUE
49     END IF
50     CALL OUTDSP

C
51     GO TO 1000

C
52 3000 CONTINUE
53     DNUM(1)=TEMP10
54     TEMP10=#FH

C
55     RETURN
56     END

```

MODULE INFORMATION:

```

CODE AREA SIZE      = 0170H   281D
VARIABLE AREA SIZE = 0002H    2D
MAXIMUM STACK SIZE = 0002H    2D
98 LINES READ

```


FORTRAN COMPILER

PAGE 9

0 PROGRAM ERROR(S) IN PROGRAM UNIT INPHX

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-11 FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT PROMPT
 OBJECT MODULE PLACED IN F1:VCS10U.OBJ
 COMPILER INVOKED BY: FORT90 F1:VCS10U.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE PROMPT
      C
      C PROMPT DISPLAYS A PROMPT IN LEDS AND INPUTS C/D
      C
      C INPUTS: NONE
      C OUTPUTS: NONE
      C CALLS: INPCDU, ATODSP
      C DESTROYS: NOTHING
      C MODIFIES: NOTHING
      C VERSION: 1.0
      C
2      INTEGER*4 CIB(80), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), YOB(2)
      C
3      COMMON/COMBUF/CIB, KIB, DOB, TOB, PIB, POB, YOB
      C
4      SAVE /COMBUF/
      C
      C*****
      C
5      CALL ATODSP(DOB(1))
      C
6      CALL INPCDU
      C
7      RETURN
8      END
    
```

MODULE INFORMATION:

CODE AREA SIZE = 000AH 100
 VARIABLE AREA SIZE = 0000H 00
 MAXIMUM STACK SIZE = 0002H 20
 25 LINES READ

0 PROGRAM ERROR(S) IN PROGRAM UNIT PROMPT

0 TOTAL PROGRAM ERROR(S)
 END OF FORTRAN COMPILATION

ISIS-II FORTRAN-S0 V2.1 COMPILATION OF PROGRAM UNIT CONFC
 OBJECT MODULE PLACED IN :F1:VCSOCH.OBJ
 COMPILER INVOKED BY: FORT80 :F1:VCSOCH.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE CONFC
      C
      C CONFC IS A TABLE DRIVEN ROUTINE WHICH IS USED TO CONVERT
      C   SENSOR DATA TO ENGINEERING UNITS AS A+B*X=Y
      C
      C INPUTS: SENSOR INDEX AND DATA
      C OUTPUTS: NONE
      C CALLS: RANGCK (OPTION)
      C DESTROYS: NOTHING
      C MODIFIES: TEMPIO
      C VERSION: 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      DIMENSION SENTAB(10,2), RCGDAT(10,2)
      C
4      COMMON/WORK/ TEMPIO, SINPNT, DUMMY(10)
      C
5      COMMON/CONTAB/SENTAB, RCGDAT
      C
6      COMMON/OPSEV/ OPMODE, MODECT, RANGSK, ARRAY(7)
      C
7      SAVE /CONTAB/, /OPSEV/, /WORK/
      C
      C*****
      C
      C CONVERT VALUE IN TEMPIO TO ENGINEERING UNITS Y = A+B*X
      C
8      TEMPIO=SENTAB(SINPNT,1)+TEMPIO*SENTAB(SINPNT,2)
      C
      C TEST IF RANGE CHECK NEEDED
      C
9      IF(RANGSK.NE.0) THEN
10     CALL RANGCK
11     END IF
      C
12     RETURN
13     END
    
```

MODULE INFORMATION:

CODE AREA SIZE = 003AH 58D
 VARIABLE AREA SIZE = 0000H 0D
 MAXIMUM STACK SIZE = 0004H 4D
 38 LINES READ

0 PROGRAM ERROR(S) IN PROGRAM UNIT CONFC

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-1: FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT RANGCK
OBJECT MODULE PLACED IN :F1:VCSOON.OBJ
COMPILER INVOKED BY: FORT90 :F1:VCSOON.FOR

```

1      SUBROUTINE RANGCK
      C
      C RANGCK TESTS CONVERTED SENSOR DATA AGAINST MAX AND MIN LIMITS
      C
      C INPUTS: INDEX POINTER, DATA
      C OUTPUTS: ERROR FLAG 1
      C CALLS: NOTHING
      C DESTROYS: NOTHING
      C MODIFIES: SDB
      C VERSION: 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      DIMENSION RGC DAT(10,2), SENTAB(10,2)
      C
4      COMMON/CONTAB/ SENTAB,RGC DAT
      C
5      COMMON/ERRFLG/ ERROR(S)
      C
6      COMMON/WORK/ TEMP10,SINPNT,DUMMY(18)
      C
7      SAVE /WORK/, /CONTAB/, /ERRFLG/
      C
      C*****
      C
      C TEST DATA AGAINST MAX AND PROCESS
      C
9      IF(TEMP10.GT.RGC DAT(SINPNT,2)) THEN
10     TEMP10=RGC DAT(SINPNT,2)
11     ERROR(1)=SINPNT
12     RETURN
      C
      C TEST DATA AGAINST MINIMUM AND PROCESS
      C
13     IF(TEMP10.LT.RGC DAT(SINPNT,1)) THEN
14     TEMP10=RGC DAT(SINPNT,1)
15     ERROR(1)=10+SINPNT
16     RETURN
17     END IF
      C
18     RETURN
19     END

```

MODULE INFORMATION:

CODE AREA SIZE = 0064H 1000
VARIABLE AREA SIZE = 0000H 00
MAXIMUM STACK SIZE = 0002H 20

FORTRAN COMPILER

PAGE 3

43 LINES READ

0 PROGRAM ERROR(S) IN PROGRAM UNIT RANGE

0 TOTAL PROGRAM ERROR(S)
END OF FORTRAN COMPILATION

**ORIGINAL PAGE IS
OF POOR QUALITY**

ORIGINAL PAGE 1
OF POOR QUALITY

ISIS-II FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT INPCID
OBJECT MODULE PLACED IN :F1:VCSINP.OBJ
COMPILER INVOKED BY: FORT83 :F1:VCSINP.FOR

```

1      SUBROUTINE INPCID
      C
      C INPCID INPUTS THE CID DATA VIA PORT 01, CONTROL VIA PORT 02
      C
      C INPUTS: NONE
      C OUTPUTS: CID DATA IN SIB
      C CALLS: @AIOCID
      C DESTROYS: NOTHING
      C MODIFIES: SIB
      C VERSION: 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      DIMENSION SIB(10), SDB(10)
      C
4      COMMON/SENBUF/ SIB, SDB
      C
5      COMMON/WORK/ TEMP10, SINPNT, DUMMY(10)
      C
6      SAVE /SENBUF/, /WORK/
      C
      C*****
      C
      C SET SINPNT TO CID VALUE
      C
7      SINPNT=6
      C
8      CALL AIOCID (TEMP10)
      C
9      SIB(SINPNT)=TEMP10
      C
10     RETURN
11     END

```

MODULE INFORMATION:

CODE AREA SIZE = 001EH 30D
VARIABLE AREA SIZE = 0000H 0D
MAXIMUM STACK SIZE = 0002H 2D
33 LINES READ

0 PROGRAM ERROR(S) IN PROGRAM UNIT INPCID

ISIS-II FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT INPPKS
 OBJECT MODULE PLACED IN :F1:VCSIMP.OBJ
 COMPILER INVOKED BY: FORT90 :F1:VCSIMP.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE INPPKS
      C
      C INPPKS INPUTS THE FRONT AND REAR PICK SIGNALS VIA PORTS 11,13/CNT 10,12
      C
      C INPUTS: NONE
      C OUTPUTS: PICK DATA IN SIB
      C CALLS: INPUT (FORTRAN ROUTINE)
      C DESTROYS: NOTHING
      C MODIFIES: SIB
      C VERSION: 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*1 I
      C
4      DIMENSION SIB(10),SDB(10)
      C
5      COMMON/SENBUF/ SIB,SDB
      C
6      COMMON/WORK/TEMP10,SIMPNT,DUMMY(10)
      C
7      SAVE /SENBUF/,/WORK/
      C
      C*****
      C
8      CALL INPUT(#10H,I)
      C INPUT PORT WITH 4 PICK BITS
      C
9      I=I.AND.#0FH
      C
10     SIB(7)=I.AND.#03H
      C
11     SIB(8)=I.AND.#0CH
      C
12     IF(SIB(7).GT.0) SIB(7)=1
      C
13     IF(SIB(8).GT.0) SIB(8)=1
      C
14     RETURN
15     END
    
```

MODULE INFORMATION:

CODE AREA SIZE = 0046H 72D
 VARIABLE AREA SIZE = 0001H 1D
 MAXIMUM STACK SIZE = 0002H 2D
 40 LINES READ

0 PROGRAM ERROR(S) IN PROGRAM UNIT INPPKS

FORTRAN COMPILER

PAGE 3

0 TOTAL PROGRAM ERRORS)
END OF FORTRAN COMPILATION

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT OUTCAS
 OBJECT MODULE PLACED IN :F1:VCSIOZ.GBJ
 COMPILER INVOKED BY: FORT60 :F1:VCSIOZ.FOR

ORIGINAL PAGE IS
 OF POOR QUALITY

```

1      SUBROUTINE OUTCAS
      C
      C OUTCAS OUTPUTS THE CASSETTE OUTPUT BUFFER TO THE DIGITAL CASSETTE
      C     VIA PORT 08,09,0A, CONTROL PORT 0B
      C
      C INPUTS: NONE
      C OUTPUTS: NONE
      C CALLS: AIOCAS
      C DESTROYS: NOTHING
      C MODIFIES: NOTHING
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*4 CIB(8), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), VOB(2)
4      INTEGER*4 DUMMY(2), IOFVEC(20), TFLAG(6), CASNRK(4)
      C
5      LOGICAL*4 IOFCAS
      C
6      COMMON/ERRFLG/ERROR(8)
      C
7      COMMON/COMBUF/ CIB, KIB, DOB, TOB, PIB, POB, VOB
      C
8      COMMON/IOFVEC/IOFVEC
      C
9      COMMON/OPSPNT/OPPNTS(8)
10     COMMON/CLOCK/TFLAG
11     DIMENSION CASDAT(10)
      C
12     EQUIVALENCE (CASNRK(1), TEMP10), (CASNRK(3), DUMMY(1))
13     EQUIVALENCE (CASNRK(4), DUMMY(2))
14     EQUIVALENCE (CASDAT(1), TOB(1))
15     EQUIVALENCE (IOFCAS, IOFVEC(15))
      C
16     SAVE /ERRFLG/, /OPSPNT/, /COMBUF/, /IOFVEC/, /CLOCK/
      C
      C *****
      C
      C FORMAT OF CASSETTE CONTROL BUFFER
      C TO AIOCAS IO DRIVER
      C
      C CASNRK(4) INTEGER*4
      C TEMP10, DUMMY(1), DUMMY(2)
      C DATA CNTL ERROR
      C WORD BYTE BYTE
      C
      C CONTROL =1 WRITE; =2 FAST FORWARD
      C
      C ERROR => 0K ; =1 SEOT
    
```

ORIGINAL PAGE IS
OF POOR QUALITY

```

C
C OPPTS(2) = POINTER TO ENTPV
C OPPTS(3) = NUMBER OF WORDS IN BLOCK
C
C *****
C
17      TFLAG(2)=0
19      IF(10FCAS) THEN
C TEST IF END OF BLOCK 64 WORDS
19      IF(OPPTS(3) GE 64) GO TO 100
C TEST IF DATA LEFT IN BUFFER
C IF 0 DONE SKIP ELSE WRITE DATA
20      IF(OPPTS(2) GT 0) THEN
C
21      DUMMY(1)=1
22      DUMMY(2)=0
23      TEMP10=CASDAT(OPPTS(2))
C
C CALL CASSETTE IO DRIVER ROUTINE
24      CALL AIOCAS(TEMP10)
C
C TEST IF ERROR CONDITION RETURNED BY AIOCAS
25      IF(DUMMY(2) NE 0) ERROR(5)=DUMMY(2)
26      OPPTS(2)=OPPTS(2)-1
27      OPPTS(3)=OPPTS(3)+1
C
29      END IF
C END SECOND IF , (OPPTS)
29      END IF
C END FIRST IF , (10FCAS)
30      RETURN
C
C RESET POINTER FOR DATA BUFFER; WAIT ONE 100MSEC INTERRUPT
31 100  OPPTS(3)=0
32      RETURN
33      END

```

MODULE INFORMATION:

```

CODE AREA SIZE   = 0074H   116D
VARIABLE AREA SIZE = 0004H    4D
MAXIMUM STACK SIZE = 0002H    2D
87 LINES READ

```

0 PROGRAM ERROR(S) IN PROGRAM UNIT OUTCAS

ISIS-II FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT OUTDSP
 OBJECT MODULE PLACED IN :F1:VCSIOZ.OBJ
 COMPILER INVOKED BY: FORT90 :F1:VCSIOZ.FOR

```

1      SUBROUTINE OUTDSP
      C
      C OUTDSP OUTPUTS THE DISPLAY BUFFER TO THE LED DISPLAY UNIT
      C
      C INPUTS: NONE
      C OUTPUTS: NONE
      C CALLS: AICDSP
      C DESTROYS: NOTHING
      C MODIFIES: NOTHING
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*1 CIB(80), KIB(8), DOB(9), TOB(129), PIB(2), POB(2), YOB(2)
      C
4      COMMON/COMBUF/ CIB, KIB, DOB, TOB, PIB, POB, YOB
      C
5      SAVE /COMBUF/
      C
      C*****
      C
6      CALL AICDSP(DOB(1))
      C
7      RETURN
8      END

```

MODULE INFORMATION:

```

CODE AREA SIZE   = 0007H    7D
VARIABLE AREA SIZE = 0000H    0D
MAXIMUM STACK SIZE = 0002H    2D
25 LINES READ

```

0 PROGRAM ERROR(S) IN PROGRAM UNIT OUTDSP

ISIS-II FORTRAN-90 V2.1 COMPILATION OF PROGRAM UNIT SAVDAT
 OBJECT MODULE PLACED IN :F1:VCS10Z.OBJ
 COMPILER INVOKED BY: FORT90 :F1:VCS10Z.FOR

```

1      SUBROUTINE SAVDAT
      C
      C SAVDAT LOADS DATA TO BE STORED ON CASSETTE INTO BUFFER
      C AND SETS UP POINTERS
      C
      C INPUTS: NONE
      C OUTPUTS: TAPE OUTPUT BUFFER AND POINTERS
      C CALLS: NOTHING
      C DESTROYS: NOTHING
      C MODIFIES: TOB, POINTERS
      C VERSION 1.0
      C
2      IMPLICIT INTEGER*2 (A-Z)
      C
3      INTEGER*4 CIB(80), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), VOB(2)
4      INTEGER*4 TFLAG(6)
      C
5      COMMON/CLOCK/TFLAG
      C
6      COMMON/COMBUF/ CIB, KIB, DOB, TOB, PIB, POB, VOB
      C
7      COMMON/SENBUF/ SIB(10), SDB(10)
      C
8      COMMON/OPSPNT/OPSPNT(8)
      C
9      COMMON/PARAMS/PARMS(20)
      C
10     COMMON/OPSEVC/OPHODE, MODECT, ODUN(8)
      C
11     DIMENSION CASDAT(10)
      C
12     EQUIVALENCE (CASDAT(1), TOB(1)), (PARMS(17), SDB(7))
      C
13     SAVE /OPSPNT/, /PARAMS/, /OPSEVC/
14     SAVE /COMBUF/, /SENBUF/, /OPSPNT/, /SENMEM/, /CLOCK/
      C
      C*****
      C
15     IF(OPSPNT(2).NE.0) GO TO 1000
      C
      C LOAD SENSOR DATA (5 WORDS) INTO BUFFER
16     DO 100 I=2,5
17     CASDAT(I)=SDB(I-1)
18     CONTINUE
      C
      C FORM = 111111XXYY111111 FOR MARKING RECORD
19     CASDAT(1)=#0FC3FH
      C CLEAR CASDAT(1) AND PACK 4 NUMBERS (NIBBLES) INTO IT
      C
20     IF(VOB(2).NE.0) CASDAT(1)=CASDAT(1).OR.#0040H
      C

```

ORIGINAL PAGE IS
OF POOR QUALITY

```

21      IF(V08(1).NE.0) CASDAT(1)=CASDAT(1).CF.#0000H
      C
22      IF(SDB(3).NE.0) CASDAT(1)=CASDAT(1).CF.#0100H
      C
23      IF(SDB(7).NE.0) CASDAT(1)=CASDAT(1).CF.#0200H
      C
      C FORM = 111100XXYY001111 FOR MARKING RECORD
24      IF(OPMODE EQ.1) THEN
25          TEMPX=#0200H
26      ELSE
27          TEMPX=#0100H
28      END IF
      C
29      IF(MODECT.EQ.1) THEN
30          TEMPY=#0000H
31      ELSE
32          TEMPY=#0040H
33      END IF
      C
34      CASDAT(7)=#0F00FH+TEMPX+TEMPY
      C
35      TFLAG(2)=0
      C
      C SET COUNTER FOR DATA WORDS TO WRITE
36      OPPTS(2)=7
      C
37      1000 CONTINUE
      C
38      RETURN
39      END

```

MODULE INFORMATION:

```

CODE AREA SIZE   = 0102H   2500
VARIABLE AREA SIZE = 0006H    60
MAXIMUM STACK SIZE = 0002H    20
31 LINES READ

```

0 PROGRAM ERROR(S) IN PROGRAM UNIT SAYCAT

0 TOTAL PROGRAM ERROR(S)
END OF FORTRAN COMPILATION

1515-11 FORTSAP-90 V2.1 COMPILATION OF PROGRAM UNIT TAPITZ
OBJECT MODULE PLACED IN :F1:VCSYAP OBJ
COMPILER INVOKED BY: FORT90 :F1:VCSYAP FOP

```

1      SUBROUTINE TAPITZ
      C
      C TAPITZ WRITES THE TAPE HEADER
      C
2      $INCLUDE(:F1:VCSYEM.FOR)
      C *****
      C
      C VCS SYSTEM MEMORY ALLOCATION
      C
3      =      IMPLICIT INTEGER*2(A-Z)
4      =      INTEGER*1  CIB, KIB, COB, TOB, PIB, POB, YOB
5      =      INTEGER*1  PKFBUF, PKRBUF, PKFSAV, PKPSAV
6      =      INTEGER*1  NMXIPX(6), TFLAG(6)
7      =      INTEGER*1  ERRBUF(8,10)
      C
8      =      LOGICAL*1  IOFVEC(20), CNTVEC(16), SINT(8), SMSG(8), DEGM(8)
9      =      LOGICAL*1  DEFIOV(20), DEFCTV(16)
10     =      LOGICAL*1  NEXT, ADJUST, RESET, RUN, CALRT, PHRFAL, AUTO, MANUAL
      C
11     =      CHARACTER*4  PARMES, MOSHES(10)
12     =      CHARACTER*1  DSPCOD(10)
13     =      CHARACTER*4  DOBC, DOEN, OPSMES(10)
14     =      CHARACTER*4  ERRMES(20), DEGMES(20), RUNMES(20)
      C
15     =      DIMENSION  DEFPRN(20), DEFPNT(8)
      C
      C COMMON BLOCK ALLOCATIONS
      C
16     =      COMMON/CPANEL/NEXT, ADJUST, RESET, AUTO, MANUAL, PHRFAL, RUN, CALRT
      C
17     =      COMMON/MESTB2/ PARMES(20)
      C
18     =      COMMON/MESTB3/ OPSMES
      C
19     =      COMMON/MOSHES/MOSHES
      C
20     =      COMMON/SENPNT/SENPTR(16)
      C
21     =      COMMON/PIKBUF/PKF2UF(10), PKRBUF(10), PKFSAV, PKPSAV
      C
22     =      COMMON/CLOCK/TFLAG
      C
23     =      COMMON/DEBUG/DEGM
      C
24     =      COMMON/SENDEL/LCDEL(40), PCDEL(60), FDRDEL(400)
      C
25     =      COMMON/IOFVEC/IOFVEC
      C
26     =      COMMON/CNTVEC/CNTVEC
      C
27     =      COMMON/OPSVEC/OPSVEC(10)

```

ORIGINAL PAGE IS
OF POOR QUALITY

```

= C
29 = C COMMON/OPPARM/ICNFNT(10), NMAX(16), NMXIPX
= C
29 = C COMMON/SENMEM/LSTPAS(3000), DSCNTL(16)
= C
30 = C COMMON/OPSPNT/OPSPNTS(8)
= C
31 = C COMMON/WORK/TEMP10, DUMMY(19)
= C
32 = C COMMON/SAVER/SAVE(20)
= C
33 = C COMMON/PARAMS/ PARAM(20)
= C
34 = C COMMON/ERRBUF/ERRBUF
= C
35 = C COMMON/ERRFLG/ ERROR(8)
= C
36 = C COMMON/COMBUF/CIB(80), KIB(8), DOB(8), TOB(128), PIB(2), POB(2), YOB(2)
= C
37 = C COMMON/SENBUF/SIB(10), SOB(10)
= C
38 = C COMMON/CONTAB/SENTAB(10, 2), RECDAT(10, 2)
= C
39 = C COMMON/MESTAB/ERRMES, DBGMES, RUNMES, DSPCCO
= C
40 = C COMMON/DEFAULT/ DEFIOY, DEFPRM, DEFCTV, DEFINT
= C
41 = C COMMON/DEFTAB/ DEFRNG(10, 2), DEFCON(10, 2)
= C
42 = C COMMON/DEFOPS/DEFOPS(10)
= C
43 = C COMMON/DEFMOS/DEFMOS(16)
= C
44 = C SAVE /CPANEL/, /PIKBUF/, /SAVER/, /ERRBUF/, /SENDEL/
45 = C SAVE /DEBUG/, /IOFVEC/, /CNTVEC/, /OPSVEC/
46 = C SAVE /OPPARM/, /SENMEM/, /OPSPNT/, /CLOCK/, /WORK/, /DEFTAB/
47 = C SAVE /PARAMS/, /ERRFLG/, /COMBUF/, /SENBUF/, /CONTAB/, /MESTAB/, /DEFAULT/
48 = C SAVE /SENPT/, /MESTB2/, /MESTB3/, /DEFOPS/
49 = C SAVE /DEFMOS/
= C
50 = C EQUIVALENCE (DOB(1), DOBC), (DOB(5), DOBN)
51 = C EQUIVALENCE (OPSVEC(1), OPMODE), (OPSVEC(2), MODECT), (OPSVEC(3), FNGMEN)
52 = C EQUIVALENCE (OPSVEC(4), OPSENR), (OPSVEC(5), RATECK)
53 = C EQUIVALENCE (OPSVEC(6), STATUS), (TIME, TFLAG(4))
= C
C
54 = C INTEGER*4 CNTL(4)
C
55 = C DIMENSION CASHRK(8)
C
56 = C EQUIVALENCE(CNTVEC(1), CASHRK(1))
57 = C EQUIVALENCE (CNTL(1), DUMMY(1))
C
C*****
C
C IF CASSETTE ON, WRITE HEADER FILE
C

```

ORIGINAL PAGE IS
OF POOR QUALITY

```

59      DOBN=DOBNES(19)
59      CALL OUTDSP
      C WRITE FILE GAP TO START
60      CRLF=#0ACDH
61      CNTL(2)=0
62      CNTL(1)=1
      C WRITE A CARRIAGE RETURN LINE FEED
63      TEMP10=CRLF
64      CALL AIOCRS(TEMP10)
65      CALL MSEC2H
      C
      C WRITE F6C5H PATTERN
66      TEMP10=#0F6C5H
67      DO 1800 I=1,20
68      CALL AIOCRS(TEMP10)
69      CALL MSEC2H
70      1800 CONTINUE
      C
71      TEMP10=CRLF
72      CALL AIOCRS(TEMP10)
73      CALL MSEC2H
      C
      C WRITE 29 WORDS THEN CRLF
74      DO 2000 I=1,20
75      TEMP10=PARAM(I)
76      CALL AIOCRS(TEMP10)
77      CALL MSEC2H
78      2000 CONTINUE
      C
79      TEMP10=CRLF
80      CALL AIOCRS(TEMP10)
81      CALL MSEC2H
      C WRITE OPERATION PARAMS
82      DO 1900 I=1,10
83      TEMP10=#0FSVEC(I)
84      CALL AIOCRS(TEMP10)
85      CALL MSEC2H
86      1900 CONTINUE
      C
87      DO 1950 I=1,10
88      TEMP10=CASHK(I)
89      CALL AIOCRS(TEMP10)
90      CALL MSEC2H
91      1950 CONTINUE
      C
92      TEMP10=CRLF
93      CALL AIOCRS(TEMP10)
94      CALL MSEC2H
      C
95      RETURN
96      END

```

MODULE INFORMATION:

CODE AREA SIZE = 012AH 2980

FORTRAN COMPILER

ORIGINAL PAGE IS
OF POOR QUALITY

PAGE 4

VARIABLE AREA SIZE = 0014H 200
MAXIMUM STACK SIZE = 000AH 100
159 LINES READ

0 PROGRAM ERROR(S) IN PROGRAM UNIT TAPITZ

0 TOTAL PROGRAM ERROR(S)
END OF FORTRAN COMPILATION

LOC	ORG	LINE	SOURCE STATEMENT
		1 ;	
		2	NAME VCSUTL
		3 ;	
		4	PUBLIC FORMAT, A100SP, APUTIT
		5 ;	
		6	EXTRN HEXASC, OUTPT
		7 ;	
		8	CSEG
		9 ;	
		10 ;	*****
		11 ;	
		12 ;	SUBROUTINE A100SP
		13 ;	
		14 ;	A100SP IS THE DISPLAY DRIVER INTERFACE FOR THE VCS
		15 ;	
		16 ;	
		17 ;	INPUTS: ADDRESS OF DOB(1) IN BC PAIR
		18 ;	OUTPUTS: NONE
		19 ;	CALLS: MONITR:OUTPT
		20 ;	DESTROYS: F/F'S
		21 ;	MODIFIES: NOTHING
		22 ;	VERSION 1 0
		23 ;	
		24	A100SP:
0000	C5	25	PUSH B ; GET BC ONTO STACK
0001	E1	26	POP H ; POP IT INTO HL PAIR FOR MEMORY REFERENCE
0002	0E08	27	MVI C,08H ; SET CHARACTER COUNT OF 8 IN C
0004	CD0000	E 28	CALL OUTPT ; CALL DISPLAY DRIVER IN MONITOR
0007	C1	29	POP B ; RECOVER BC PAIR
0008	C9	30	RET ; RETURN TO FORTRAN CALLING ROUTINE
		31 ;	
		32 ;	*****
		33 ;	
		34 ;	SUBROUTINE FORMAT
		35 ;	
		36 ;	FORMAT TURNS 2 HEX BYTES IN DOB(5,6) INTO ASCII IN DOB(5,6,7,8)
		37 ;	
		38 ;	INPUTS: ADDRESS OF DOB(5) IN BC PAIR
		39 ;	OUTPUTS: ASCII CODE IN DOB(5,6,7,8)
		40 ;	CALLS: MONITR:HEXASC
		41 ;	DESTROYS: A, F/F'S, H, L
		42 ;	MODIFIES: NOTHING
		43 ;	VERSION: 1 0
		44 ;	
		45	FORMAT:
0009	C5	46	PUSH B ; PUSH BC ONTO STACK
000A	E1	47	POP H ; POP ADDRESS INTO HL PAIR
000B	23	48	INX H ; SET HL TO POINT TO DOB(8)
000C	23	49	INX H
000D	23	50	INX H
000E	C5	51	PUSH B ; SAVE BC ADDRESS OF DOB(5) ONTO STACK
000F	CD1900	C 52	CALL FORM05 ; CALL DECODING ROUTINE
0012	C1	53	POP B ; GET BACK POINTER TO DOB(5)
0013	03	54	INX B ; SET BC TO SECOND BYTE

```

LOC OBJ      LINE      SOURCE STATEMENT
0014 2B      55 DCX H ; MOVE HL -1 TO DOB(E)
0015 CD1900  C      56 CALL FORM05 ; CALL DECODING ROUTINE
0018 C9      57 RET ; RETURN TO FORTRAN
                    58 ;
                    59 FORM05:
0019 0A      60 LDAX B ; GET # (BC)
001A 57      61 MOV D,A ; SAVE IN D
001B EF0F    62 ANI 0FH ; KEEP LOWER NIBBLE
001D CD0000  E      63 CALL HEXASC ; CALL MONITOR HEX TO ASCII
0020 77      64 MOV M,A ; STORE ASCII INTO DOB
0021 2B      65 DCX H ; MOVE HL -1 IN DOB
0022 7A      66 MOV A,D ; GET FROM D
0023 0F      67 RRC
0024 0F      68 RRC ; KEEP UPPER NIBBLE
0025 0F      69 RRC
0026 0F      70 RRC
0027 CD0000  E      71 CALL HEXASC ; CALL MONITOR HEX TO ASCII ROUTINE
002A 77      72 MOV M,A ; STORE ASCII (HL)
002B C9      73 RET ; RETURN TO FORMAT CALL
                    74 ;
                    75 ;*****
                    76 ;
                    77 ; SUBROUTINE APUTIT
                    78 ;
                    79 ; APUTIT PUTS A BYTE INTO MEMORY FROM FORTRAN (POKE)
                    80 ;
                    81 ; INPUTS: BC -> TEMP0=ADDR, BYTE
                    82 ; OUTPUTS: NONE
                    83 ; CALLS: NOTHING
                    84 ; DESTROYS: A,F/F'S,BC
                    85 ; MODIFIES: MEMORY AT ADDR
                    86 ; VERSION: 1.0
                    87 ;
                    88 APUTIT:
002C 0A      89 LDAX B ; GET ADDR LSB
002D 0F      90 MOV L,A
002E 03      91 INX B ; POINT TO MSB
002F 0A      92 LDAX B ; GET MSB
0030 67      93 MOV H,A
                    94 ; HL -> MEMORY PATCH ADDR
0031 03      95 INX B ; BC -> BYTE
0032 0A      96 LDAX B ; ACC = BYTE
0033 77      97 MOV M,A ; SET BYTE IN RAM
0034 C9      98 RET
                    99 ;
                   100 END

```

PUBLIC SYMBOLS
RIODSP C 0000 APUTIT C 002C FORMAT C 0009

EXTERNAL SYMBOLS
HEXASC E 0000 OUTPT E 0000

USER SYMBOLS

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-11 9000/9005 MACRO ASSEMBLER V3.0 YCSUTL PAGE 2

ATCDSP C 0000 AFUTIT C 0020 FORM05 C 0019 FORMAT C 0009 HEXASC E 0000 OUTPT E 0000

ASSEMBLY COMPLETE. NO ERRORS

ORIGINAL PAGE IS
OF POOR QUALITY

LOC	OBJ	LINE	SOURCE STATEMENT
		1 ;	
		2	NAME AIOIOX
		3 ;	
		4	PUBLIC AIOCID, AIOVOT , AIOCAS
		5 ;	
		6	EXTRN MSEC2H
		7 ;	
		8	CSEG
		9 ;	
		10 ;	*****
		11 ;	
		12 ;	SUBROUTINE AIOCID
		13 ;	
		14 ;	AIOCID IS THE INPUT DRIVER FOR THE CID UNIT
		15 ;	
		16 ;	INPUTS: ADDRESS OF TEMP10 IN BC
		17 ;	OUTPUTS: CID DATA IN TEMP10
		18 ;	CALLS: NOTHING
		19 ;	DESTROYS: R, F/F'S
		20 ;	MODIFIES: TEMP10
		21 ;	VERSION 1.0
		22 ;	
		23	AIOCID:
		24 ;	GET ADDR BC - TEMP10
0000	69	25	MOV L, C
0001	68	26	MOV H, B
0002	0833	27	IN 033H ; LATCH COUNT
0004	0832	28	IN 032H ; RESET TO START COUNT
0005	0831	29	IN 031H ; INPUT MSB
0008	47	30	MOV B, A ; PUT MSB INTO B
0009	0830	31	IN 030H ; GET LSB
000B	4F	32	MOV C, A ; PUT INTO C
		33 ;	HL NOW POINTS TO TEMP10 FOR STORE
000C	71	34	MOV M, C ; PUT LSB AT TEMP10
000D	23	35	INC H ; HL=HL+1
000E	70	36	MOV M, B ; PUT MSB AT TEMP10 +1
		37 ;	
000F	09	38	RET ; RETURN TO FORTRAN
		39 ;	
		40 ;	*****
		41 ;	
		42 ;	SUBROUTINE AIOVOT
		43 ;	
		44 ;	AIOVOT IS THE VALVE DRIVER IO ROUTINE
		45 ;	
		46 ;	INPUTS: ADDRESS OF CBYTE IN BC
		47 ;	OUTPUTS: VALVE CONTROL BITS TO PORT 3, RESET+LEDS
		48 ;	CALLS: NOTHING
		49 ;	DESTROYS: R, F/F'S
		50 ;	MODIFIES: TEMP10
		51 ;	VERSION 1.0
		52 ;	
		53	AIOVOT:
0010	3E0F	54	NYI R, 0FH ; CLEAR ACC - OUTPUT = 00001111

LOC	OBJ	LINE	SOURCE STATEMENT
0012	D306	55	OUT 06 ; SEND TO CLEAR PORT BITS
0014	C5	56	PUSH B ; WASTE TIME
0015	C1	57	POP B
0016	3E2F	58	MVI A,02FH ; LOAD 1 BIT TO RESET LINE FOR ONE SHOT
0018	D306	59	OUT 06 ; SEND BIT TO UNIT - OUTPUT 00101111
001A	C5	60	PUSH B ; WASTE TIME
001B	C1	61	POP B
001C	3E0F	62	MVI A,0FH ; SEND 00001111
001E	D306	63	OUT 06
0020	C5	64	PUSH B ; WASTE TIME
0021	C1	65	POP B
0022	3E1F	66	MVI A,01FH ; LOAD TRIGGER BIT
0024	D306	67	OUT 06 ; SEND 00011111
0026	C5	68	PUSH B ; WASTE TIME
0027	C1	69	POP B
0029	3E0F	70	MVI A,0FH ; CLEAR BITS
002A	D306	71	OUT 06 ; SEND 00001111
		72 ;	
002C	0A	73	LDAX B ; GET CBYTE FOR OUTPUT
002D	E60F	74	ANI 0FH ; KEEP LOW NIBBLE
002F	D303	75	OUT 03 ; TRANSMITT TO VALVE DRIVER
		76 ;	
0031	C9	77	RET ; RETURN TO FORTRAN
		78 ;	
		79 ;*****	
		80 ;	
		81 ; SUBROUTINE AIOCAS	
		82 ;	
		83 ; AIOCAS IS THE CASSETTE OUTPUT DRIVER ROUTINE	
		84 ;	
		85 ; INPUTS: ADDRESS OF TEMP10 IN BC	
		86 ; OUTPUTS: DATA TO CASSETTE	
		87 ; CALLS: NOTHING	
		88 ; DESTROYS: A,F/F'S, B,C,D,E	
		89 ; MODIFIES: NOTHING	
		90 ; VERSION 1.0	
		91 ;	
		92 ; USE FROM FORTRAN CALL:	
		93 ;	
		94 ; CALL AIOCAS (TEMP10)	
		95 ;	
		96 ; TEMP10 = 16 BIT DATA WORD	
		97 ; TEMP10+1 = CONTROL FLAG BYTE	
		98 ; TEMP10+2 = ERROR FLAG BYTE	
		99 ;	
0000		100	CSCNTL EQU 0AH ; NULL CONTROL BYTE
0001		101	COK EQU 1H ; CASSETTE OK STATUS
0000		102	CBEOT EQU 0AH ; CASSETTE BEOT STATUS
0009		103	COUTH EQU 0AH ; MSB OUTPUT PORT
0000		104	COUTL EQU 02H ; LSB OUTPUT PORT
000B		105	CSTAT EQU 0AH ; STATUS PORT
000A		106	CCNTL EQU 0AH ; CONTROL PORT
0001		107	CWCNTL EQU 1H ; WRITE CONTROL BYTE
0002		108	CFCNTL EQU 2H ; FORWARD CONTROL BYTE
		109 ;	

LOC	OBJ	LINE	SOURCE STATEMENT
		110	; STATUS BYTE D2 = NOT BEOT, D1 - D7 SPARES
		111	RIOCAS:
		112	; BC POINTS TO TEMP10 ADDRESS
0032	0A	113	LDAX B ; GET LSB OF DATA
0033	5F	114	MOV E, A ; PUT IT IN E
0034	C5	115	PUSH B ; SAVE BC ON STACK
0035	03	116	INX B ; INCREMENT BC TO MSB
0036	0A	117	LDAX B ; GET MSB INTO ACC
0037	57	118	MOV D, A ; PUT IT IN D
		119	; DE HOLDS DATA (TEMP10)
0038	03	120	INX B ; POINT TO CONTROL BYTE
0039	0A	121	LDAX B ; GET CONTROL BYTE
003A	07	122	INX B ; POINT BC TO ERROR FLAG BYTE
		123	;
		124	; TEST INPUT CONTROL BYTE FOR FUNCTION
003B	FE01	125	CPI 01H ; TEST IF CONTROL = 1
003D	C9A00	C 126	JZ CWRITE ; IF EQUAL GO TO WRITE
0040	FE02	127	CPI 02H ; TEST IF CONTROL = 2
0042	C9CC00	C 128	JZ CFRWRD ; IF EQUAL GO TO FORWARD
0045	3E02	129	MVI A, 02H ; SET ERROR = 2 FOR ILLEGAL COMMAND
0047	C38900	C 130	JMP CEXIT ; UNDEFINED OPERATION , EXIT
		131	;
		132	CWRITE:
004A	D80B	133	IN CSTAT ; READ STATUS WORD
004C	E601	134	RNI 01H ; KILL ALL BUT BEOT BIT
004E	FE01	135	CPI COK ; TEST IF STATUS OK
0050	C29300	C 136	JNZ CERROR ; IF ERROR GO TO PROCESS
0053	7B	137	MOV A, E ; GET LSB INTO ACC
0054	D300	138	OUT COUTL ; SEND BYTE TO PORT
0056	7A	139	MOV A, D ; GET MSB INTO ACC
0057	D309	140	OUT COUTH ; OUTPUT BYTE TO PORT
0059	3E01	141	MVI A, CMCNTL ; GET WRITE CONTROL BYTE
005B	D30A	142	OUT CCNTL ; SEND TO CONTROL PORT
		143	; HOLD START PULSE FOR 10 USEC (MIN)
005D	3E05	144	MVI A, 05H ; SET COUNT IN ACC
005F	3D	145	CLOOP: DCR A ; DECREMENT COUNTER
0060	C25F00	C 146	JNZ CLOOP ; IF NOT ZERO LOOP
0063	3E00	147	MVI A, CSCNTL ; SEND NULL CODE TO CASSETTE
0065	D30A	148	OUT CCNTL ; SEND TO CONTROL PORT
0067	3E00	149	MVI A, 0 ; LOAD ZERO FOR ERROR FLAG
0069	C38900	C 150	JMP CEXIT
		151	;
		152	CFRWRD:
006C	D80B	153	IN CSTAT ; TEST STATUS
006E	E601	154	RNI 01H ; KEEP BEOT BIT
0070	FE00	155	CPI CBEOT ; TEST IF B OR E OF TAPE FLAG
0072	C99300	C 156	JZ CERROR ; IF BEOT LOW ERROR
0075	3E02	157	MVI A, CFCNTL ; LOAD FFRWD BYTE
0077	D30A	158	OUT CCNTL
0079	CD0000	E 159	CALL MSEC2H
007C	3E02	160	MVI A, 0
007E	D30A	161	OUT CCNTL
0080	C38900	C 162	JMP CEXIT
		163	;
474		164	CERROR:

ORIGINAL PAGE IS
OF POOR QUALITY

1515-II 0000-0095 MACRO ASSEMBLER, V3.0 A1010X PAGE 4

LOC	OBJ	LINE	SOURCE STATEMENT
0000	0E00	155	MVI A,CENTL ; STOP BYTE
0005	030A	166	OUT CNTL
0007	1E01	167	MVI A,01; SET ERROR FLAG E01
		168	CEXIT:
0009	02	169	STAX B ; STORE ERROR BYTE IN MEMORY LOCATION (BC)
000A	C1	170	POP B ; SET BC BACK AS IN CALL
000B	C9	171	RET ; RETURN TO FORTRAN
		172	;
		173	END

PUBLIC SYMBOLS

A10CAS C 0032 A10CID C 0000 A10VOT C 0010

EXTERNAL SYMBOLS

MSEC2H E 0000

USER SYMBOLS

A10CAS C 0032	A10CID C 0000	A10VOT C 0010	CE0T A 0000	CENTL A 000A	CEFR0R C 0003	CEXIT C 0009
CF0NTL A 0002	CF0NRD C 000C	CLDOP C 005F	C* K A 0001	COU* L A 0009	COU* I A 0009	CSCNTL A 0000
CSTAT A 000B	CKCNTL A 0001	CWRITE C 004A	MSEC2H E 0000			

ASSEMBLY COMPLETE. NO ERRORS

ORIGINAL PAGE IS
OF POOR QUALITY

LOC	OBJ	LINE	SOURCE STATEMENT
		1	;
		2	NAME VCS100
		3	;
		4	PUBLIC A10ITZ, A10ADC, AGETIT, A10CDU, CLKITZ, AQCITZ
		5	;
		6	EXTRN MSEC2H ; CALL TO MONITOR WAIT 200 M SEC
		7	;
		8	CSEG
		9	;
		10	*****
		11	;
		12	SUBROUTINE A10ADC (I, J)
		13	;
		14	A10ADC IS THE A/D CONVERTER I/O DRIVER ROUTINE
		15	;
		16	INPUTS: BC, DE ADDRESS POINTERS
		17	OUTPUTS: DATA IN (DE)
		18	CALLS: NOTHING
		19	DESTROYS: A, F, F'S
		20	MODIFIES: WORK
		21	VERSION: 1.0
		22	;
		23	A10ADC: ; (SIMPNT, TEMP10)
		24	;
		25	BC POINTS TO SIMPNT - CHANNEL #, DE POINTS TO STORAGE LOCATION
		25	;
0000	05	27	PUSH B ; SAVE BC ON STACK
0001	05	28	PUSH D ; SAVE DE ON STACK
0002	0A	29	LDAX B ; GET VALUE OF SIMPNT INTO A
0003	2D	30	DCR A ; SET POINTER -1 TO 0-7 FROM 1-0
0004	F3	31	DI ; DISABLE INTERRUPTS
0005	260A	32	MVI H, 0AH ; SET UP TIME OUT COUNTER
0007	D360	33	OUT MPXTR ; SEND CHAN SELECT TO MPX OUTPUT REGISTER
0009	002600	C 34	CALL WAIT50
		35	ADCO5:
000C	25	36	DCR H ; DECREMENT COUNT
000D	CA1700	C 37	JZ ADC00 ; IF TIME OUT EXIT LOOP
0010	D881	38	IN MPX1P ; SAMPLE A/D DONE
0012	E680	39	ANI 80H ; TEST MSB
0014	CA0C00	C 40	JZ ADC05 ; IF NOT READY LOOP
0017	D694	41	ADCO0: IN MPXD01 ; GET H. S. BYTE
0019	E60F	42	ANI 0FH ; KEEP 12 BITS
001B	47	43	MOV B, A ; SAVE IN B REG
001C	D695	44	IN MPXD02 ; GET L. S. BYTE
001E	12	45	STAX D ; STORE AT TEMP10 LSB
001F	FB	46	EI ; REENABLE INTERRUPTS
0020	78	47	MOV A, B ; GET H. S. BYTE INTO A
0021	13	48	INX D ; SET POINTER TO MSB OF TEMP10
0022	12	49	STAX D ; STORE AT TEMP10 MSB
0023	01	50	POP D ; RESTORE DE
0024	01	51	POP B ; RESTORE BC
0025	09	52	RET ; RETURN TO FORTRAN
		53	;
		54	DELAY ROUTINE

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II 8080/8085 MACRO ASSEMBLER, V3.0 VCSIOD PAGE 2

LOC	OBJ	LINE	SOURCE STATEMENT
0026	060A	55	WAIT50: MVI B, 0AH ; LOAD COUNT FOR 50 USEC DELAY
0028	05	56	WAITDC: DCR B
0029	C22900	57	JNZ WAITDC C
002C	09	58	RET
		59	;
0084		60	MPXDA1 EQU 04H ; MPX DATA 1
0085		61	MPXDA2 EQU 05H ; MPX DATA 2 HEX 05 PORT
0086		62	MPXOTR EQU 09H ; MPX OUTPUT REGISTER HEX 09 PORT
0081		63	MPXSTP EQU 01H ; MPX STATUS INPUT REGISTER HEX 01 PORT
		64	;
		65	*****
		66	;
		67	;
		68	;
		69	;
		70	;
		71	;
		72	;
		73	;
		74	;
		75	;
		76	;
		77	;
		78	;
		79	AGETIT:
002D	0A	80	LDAX B ; LOAD A WITH (BC)
002E	0F	81	MOV L,A ; STORE LSB IN L FOR MEM REF
002F	03	82	INX B ; INCREMENT BC
0030	0A	83	LDAX B ; LOAD A WITH (BC)
0031	07	84	MOV H,A ; STORE IN H MSB FOR POINT TO SINPNT
		85	;
		86	;
0032	7E	86	MOV A,M ; LOAD A WITH DATA 1
0033	13	87	INX D ; POINT DE TO DOB(6) FOR FORMAT PACK REVERSE
0034	12	88	STAX D ; STORE DATA AT (DE)
0035	1B	89	DCX D ; DECREMENT DC TO DOB(5) FOR NEXT BYTE
0036	23	90	INX H ; INCREMENT HL
0037	7E	91	MOV A,M ; LOAD A WITH DATA 2
0038	12	92	STAX D ; STORE AT (DE)
0039	09	93	RET ; RETURN TO FORTRAN
		94	;
		95	*****
		96	;
		97	;
		98	;
		99	;
		100	;
		101	;
		102	;
		103	;
		104	;
		105	;
		106	;
		107	;
		108	;
		109	AIOITZ:
003A	F3	109	DI ; DISABLE INTERRUPTS

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II 8088/8085 MACRO ASSEMBLER, V3.0 VC5100 PAGE 2

LOC	OBJ	LINE	SOURCE STATEMENT
		110 ;	
003B	3E00	111	MVI A,0 ; LOAD A REG WITH 0
003D	D307	112	OUT 07 ; PANEL
003F	D308	113	OUT 08 ; CASSETTE
0041	D309	114	OUT 09 ; CASSETTE
0043	D30A	115	OUT 0AH ; CASSETTE
0045	3EFF	116	MVI A,0FFH ; LOAD ALL ONES (NEGATIVE LOGIC)
0047	D303	117	OUT 03 ; ARM VALVES
0049	3EF0	118	MVI A,0F0H ; SEND 00001111
004B	D306	119	OUT 06 ; PANEL
		120 ;	
		121 ;	CALL A/D INITIALIZE
004D	0D5A00	C 122	CALL ADCITZ
		123 ;	
		124 ;	CALL CLOCK INITIALIZE
0050	0D6F00	C 125	CALL CLKITZ
		126 ;	
		127 ;	SET UP NBS
0053	0835	128	IN 035H ; SET NBS TO DIS COUNT
0055	D832	129	IN 033H ; LATCH DATA
0057	D832	130	IN 032H ; RESET SYSTEM
		131 ;	
0059	C9	132	RET ; RETURN
		133 ;	
		134 ;	*****
		135 ;	
		136 ;	SUBROUTINE ADCITZ
		137 ;	
		138 ;	ADCITZ INITIALIZES THE DATA TRANSLATION A/D
		139 ;	
		140	ADCITZ: ; ENTRY POINT
		141 ;	
005A	3E0F	142	MVI A,0FH ; LOAD PORT A, MODE 0
005C	D382	143	OUT MPXOCP ; MULTIPLEXOR OUTPUT CONTROL PORT
005E	3E07	144	MVI A,07H ; DISABLE INTERRUPT
0060	D382	145	OUT MPXOCP ; MUX OUT CONTROL PORT
0062	3E0F	146	MVI A,0CFH ; LOAD PORT B, MODE 3
0064	D383	147	OUT MPXSOP ; MULTIPLEXOR STATUS CONTROL PORT
0066	3EFF	148	MVI A,0FFH ; SET FOR INPUT BITS
0068	D383	149	OUT MPXSOP ;
006A	3E07	150	MVI A,07H ; DISABLE INTERRUPTS
006C	D382	151	OUT MPXSOP
006E	C9	152	RET ; RETURN
		153 ;	
0083		154	MPXSOP EQU 083H ; 83 HEX FOR MPX STAT CONTROL PORT
0082		155	MPXOCP EQU 082H ; 82 HEX FOR MPX OUT CONTROL PORT
		156 ;	
		157 ;	*****
		158 ;	
		159 ;	SUBROUTINE CLKITZ
		160 ;	
		161 ;	CLKITZ INITIALIZES THE TIME UNITS FOR NORMAL OPERATION
		162 ;	
0023		163	CLKONT EQU 023H ; CLOCK CONTROL PORT
		164 ;	

```

LOC  OBJ      LINE      SOURCE STATEMENT
006F 3E00      165  CLKITZ: MVI A,0 ; CLEAR ACC
0071 0325      166  OUT 25H ; STOP TIMER GATE 0,1,2
      167 ; INITIALIZE TIMER 0 TO 1 MSEC
0073 3E34      168  MVI A,34H ; 00110100 CTL 0,L-M,MODE 2,EIN 34H
0075 0323      169  OUT CLKCNT ; CONTROL PORT
0077 3E71      170  MVI A,71H ; LSB OF 0271H
0079 0320      171  OUT 20H ; COUNTER PORT 0
007B 3E02      172  MVI A,02H ; MSB OF 0271H
007D 0320      173  OUT 20H ; COUNTER PORT 0
      174 ; INITIALIZE TIMER 1 TO 100 MSEC
007F 3E74      175  MVI A,74H ; 01110100 CTL 1,L-M,MODE 2,PIN 74H
0081 0323      176  OUT CLKCNT ; CONTROL PORT
0083 3E64      177  MVI A,664H ; LSB OF 0064H
0085 0321      178  OUT 21H ; COUNTER PORT 1
0087 3E00      179  MVI A,00H ; MSB OF 0064H
0089 0321      180  OUT 21H ; COUNTER PORT 1
      181 ; INITIALIZE TIMER 2 TO 1 SEC
008B 3E84      182  MVI A,084H ; 10110100 CTL 2,L-M,MODE 2,EIN 84H
008D 0323      183  OUT CLKCNT ; CONTROL PORT
008F 3EE8      184  MVI A,0EE8H ; LSB OF 03E8H
0091 0322      185  OUT 22H ; COUNTER PORT 2
0093 3E03      186  MVI A,03H ; MSB OF 03E8H
0095 0322      187  OUT 22H ; COUNTER PORT 2
      188 ; START COUNTERS
0097 3E07      189  MVI A,07H ; 0111,GATE 1,2,3
0099 0325      190  OUT 25H ; GATE PORT
009B C9        191  RET ; RETURN
      192 ;
      193 ;*****
      194 ;
      195 ; SUBROUTINE AIOCDU (BUF)
      196 ;
      197 ; AIOCDU READS DATA FROM THE C/D PANEL PORT 04
      198 ;
      199 ; INPUTS: BC POINT TO WORK BUFFER
      200 ; OUTPUTS: NONE
      201 ; CALLS: HSEC2H
      202 ; DESTROYS: A,F/F'S,DE,HL
      203 ; MODIFIES: /WORK/
      204 ; VERSION 1.0
      205 ;
      206 AIOCDU:
009C 16FF      207  MVI D,0FFH ; SET D AS FLAG TO FF
      208 ; FRONT PANEL I/O DRIVER
      209 ; CLEAR LATCHES,READ PORT AND CLEAR LATCHES
      210 ; NOTE : LATCHES INVERT SWITCH DATA LINES TO BUS
      211 ;
      212 CDURD: ; LOOP ENTRY POINT
009E 3E00      213  MVI A,00H ; LOAD 00000000 INTO A
00A0 0306      214  OUT CDUCLR ; SEND CLEAR PULSE
00A2 3E80      215  MVI A,80H ; TURN ON LATCH BIT ONLY
00A4 0306      216  OUT CDUCLR ; REMOVE CLEAR PULSE
      217 ;
00A6 0E04      218  IN CDUINP ; READ C/D PORT
00A8 2F        219  CMA ; INVERT BITS FROM INTERFACE (NEG LOGIC)

```

ORIGINAL PAGE IS
OF POOR QUALITY

1515-II 8080/8085 MACRO ASSEMBLER, V3.0 MCS100 PAGE 5

LOC	OBJ	LINE	SOURCE STATEMENT
00A9	E57F	220	ANI 7FH ; MASK NON EXISTANT BIT
		221	; TEST IF RUN MODE OR CALIBRATE
00AB	5F	222	MOV E,A ; SAVE INPUT IN E REG
00AC	E594	223	ANI 04H ; AND WITH 00000100 TO SEE RUN BIT
00AE	FE04	224	CPI 04H ; TEST IF ON
00B0	CACB00	C 225	JZ CDUGO ; TEST IF EQUAL (ON) AND JUMP TO GO
		226	; CALIBRATE MODE
00B3	7B	227	MOV A,E ; RESTORE INPUT
00B4	E60B	228	ANI 0EH ; 00001011 TEST NXT,RST,RCJ BITS FOR ON
00B6	FE2B	229	CPI 0EH ;
00B8	CAC100	C 230	JZ CCTEST ; IF = 0 SET ZERO FLAG SO JUMP TO TEST
		231	;
00BB	1600	232	MVI D,0 ; CLEAR FLAG IN D
00BD	63	233	MOV H,E ; SAVE NON ZERO INPUT IN H REG
00BE	C39E00	C 234	JMP CDURD ; GO BACK AND CONTINUE READ
		235	;
00C1	7A	236	CCTEST: MOV A,D ; TEST FLAG IN D
00C2	FE00	237	CPI 0
00C4	CAC000	C 238	JZ CDUGOX ; IF FLAG CLEARED GO TO UNPACK BITS
00C7	C39E00	C 239	JMP CDURD
		240	;
00CA	5C	241	CDUGOX: MOV E,H ; MOVE DATA TO E IF CAL MODE
		242	CDUGO:
00CB	7B	243	MOV A,E ; RESTORE INPUT BEFORE 0
00CC	F5	244	PUSH PSW ; SAVE A AND FLAGS
00CD	C5	245	PUSH B ; PUT ADDRESS IN HL
00CE	E1	246	POP H ; VIA STACK
00CF	16FF	247	MVI D,0FFH ; SET D TO 11111111 . TRUE
00D1	1E00	248	MVI E,0H ; SET E TO 00000000 . FALSE
00D3	0E00	249	MVI C,8 ; LOAD C WITH 8 COUNT
00D5	1F	250	CDU05: RAR ; ROTATE ACC INTO CARRY (RIGHT)
00D6	DADD77	C 251	JC CDUTRU ; IF BIT ON GO TO TRUE (CARRY ON (CMA) SEE NOTE)
00D9	73	252	MOV M,E ; STORE .FALSE. IN ARRAY(1)
00DA	C3DE00	C 253	JMP CDUDCR ; GO TO COUNT TEST
00DD	72	254	CDUTRU: MOV M,D ; STORE .TRUE. IN ARRAY(1)
00DE	00	255	CDUDCR: DCR C ; DECREMENT COUNTER C
00DF	C9E600	C 256	JZ CDUDON ; DONE ALL BITS
00E2	23	257	INX H ; HL = HL+1
00E3	C3D500	C 258	JMP CDU05 ; LOOP BACK FOR NEXT BIT
		259	CDUDON:
00E6	F1	260	POP PSW ; RECOVER INPUT BITS
00E7	E604	261	ANI 04H ; KEEP RUN BIT
00E9	FE04	262	CPI 04H ; TEST IF RUN MODE
00EB	C9F100	C 263	JZ CDUD10 ; SKIP WAIT IF RUN MODE
00EE	C00000	E 264	CALL NSEC2H ; WAIT FOR SWITCH DEBOUNCE
		265	CDUD10:
00F1	E5	266	PUSH H ; PUT ADDRESS BACK IN
00F2	C1	267	POP B ; BC VIA STACK
00F3	C9	268	RET ; RETURN TO FORTRAN
		269	;
006B		270	CLTEST EQU 06EH ; MASK FOR CALIBRATE TEST
0004		271	CDUIMP EQU 04H ; PORT 4 FOR C/D INPUT
006F		272	CDTEST EQU 06FH ; MASK FOR RUN TEST
0006		273	CDUCLR EQU 06H ; PORT 6 FOR CDU LATCH CLEAR
		274	;

ORIGINAL PAGE IS
OF POOR QUALITY

1515-II 9393-9095 MACRO ASSEMBLER, V1.0

VCS100 PAGE 4

LOC	OBJ	LINE	SOURCE STATEMENT
			8 7 6 5 4 3 2 1
275	:		FOPT 04 = X, PWR, MAN, AUT, PST, RUN/CAL, POS, INT
276	:		TYPE NC NC NO NC NC NC NC
277	:		VALUE X 1 1 0 1 1 1 1
278	:		NC - 0 ACTIVE WHEN PRESSED
279	:		
280	:		
281	:		END

PUBLIC SYMBOLS
 AOCITZ C 005A AGETIT C 002D AIOASC C 0000 AIOCDU C 009C AIOITZ C 003A CLKITZ C 006F

EXTERNAL SYMBOLS
 MSEC2H E 0000

USER SYMBOLS
 APC05 C 000C AOC00 C 0017 AOCITZ C 005A AGETIT C 002D AIOASC C 0000 AIOCDU C 009C AIOITZ C 003A
 CCTEST C 00C1 COTEST A 006F CDU05 C 0005 CDUCLP A 0005 CDU010 C 00F1 CDUDCR C 000E CDUDEN C 00E5
 CDUS0 C 00CB CDUS0X C 00CA CDUINP A 0004 CDURD C 009E CDUTRU C 0000 CLKINT A 0023 CLKITZ C 006F
 CLTEST A 006B MPYDA1 A 0084 MPYDA2 A 0085 MPXOCP A 0082 MPYOTR A 0080 MPYSCP A 0023 MPXSLP A 0081
 MSEC2H E 0000 WAIT50 C 0025 WAITDC C 0025

ASSEMBLY COMPLETE, NO ERRORS

LOC	OBJ	LINE	SOURCE STATEMENT
		1	:
		2	NAME INTRPT
		3	:
		4	PUBLIC INTRPT, INTRDS, INTREN
		5	:
		6	EXTRN OUTCAS
		7	:
		8	CLOCK INTERRUPT SERVICE ROUTINE
		9	:
		10	CSEG
		11	:
		12	*****
		13	:
		14	SUBROUTINE INTRPT
		15	:
		16	INTRPT IS THE CLOCK INTERRUPT SERVICE ROUTINE
		17	:
		18	INPUTS: NONE
		19	OUTPUTS: NONE
		20	CALLS: OUTCAS
		21	DESTROYS: NOTHING
		22	MODIFIES: CLOCK STATUS AND COUNTER BYTES
		23	VERSION: 1.0
		24	:
		25	INTRPT:
0000	F5	26	PUSH PSW ; SAVE R,F,F'S
0001	0924	27	IN 024H ; READ CLOCK DATA FAST
0003	E5	28	PUSH H ; SAVE HL
0004	05	29	PUSH D ; SAVE DE
0005	05	30	PUSH B ; SAVE BC
0006	F5	31	PUSH PSW ; SAVE INPUT FROM CLOCK
		32	:
		33	INTERRUPTS ARE DISABLED, READ CLOCK
		34	:
		35	CLEAR BYTE FLAGS
0007	3E00	36	MVI A,0 ; CLEAR ACC
0009	21C220	37	LXI H,20C2H ; POINT M TO FIRST FLAG
000C	77	38	MOV M,A ; CLEAR FLAG
000D	23	39	INX H
000E	77	40	MOV M,A ; CLEAR 100 FLAG
000F	23	41	INX H
0010	77	42	MOV M,A ; CLEAR SECOND FLAG
0011	F1	43	POP PSW ; GET INPUT BACK IN A REG
0012	2F	44	CMA ; INVERT BITS TO GET LOW DATA ACTIVE = 1
0013	E607	45	ANI 07H ; MASK UPPER 5 BITS
0015	0F	46	RRC ; SHIFT 1 SEC LINE INTO CARRY
0016	F5	47	PUSH PSW ; SAVE R,F,F'S
0017	0C5700	48	CC HILSEC ; TEST FOR BIT SET IN CARRY
001A	F1	49	POP PSW ; RESTORE A AFTER CALL
001B	0F	50	RRC ; SHIFT 100 USEC BIT TO CARRY
001C	F5	51	PUSH PSW ; SAVE R,F,F'S
001D	0C4000	52	CC HUNDRO ; TEST FOR BIT SET
0020	F1	53	POP PSW
0021	0F	54	RRC ; SHIFT 1 MSEC BIT TO CARRY

ORIGINAL PAGE IS
OF POOR QUALITY

```

LOC OBJ      LINE      SOURCE STATEMENT
0022 003400  C   55  CC ONESEC ; TEST FOR BIT SET
      56 ;
      57  EXIT:
      58 ; WAIT FOR LINES TO GO HIGH AGAIN
0025 0024      59  IN 024H
0027 E607      60  ANI 07H
0029 FE07      61  CPI 07H
002B C22500  C   62  JNZ EXIT
      63 ;
002E C1       64  POP B ; RESTORE BC
002F D1       65  POP D ; RESTORE DE
0030 E1       66  POP H ; RESTORE HL
0031 F1       67  POP PSW ; RESTORE R,F,F'S
      68 ;
0032 FB       69  EI ; ENABLE INTERRUPTS
0033 C9       70  RET ; RETURN TO MONITOR CALLING POINT
      71 ;
      72  ONESEC:
0034 21C420  73  LXI H,20C4H ; SET HL TO SECOND FLAG BYTE
0037 3EFF      74  MVI A,0FFH ; LOAD A WITH 11111111
0039 77      75  MOV M,A ; SET FLAG BYTE
003A 23      76  INX H ; POINT HL TO COUNT BYTE
003B 3E01      77  MVI A,01H ; SET A TO 1
003D 86      78  ADD M ; ADD COUNT TO ACC
003E 77      79  MOV M,A ; STORE COUNT BACK IN MEMORY BYTE
003F 23      80  INX H ; POINT TO MSB
0040 3E00      81  MVI A,00H ; ADD ZERO AND CARRY TO MSB COUNT
0042 8E      82  ADC M ; ADD CARRY TO COUNT MSB
0043 77      83  MOV M,A ; SAVE IT AWAY
      84 ;
0044 3E00      85  MVI A,0
0046 D325      86  OUT 25H ; SET GATE TRIGGER LOW-HIGH TO SYNCPONIZE
0048 3E07      87  MVI A,07H
004A D325      88  OUT 25H
004C C9      89  RET
      90 ;
      91  HUNDRO:
004D 21C320  92  LXI H,20C3H ; SET HL TO 100 MSEC FLAG BYTE
0050 3EFF      93  MVI A,0FFH ; SET ACC TO 11111111
0052 77      94  MOV M,A ; SET FLAG BYTE
0053 C00000  E   95  CALL OUTCRS
0056 C9      96  RET
      97 ;
      98  MILSEC:
0057 21C220  99  LXI H,20C2H ; HL POINTS TO 1 MSEC FLAG BYTE
005A 3EFF     100  MVI A,0FFH ; SET ACC TO 11111111
005C 77     101  MOV M,A ; SET FLAG BYTE TRUE
005D C9     102  RET
      103 ;
      104 ; *****
      105 ;
      106 ; SUBROUTINE INTRDS
      107 ;
      108 ; INTRDS DISABLES THE CPU INTERRUPT LINES
      109 ;

```


ORIGINAL PAGE IS
OF POOR QUALITY

ISTS-II 0000/0095 MACRO ASSEMBLER, V3.0 INTPT PAGE 3

```
LCC 091      LINE      SOURCE STATEMENT

              110 ; INPUTS: NONE
              111 ; OUTPUTS: NONE
              112 ; CALLS: NOTHING
              113 ; DESTROYS: NOTHING
              114 ; MODIFIES: INTERRUPT MASK FOR CPU
              115 ; VERSION: 1.0
              116 ;
005E F3      117 INTDS:
005F C9      118 DI
              119 RET ; RETURN AFTER DISABLING INTERRUPTS
              120 ;
              121 ; *****
              122 ;
              123 ; SUBROUTINE INTREN
              124 ;
              125 ; INTREN ENABLES THE CPU INTERRUPT LINES
              126 ;
              127 ; INPUTS: NONE
              128 ; OUTPUTS: NONE
              129 ; CALLS: NOTHING
              130 ; DESTROYS: A,F/F'S
              131 ; MODIFIES: CPU INTERRUPT MASK
              132 ; VERSION: 1.0
              133 ;
0060 3E08     134 INTREN:
0062 30      135 MVI A,08H ; LOAD A WITH INTERRUPT MASK
0063 FB      136 SIM ; SET INTERRUPT MASK
0064 C9      137 EI ; ENABLE INTERRUPTS
              138 RET ; RETURN
              139 ;
              140 END

PUBLIC SYMBOLS
INTDS C 005E  INTREN C 0060  INTRPT C 0000

EXTERNAL SYMBOLS
OUTCAS E 0000

USER SYMBOLS
EXIT C 0025  HUNDRO C 004D  INTDS C 005E  INTREN C 0060  INTRPT C 0000  NILESEC C 0057  ONESEC C 0034
OUTCAS E 0000

ASSEMBLY COMPLETE, NO ERRORS
```

ORIGINAL PAGE IS
OF POOR QUALITY

LOC	OBJ	LINE	SOURCE STATEMENT
		1 ;	
		2 ;	SUBROUTINE DEFALT
		3 ;	
		4 ;	DEFALT IS A TABLE OF OPERATION DEFAULT DATA IN ROM
		5 ;	
		6 ;	*****
		7 ;	
		8 ;	COMMON/DEFALT/ DEFIOF, DEFCTV, DEFPRM, DEFINT, ICMPT, NMXYEC, NMXPX
		9 ;	
		10 ;	DEFIOV(20) LOG*1
		11 ;	DEFPRM(20) INT*2
		12 ;	DEFCTV(16) LOG*1
		13 ;	DEFINT(8) INT*2
		14 ;	ICMPT(10) INT*2
		15 ;	NMXYEC(16) INT*2
		16 ;	NMXPX(6) INT*1
		17 ;	
		18	NAME DEFALT
		19 ;	
		20	PUBLIC DEFALT
		21 ;	
0050		22	ORG 0050H
		23 ;	
		24	DEFALT: ; PUBLIC SYMBOL ENTRY POINT
0050	FF	25	DEFIOV: DB 0FFH ; IOFYEC(1) = SEN
0051	FF	26	DB 0FFH ; EFD
0052	FF	27	DB 0FFH ; PCF
0053	FF	28	DB 0FFH ; LCF
0054	FF	29	DB 0FFH ; LAP
0055	FF	30	DB 0FFH ; RAP
0056	FF	31	DB 0FFH ; CID
0057	FF	32	DB 0FFH ; PKF
0058	00	33	DB 000H ; PKR
0059	FF	34	DB 0FFH ; VCF
005A	FF	35	DB 0FFH ; VCR
005B	FF	36	DB 0FFH ; VOT
005C	FF	37	DB 0FFH ; DSP
005D	00	38	DB 000H ; KEY
005E	00	39	DB 000H ; CAS
005F	00	40	DB 000H ; CRT
0060	FF	41	DB 0FFH ; CDU
0061	00	42	DB 000H ; DUMMY
0062	00	43	DB 000H ; DUMMY
0063	00	44	DB 000H ; DUMMY
		45 ;	
		46	DEFPRM: ; /DEFPRM/ ; INT*2 PARAMETERS
0064	0000	47	DW 0000H ; MAX DRUM VALUE DMAX
0066	00FE	48	DW -200H ; MIN DRUM VALUE DMIN
0069	0000	49	DW 9 ; ERROR LIMIT COUNT FOR TRIP MODE
006A	F000	50	DW 0FAH ; CID STEP
006C	0000	51	DW 0 ; PICK AVEAGING NUMBER
006E	F000	52	DW 0FAH ; PICK STEP
0070	6000	53	DW 60H ; FRONT DEAD BAND
0072	5000	54	DW 50H ; REAR DEAD BAND

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II 9000/9085 MACRO ASSEMBLER, V3.0 DEFAULT PAGE 2

LOC	OBJ	LINE	SOURCE STATEMENT
0874	0100	55	DW 1 ; LENGTH OF EICKOFF ARMS
0876	3E00	56	DW 54 ; RADIUS OF DRUMS
0878	0A00	57	DW 10 ; LAST CUT POSITION
087A	1100	58	DW 17 ; PRESENT CUT POSITION
087C	0000	59	DW 0 ; CID POSITION
087E	6800	60	DW 68H ; FTRLOC
0880	0100	61	DW 1 ; DFDFACT
0882	0100	62	DW 1 ; DSTP
0884	E000	63	DW 0E0H ; FRONT DBIAS
0886	0000	64	DW 0 ; REAR DRUM BIAS
0888	0000	65	DW 0 ; SRKVAL
088A	0000	66	DW 0 ; TRGFCT
		67 ;	
088C	FF	68	DEFCTV: DB 0FFH ; LOG*1 CNMVEC(1) CID
088D	FF	69	DB 0FFH ; LCF
088E	00	70	DB 00H ; PKF
088F	00	71	DB 000H ; PKR
0890	FF	72	DB 0FFH ; PCF
0891	FF	73	DB 0FFH ; VCF
0892	FF	74	DB 0FFH ; VCR
0893	FF	75	DB 0FFH ; FRT
0894	FF	76	DB 0FFH ; RER
0895	FF	77	DB 0FFH ; CUT
0896	00	78	DB 0 ; DUMMY
0897	00	79	DB 0 ; DUMMY
0898	00	80	DB 0 ; DUMMY
0899	00	81	DB 0 ; DUMMY
089A	00	82	DB 0 ; DUMMY
089B	00	83	DB 0 ; DUMMY
		84 ;	
089C	0000	85	DEFPNT: DW 0 ; INT*2
089E	0000	86	DW 0
08A0	0000	87	DW 0
08A2	0000	88	DW 0
08A4	0000	89	DW 0
08A6	0000	90	DW 0
08A8	0000	91	DW 0
08AA	0000	92	DW 0
		93 ;	
		94 ; /OPPARM/	
		95 ;	
08AC	0700	96	ICNPNT: DW 7 ; INT*2 (1)
08AE	0400	97	DW 4
08B0	0800	98	DW 8
08B2	0900	99	DW 9
08B4	0300	100	DW 3
08B6	0F00	101	DW 10
08B8	0E00	102	DW 11
08BA	1200	103	DW 18
08BC	1300	104	DW 19
08BE	1400	105	DW 20
		106 ;	
08C0	0900	107	NMXYEC: DW 9 ; INT*2 SEN
08C2	0900	108	DW 9 ; ERR
08C4	0000	109	DW 0 ; SIR

LOC	OBJ	LINE	SOURCE STATEMENT
0B06	0700	110	DW 7 ; IPH
0B08	0800	111	DW 8
0B0A	0900	112	DW 9 ; DSP
0B0C	1400	113	DW 20 ; IOF
0B0E	0A00	114	DW 10 ; CHM CTY
0B10	0B00	115	DW 8 ; DBG
0B12	0900	116	DW 9 ; CBF
0B14	0800	117	DW 128 ; TAP
0B16	0800	118	DW 8 ; KIB
0B18	1400	119	DW 20 ; PRM
0B1A	0A00	120	DW 10 ; OPS
0B1C	0800	121	DW 8 ; PNT
0B1E	0800	122	DW 0 ; DUMMY
		123 ;	
0B20	11	124	MMXIPX: DB 17 ; MMXIPX(1) IOF VECTOR PATCHING
0B21	0A	125	DB 16 ; CONTROL VECTOR PATCHING
0B22	09	126	DB 9 ; OPERATION CONTROL PATCHING
0B23	14	127	DB 20 ; PARAMETERS TO BE RESET
0B24	01	128	DB 1 ; DATA INITIALIZE , CLEAR CMOS BUFFERS
0B25	20	129	DB 32 ; SENSOR TABLES
0B26	0A	130	DB 10 ; MOS CONTROL WORDS
		131 ;	
0C90		132	ORG 0C90H
		133 ;	
		134	DEFOPS:
		135 ;	COMMON /DEFOPS/ DEFOPS(10)
0C90	0200	136	DW 2 ; OFMODE
0C92	0100	137	DW 1 ; MODECT
0C94	0100	138	DW 1 ; RNGMSK
0C96	0100	139	DW 1 ; SENDEL
0C98	0000	140	DW 0 ; RATE CHECK
0C9A	0000	141	DW 0 ; STATUS
0C9C	0D00	142	DW 13 ; FDYGN
0C9E	0002	143	DW 300H ; FDCAL
0CA0	0600	144	DW 6 ; RDYGN
0CA2	0003	145	DW 300H ; RDCAL
		146 ;	
0CA4		147	ORG 0CA4H
		148 ;	
		149	DEFMOS:
		150 ;	COMMON /DEFMOS/ DEFMOS(10)
0CA4	0060	151	DW 6000H ; MAXSLT
0CA6	0000	152	DW 0 ; STRIPT
0CA8	0000	153	DW 0 ; STEPSZ
0CAA	00A0	154	DW 0A00H ; NEGMAX
0CAC	0060	155	DW 6000H ; POSMAX
0CAE	0000	156	DW 0 ; LSTPNT
0CB0	0600	157	DW 6 ; ISNIND
0CB2	0000	158	DW 0 ; ISMPOS
0CB4	1001	159	DW 0110H ; CIDMAX
0CB6	FA00	160	DW 0FAH ; CIDMIN
		161 ;	
		162	END

ISIS-II 8080/8085 MACRO ASSEMBLER, V3.0

DEFAULT PAGE 4

ORIGINAL PAGE IS
OF POOR QUALITY

PUBLIC SYMBOLS
DEFAULT A 0B50

EXTERNAL SYMBOLS

USER SYMBOLS

DEFAULT A 0B50 DEFCTY A 0B8C DEFIOY A 0B50 DEFPOS A 0C84 DEFOPE A 0C90 DEFENY A 0E9C DEFPRM A 0B64
ICMPNT A 0BAC MMXIPX A 0BEB MMXVEC A 0BC0

ASSEMBLY COMPLETE, NO ERRORS

ORIGINAL PAGE IS
OF POOR QUALITY

LOC	OBJ	LINE	SOURCE STATEMENT
		1	NAME TABLE
		2	;
		3	PUBLIC ASCTAB
		4	;
		5	*****
		6	;
		7	COMMON /MESTAB/
		8	;
		9	DATA INITIALIZATION OF ASCII TABLES
		10	;
0A00		11	ORG 0A00H
		12	/MESTAB/ STARTS AT 0A00 HEX
		13	;
		14	ASCTAB:
		15	ALLOCATION OF EPRMS(20) CHARACTER*4 ARRAY
0A00	2453454E	16	DB '\$SEN'
0A04	24444644	17	DB '\$CFD'
0A08	24504346	18	DB '\$PCF'
0A0C	244C4346	19	DB '\$LCF'
0A10	244C4150	20	DB '\$LAP'
0A14	24524150	21	DB '\$RAP'
0A18	24434944	22	DB '\$CID'
0A1C	24504B46	23	DB '\$PKF'
0A20	24504B52	24	DB '\$PKR'
0A24	24564346	25	DB '\$VCF'
0A28	24564352	26	DB '\$VCR'
0A2C	24564F54	27	DB '\$VOT'
0A30	24445350	28	DB '\$DSP'
0A34	244B4559	29	DB '\$KEY'
0A38	24434153	30	DB '\$CRS'
0A3C	24435254	31	DB '\$CRT'
0A40	24434455	32	DB '\$COU'
0A44	24465254	33	DB '\$FRT'
0A48	24524552	34	DB '\$RER'
0A4C	24434F54	35	DB '\$COT'
		36	;
		37	ALLOCATION OF DEGMES(20) CHARACTER*4 ARRAY
		38	;
0A50	44425547	39	DB 'DEBUG'
0A54	4F55543F	40	DB 'OUT?'
0A58	494E502F	41	DB 'IMP?'
0A5C	4441543F	42	DB 'DAT?'
0A60	49545A3F	43	DB 'ITZ?'
0A64	5441583F	44	DB 'TAP?'
0A68	492F4F3F	45	DB 'I/O?'
0A6C	434C4B3F	46	DB 'CLK?'
0A70	40454D3F	47	DB 'MEM?'
0A74	5244593F	48	DB 'RDY?'
0A78	454E443F	49	DB 'END?'
0A7C	5359532D	50	DB 'SYS-'
0A80	504F5254	51	DB 'PORT'
0A84	43494E4C	52	DB 'CHNL'
0A88	20555020	53	DB 'UP '
0A8C	444F574E	54	DB 'DOWN'

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-11 8080/8085 MACRO ASSEMBLER, V3.0 TABLE PAGE 2

LOC	OBJ	LINE	SOURCE STATEMENT
0A90	40414E2D	55	DB 'MAN-'
0A94	404F4445	56	DB 'MODE'
0A98	57524954	57	DB 'WRIT'
0A9C	4144521F	58	DB 'ADR?'
		59	;
		60	; ALLOCATION OR RUNMES(20) CHARACTER*4 ARRAY
		61	;
0AA0	3F432F4F	62	DB '?I/O'
0AA4	3F434E54	63	DB '?CIT'
0AA8	3F4F5053	64	DB '?OPS'
0AAC	3F565242	65	DB '?YRB'
0AB0	2A52554E	66	DB '*RUN-OK*'
0AB4	2D4F482A		
0AB8	2A444542	57	DB '*DEBUG *'
0ABC	5547292A		
0AC0	3F43414C	68	DB '?CALBRAT'
0AC4	42524154		
0AC8	2A204841	69	DB '* HALT *'
0ACC	4C54202A		
0AD0	4D415348	70	DB 'MASK'
0AD4	5041524D	71	DB 'PARM'
0AD8	45525220	72	DB 'ERR '
0ADC	25205354	73	DB '%-STOP-%'
0AE0	4F502D25		
0AE4	2A2D4558	74	DB '*-EXIT-*'
0AE8	49542D2A		
0AEC	20232320	75	DB ' ## '
		76	;
		77	; ALLOCATION OF DSPCODE(10) CHARACTER*1 ARRAY
		78	;
0AF0	24202326	79	DB '\$*#%&' =/'
0AF4	25403F20		
0AF8	3D2F		
		80	;
		81	; /MESTB2' STARTS AT 0AFAH
		82	;
		83	; ALLOCATION OF PARMES(20) CHARATER*4
		84	;
0AFA	444D4158	85	DB 'DMAX' ; MAX DRUM VALUE
0AFE	444D494E	86	DB 'DMIN' ; MIN DRUM VALUE
0B02	45524C4D	87	DB 'ERLM' ; ERROR LIMIT
0B06	43445354	88	DB 'CDST' ; CID STEP
0B0A	50415645	89	DB 'PAVE' ; NUMBER OF PICK SIGNALS TO AVERAGE
0B0E	504B5350	90	DB 'PKSP' ; PICK STEP
0B12	44424446	91	DB 'D0DF' ; FRONT DEAD BAND FOR CONTROLLER
0B16	44424452	92	DB 'D0DR' ; REAR DEAD BAND
0B1A	4C454E47	93	DB 'LENG' ; LENGTH OF ARM
0B1E	44524144	94	DB 'DRAD' ; DRUM RADIUS
0B22	4C435053	95	DB 'LCPS' ; LAST CUT POSITION
0B26	50435053	96	DB 'PCPS' ; PRESENT CUT POSITION
0B2A	43445053	97	DB 'CDPS' ; CID POSITION
0B2E	464C4F43	98	DB 'FLOC' ; FRONT TO REAR DISTANCE
0B32	44464354	99	DB 'DFCT' ; DFD FACTOR
0B36	44535450	100	DB 'DSTP' ; DFD STEP UPDATE FOR CMOS
0B3A	46424153	101	DB 'FBAS' ; FRONT DRUM BIAS

ORIGINAL PAGE IS
OF POOR QUALITY

LOC	OBJ	LINE	SOURCE STATEMENT
0B3E	52404452	102	DB 'RBAS' ; REAR DRUM BIAS
0B42	53485256	103	DB 'SKRV' ; RATE CHECK PARAMETER
0B46	54524746	104	DB 'TRGF' ; TRIG FACTOR
		105	;
0C48		106	ORG 0C40H
		107	;
		108	; /MESTB3/ STARTS AT 0C40H
		109	;
		110	; ALLOCATION OF OPSMES(10) CHARACTER*4
		111	;
0C40	404F4445	112	DB 'MODE' ; MODE MODE
0C44	52414E47	113	DB 'RANG' ; RANGE CHECK
0C48	5344454C	114	DB 'SDEL' ; OPERATION SENSOR DELAY FLAG
0C4C	52415445	115	DB 'RATE' ; SENSOR RATE TEST
0C50	53545553	116	DB 'STUS' ; STATUS WORD
0C54	46445647	117	DB 'FDVG' ; FRONT DRUM GAIN
0C58	4644434C	118	DB 'FDCL' ; FRONT DRUM CAL
0C5C	52445E47	119	DB 'RDVG' ; REAR DRUM GAIN
0C60	5244434C	120	DB 'RDCL' ; REAR DRUM CAL
0C64	20202020	121	DB ' ' ;
		122	;
0CC8		123	ORG 0CC8H
		124	;
		125	; /MOSMES/ STARTS AT 0CC8H
		126	;
		127	; ALLOCATION OF MOSMES(16) CHARACTER*4
		128	;
0CC8	40585354	129	DB 'MXST'
0CCC	53545854	130	DB 'STPT'
0CD0	53585358	131	DB 'SPSZ' ; STEP SIZE
0CD4	4E474D58	132	DB 'NGMX' ; NEGMAX
0CD8	58534D58	133	DB 'PSMX' ; POSMAX
0CDC	4C535854	134	DB 'LSPT' ; LSTPNT
0CE0	534E4944	135	DB 'SNID' ; ISNIND
0CE4	534E5853	136	DB 'SNPS' ; ISNPOS
0CE8	43444D58	137	DB 'COMX' ; CIDMAX
0CEC	43444D4E	138	DB 'CDMN' ; CIDMIN
0CF0	20202020	139	DB ' ' ;
0CF4	20202020	140	DB ' ' ;
0CF8	20202020	141	DB ' ' ;
0CFC	20202020	142	DB ' ' ;
0D00	20202020	143	DB ' ' ;
0D04	20202020	144	DB ' ' ;
		145	;
		146	END

PUBLIC SYMBOLS
ASCTAB A 0A00

EXTERNAL SYMBOLS

USER SYMBOLS
ASCTAB A 0A00

ISIS-11 8080/8085 MACRO ASSEMBLER, V3.0

TABLE PAGE 4

**ORIGINAL PAGE IS
OF POOR QUALITY**

ASSEMBLY COMPLETE. NO ERRORS

```

LOC  OBJ      LINE      SOURCE STATEMENT
      1 ;
      2 ; SUBROUTINE DEFTAB
      3 ;
      4 ;
      5 ; DEFAULT TABLE FOR CONVERSION AND RANGE DATA
      6 ;
      7 ; *****
      8 ;
      9 NAME DEFTAB
     10 ;
     11 PUBLIC DEFTBL
     12 ;
0BE9   13 ORG 0BE8H ; ORIGIN FOR COMMON
     14 ;
     15 ; COMMON/DEFTAB/ DEFRNG,DEFCON
     16 ;
     17 ; DEFRNG(10,2) INT*2
     18 ; DEFCON(10,2) INT*2
     19 ;
     20 ; RANGE CHECK TABLE
     21 ;
     22 DEFTBL: ;
     23 ; MINIMUMS
     24 DEFRNG: ; RANGE DEFAULTS
0BE9 0BF0   25 DW -1000H ; DFD
0BEA 0BF0   26 DW -1000H ; PCF
0BEC 0BF0   27 DW -1000H ; LCF
0BEE 0BF0   28 DW -1000H ; LAF
0BF0 0BF0   29 DW -1000H ; RPF
0BF2 0B00   30 DW 00000 ; NBS CID MIN = 0
0BF4 0B00   31 DW -32760 ;
0BF6 0B00   32 DW -32760 ;
0BF8 0B00   33 DW -32760 ;
0BFa 0B00   34 DW -32760 ;
     35 ; MAXIMUMS
0BFC F87F   36 DW 32760 ; DFD
0BFE F87F   37 DW 32760 ; PCF
0C00 F87F   38 DW 32760 ; LCF
0C02 0010   39 DW 1000H ; LAF
0C04 0010   40 DW 1000H ; RPF
0C06 1027   41 DW 10000 ; NBS CID MAX
0C08 F87F   42 DW 32760 ;
0C0A F87F   43 DW 32760 ;
0C0C F87F   44 DW 32760 ;
0C0E F87F   45 DW 32760 ;
     46 ;
     47 ; CONVERSION TABLE
     48 ;
     49 ; OFFSET TERMS
0C10 97FB   50 DEFCON: DW 0FB97H ; DFD
0C12 6006   51 DW 0660H ; PCF
0C14 6006   52 DW 0650H ; LCF
0C16 00F3   53 DW 0F800H ; LAF
0C18 00F3   54 DW 0F800H ; RPF

```

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II 8000/8085 MACRO ASSEMBLER, V3.0

DEFTAB PAGE 2

LOC	OBJ	LINE	SOURCE STATEMENT
0C1A	0000	55	DW 0 ; NBS CID
0C1C	0000	56	DW 0 ;
0C1E	0000	57	DW 0 ;
0C20	0000	58	DW 0 ;
0C22	0000	59	DW 0 ;
		60	; GAIN-TERMS
0C24	0100	61	DW 1 ; DFD
0C26	FFFF	62	DW -1 ; PCF
0C28	FFFF	63	DW -1 ; LCF
0C2A	0400	64	DW 4 ; LAP
0C2C	0400	65	DW 4 ; RAP
0C2E	0100	66	DW 1 ; CID
0C30	0100	67	DW 1 ;
0C32	0100	68	DW 1 ;
0C34	0000	69	DW 0 ;
0C36	0000	70	DW 0 ;
		71	;
		72	END

PUBLIC SYMBOLS
DEFTBL A 00E8

EXTERNAL SYMBOLS

USER SYMBOLS
DEFCOM A 0C10 DEFRMG A 00E8 DEFTBL A 00E8

ASSEMBLY COMPLETE NO ERRORS

```

LOC OBJ      LINE      SOURCE STATEMENT
1 ; *****
2 ;
3 ;          PROGRAM: STOMON MONITOR VER 1.0
4 ;
5 ;          ORIGINAL SOURCE STD-85, SEC-80, LG MONITORS, FRO-LOG
6 ;          7303 KEYBOARD MONITOR.
7 ;
8 ;          MODIFIED BY FOSTER-HILLER ASSOC
9 ;          NOVEMBER 01, 1989
10 ;         FOR FRO-LOG STD BUS 8085 WITH 7303 AND LEFT
11 ;         VCS HARDWARE CONFIGURATION
12 ;
13 ; *****
14 ;
15 ; ABSTRACT
16 ; =====
17 ;
18 ; THIS PROGRAM IS A 2K MONITOR FOR THE INTEL 8085 AND
19 ; PROVIDES A MINIMUM LEVEL OF UTILITY FUNCTIONS FOR THE USER EMPLOYING
20 ; EITHER AN INTER-ACTIVE CONSOLE (I.E. TELETYPE) OR THE USER EMPLOYING
21 ; THE KEYBOARD-DISPLAY. THE KEYBOARD MONITOR ALLOWS THE USER TO PERFORM
22 ; SUCH FUNCTIONS AS MEMORY AND REGISTER MANIPULATION, PROGRAM LOADING,
23 ; PROGRAM EXECUTION, INTERRUPTION OF AN EXECUTING PROGRAM, AND
24 ; SYSTEM RESET. THE MONITOR ALSO PROVIDES MINIMAL TAFE I/O.
25 ;
26 ; PROGRAM ORGANIZATION
27 ; =====
28 ;
29 ; THE PROGRAM IS ORGANIZED AS FOLLOWS :-
30 ;     1) COLD START ROUTINE (RESET)
31 ;     2) WARM START - REGISTER SAVE ROUTINE
32 ;     3) INTERRUPT VECTORS
33 ;     4) KEYBOARD MONITOR
34 ;     5) TTY MONITOR
35 ;     6) LAYOUT OF RAM USAGE
36 ;
37 ; THE KEYBOARD MONITOR BEGINS WITH THE COMMAND RECOGNIZER, FOLLOWED BY
38 ; THE COMMAND ROUTINE SECTION, UTILITY ROUTINE SECTION AND MONITOR
39 ; TABLES. THE COMMAND AND UTILITY ROUTINES ARE IN ALPHABETICAL ORDER
40 ; WITHIN THEIR RESPECTIVE SECTIONS.
41 ; THROUGHOUT THE KEYBOARD MONITOR, A COMMENT FIELD BEGINNING
42 ; WITH "ARG - " INDICATES A STATEMENT WHICH LOADS A VALUE INTO
43 ; A REGISTER AS AN ARGUMENT FOR A FUNCTION. WHEN THE DESIRED VALUE
44 ; LIST OF KEYBOARD MONITOR ROUTINES
45 ; =====
46 ;
47 ; CMDND
48 ; -----
49 ; EXAM
50 ; GOCHD
51 ; SSTEP
52 ; SUBST
53 ; -----
54 ; CLEAR

```

```

LOC OBJ      LINE      SOURCE STATEMENT
              55 ; CLDIS
              56 ; CLDST
              57 ; DISPC
              58 ; ERR
              59 ; GTHEX
              60 ; HMDSP
              61 ; ININT
              62 ; INSDG
              63 ; NXRTRG
              64 ; OUTPT
              65 ; RDKBD
              66 ; RETF
              67 ; RETT
              68 ; RGLLOC
              69 ; RSTOR
              70 ; SETRG
              71 ; UFDAD
              72 ; UFDOT
              73 ;
              74 NAME MONITR
              75 ;
              76 ;*****
              77 ;
              78 ;           SET CONDITIONAL ASSEMBLY FLAG
              79 ;
              80 ;*****
              81 ;
              82 ;
              83 ;WAITS SET 0 ;0=NO WAIT STATES
              84 ;           ;1=A WAIT STATE IS GENERATED FOR EVERY M CYCLE
              85 ;           ;THE APPROPRIATE DELAY TIME MUST BE USED FOR
              86 ;           ;TTY DELAY OR SET UP SINGLE
              87 ;           ;STEP TIMER FOR EACH CASE
              88 ;
              89 ;
              90 ;*****
              91 ;
              92 ;           MONITOR EQUATES
              93 ;
              94 ;*****
              95 ;
2000          96 RAMST EQU 2000H ;START ADDRESS OF RAM - THIS PROGRAM ASSUMES
              97 ; THAT 256 BYTES OF RANDOM ACCESS MEMORY BEGIN AT THIS ADDRESS.
              98 ; THE PROGRAM USES STORAGE AT THE END OF THIS SPACE FOR VARIABLES,
              99 ; SAVING REGISTERS AND THE PROGRAM STACK.
              100 ;
0017          101 RMUSE EQU 23 ; RAM USAGE - CURRENTLY 23 BYTES ARE USED FOR
              102 ;           ; /SAVING REGISTERS AND VARIABLES
              103 ;
0012          104 SKLN EQU 10 ; MONITOR STACK USAGE - MAX OF 9 LEVELS
              105 ;
000F          106 UBRLN EQU 15 ; 5 USER BRANCHES - 3 BYTES EACH
              107 ;
0000          108 ADFLD EQU 0 ; INDICATES USE OF ADDRESS FIELD OF DISPLAY
0050          109 ADISP EQU 30H ; CONTROL CHARACTER TO INDICATE OUTPUT TO

```

ORIGINAL PAGE IS
OF POOR QUALITY.

1513-II 5050/5085 MACRO RESEMBLER, V3.0 MONITR PAGE 2

LOC	OBJ	LINE	SOURCE STATEMENT
		110	; /ADDRESS FIELD OF DISPLAY
0001		111	CNTRL EQU 001H ; ADDRESS FOR SENDING CONTROL CHARACTERS TO
		112	; /DISPLAY CHIP
0011		113	COMMA EQU 11H ; COMMA FROM KEYBOARD
0000		114	CSNIT EQU 0 ; INITIAL VALUE FOR COMMAND STATUS REGISTER
0020		115	CSR EQU 20H ; OUTPUT PORT FOR COMMAND STATUS REGISTER
0054		116	DDISP EQU 04H ; CONTROL CHARACTER TO INDICATE OUTPUT TO
		117	; /DATA FIELD OF DISPLAY
0001		118	DOT EQU 1 ; INDICATOR FOR DOT IN DISPLAY
0000		119	DSPLY EQU 000H ; ADDRESS FOR SENDING CHARACTERS TO DISPLAY
0001		120	DTFLD EQU 1 ; INDICATES USE OF DATA FIELD OF DISPLAY
0000		121	EMPTY EQU 00H ; HIGH ORDER 1 INDICATES EMPTY INPUT BUFFER
20E9		122	MNSTK EQU RAMST + 256 - RMUSE ; START OF MONITOR STACK
0000		123	NODOT EQU 0 ; INDICATOR FOR NO DOT IN DISPLAY
		124	; NUMAC - DEFINED LATER ; NUMBER OF COMMANDS
		125	; NUMARG - DEFINED LATER ; NUMBER OF REGISTER SAVE LOCATIONS
0010		126	PERIOD EQU 10H ; PERIOD FROM KEYBOARD
00FD		127	PROMPT EQU 0A0H ; PROMPT CHARACTER FOR DISPLAY (DASH)
000E		128	UNMSK EQU 0EH ; UNMASK INPUT INTERRUPT
20C8		129	USRER EQU RAMST + 256 - (RMUSE + SKLH + USPLN) ; START OF USER
		130	; /BRANCH LOCATIONS
		131	;
		132	; ***** PUBLIC SYMBOLS FOR PROGRAM LINKAGE
		133	;
		134	PUBLIC CO, CI, RKBD, DISP1, CNVBN, HEXASC, MSEC14
		135	PUBLIC DELAY, SECDT, MSEC24, MSEC20, OUTPT, GO, MONITR
		136	;
		137	EXTRN INTRPT
		138	;
		139	*****
		140	;
		141	;
		142	;
		143	*****
		144	;
		145	TRUE MACRO WHERE ; BRANCH IF FUNCTION RETURNS TRUE
		146	JC WHERE
		147	ENDM
		148	;
		149	FALSE MACRO WHERE ; BRANCH IF FUNCTION RETURNS FALSE
		150	JNC WHERE
		151	ENDM
		152	;
		153	;
		154	*****
		155	;
		156	;
		157	;
		158	*****
		159	;
		160	THE USART IS ASSUMED TO COME UP IN THE RESET POSITION (THIS
		161	FUNCTION IS TAKEN CARE OF BY THE HARDWARE). THE USART WILL
		162	BE INITIALIZED IN THE SAME WAY FOR EITHER TTY OR CRT
		163	INTERFACE. THE FOLLOWING PARAMETERS ARE USED:
		164	;

```

LOC 0000      LINE      SOURCE STATEMENT
              165 :      MODE INSTRUCTION
              166 :      =====
              167 ;
              168 ;      2 STOP BITS
              169 ;      PARITY DISABLED
              170 ;      8 BIT CHARACTERS
              171 ;      BAUD RATE FACTOR OF 64
              172 ;
              173 ;      COMMAND INSTRUCTION
              174 ;      =====
              175 ;
              176 ;      NO HUNT MODE
              177 ;      NOT(RTS) FORCED TO 0
              178 ;      RECIEVE ENABLED
              179 ;      TRANSHIT ENABLED
              180 ;
              181 ; *****
              182 ;
              183 ; PRO-LOG KEYBOARD LAYOUT
              184 ;
              185 ; 14 - TTY 15 - SNGL 16 - **** 17 - EXAM  RESET
              186 ;      MON      STEP      PECS  SYSTEM
              187 ; -----
              188 ;
              189 ;      C      D      E      F-FLAG      I 12 - SUSS
              190 ;
              191 ;
              192 ;      8 - H  9 - L  A      B      I 12 - GO
              193 ;
              194 ;
              195 ;      4 - SPH 5 - SPL 6 - PCH 7 - PCL I 11 - , - MEVT
              196 ;
              197 ;
              198 ;      0      1      2      3      I 10 - . - EVEC
              199 ;
              200 ;
              201 ; *****
              202 ;
              203 ;
              204 ; ***** "RESET" KEY ENTRY POINT - COLD START
              205 ; ***** RST 0 ENTRY POINT
              206 ;
0000          207 ORG 0
              208 MONTR: ; MONITOR ENTRY POINT
0000 0030      209 INITUT: MVI A,0 ; CLEAR ACCUMULATOR
              210 ;
              211 ; *****
              212 ;
0002 00001      213 JMP CLDST ; GO FINISH COLD START
              214 CLDRK: ; THEN JUMP BACK HERE
0005 000F0      215 JMP RES10 ; SKIP OVER WARM START CODE
              216 ;
              217 ; ***** RST 1 ENTRY POINT - WARM START
              218 ;
0008          219 ORG 8
    
```

```

    220 :          SAVE REGISTERS
0009 22E7D0 221 SHLD LSHV ; SAVE H & L REGISTERS
0009 E1 222 POP H ; GET USER PROGRAM COUNTER FROM TOP OF STACK
000C 22F2D0 223 SHLD PSHV ; /AND SAVE IT
000F F3 224 PUSH PSW
225 ; ***** 010H IS RST 2 ENTRY POINT (NOT USED)
0010 E1 226 POP H ; LOAD R/F/F'S INTO HL
0014 22EDD0 227 SHLD FSHV ; SAVE FLIP, FLOPS & REGISTER A
0014 210000 228 LXI H,0 ; CLEAR H & L
0017 39 229 DAD SP ; GET USER STACK POINTER
230 ; ***** 018H IS RST 3 ENTRY POINT (NOT USED)
0019 22F4D0 231 SHLD SSHV ; /AND SAVE IT
0019 21E7D0 232 LXI H,BSAV+1 ; SET STACK POINTER FOR SAVING
001E F9 233 SPHL ; /REMAINING REGISTERS
001F 05 234 PUSH B ; SAVE B & C
235 ; ***** 020H IS RST 4 ENTRY POINT (NOT USED)
0020 75 236 PUSH D ; SAVE D & E
0021 02F7D0 237 JMP RESET0 ; LEAVE ROOM FOR VECTORED INTERRUPTS
238 ;
239 ; *****
240 ;
241 ; ***** TRAP ENTRY POINT
242 ;
0024 243 ORG 24H
0024 039107 244 JMP TRAPR
245 ;
246 ; ***** RST 5 ENTRY POINT
247 ;
0028 248 ORG 28H
0028 039207 249 JMP RESET5 ; RST 5 JMP VECTOR
250 ;
251 ; ***** RST 5.5 ENTRY POINT
252 ;
002C 253 ORG 2CH
002C 013000 E 254 CALL INTPT ; CALL SERVICE ROUTINE
002F 09 255 RET ; RETURN TO CODE WHERE INTERRUPT HAPPENED
256 ;
257 ; ***** RST 6 ENTRY POINT
258 ;
0020 259 ORG 20H
0020 039107 260 JMP RESET6 ; RST 6 JMP VECTOR
261 ;
262 ; ***** RST 6.5 ENTRY POINT
263 ;
0024 264 ORG 24H
0024 039107 265 JMP RESET65 ; RST 6.5 JMP VECTOR
266 ;
267 ; ***** RST 7 ENTRY POINT
268 ;
0028 269 ORG 28H
0028 039107 270 JMP RESET7 ; RST 7 JMP VECTOR
271 ;
272 ; ***** RST 7.5 ENTRY POINT
002C 273 ORG 2CH
002C 039107 274 JMP RESET75 ; RST 7.5 JMP LOCATION
    
```


ORIGINAL PAGE IS
OF POOR QUALITY

1513-11 8090/8095 MACRO ASSEMBLER, V2.0 MONTR PAGE 6

```

275 ;
276 ;*****
277 ;
278 RES10: ; CONTINUE SAVING USER STATUS
003F 29 279 RIM ; GET USER INTERRUPT STATUS AND INTERRUPT MASK
0040 E60F 280 ANI 0FH ; KEEP STATUS AND MASK BITS
0042 32F120 281 STA ISAV ; SAVE INTERRUPT STATUS AND MASK
0045 3E0E 282 MVI A,UNMSK ; UNMASK INTERRUPTS FOR MONITOR USE
0047 30 283 SIM
0048 F3 284 DI ; INTERRUPTS DISABLED WHILE MONITOR IS RUNNING
285 ; (EXCEPT WHEN WAITING FOR INTERRUPT)
286 ; CHECK FOR 7303 INSTALLATION
0049 D800 287 IN 000H ; READ S1,S2
004B E6C0 288 ANI 0C0H ; KEEP UPPER TWO BITS
004D 47 289 MOV B,A ; SAVE BITS
004E E680 290 ANI 080H
0050 C20040 291 JNZ 4000H ; IF 8 BIT ON GO TO PROGRAM
0053 78 292 MOV A,B ; GET BITS BACK
0054 E640 293 ANI 040H
0056 C20010 294 JNZ 1000H ; IF BIT 7 ON GO TO PPLOG MONITOR AT 1000H
295 ;
0059 C09703 296 CALL MSEC2H ; CALL 200 MSEC DELAY
297 ;
298 ;*****
299 ;
300 ; BEGINNING OF KEYBOARD MONITOR CODE
301 ;
302 ;*****
303 ;
005C C0C001 304 CALL CLEAR
005F 3E50 305 MVI A,00H ; LOAD BUFFER EMPTY FLAG
0061 32FE20 306 STA Ibuff ; SET INPUT BUFFER EMPTY FLAG
307 ;
308 ;*****
309 ;
310 ; FUNCTION: CMND - COMMAND RECOGNIZER
311 ; INPUTS: NONE
312 ; OUTPUTS: NONE
313 ; CALLS: RDKBD,ERR,SUBST,EXPL,C0C7D,SSTEP
314 ; DESTROYS: A,B,C,D,E,H,L,F/S
315 ;
316 CMND:
0064 21E920 317 LXI H,MISTK ; INITIALIZE MONITOR STACK POINTER
0067 F9 318 SPHL ; HL TO STACK POINTER STORE
0068 21F303 319 LXI H,RDVTBL ; LOAD ADDRESS OF READY MESSAGE TO HL
006B 9E00 320 MVI C,8 ; LOAD C WITH CHARACTER COUNT
006D C09E02 321 CALL OUTPT ; DISPLAY MESSAGE
322 ; READ KEYBOARD FUNCTION KEYS
0070 3E9F 323 MVI A,0FH ; 00001111
0072 D3D0 324 OUT 000H ; OUTPUT TO D0
0074 0E00 325 MKEY: IN 000H ; INPUT FROM D0
0076 E630 326 ANI 070H ; AND IN A 0011000
0078 C97400 327 JZ MKEY ; LOOP BACK IF NO KEY PRESSED
007F C0C001 328 CALL CLEAR ; CLEAR DISPLAY
007E C0C002 329 MONRDK: CALL RDKBD ; READ KEYBOARD

```

ORIGINAL PAGE IS
OF POOR QUALITY

```

LOC  OBJ      LINE      SOURCE STATEMENT
0081  210500    330  LXI B,NUMC ; COUNTER FOR NUMBER OF COMMANDS IN C
0084  21E502    331  LXI H,CMDTB ; GET ADDRESS OF COMMAND TABLE
                                332  CMD10:
0087  5E        333  CNP M ; RECOGNIZE COMMAND ?
0089  0A9300    334  JZ CMD15 ; YES - GO PROCESS IT
008B  23        335  INX H ; NO - NEXT COMMAND TABLE ENTRY
008C  00        336  DCR C ; END OF TABLE
008D  C28700    337  JNZ CMD10 ; NO - GO CHECK NEXT ENTRY
                                338  ; YES - COMMAND UNKNOWN
0090  03FF01    339  JMP ERR ; DISPLAY ERROR MESSAGE AND GET ANOTHER COMMAND
                                340  CMD15:
0093  21E803    341  LXI H,CMDAD ; GET ADDRESS OF COMMAND ADDRESS TABLE
0096  00        342  DCR C ; ADJUST COMMAND COUNTER
                                343  ; COUNTER ACTS AS POINTER TO COMMAND ADDRESS TABLE
0097  09        344  DAD B ; ADD POINTER TO TABLE ADDRESS TWICE BECAUSE
0099  09        345  DAD B ; TABLE HAS 2 BYTE ENTRIES
0099  7E        346  MOV A,M ; GET LOW ORDER BYTE OF COMMAND ADDRESS
009A  23        347  INX H
009B  56        348  MOV H,M ; GET HIGH ORDER BYTE OF COMMAND ADDRESS IN H
009C  5F        349  MOV L,A ; PUT LOW ORDER BYTE IN L
                                350  ; COMMAND ROUTINE ADDRESS IS NOW IN H & L
009D  E3        351  PCHL ; BRANCH TO ADDRESS IN H & L BY LOADING PC
                                352 ;
                                353 ; *****
                                354 ;
                                355 ;             COMMAND ROUTINES
                                356 ;
                                357 ; *****
                                358 ;
                                359 ; FUNCTION: EXAM - EXAMINE AND MODIFY REGISTERS
                                360 ; INPUTS: NONE
                                361 ; OUTPUTS: NONE
                                362 ; CALLS: CLEAR, SETRG, ERR, RGNAM, RGLOC, UPDT, GTHEX, NTRG
                                363 ; DESTROYS: A, B, C, D, E, H, L, F/F'S
                                364 ;
                                365 EXAM:
009E  C0C001    366  CALL CLEAR ; CLEAR DISPLAY
00A1  21E803    367  LXI H,MSG ; DISPLAY EXAMINE MESSAGE
00A4  0E04      368  MVI C,4
00A6  C09E02    369  CALL OUTPT
00A9  C05403    370  CALL SETRG ; GET REGISTER DESIGNATOR FROM KEYBOARD AND
                                371  ; /SET REGISTER POINTER ACCORDINGLY
                                372  ; WAS CHARACTER A REGISTER DESIGNATOR ?
                                373  FALSE ERR ; NO - DISPLAY ERROR MSG AND TERMINATE COMMAND
00AC  02FF01    374+ JNC ERR
                                375 EXMG5:
00AF  001A03    376  CALL RGNAM ; OUTPUT REGISTER NAME TO ADDRESS FIELD
00B2  C08003    377  CALL RGLOC ; GET REGISTER SAVE LOCATION IN H & L
00B5  7E        378  MOV A,M ; GET REGISTER CONTENTS
00B6  32F800    379  STA CURDT ; STORE REGISTER CONTENTS AT CURRENT DATA
00B9  C07C03    380  CALL UPDT ; UPDATE DATA FIELD OF DISPLAY
00BC  0E01      381  MVI B,DTFLD ; ARG - USE DATA FIELD OF DISPLAY
00BE  C08002    382  CALL GTHEX ; GET HEX DIGITS - WERE ANY DIGITS RECEIVED?
                                383  FALSE EXML0 ; NO - DO NOT UPDATE REGISTER CONTENTS
00C1  02C800    384+ JNC EXML0

```

ORIGINAL PAGE IS
OF POOR QUALITY

1515-11 6080/3085 MACRO ASSEMBLER V3.0 MONTR PAGE 2

LOC	OBJ	LINE	SOURCE STATEMENT
0004	CD0003	385	CALL RGLOC ; YES - GET REGISTER SAVE LOCATION IN H & L
0007	7D	386	MOV R6,E ; UPDATE REGISTER CONTENTS
		387	EXM10:
0008	FE10	388	CPI PERIO ; WAS LAST CHARACTER A PERIOD ?
000A	CD0601	389	JZ CLDIS ; YES - CLEAR DISPLAY AND TERMINATE COMMAND
000D	FE11	390	CPI COMMA ; WAS LAST CHARACTER ',' ?
000F	C2FF01	391	JNZ ERR ; NO - DISPLAY ERROR MSG. AND TERMINATE COMMAND
0002	CD0F02	392	CALL IXTRG ; YES - ADVANCE REGISTER POINTER TO
		393	; /NEXT REGISTER
		394	; ANY MORE REGISTERS ?
		395	TRUE EXM05 ; YES - CONTINUE PROCESSING WITH NEXT REGISTER
0005	DAAF00	396+	JC EXM05
0008	CD0601	397	JMP CLDIS ; NO - CLEAR DISPLAY AND TERMINATE COMMAND
		398	;
		399	*****
		400	;
		401	; FUNCTION: G0CMD - EXECUTE USER PROGRAM
		402	; INPUTS: NONE
		403	; OUTPUTS: NONE
		404	; CALLS: DISPC, RDKBD, CLEAR, GTHEX, SPP, OUTPT
		405	; DESTROYS: A, B, C, D, E, H, L, F/F'S
		406	;
		407	G0CMD:
0008	CD0E01	408	CALL DISPC ; DISPLAY USER PROGRAM COUNTER
000E	CD0002	409	CALL RDKBD ; READ FROM KEYBOARD
0011	FE10	410	CPI PERIO ; IS CHARACTER A PERIOD ?
0013	CAFA00	411	JZ G10 ; YES - GO EXECUTE THE COMMAND
		412	; NO - ARG - CHARACTER IS STILL IN A
0015	32FE20	413	STA IBUFF ; REPLACE CHARACTER IN INPUT BUFFER
0019	CD0001	414	CALL CLEAR ; CLEAR DISPLAY
001C	0300	415	MVI B, R0FLD ; ARG - USE ADDRESS FIELD
001E	CD0002	416	CALL GTHEX ; GET HEX DIGITS
0021	FE10	417	CPI PERIO ; WAS LAST CHARACTER A PERIOD ?
0023	C2FF01	418	JNZ ERR ; NO - DISPLAY ERROR MSG. AND TERMINATE COMMAND
0025	EB	419	XCHG ; PUT HEX VALUE FROM GTHEX TO H & L
0027	22F320	420	SHLD PSRV ; HEX VALUE IS NEW USER PC
		421	G10:
002A	CD0D01	422	CALL CLEAR ; CLEAR DISPLAY
002D	21E703	423	LXI H, EXMSG ; GET ADDRESS OF EXECUTION MESSAGE IN H & L
0028	0E04	424	MVI C, 4 ; LOAD C WITH COUNT OF 4
002C	CD0E02	425	CALL OUTPT ; DISPLAY EXECUTION MESSAGE
0025	C32B03	426	JMP RSTOR ; RESTORE USER REGISTERS INCL. PROGRAM COUNTER
		427	; /I. E. BEGIN EXECUTION OF USER PROGRAM
		428	;
		429	*****
		430	;
		431	; FUNCTION SSTEP - SINGLE STEP (EXECUTE ONE USER INSTRUCTION)
		432	; INPUTS: NONE
		433	; OUTPUTS: NONE
		434	; CALLS: DISPC, RDKBD, CLEAR, GTHEX, SPP
		435	; DESTROYS: A, B, C, D, E, H, L, F/F'S
		436	;
		437	SSTEP:
0028	CD0E01	438	CALL DISPC ; DISPLAY USER PROGRAM COUNTER
0028	CD0002	439	CALL RDKBD ; READ FROM KEYBOARD

ORIGINAL PAGE IS
OF POOR QUALITY

IS15-11 8080/8085 MACRO ASSEMBLER, V3.0

MONITOR PAGE 2

LOC	OBJ	LINE	SOURCE STATEMENT
010E	FE10	440	CPI PERIO ; WAS CHARACTER A PERIOD ?
0110	CPD501	441	JZ CLDIS ; YES - CLEAR DISPLAY AND TERMINATE COMMAND
0113	FE11	442	CPI COMMA ; WAS LAST CHARACTER A COMMA ?
0115	CR2001	443	JZ STP20 ; YES - GO SET TIMER
		444	; NO - CHARACTER FROM KEYBOARD WAS NIETER PERIOD OR COMMA
0118	32FE20	445	STA Ibuff ; REPLACE THE CHARACTER IN THE INPUT BUFFER
011B	CD0D01	446	CALL CLEAR ; CLEAR DISPLAY
011E	CD0D02	447	CALL GTHex ; GET HEX DIGITS - WERE ANY DIGITS RECEIVED ?
		448	FALSE ERR ; NO - DISPLAY ERROR MSG. AND TERMINATE COMMAND
0121	D2FF01	449+	JNC ERR
0124	EB	450	XCHG ; HEX VALUE FROM GTHex TO H & L
0125	22F220	451	SHLD PSW ; HEX VALUE IS NEW USER PC
0128	FE10	452	CPI PERIO ; WAS LAST CHARACTER FROM GTHex A PERIOD ?
012A	CRD601	453	JZ CLDIS ; YES - CLEAR DISPLAY AND TERMINATE COMMAND
		454	; NO - MUST HAVE BEEN A COMMA
		455	STP20:
012D	3AF120	456	LDA ISW ; GET USER INTERRUPT MASK
0130	E500	457	ANI 00H ; KEEP INTERRUPT STATUS
0132	32FD20	458	STA TEMP ; SAVE USER INTERRUPT STATUS IN TEMP
0135	2AF220	459	LHLD PSW ; GET USER PC
0138	7E	460	MOV R,M ; GET USER INSTRUCTION
0139	FEF3	461	CPI (DI) ; DI INSTRUCTION ?
013B	C24201	462	JNZ STP21 ; NO
013E	AF	463	MVA R ; YES - RESET USER INTERRUPT STATUS
013F	C34901	464	JMP STP22
		465	STP21:
0142	FEF8	466	CPI (EI) ; EI INSTRUCTION ?
0144	C24C01	467	JNZ STP23 ; NO
0147	3E00	468	MVI R,00H ; YES - SET USER INTERRUPT STATUS
		469	STP22:
0149	32FD20	470	STA TEMP ; SAVE NEW USER INTERRUPT STATUS
		471	STP23:
014C	C32B03	472	JMP RSTOR ; RESTORE USER REGISTERS
		473	;
		474	STP25 ; BRANCH HERE WHEN TIMER INTERRUPTS AFTER
		475	; /ONE USER INSTRUCTION
014F	F5	476	PUSH PSW ; SAVE PSW
0150	3AFF20	477	LDA USCSR ; GET USER IMAGE OF WHAT'S IN CSR
0153	E53F	478	ANI 3FH ; CLEAR 2 HIGH ORDER BITS
0155	F1	479	POP PSW ; RETRIEVE PSW
0156	22EF20	480	SHLD LSW ; SAVE H & L
0159	E1	481	POP H ; GET USER PROGRAM COUNTER FROM TOP OF STACK
015A	22F220	482	SHLD PSW ; SAVE USER PC
015D	F5	483	PUSH PSW
015E	E1	484	POP H
015F	22ED20	485	SHLD PSW ; SAVE FLIP/FLOPS AND A REGISTER
0162	210000	486	LXI H,0 ; CLEAR H & L
0165	29	487	DAD SP ; GET USER STACK POINTER
0166	22FA20	488	SHLD SSW ; SAVE USER STACK POINTER
0169	21ED20	489	LXI H,SSW+1 ; SET MONITOR STACK POINTER FOR
016C	F9	490	SPHL ; /SAVING REMAINING USER REGISTERS
016D	C5	491	PUSH B ; SAVE B & C
016E	D5	492	PUSH D ; SAVE D & E
016F	29	493	RIM ; GET USER INTERRUPT MASK
0170	E507	494	ANI 07H ; KEEP MASK BITS

ORIGINAL PAGE IS
OF POOR QUALITY

LOC	OBJ	LINE	SOURCE STATEMENT
0172	21F020	495	LXI H,TEMP ; GET USER INTERRUPT STATUS
0175	86	496	ORA M ; OR IT INTO MASK
0176	32F120	497	STA ISAV ; SAVE INTERRUPT STATUS AND MASK
0179	3E8E	498	MVI A,UNMSK ; UNMASK INTERRUPTS FOR MONITOR USE
017B	30	499	SIM
017C	C30801	500	JMP SSTEP ; GO GET READY FOR ANOTHER INSTRUCTION
		501 ;	
		502 ;	*****
		503 ;	
		504 ;	FUNCTION: SUBST - SUBSTITUTE MEMORY
		505 ;	INPUTS: NONE
		506 ;	OUTPUTS: NONE
		507 ;	CALLS: CLEAR, GTHEX, UPDAD, UPDDT, EPR
		508 ;	DESTROYS: A, B, C, D, E, H, L, F, F'S
		509 ;	
		510	SUBST:
017F	C0C001	511	CALL CLEAR ; CLEAR THE DISPLAY
0192	21EF01	512	LXI H,MSG ; DISPLAY SUBSTITUTE MESSAGE
0185	0E04	513	MVI C,4
0187	C09E82	514	CALL OUTPT
018A	C00002	515	CALL GTHEX ; GET HEX DIGITS - WERE ANY DIGITS RECEIVED ?
		516	FALSE EPR ; NO - DISPLAY ERROR MSG. AND TERMINATE COMMAND
018D	D2FF01	517+	JNC ERR
0190	EB	518	XCHG ; ASSIGN HEX VALUE RETURNED BY GTHEX TO
0191	22FE20	519	SHLD CURAD ; / CURRENT ADDRESS
		520	SUB05:
0194	FE11	521	CPI COMMA ; WAS ',' THE LAST CHARACTER FROM KEYBOARD ?
0196	C2C501	522	JNZ SUB15 ; NO - GO TERMINATE THE COMMAND
0199	0E00	523	MVI B,NODOT ; ARG - NO DOT IN ADDRESS FIELD
019B	C06F03	524	CALL UPDAD ; UPDATE ADDRESS FIELD OF DISPLAY
019E	2AF620	525	LHLD CURAD ; GET CURRENT ADDRESS IN H & L
01A1	7E	526	MOV A,M ; GET DATA BYTE POINTED TO BY CURRENT ADDRESS
01A2	32F820	527	STA CURDT ; STORE DATA BYTE AT CURRENT DATA
01A5	C07C03	528	CALL UPDDT ; UPDATE DATA FIELD OF DISPLAY
01A8	0601	529	MVI B,DTFLD ; ARG - USE DATA FIELD
01AA	C08D02	530	CALL GTHEX ; GET HEX DIGITS - WERE ANY HEX DIGITS RECEIVED ?
01AD	F5	531	PUSH PSW ; (SAVE LAST CHARACTER)
		532	FALSE SUB10 ; NO - LEAVE DATA UNCHANGED AT CURRENT ADDRESS
01AE	D2BA01	533+	JNC SUB10
01B1	2AF620	534	LHLD CURAD ; YES - GET CURRENT ADDRESS IN H & L
01B4	73	535	MOV M,E ; STORE NEW DATA AT CURRENT ADDRESS
		536	; MAKE SURE DATA WAS ACTUALLY STORED IN CASE
		537	;/CURRENT ADDRESS IS IN ROM OR IS NON-VOLITILE
01B5	78	538	MOV A,E ; DATA TO A FOR COMPARISON
01B6	BE	539	CMP M ; WAS DATA STORED CORRECTLY
01B7	C2FF01	540	JNZ ERR ; NO - DISPLAY ERROR MSG. AND TERMINATE COMMAND
		541	SUB10:
01BA	2AF620	542	LHLD CURAD ; INCREMENT CURRENT ADDRESS
01BD	23	543	INX H
01BE	22FE20	544	SHLD CURAD
01C1	F1	545	POP PSW ; RETRIEVE LAST CHARACTER
01C2	C39401	546	JMP SUB05 ;
		547	SUB15:
01C5	FE10	548	CPI PERIO ; WAS LAST CHARACTER A PERIOD ?
01C7	C2FF01	549	JNZ ERR ; NO - DISPLAY ERROR MSG. AND TERMINATE COMMAND

```

LOC 081      LINE      SOURCE STATEMENT
010A 020601   550 JMP CLDIS ; YES - CLEAR DISPLAY AND TERMINATE COMMAND
              551 ;
              552 ;
              553 ;*****
              554 ;
              555 ;           UTILITY ROUTINES
              556 ;
              557 ;*****
              558 ;
              559 ; FUNCTION: CLEAR - CLEAR DISPLAY
              560 ; INPUTS: NONE
              561 ; OUTPUTS: NONE
              562 ; CALLS: OUTPT
              563 ; DESTROYES: A, B, C, D, E, H, L, F/F'S
              564 ; DESCRIPTION: CLEAR SENDS BLANK CHARACTERS TO BOTH THE ADDRESS FIELD
              565 ;           AND THE DATA FIELD OF THE DISPLAY. IF THE DOT FLAG IS
              566 ;           SET THEN A DOT WILL APPEAR AT THE RIGHT EDGE OF THE
              567 ;           ADDRESS FIELD
              568 ;
              569 CLEAR:
0100 210803   570 LXI H, BLANKS ; ARG - ADDRESS OF BLANKS FOR DISPLAY
0100 0E08     571 MVI C, 8 ; LOAD C WITH CHARACTER COUNT
01D2 0D9E02   572 CALL OUTPT ; OUTPUT BLANKS TO ADDRESS FIELD
01D5 09      573 RET ; RETURN
              574 ;
              575 ;*****
              576 ;
              577 ; FUNCTION: CLDIS - CLEAR DISPLAY AND TERMINATE COMMAND
              578 ; INPUTS: NONE
              579 ; OUTPUTS: NONE
              580 ; CALLS: CLEAR
              581 ; DESTROYES: A, B, C, D, E, H, L, F/F'S
              582 ; DESCRIPTION: CLDIS IS JUMPED TO BY COMMAND ROUTINES WISHING TO
              583 ;           TERMINATE NORMALLY. CLDIS CLEARS THE DISPLAY AND
              584 ;           BRANCHES TO THE COMMAND RECOGNIZER.
              585 ;
              586 CLDIS:
01D6 0C0D01   587 CALL CLEAR ; CLEAR THE DISPLAY
01D9 036400   588 JMP CMND / GO GET ANOTHER COMMAND
              589 ;
              590 ;*****
              591 ;
              592 ; FUNCTION: CLDST - COLD START
              593 ; INPUTS: NONE
              594 ; OUTPUTS: NONE
              595 ; CALLS: NOTHING
              596 ; DESTROYES: A
              597 ; DESCRIPTION: CLDST IS JUMPED TO BY THE MAIN COLD START PROCEDURE
              598 ;           COMPLETES THE COLD START INITIALIZATION,
              599 ;           AND JUMPS BACK TO THE MAIN COLD START PROCEDURE.
              600 ;
              601 CLDST:
01DC 3E90     602 MVI A, URTPC ; LOAD UART PORT CONTROL BYTE
01DE 0200     603 OUT CONCP ; OUTPUT PORT CONTROL BYTE
01E9 3E93     604 MVI A, URTPC ; LOAD UART SYSTEM CONTROL BYTE

```

ORIGINAL PAGE IS
OF POOR QUALITY

IS15-II 6060/6065 MACRO ASSEMBLER, V3.0

MONITOR PAGE 10

LSC OBJ	LINE	SOURCE STATEMENT
01E2 03DE	605	OUT CONSCP ; OUTPUT SYSTEM CONTROL BYTE TO SYSTEM PORT
	606	;
01E4 21E920	607	LXI H, MNSTK ; LOAD HL WITH STACK START ADDRESS
01E7 F9	608	SPHL ; STACK POINTER SET UP
	609	;
01E8 030500	610	JMP CLDBK ; BACK TO MAIN PROCEDURE
	611	;
	612	*****
	613	;
	614	FUNCTION: DISPC - DISPLAY PROGRAM COUNTER
	615	INPUTS: NONE
	616	OUTPUTS: NONE
	617	CALLS: UPDAD, UPDDT
	618	DESTROYES: A, B, C, D, E, H, L, F/F'S
	619	DESCRIPTION: DISPC DISPLAYS THE USER PROGRAM COUNTER IN THE ADDRESS
	620	FIELD OF THE DISPLAY, WITH A DOT AT THE RIGHT EDGE
	621	OF THE FIELD. THE BYTE OF DATA ADDRESSED BY THE PROGRAM
	622	COUNTER IS DISPLAYED IN THE DATA FIELD OF THE DISPLAY.
	623	;
	624	DISPC:
01EB 00DD01	625	CALL CLEAR ; CLEAR DISPLAY
01EE 2AF220	626	LHLD PSRV ; GET USER PROGRAM COUNTER
01F1 22F620	627	SHLD CURAD ; MAKE IT THE CURRENT ADDRESS
01F4 7E	628	MOV A, M ; GET THE INSTRUCTION AT THAT ADDRESS
01F5 32F820	629	STA CURDT ; MAKE IT THE CURRENT DATA
01F8 06F03	630	CALL UPDAD ; UPDATE ADDRESS FIELD OF DISPLAY
01FB 0D703	631	CALL UPDDT ; UPDATE DATA FIELD OF DISPLAY
01FE 09	632	RET ; RETURN
	633	;
	634	*****
	635	;
	636	FUNCTION: ERR - DISPLAY ERROR MESSAGE
	637	INPUTS: NONE
	638	OUTPUTS: NONE
	639	CALLS: OUTPT
	640	DESTROYES: A, B, C, D, E, H, L, F/F'S
	641	DESCRIPTION: ERR IS JUMPED TO BY COMMAND ROUTINES WISHING TO
	642	TERMINATE BECAUSE OF AN ERROR.
	643	ERR OUTPUTS AN ERROR MESSAGE TO THE DISPLAY AND
	644	BRANCHES TO THE COMMAND RECOGNIZER.
	645	;
	646	ERR:
01FF 21E303	647	LXI H, ERMSG ; ARG - ADDRESS OF ERROR MESSAGE
0202 0E04	648	MVI C, 4 ; LOAD 4 COUNT
0204 0D9E02	649	CALL OUTPT ; OUTPUT ERROR MESSAGE TO ADDRESS FIELD
0207 0D9103	650	CALL SECOT ; DELAY FOR 2 SECONDS
	651	;
020A 036400	652	JMP CHMND ; GO GET A NEW COMMAND
	653	;
	654	*****
	655	;
	656	FUNCTION: GTHX - GET HEX DIGITS
	657	INPUTS: NONE
	658	OUTPUTS: A - LAST CHARACTER READ FROM KEYBOARD
	659	DE - HEX DIGITS FROM KEYBOARD EVALUATED MODULO 16

ORIGINAL PAGE IS
OF POOR QUALITY.

ISIS-II 8080/8085 MACRO ASSEMBLER, V3.0

MONTR PAGE 13

LOC	OBJ	LINE	SOURCE STATEMENT
		660 ;	CARRY - SET IF AT LEAST ONE VALID HEX DIGIT WAS READ
		661 ;	- RESET OTHERWISE
		662 ;	CALLS ROKBD, INSDG, HXDSP, OUTPT
		663 ;	DESTROYS: A, B, C, D, E, H, L, F/PS
		664 ;	DESCRIPTION: GTHX ACCEPTS A STRING OF HEX DIGITS FROM THE KEYBOARD,
		665 ;	DISPLAYS THEM AS THEY ARE RECEIVED, AND RETURNS THEIR
		666 ;	VALUE AS A 16 BIT INTEGER. IF MORE THAN 4 HEX DIGITS
		667 ;	ARE RECEIVED, ONLY THE LAST 4 ARE USED.
		668 ;	THE LAST FOUR HEXIDEcimal
		669 ;	DIGITS ARE DISPLAYED IN THE ADDRESS FIELD OF THE
		670 ;	DISPLAY. A CHARACTER WHICH IS NOT
		671 ;	A HEX DIGIT TERMINATES THE STRING AND IS RETURNED AS
		672 ;	AN OUTPUT OF THE FUNCTION. IF THE TERMINATOR IS NOT
		673 ;	A PERIOD OR A COMMA THEN ANY HEX DIGITS WHICH MAY HAVE
		674 ;	BEEN RECEIVED ARE CONSIDERED TO BE INVALID. THE
		675 ;	FUNCTION RETURNS A FLAG INDICATING WHETHER OR NOT ANY
		676 ;	VALID HEX DIGITS WERE RECEIVED.
		677 ;	
		578	GTHX:
0200	0E00	679	MVI C,0 ; RESET HEX DIGIT FLAG
020F	110000	680	LXI D,0 ; SET HEX VALUE TO ZERO
0212	05	681	PUSH B ; SAVE BC
0213	05	682	PUSH D ; SAVE HEX VALUE
		683	GTH05:
0214	0C0002	684	CALL ROKBD ; READ KEYBOARD
0217	FE10	685	CPI 10H ; IS CHARACTER A HEX DIGIT ?
0219	023702	686	JNC GTH20 ; NO - GO CHECK FOR TERMINATOR
		687	; YES - ARG - NEW HEX DIGIT IS IN A
021C	01	688	POP D ; ARG - RETRIEVE HEX VALUE
021D	008602	689	CALL INSDG ; INSERT NEW DIGIT IN HEX VALUE
0220	C1	690	POP B ; RETRIEVE DISPLAY FLAG
0221	0E01	691	MVI C,1 ; SET HEX DIGIT FLAG
		692	; / (I.E. A HEX DIGIT HAS BEEN READ)
0223	05	693	PUSH B ; SAVE BC
0224	05	694	PUSH D ; SAVE HEX VALUE
0225	78	695	MOV A,B ; TEST DISPLAY FLAG
0226	0F	696	RRC ; SHOULD ADDRESS FIELD OF DISPLAY BE USED ?
0227	023102	697	JNC GTH10 ; YES - USE HEX VALUE AS IS
		698	; NO - ONLY LOW ORDER BYTE OF HEX VALUE SHOULD
		699	; / BE USED FOR DATA FIELD OF DISPLAY
022A	53	700	MOV D,E ; PUT LOW ORDER BYTE OF HEX VALUE IN D
022B	000003	701	CALL DSPDT2
022E	031402	702	JMP GTH05
		703	GTH10:
		704	; ARG - HEX VALUE TO BE EXPANDED IS IN D & E
0231	007203	705	CALL DSPDT4 ; GO DO 2 CHARACTER OUTPUT
		706	;
0234	031402	707	JMP GTH05 ; GO GET NEXT CHARACTER
		708	GTH20:
		709	; LAST CHARACTER WAS NOT A HEX DIGIT
0237	01	710	POP D ; RETRIEVE HEX VALUE
0238	FE11	711	CPI COMMA ; WAS LAST CHARACTER A COMMA ?
023A	0A4002	712	JZ GTH25 ; YES - READY TO RETURN
023D	FE10	713	CPI PERIO ; NO - WAS LAST CHARACTER A PERIOD ?
023F	0A4002	714	JZ GTH25 ; YES - READY TO RETURN

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II 8080/8085 MACRO ASSEMBLER, V2.0 MONITR PAGE 14

LOC	OBJ	LINE	SOURCE STATEMENT
		715	; NO - INVALID TERMINATOR - IGNORE ANY HEX DIGITS READ
0242	110000	716	LXI D,0 ; SET HEX VALUE TO ZERO
0245	020903	717	JMP RETF ; RETURN FALSE
		718	GTH25:
0248	C1	719	POP B ; POP BC
0249	47	720	MOV B,A ; SAVE LAST CHARACTER
024A	79	721	MOV A,C ; SHIFT HEX DIGIT FLAG TO
024B	0F	722	RRC ; /CARRY BIT
024C	78	723	MOV A,B ; RESTORE LAST CHARACTER
024D	C9	724	RET ; RETURN
		725	;
		726	;*****
		727	;
		728	; FUNCTION: HXDSP - EXPAND HEX DIGITS FOR DISPLAY
		729	; INPUTS: DE - 4 HEX DIGITS
		730	; OUTPUTS: HL - ADDRESS OF OUTPUT BUFFER
		731	; CALLS: NOTHING
		732	; DESTROYS: A,H,L,F/Y'S
		733	; DESCRIPTION: HXDSP EXPANDS EACH INPUT BYTE TO 2 BYTES IN A FORM
		734	; SUITABLE FOR DISPLAY BY THE OUTPUT ROUTINES. EACH INPUT
		735	; BYTE IS DIVIDED INTO 2 HEX DIGITS. EACH HEX DIGIT IS
		736	; STORED IN THE OUTPUT BUFFER. THE FUNCTION RETURNS THE
		737	; ADDRESS OF THE OUTPUT BUFFER.
		738	;
		739	HXDSP:
024E	7A	740	MOV A,D ; GET FIRST DATA BYTE
024F	0F	741	RRC ; CONVERT 4 HIGH ORDER BITS
0250	0F	742	RRC ; /TO A SINGLE CHARACTER
0251	0F	743	RRC
0252	0F	744	RRC
0253	21F920	745	LXI H,OBUFF ; GET ADDRESS OF OUTPUT BUFFER
0256	0D7402	746	CALL HEXASC ; CONVERT BITS TO ASCII CODE IN A
0259	77	747	MOV M,A ; STORE CHARACTER IN OUTPUT BUFFER
025A	7A	748	MOV A,D ; GET FIRST DATA BYTE AND CONVERT 4 LOW ORDER
025B	23	749	INX H ; NEXT BUFFER POSITION
025C	0D7402	750	CALL HEXASC
025F	77	751	MOV M,A ; STORE CHARACTER IN BUFFER
0260	7B	752	HXDSP2: MOV A,E ; GET SECOND DATA BYTE
0261	0F	753	RRC ; CONVERT 4 HIGH ORDER BITS
0262	0F	754	RRC ; /TO A SINGLE CHARACTER
0263	0F	755	RRC
0264	0F	756	RRC
0265	23	757	INX H ; NEXT BUFFER POSITION
0266	0D7402	758	CALL HEXASC
0269	77	759	MOV M,A ; STORE CHARACTER IN BUFFER
026A	7B	760	MOV A,E ; GET SECOND DATA BYTE AND CONVERT LOW ORDER
026B	23	761	INX H ; NEXT BUFFER POSITION
026C	0D7402	762	CALL HEXASC
026F	77	763	MOV M,A ; STORE CHARACTER IN BUFFER
0270	21F920	764	LXI H,OBUFF ; RETURN ADDRESS OF OUTPUT BUFFER IN H & L
0273	C9	765	RET ; RETURN
		766	;
		767	;*****
		768	;
		769	; FUNCTION: HEXASC

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-11 2080/5085 MACRO ASSEMBLER V3.0 MONITR PAGE 15

LOC	OBJ	LINE	SOURCE STATEMENT
		770	; INPUTS: HEX DIGIT IN ACCUMULATOR
		771	; OUTPUTS: ASCII CODE IN A
		772	; CALLS: NOTHING
		773	; DESTROYS: A,F/F'S
		774	; DESCRIPTION: HEXASC CONVERTS A HEX NIBBLE IN A TO AN ASCII CODE
		775	;
		776	HEXASC:
0274	E60F	777	ANI 0FH ; CLEAR UPPER BITS TO ZERO
0275	FE9A	778	CPI 0AH ; TEST BITS IF A-F
0278	DA7E02	779	JC HEX05 ; JUMP IF 0-9
027B	C637	780	ADI 037H ; ADD 37 TO FORM ASCII
027D	C9	781	RET ; RETURN
		782	HEX05:
027E	F630	783	ORI 070H ; OR IN A 30 TO 0-9
0280	C9	784	RET ; RETURN
		785	;
		786	*****
		787	;
		788	; FUNCTION: ININT -- INPUT INTERRUPT PROCESSING
		789	; INPUTS: NONE
		790	; OUTPUTS: NONE
		791	; CALLS: NOTHING
		792	; DESTROYS: NOTHING
		793	; DESCRIPTION: ININT IS ENTERED BY MEANS OF AN INTERRUPT VECTOR (IV?)
		794	;
		795	ININT:
0281	E5	796	PUSH H ; SAVE H & L
0282	F3	797	PUSH PSW ; SAVE F/F'S & REGISTER A
		798	; ***** INTERRUPT CODE GOES HERE
0283	F1	799	POP PSW ; RESTORE F/F'S & REGISTER A
0284	E1	800	POP H ; RESTORE H & L
0285	C9	801	RET ; RETURN
		802	;
		803	*****
		804	;
		805	; FUNCTION: INSDG -- INSERT HEX DIGIT
		806	; INPUTS: A - HEX DIGIT TO BE INSERTED
		807	; DE - HEX VALUE
		808	; OUTPUTS: DE - HEX VALUE WITH DIGIT INSERTED
		809	; CALLS: NOTHING
		810	; DESTROYES: A,F/F'S
		811	; DESCRIPTION: INSDG SHIFTS THE CONTENTS OF D & E LEFT 4 BITS
		812	; (1 HEX DIGIT) AND INSERTS THE HEX DIGIT IN THE LOW
		813	; ORDER DIGIT POSITION OF THE RESULT. A IS ASSUMED TO
		814	; CONTAIN A SINGLE HEX DIGIT IN THE LOW ORDER 4 BITS AND
		815	; ZEROS IN THE HIGH ORDER 4 BITS.
		816	;
		817	INSDG:
0286	EB	818	XCHG ; PUT D & E IN H & L
0287	29	819	DAD H ; SHIFT H & L LEFT 4 BITS
0288	29	820	DAD H
0289	29	821	DAD H
028A	29	822	DAD H
028B	95	823	ADD L ; INSERT LOW ORDER DIGIT
028C	6F	824	MOV L,A ; BY ADDING L+A = A

```

LOC OBJ      LINE      SOURCE STATEMENT
029D EB      825  MCHG ; PUT H & L BACK IN D & E
029E C9      826  RET ; RETURN
827 ;
828 ; *****
829 ;
830 ; FUNCTION: NXTRG - ADVANCE REGISTER POINTER TO NEXT REGISTER
831 ; INPUTS: NONE
832 ; OUTPUTS: CARRY - 1 IF POINTER IS ADVANCED SUCCESSFULLY
833 ;           - 0 OTHERWISE
834 ; CALLS: NOTHING
835 ; DESTROYS: A, F/F'S
836 ; DESCRIPTION: IF THE REGISTER POINTER POINTS TO THE LAST REGISTER IN
837 ;               THE EXAMINE REGISTER SEQUENCE, THE POINTER IS NOT
838 ;               CHANGED AND THE FUNCTION RETURNS FALSE. IF THE REGISTER
839 ;               POINTER DOES NOT POINT TO THE LAST REGISTER THEN THE
840 ;               POINTER IS ADVANCED TO THE NEXT REGISTER IN THE SEQUENCE
841 ;               AND THE FUNCTION RETURNS TRUE.
842 ;
843 NXTRG:
029F 3AFD20   844  LDA ROPTR ; GET REGISTER POINTER
02A2 FE0C    845  CPI NUMRG-1 ; DOES POINTER POINT TO LAST REGISTER ?
0294 D20803  846  JNC RETF ; YES - UNABLE TO ADVANCE POINTER - RETURN FALSE
0297 3C      847  INR R ; NO - ADVANCE REGISTER POINTER
0298 32FD20   848  STA ROPTR ; SAVE REGISTER POINTER
0298 C30E03   849  JMP RETT ; RETURN TRUE
850 ;
851 ; *****
852 ;
853 ; FUNCTION: OUTPT - OUTPUT CHARACTERS TO DISPLAY
854 ; INPUTS:
855 ;       C - CHARACTER COUNT
856 ;       HL - ADDRESS OF CHARACTERS TO BE OUTPUT
857 ; CALLS: NOTHING
858 ; DESTROYS: A, B, C, D, E, H, L, F/F'S
859 ; DESCRIPTION: OUTPT SENDS CHARACTERS TO THE DISPLAY. THE ADDRESS
860 ;               OF THE CHARACTERS IS RECEIVED AS AN ARGUMENT
861 ;
862 OUTPT:
029E 1507    863  MVI E, 7 ; CLEAR E TO 7 FOR ZERO CHARACTER POSITION
02A0 56      864  OUT05: MOV D, H ; LOAD CHARACTER IN (HL)
02A1 CDAB02  865  CALL DISP1 ; CALL DISPLAY ROUTINE FOR 1 CHARACTER
02A4 1D      866  DCR E ; DECREMENT E FOR POSITION COUNT
02A5 23      867  INX H ; INCREMENT ADDRESS REGISTER HL TO NEXT CHARACTER
02A6 00      868  DCR C ; DECREMENT CHARACTER COUNT
02A7 C2A002  869  JNZ OUT05 ; LOOP BACK IF NOT DONE DISPLAY
02AA C9      870  RET ; RETURN
871 ; *****
872 ; PRO-LOG 7303 DISPLAY OUTPUT CODE
02A8 7A      873  DISP1: MOV A, D ; OUTPUT DISPLAY DATA
02AC F680    874  ORI 080H ; TURN ON BIT 8 FOR PRO-LOG
02AE D3D0    875  OUT ED0H ; PORT D0, SEND DATA
02B0 78      876  MOV A, E ; OUTPUT DISPLAY ADDRESS, SET NOT/UP HIGH
02B1 E5F7    877  ANI 0F7H ; AND TO FORM CODE 11110111
02B3 03D1    878  OUT 0D1H ; PORT D1, SEND POSITION TO D1
02B5 78      879  MOV A, E ; SET NOT NR LCN

```

ORIGINAL PAGE IS
OF POOR QUALITY

LOC	OBJ	LINE	SOURCE STATEMENT
02B6	F608	880	ORI 06H ; OR IN A 00001000
02B8	07D1	881	OUT 0D1H ; PORT D1
02BA	78	882	MOV A,E
02BB	E6F7	883	ANI 0F7H ; AND IN A 11110111
02BD	D3D1	884	OUT 0D1H ; PORT D1
02BF	C9	885	RET ; RETURN
		886 ;	
		887 ;	*****
		888 ;	
		889 ;	FUNCTION: RDKBD - READ KEYBOARD
		890 ;	INPUTS: NONE
		891 ;	OUTPUTS: A - CHARACTER READ FROM KEYBOARD
		892 ;	CALLS: NOTHING
		893 ;	DESTROYS: R,H,L,F/S
		894 ;	DESCRIPTION: RDKBD DETERMINES WHETHER OR NOT THERE IS A CHARACTER IN
		895 ;	THE INPUT BUFFER. IF NOT, THE FUNCTION ENABLES
		896 ;	INTERRUPTS AND LOOPS UNTIL THE INPUT INTERRUPT
		897 ;	ROUTINE STORES A CHARACTER IN THE BUFFER. WHEN
		898 ;	THE BUFFER CONTAINS A CHARACTER, THE FUNCTION FLAG
		899 ;	THE BUFFER AS EMPTY AND RETURNS THE CHARACTER
		900 ;	AS OUTPUT.
		901 ;	
		902	RDKBD:
		903 ;	*****
		904 ;	PRO-LOG 7303 KEYBOARD INPUT DRIVER
02C0	D5	905	PUSH D ; SCAN KEYBOARD BY ENABLING
02C1	C5	906	PUSH B ; ONE COLUMN AT A TIME AND
		907 ;	
02C2	1688	908	MYI D,66H ; LOOKING FOR A KEY CLOSURE, 10001000
02C4	7A	909	NXTCOL: MOV A,D
02C5	07	910	RLC ; ROTATE A LEFT AND SET CARRY
02C6	57	911	MOV D,A ; SAVE SHIFTED PATTERN
02C7	E60F	912	ANI 0FH ; AND IN A 00001111
02C9	D3D0	913	OUT 0D0H ; PORT D0
02CB	06D0	914	IN 0D0H ; PORT D0
02CD	E63F	915	ANI 3FH ; AND IN A 00111111
02CF	EAC402	916	JPE NXTCOL
02D2	5F	917	MOV E,A ; LOAD E WITH INPUT
02D3	0A303	918	CALL MSEC20 ; WAIT 20 MSEC
02D6	D6D0	919	IN 0D0H ; PORT D0
02D8	E63F	920	ANI 3FH ; AND IN A 00111111
02DA	AB	921	XRA E ; EOR E INTO ACC
02DB	C2C402	922	JNZ NXTCOL ; IF NOT SAME IGNORE AND NEXT COLUMN
02DE	010000	923	LXI B,0 ; CLEAR BC
02E1	7A	924	MOV A,D ; LOAD PATTERN
02E2	1F	925	COLCNT: RAR ; CONVERT COLUMN OUTPUT TO A COUNT K
02E3	0A0A02	926	JC ROWCNT ; JUMP ON CARRY TO ROW COUNT
02E6	04	927	INR B
02E7	C3E202	928	JMP COLCNT
02EA	78	929	ROWCNT: MOV A,E ; CONVERT ROW INPUT TO A COUNT J
02EB	1F	930	RAR
02EC	0C	931	INR C
02ED	04F302	932	JC ENCODE ; JUMP ON CARRY TO ENCODE
02F0	C30A02	933	JMP ROWCNT+1
02F3	0D	934	ENCODE: DCR C ; DECREMENT REGISTER C

ORIGINAL PAGE IS
OF POOR QUALITY

1515-II 8080/8085 MACRO ASSEMBLER, V3.0

MONTR PAGE 19

LOC	OBJ	LINE	SOURCE STATEMENT
02F4	78	935	MOV A,B ; LOAD ACC WITH ROM
02F5	C9FE02	936	JZ RKEEXIT
02F9	C604	937	ADDR0W: ADI 04H ; IF J.NE.0 ADD J*M (# OF COLS)
02FA	0D	938	DCR C
02FB	C2F602	939	JNZ ADDR0W
		940	RKEEXIT:
02FE	F5	941	PUSH PSH
02FF	E5	942	PUSH H
0300	CD9703	943	CALL MSEC2H
0303	E1	944	POP H
0304	F1	945	POP PSH
0305	C1	946	POP B ; RESTORE ALL REGISTERS
0306	D1	947	POP D ; POP STACK FOR DE
0307	C9	948	RET ; RETURN
		949 ;	
		950 ;	*****
		951 ;	
		952 ;	FUNCTION: RETF - RETURN FALSE
		953 ;	INPUTS: NONE
		954 ;	OUTPUTS: CARRY = 0 (FALSE)
		955 ;	CALLS: NOTHING
		956 ;	DESTROYS: CARRY
		957 ;	DESCRIPTION: RETF IS JUMPED TO BY FUNCTIONS WISHING TO RETURN FALSE
		958 ;	RETF RESETS CARRY TO 0 AND RETURNS TO THE CALLER OF
		959 ;	THE ROUTINE INVOKING RETF.
		960 ;	
		961	RETF:
0308	37	962	STC ; SET CARRY TRUE
0309	3F	963	CMC ; COMPLEMENT CARRY TO MAKE IT FALSE
030A	C9	964	RET ; RETURN
		965 ;	
		966 ;	*****
		967 ;	
		968 ;	FUNCTION RETT - RETURN TRUE
		969 ;	INPUTS: NONE
		970 ;	OUTPUTS: CARRY = 1 (TRUE)
		971 ;	CALLS: NOTHING
		972 ;	DESTROYS: CARRY
		973 ;	DESCRIPTION: RETT IS JUMPED TO BY ROUTINES WISHING TO RETURN TRUE
		974 ;	RETT SETS CARRY TO 1 AND RETURNS TO THE CALLER OF
		975 ;	THE ROUTINE INVOKING RETT.
		976 ;	
		977	RETT:
030B	37	978	STC ; SET CARRY TRUE
030C	C9	979	RET ; RETURN
		980 ;	
		981 ;	*****
		982 ;	
		983 ;	FUNCTION: RGL0C - GET REGISTER SAVE LOCATION
		984 ;	INPUTS: NONE
		985 ;	OUTPUTS: HL - REGISTER SAVE LOCATION
		986 ;	CALLS: NOTHING
		987 ;	DESTROYS: B,C,H,L,F'S
		988 ;	DESCRIPTION: RGL0C RETURNS THE SAVE LOCATION OF THE REGISTER
		989 ;	INDICATED BY THE CURRENT REGISTER POINTER VALUE

ORIGINAL PAGE IS
OF POOR QUALITY

```

LOC OBJ      LINE      SOURCE STATEMENT
          990 ;
          991 RGLOC:
0300 2AFD20    992 LHLD RGPTR ; GET REGISTER POINTER.
0310 2600      993 MVI H,0 ; /IN H & L
0312 013004    994 LXI B,RGTBL ; GET REGISTER SAVE LOCATION TABLE ADDRESS
0315 09        995 DAD B ; POINTER INDEXES TABLE
0316 6E        996 MOV L,H ; GET LOW ORDER BYTE OF REGISTER SAVE LOC.
0317 2620      997 MVI H,(RAMPST SHR 8) ; GET HIGH ORDER BYTE OF
          998           ; /REGISTER SAVE LOCATION
0319 C9        999 RET ; RETURN
1000 ;
1001 ; *****
1002 ;
1003 ; FUNCTION: RGNAM - DISPLAY REGISTER NAME
1004 ; INPUTS: NONE
1005 ; OUTPUTS: NONE
1006 ; CALLS: OUTPT
1007 ; DESTROYS: R, B, C, D, E, H, L, F/F'S
1008 ; DESCRIPTION: RGNAM DISPLAYS, IN THE ADDRESS FIELD OF THE DISPLAY,
1009 ;                 THE REGISTER NAME CORRESPONDING TO THE CURRENT
1010 ;                 REGISTER POINTER VALUE
1011 ;
1012 RGNAM:
031A 2AFD20    1013 LHLD RGPTR ; GET REGISTER POINTER
031D 2500      1014 MVI H,0
031F 29        1015 DAD H ; MULTIPLY POINTER VALUE BY 4
0320 29        1016 DAD H ;/(REGISTER NAME TABLE HAS 4 BYTE ENTRIES)
0321 010004    1017 LXI B,NMTEL ; GET ADDRESS OF START OF REGISTER NAME TABLE
0324 09        1018 DAD B ; ARG - ADD TABLE ADDRESS TO POINTER
          1019           ; /ADDRESS OF APPROPRIATE REGISTER NAME IN H & L
0325 0E04      1020 MVI C,4
0327 CD9E02    1021 CALL OUTPY ; OUTPUT REGISTER NAME TO ADDRESS FIELD
032A C9        1022 RET ;RETURN
1023 ;
1024 ; *****
1025 ;
1026 ; FUNCTION: RSTOR - RESTOR USER REGISTERS
1027 ; INPUTS: NONE
1028 ; OUTPUTS: NONE
1029 ; CALLS: NOTHING
1030 ; DESTROYS: R, B, C, D, E, H, L, F/F'S
1031 ; DESCRIPTION: RSTOR RESTORES ALL CPU REGISTERS, FLIP/FLOPS,
1032 ;                 INTERRUPT STATUS, INTERRUPT MASK, STACK POINTER
1033 ;                 AND PROGRAM COUNTER FROM THEIR RESPECTIVE SAVE
1034 ;                 LOCATIONS IN MEMORY. BY RESTORING THE PROGRAM
1035 ;                 COUNTER, THE ROUTINE EFFECTIVELY TRANSFERS CONTROL TO
1036 ;                 THE ADDRESS IN THE PROGRAM COUNTER SAVE LOCATION.
1037 ;
1038 ;                 THE TIMING OF THIS ROUTINE IS CRITICAL TO THE
1039 ;                 CORRECT OPERATION OF THE SINGLE STEP ROUTINE.
1040 ;                 IF ANY MODIFICATION CHANGES THE NUMBER OF CPU
1041 ;                 STATES NEEDED TO EXECUTE THIS ROUTINE THEN THE
1042 ;                 TIMER VALUE MUST BE ADJUSTED BY THE SAME NUMBER.
1043 ;
1044 ; ***** THIS IS ALSO THE ENTRY POINT FOR THE TTY MONITOR

```

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II 8080/8085 MACRO ASSEMBLER, V3.0

MONITR PAGE 20

LOC	OBJ	LINE	SOURCE STATEMENT
		1045 ;	TO RESTORE REGISTERS.
		1046 ;	
		1047	RESTOR.
0328	3AF120	1048	LDA ISAV ; GET USER INTERRUPT MASK
032E	F619	1049	ORI 1SH ; ENABLE SETTING INTERRUPT MASK AND
		1050	; /RESET IV3C FLIP FLOP
0330	30	1051	SIM ; RESTORE USER INTERRUPT MASK
		1052 ;	RESTORE USER INTERRUPT STATUS
0331	3AF120	1053	LDA ISAV ; GET USER INTERRUPT MASK
0334	E608	1054	ANI 08H ; SHOULD USER INTERRUPTS BE ENABLED ?
0336	CA3D03	1055	JZ RSR05 ; NO - LEAVE INTERRUPTS DISABLED
0339	FB	1056	EI ; YES - ENABLE INTERRUPTS FOR USER PROGRAM
033A	C34103	1057	JMP RSR10
		1058	RSR05:
033D	37	1059	STC ; DUMMY INSTRUCTIONS - WHEN SINGLE STEP ROUTINE
033E	D24103	1060	JNC RSR10 ; /IS BEING USED, THE TIMER IS RUNNING AND
		1061	; /EXECUTE TIME FOR THIS ROUTINE MUST
		1062	; /VARY.
		1063	RSR10:
0341	21E920	1064	LXI H,MNSTK ; SET MONITOR STACK POINTER TO START OF STACK
0344	F9	1065	SPHL ; /WHICH IS ALSO END OF REGISTER SAVE AREA
0345	D1	1066	POP D ; RESTORE REGISTERS
0346	C1	1067	POP B
0347	F1	1068	POP PSW
0349	3AF420	1069	LHLD SSVV ; RESTORE USER STACK POINTER
034B	F9	1070	SPHL
034C	3AF220	1071	LHLD PSHV
034F	E5	1072	PUSH H ; PUT USER PROGRAM COUNTER ON STACK
0350	3AEF20	1073	LHLD LSHV ; RESTORE H & L REGISTERS
0353	C9	1074	RET ; RETURN
		1075 ;	
		1076 ;	*****
		1077 ;	
		1078 ;	FUNCTION: SETRG -- SET REGISTER POINTER
		1079 ;	INPUTS: NONE
		1080 ;	OUTPUTS: CARRY - SET IF CHARACTER FROM KEYBOARD IS A REGISTER DESIGNATOR
		1081 ;	RESET OTHERWISE
		1082 ;	CALLS: RDKBD
		1083 ;	DESTROYS: A, B, C, H, L, F/F'S
		1084 ;	DESCRIPTION: SETRG READS A CHARACTER FROM THE KEYBOARD. IF THE
		1085 ;	CHARACTER IS A REGISTER DESIGNATOR, IT IS CONVERTED TO
		1086 ;	THE CORRESPONDING REGISTER POINTER VALUE. THE POINTER IS
		1087 ;	SAVED, AND THE FUNCTION RETURNS 'TRUE' OTHERWISE, THE
		1088 ;	FUNCTION RETURNS 'FALSE'
		1089 ;	
		1090	SETRG:
0354	CDC002	1091	CALL RDKBD ; READ FROM KEYBOARD
0357	FE10	1092	CPI 10H ; IS CHARACTER A DIGIT ?
0359	020003	1093	JNC RETF ; NO - RETURN FALSE - CHARACTER IS NOT A
		1094	; /REGISTER DESIGNATOR
035C	D603	1095	SUI 3 ; YES - TRY TO CONVERT REGISTER DESIGNATOR TO
		1096	; / INDEX INTO REGISTER POINTER TABLE
		1097	; WAS CONVERSION SUCCESSFUL ?
035E	040003	1098	JC RETF ; NO - RETURN FALSE
0361	4F	1099	MOV C,A ; INDEX TO B & C

ORIGINAL PAGE IS
OF POOR QUALITY

```

LOC OBJ            LINE        SOURCE STATEMENT

0362 0E00           1100 MVI B,0 ;
0364 21FB02        1101 LXI H,ROPTB ; GET ADDRESS OF REGISTER POINTER TABLE
0367 09            1102 DAD B ; INDEX POINTS INTO TABLE
0368 7E            1103 MOV A,M ; GET REGISTER POINTER FROM TABLE
0369 32FD20        1104 STA ROPTR ; SAVE REGISTER POINTER
036C C30803        1105 JMP RETT ; RETURN TRUE
                  1106 ;
                  1107 ;*****
                  1108 ;
                  1109 ; FUNCTION: UPDAD - UPDATE ADDRESS FIELD OF DISPLAY
                  1110 ; INPUTS: NONE
                  1111 ; OUTPUTS: NONE
                  1112 ; CALLS: HXDSP,OUTPT
                  1113 ; DESTROYS: A,B,C,D,E,H,L,F/'S
                  1114 ; DESCRIPTION: UPDAD UPDATES THE ADDRESS FIELD OF THE DISPLAY USING
                  1115 ;                    THE CURRENT ADDRESS.
                  1116 ;
                  1117 UPDAD:
036F 2AF620        1118 LHLD CURAD ; GET THE CURRENT ADDRESS
0372 EB            1119 MCHG ; ARG - PUT CURRENT ADDRESS IN D & E
                  1120 DSPDT4 ; ENTRY POINT FOR 4 CHARACTER ADDRESS OUTPUT
0373 CD4E02        1121 CALL HXDSP ; EXPAND CURRENT ADDRESS FOR DISPLAY
                  1122                    ; ARG - ADDRESS OF EXPANDED ADDRESS IS IN H & L
0376 0E04        1123 MVI C,04H ; LOAD 4 CHARACTER COUNT
0379 CD9E02        1124 CALL OUTPT ; OUTPUT CURRENT ADDRESS TO ADDRESS FIELD
037B C9            1125 RET ; RETURN
                  1126 ;
                  1127 ;*****
                  1128 ;
                  1129 ; FUNCTION: UPDDT - UPDATE DATA FIELD OF DISPLAY
                  1130 ; INPUTS: NONE
                  1131 ; OUTPUTS: NONE
                  1132 ; CALLS: HXDSP,OUTPT
                  1133 ; DESTROYS: A,B,C,D,E,H,L,F/'S
                  1134 ; DESCRIPTION: UPDDT UPDATES THE DATA FIELD OF THE DISPLAY USING
                  1135 ;                    THE CURRENT DATA BYTE.
                  1136 ;
                  1137 UPDDT:
037C 3AF920        1138 LDA CURDT ; GET CURRENT DATA
037F 57            1139 MOV D,A ; ARG - PUT CURRENT DATA IN D
                  1140 DSPDT2 ; ENTRY POINT FOR 2 CHARACTER DISPLAY
0380 CD4E02        1141 CALL HXDSP ; EXPAND CURRENT DATA FOR DISPLAY
                  1142                    ; ARG - ADDRESS OF EXPANDED DATA IS IN H & L
0383 0E02        1143 MVI C,2
0385 1E02        1144 MVI E,2 ; SET TO 6TH SLOT
0387 CD9002        1145 CALL OUT05 ; ENTER OUTPUT ROUTINE
038A C9            1146 RET ; RETURN
                  1147 ;
                  1148 ;*****
                  1149 ;
                  1150 ; FUNCTION: DELAYS
                  1151 ; INPUTS: NONE
                  1152 ; OUTPUTS: NONE
                  1153 ; CALLS: NOTHING
                  1154 ; DESTROYS: A,B,C,F/'S

```


ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II 0000/0005 MACRO ASSEMBLER, V3.0 MONTR PAGE 22

LOC	OBJ	LINE	SOURCE STATEMENT
		1155 ;	DESCRIPTION. DELAYS IS THE DELAY TIME FUNCTION BLOCK
		1156 ;	FROM THE PRO-LOG MONITOR. THE ENTRY POINTS
		1157 ;	INCLUDE 1 SEC, 200 MSEC, 100 MSEC, 20 MSEC, AND 1 MSEC.
		1158 ;	THE DELAY ROUTINES ARE CALLED AND RETURN
		1159 ;	WHEN DELAY FINISHES.
		1160 ;	
0388	010100	1161	DELAY: LXI B,1 ; LOAD BC WITH A 1
038E	03A603	1162	JMP MSEC0T ; GO TO 1 MSEC DELAY LOOP
		1163	SEC0T:
0391	01E803	1164	LXI B,03EEH ; LOAD BC WITH 1000 DECIMAL
0394	03A603	1165	JMP MSEC0T
0397	01C800	1166	MSEC2H: LXI B,0202H ; LOAD BC WITH 200 DECIMAL
039A	03A603	1167	JMP MSEC0T
039D	016400	1168	MSEC1H: LXI B,064H ; LOAD BC WITH 100 DECIMAL
03A0	03A603	1169	JMP MSEC0T
03A3	011400	1170	MSEC20: LXI B,0014H ; LOAD BC WITH 20 DECIMAL
03A6	09	1171	MSEC0T: DCX B ; DELAY N MILLISECONDS
03A7	05	1172	PUSH B ; WHERE N16=(BC)
03A8	0ED8	1173	MVI C,0DBH
03AA	0D	1174	DELENT: DCR C
03AB	03AA03	1175	JNZ DELENT
03AE	01	1176	POP B ; POP BC OFF STACK
03AF	78	1177	MOV A,B
03B0	81	1178	ORA C
03B1	03A603	1179	JNZ MSEC0T ; JUMP BACK TO MSEC0T IF NOT DONE
03B4	09	1180	RET ; RETURN
		1181 ;	
		1182 ;	*****
		1183 ;	
		1184 ;	MONITOR TABLES
		1185 ;	
		1186 ;	*****
		1187 ;	
		1188 ;	COMMAND TABLE
		1189 ;	COMMAND CHARACTERS AS RECEIVED FROM KEYBOARD
		1190	CMDTB:
03B5	12	1191	DB 12H ; GO COMMAND
03B6	13	1192	DB 13H ; SUBSTITUTE COMMAND
03B7	17	1193	DB 17H ; EXAMINE REGISTERS COMMAND
03B8	15	1194	DB 15H ; SINGLE STEP COMMAND
		1195 ;	DB 10H ; EXEC KEY
		1196 ;	DB 11H ; NEXT KEY
		1197 ;	DB 16H ; QUMMY
03B9	14	1198	DB 14H ; TTY MONITOR
		1199 ;	
0005		1200	MUNC EQU *-CMDTB ; NUMBER OF COMMANDS
		1201 ;	
		1202 ;	*****
		1203 ;	
		1204 ;	COMMAND ROUTINE ADDRESS TABLE
		1205 ;	(MUST BE IN REVERSE ORDER OF COMMAND TABLE)
		1206	CMDAD:
		1207 ;	DW DUMMY COMMAND 1
		1208 ;	DW DUMMY COMMAND 2
		1209 ;	DW DUMMY COMMAND 3

LOC	OBJ	LINE	SOURCE STATEMENT
03EA	4904	1210	DN GO ; TTY MONITOR
03EC	0201	1211	DN SSTEP ; ADDRESS OF SINGLE STEP ROUTINE
03EE	9E00	1212	DN EXAM ; ADDRESS OF EXAMINE REGISTERS ROUTINE
0308	7F01	1213	DN SUBST ; ADDRESS OF SUBSTITUTE MEMORY ROUTINE
03C2	0E00	1214	DN GOCHD ; ADDRESS OF GO ROUTINE
		1215 ;	
		1216 ;	*****
		1217 ;	
		1218	OSPNUM: ; DISPLAY TABLE FOR HEX DIGITS
		1219 ;	
		1220	OSPTB: ; TABLE FOR TRANSLATING CHARACTERS FOR OUTPUT
		1221 ;	
		1222 ;	DISPLAY
		1223 ;	FORMAT CHARACTERS
		1224 ;	=====
		1225 ;	
		1226 ;	PRO-LOG 7303 USES 8 BIT ASCII, 7 BIT PLUS BIT 8 = 1
		1227 ;	
00E0		1228	ZERO EQU 000H
03C4	B0	1229	DB 000H ; 0
03C5	B1	1230	DB 001H ; 1
03C6	B2	1231	DB 002H ; 2
03C7	B3	1232	DB 003H ; 3
03C8	B4	1233	DB 004H ; 4
00B5		1234	FIVE EQU 005H
03C9	B5	1235	DB 005H ; 5
03CA	B6	1236	DB 006H ; 6
03CB	B7	1237	DB 007H ; 7
00B8		1238	EIGHT EQU 008H
03CC	B8	1239	DB 008H ; 8
03CD	B9	1240	DB 009H ; 9
00C1		1241	LETRA EQU 0C1H
03CE	C1	1242	DB 0C1H ; A
00C2		1243	LETRB EQU 0C2H
03CF	C2	1244	DB 0C2H ; B
00C3		1245	LETRC EQU 0C3H
03D0	C3	1246	DB 0C3H ; C
00C4		1247	LETRD EQU 0C4H
03D1	C4	1248	DB 0C4H ; D
00C5		1249	LETR E EQU 0C5H
03D2	C5	1250	DB 0C5H ; E
00C6		1251	LETRF EQU 0C6H
03D3	C6	1252	DB 0C6H ; F
00C8		1253	LETRH EQU 0C8H
03D4	C8	1254	DB 0C8H ; H
00CC		1255	LETRL EQU 0CCH
03D5	CC	1256	DB 0CCH ; L
00D0		1257	LETRP EQU 0D0H
03D6	D0	1258	DB 0D0H ; P
00C9		1259	LETRI EQU 0C9H
03D7	C9	1260	DB 0C9H ; I
00D2		1261	LETRR EQU 0D2H
03D8	D2	1262	DB 0D2H ; R
00D3		1263	LETRS EQU 0D3H
03D9	D3	1264	DB 0D3H ; S

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II 8086/8085 MACRO ASSEMBLER, V3.0

MONITR PAGE 24

LOC	OBJ	LINE	SOURCE STATEMENT
0398		1265	BLANK EQU 0A0H
03DA	A0	1266	DB 0A0H ; BLANK
		1267	;
		1268	*****
		1269	;
		1270	MESSAGES FOR OUTPUT TO DISPLAY
		1271	;
03DB	A0	1272	BLANKS: DB BLANK, BLANK, BLANK, BLANK
03DC	A0		
03DD	A0		
03DE	A0		
03DF	A0	1273	BLANKS: DB BLANK, BLANK, BLANK, BLANK ; FOR ADDRESS OR DATA FIELD
03E0	A0		
03E1	A0		
03E2	A0		
03E3	2A	1274	ERMSG: DB '*', LETRE, LETRA, LETRR ; ERROR MESSAGE FOR ADDR. FIELD
03E4	C5		
03E5	D2		
03E6	D2		
03E7	C5	1275	EXMSG: DB LETRE, 'X', LETRE, 'Q' ; EXECUTION MESSAGE
03E8	58		
03E9	C5		
03EA	51		
03EB	2A45584D	1276	XMSG: DB '*EXM' ; EXAMINE MESSAGE
03EF	2A53424D	1277	SMSG: DB '*SBM' ; SUBSTITUTE MEMORY
		1278	;
		1279	RDYTABLE FOR MONITOR PROMPT '@MONITR'
		1280	;
03F3	2A524541	1281	RDYTAB: DB '*READY *' ; MONITOR PROMPT
03F7	4459202A		
		1282	;
		1283	*****
		1284	;
		1285	RGPTB: ; REGISTER POINTER TABLE
		1286	;
		1287	; THE ENTRIES IN THIS TABLE ARE IN THE SAME ORDER
		1288	; AS THE REGISTER DESIGNATION KEYS ON THE KEYBOARD.
		1289	; EACH ENTRY CONTAINS THE REGISTER POINTER VALUE WHICH
		1290	; CORRESPONDS TO THE REGISTER DESIGNATOR, REGISTER
		1291	; POINTER VALUES ARE USED TO POINT INTO THE REGISTER
		1292	; NAME TABLE (NMTEL) AND REGISTER SAVE LOCATION
		1293	; TABLE (RGTEL).
03F8	06	1294	DB 6 ; INTERRUPT MASK
03FC	09	1295	DB 9 ; SPH
03FD	0A	1296	DB 10 ; SPL
03FE	08	1297	DB 11 ; PCH
03FF	0C	1298	DB 12 ; PCL
0400	07	1299	DB 7 ; H
0401	08	1300	DB 8 ; L
0402	00	1301	DB 0 ; A
0403	01	1302	DB 1 ; B
0404	02	1303	DB 2 ; C
0405	03	1304	DB 3 ; D
0406	04	1305	DB 4 ; E
0407	05	1306	DB 5 ; FLAGS

ORIGINAL PAGE IS
OF POOR QUALITY

1575-II 9090/9085 (MACRO ASSEMBLER) V3.0

MONITOR PAGE 25

LOC	DB	LINE	SOURCE STATEMENT
		1307	;
		1308	*****
		1309	;
		1310	INTEL: ; REGISTER NAME TABLE
		1311	; NAMES OF REGISTERS IN DISPLAY FORMAT
0408	A0	1312	DB BLANK, BLANK, LETRA, BLANK ; A REGISTER
0409	A0		
040A	C1		
040B	A0		
040C	A0	1313	DB BLANK, BLANK, LETRB, BLANK ; B REGISTER
040D	A0		
040E	C2		
040F	A0		
0410	A0	1314	DB BLANK, BLANK, LETRC, BLANK ; C REGISTER
0411	A0		
0412	C3		
0413	A0		
0414	A0	1315	DB BLANK, BLANK, LETRD, BLANK ; D REGISTER
0415	A0		
0416	C4		
0417	A0		
0418	A0	1316	DB BLANK, BLANK, LETRE, BLANK ; E REGISTER
0419	A0		
041A	A0		
041B	C5		
041C	A0		
041D	A0	1317	DB BLANK, BLANK, LETRF, BLANK ; FLAGS
041E	C6		
041F	A0		
0420	A0	1318	DB BLANK, BLANK, LETRI, BLANK ; INTERRUPT MASK
0421	A0		
0422	C9		
0423	A0		
0424	A0	1319	DB BLANK, BLANK, LETRH, BLANK ; H REGISTER
0425	A0		
0426	C9		
0427	A0		
0428	A0	1320	DB BLANK, BLANK, LETRL, BLANK ; L REGISTER
0429	A0		
042A	CC		
042B	A0		
042C	D3	1321	DB LETRS, LETRP, LETRH, BLANK ; STACK POINTER HIGH ORDER BYTE
042D	D0		
042E	C8		
042F	A0		
0430	D3	1322	DB LETRS, LETRP, LETRL, BLANK ; STACK POINTER LOW ORDER BYTE
0431	D0		
0432	CC		
0433	A0		
0434	D0	1323	DB LETRP, LETRC, LETRH, BLANK ; PROGRAM COUNTER HIGH BYTE
0435	C2		
0436	C0		
0437	A0		
0438	D0	1324	DB LETRP, LETRC, LETRL, BLANK ; PROGRAM COUNTER LOW BYTE
0439	C3		

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II 8080/8085 MACRO ASSEMBLER, V3.0

MONITOR PAGE 26

```

LOC OBJ      LINE      SOURCE STATEMENT
0428 CC
0428 A0
1325 ;
1326 ;*****
1327 ;
1328 ; REGISTER SAVE LOCATION TABLE
1329 ; ADDRESSES OF SAVE LOCATIONS OF REGISTERS IN THE ORDER IN WHICH
1330 ; THE REGISTERS ARE DISPLAYED BY THE EXAMINE COMMAND
1331 ;
1332 RGTBL:
0430 EE      1333 DB ASAV AND 0FFH ; A REGISTER
0430 EC      1334 DB BSAY AND 0FFH ; B REGISTER
043E EB      1335 DB CSAY AND 0FFH ; C REGISTER
043F EA      1336 DB DSAY AND 0FFH ; D REGISTER
0440 E9      1337 DB ESAY AND 0FFH ; E REGISTER
0441 ED      1338 DB FSAY AND 0FFH ; FLAGS
0442 F1      1339 DB ISAY AND 0FFH ; INTERRUPT MASK
0443 F0      1340 DB HSAY AND 0FFH ; H REGISTER
0444 EF      1341 DB LSAY AND 0FFH ; L REGISTER
0445 F5      1342 DB SPHSV AND 0FFH ; STACK POINTER HIGH ORDER BYTE
0446 F4      1343 DB SPLSV AND 0FFH ; STACK POINTER LOW ORDER BYTE
0447 F3      1344 DB PCHSV AND 0FFH ; PROGRAM COUNTER HIGH ORDER BYTE
0448 F2      1345 DB PCLSV AND 0FFH ; PROGRAM COUNTER LOW ORDER BYTE
0000      1346 NUMRG EQU ($ - RGTBL) ; NUMBER OF ENTRIES IN
1347      ; /REGISTER SAVE LOCATION TABLE
1348 ;
1349 ;*****
1350 ;*****
1351 ;
1352 ;          STDMON TTY MONITOR
1353 ;
1354 ;*****
1355 ;*****
1356 ;
1357 ;
1358 ; ABSTRACT
1359 ; =====
1360 ;
1361 ; THIS PROGRAM RUNS ON THE 8085 BOARD AND IS DESIGNED TO PROVIDE
1362 ; THE USER WITH A MINIMAL MONITOR. BY USING THIS PROGRAM
1363 ; THE USER CAN EXAMINE AND CHANGE MEMORY OR CPU REGISTERS, LOAD
1364 ; A PROGRAM (IN ABSOLUTE HEX) INTO RAM, AND EXECUTE INSTRUCTIONS
1365 ; ALREADY IN MEMORY. THE MONITOR ALSO PROVIDES THE USER WITH
1366 ; ROUTINES FOR PERFORMING CONSOLE I/O.
1367 ;
1368 ;
1369 ; PROGRAM ORGANIZATION
1370 ; =====
1371 ;
1372 ; THE LISTING IS ORGANIZED IN THE FOLLOWING WAY. FIRST THE COMMAND
1373 ; RECOGNIZER, WHICH IS THE HIGHEST LEVEL ROUTINE IN THE PROGRAM.
1374 ; NEXT THE ROUTINES TO IMPLEMENT THE VARIOUS COMMANDS. FINALLY,
1375 ; THE UTILITY ROUTINES WHICH ACTUALLY DO THE DIRTY WORK. WITHIN
1376 ; EACH SECTION, THE ROUTINES ARE ORGANIZED IN ALPHABETICAL
520 1377 ; ORDER, BY ENTRY POINT OF THE ROUTINE

```

ORIGINAL PAGE IS
OF POOR QUALITY

1515-II 8080/8085 MACRO ASSEMBLER, V3.0

MONTR PAGE 27

```
LOC OBJ      LINE      SOURCE STATEMENT
1379 ;
1379 ; MACROS USED IN THE TTY MONITOR ARE DEFINED IN THE KEYBOARD MONITOR.
1380 ;
1381 ; LIST OF FUNCTIONS
1382 ; =====
1383 ;
1384 ;     GETCM
1385 ;     -----
1386 ;
1387 ;     DCMD
1388 ;     GCMD
1389 ;     ICMD
1390 ;     MCMD
1391 ;     SCMD
1392 ;     XCMD
1393 ;     -----
1394 ;
1395 ;     CI
1396 ;     CNVEN
1397 ;     CO
1398 ;     CROUT
1399 ;     DELAY
1400 ;     ECHO
1401 ;     ERROR
1402 ;     FRET
1403 ;     GETCH
1404 ;     GETHX
1405 ;     GETNM
1406 ;     HILO
1407 ;     NMOUT
1408 ;     PRVAL
1409 ;     REGDS
1410 ;     RGAOR
1411 ;     SRET
1412 ;     STHF0
1413 ;     STHLF
1414 ;     VALDG
1415 ;     VALDL
1416 ;     -----
1417 ;
1418 ;
1419 ; *****
1420 ;
1421 ;
1422 ;                               MONITOR EQUATES
1423 ;
1424 ;
1425 ; *****
1426 ;
1427 ;
1428 ; THIS TABLE IS CODED IN 7 BIT ASCII FOR TTY OR CRT
1429 ;
0013 1430 BRCHR EQU 19H ; CODE FOR BREAK CHARACTER (ESC/SE)
0929 1431 BRTAB EQU 0920H ; LOCATION OF START OF BRANCH TABLE IN ROM
0000 1432 CR EQU 0DH ; CODE FOR CARRIAGE RETURN
```



```

LOC  OBJ      LINE      SOURCE STATEMENT
      1488 ;
      1489 ;          COMMAND RECOGNIZING ROUTINE
      1490 ;
      1491 ;
      1492 ;*****
      1493 ;
      1494 ; FUNCTION: GETCM
      1495 ; INPUTS: NONE
      1496 ; OUTPUTS: NONE
      1497 ; CALLS: GETCH, ECHO, ERROR
      1498 ; DESTROYS: A, B, C, H, L, F/F'S
      1499 ; DESCRIPTION: GETCM RECIEVES AN INPUT CHARACTER FROM THE USER
      1500 ;          AND ATTEMPTS TO LOCATE THIS CHARACTER IN ITS COMMAND
      1501 ;          CHARACTER TABLE. IF SUCCESSFUL, THE ROUTINE
      1502 ;          CORRESPONDING TO THIS CHARACTER IS SELECTED FROM
      1503 ;          A TABLE OF COMMAND ROUTINE ADDRESSES, AND CONTROL
      1504 ;          IS TRANSFERED TO THIS ROUTINE. IF THE CHARACTER
      1505 ;          DOES NOT MATCH ANY ENTRIES, CONTROL IS PASSED TO
      1506 ;          THE ERROR HANDLER.
      1507 ;
      1508 GETCM:
0457 21E920 1509 LXI H, MNSTK ; ALWAYS WANT TO RESET STACK PTR TO MONITOR
0458 F9      1510 SPHL ; /STARTING VALUE SO ROUTINES NEEDN'T CLEAN UP
0459 0E2E     1511 MVI C, '.' ; PROMPT CHARACTER TO C
045D C00506 1512 CALL ECHO ; SEND PROMPT CHARACTER TO USER TERMINAL
0460 C36304 1513 JMP GTC03 ; WANT TO LEAVE ROOM FOR PST BRANCH
      1514 GTC03:
0463 C02C06 1515 CALL GETCH ; GET COMMAND CHARACTER TO A
0466 C00506 1516 CALL ECHO ; ECHO CHARACTER TO USER
0469 79      1517 MOV A, C ; PUT COMMAND CHARACTER INTO ACCUMULATOR.
      5A 010600 1518 LXI B, NCMDS ; C CONTAINS LOOP AND INDEX COUNT
      40D 21B507 1519 LXI H, CTAB ; HL POINTS INTO COMMAND TABLE
      1520 GTC05:
0470 BE      1521 CMP M ; COMPARE TABLE ENTRY AND CHARACTER
0471 C07C04 1522 JZ GTC10 ; BRANCH IF EQUAL - COMMAND RECOGNIZED
0474 23      1523 INX H ; ELSE, INCREMENT TABLE POINTER
0475 0D      1524 DCR C ; DECREMENT LOOP COUNT
0476 C27004 1525 JNZ GTC05 ; BRANCH IF NOT AT TABLE END
0479 C31E06 1526 JMP ERROR ; ELSE, COMMAND CHARACTER IS ILLEGL
      1527 GTC10:
047C 21A707 1528 LXI H, CADR ; IF GOOD COMMAND, LOAD ADDRESS OF TABLE
      1529 ;          ; /OF COMMAND ROUTINE ADDRESSES
047F 05      1530 DAD B ; ADD WHAT IS LEFT OF LOOP COUNT
0480 09      1531 DAD B ; ADD AGAIN - EACH ENTRY IN CADR IS 2 BYTES LONG
0481 7E      1532 MOV A, M ; GET LSP OF ADDRESS OF TABLE ENTRY TO A
0482 23      1533 INX H ; POINT TO NEXT BYTE IN TABLE
0483 66      1534 MOV H, Y ; GET MSP OF ADDRESS OF TABLE ENTRY TO H
0484 6F      1535 MOV L, A ; PUT LSP OF ADDRESS OF TABLE ENTRY INTO L
0485 E9      1536 PCHL ; NEXT INSTRUCTION COMES FROM COMMAND ROUTINE
      1537 ;
      1538 ;
      1539 ;*****
      1540 ;
      1541 ;
      1542 ;

```


LOC	OBJ	LINE	SOURCE STATEMENT
		1598	FALSE GCM05 ; BRANCH IF NO NUMBER PRESENT
048A	D2CC04	1599+	JNC GCM05
048D	7A	1600	MOV A,D ; ELSE, GET TERMINATOR
048E	FE0D	1601	CPI CR ; SEE IF CARRIAGE RETURN
04C0	C21E06	1602	JNZ ERROR ; ERROR IF NOT PROPERLY TERMINATED
04C3	21F220	1603	LXI H,PSAV ; WANT NUMBER TO REPLACE SAVE PGM COUNTER
04C6	71	1604	MOV M,C
04C7	23	1605	INX H
04C9	70	1606	MOV M,B
04C9	C3D204	1607	JMP GCM10
		1608	GCM05:
04CC	7A	1609	MOV A,D ; IF NO STARTING ADDRESS, MAKE SURE THAT
04CD	FE0D	1610	CPI CR ; /CARRIAGE RETURN TERMINATED COMMAND
04CF	C21E06	1611	JNZ ERROR ; ERROR IF NOT
		1612	GCM10:
04D2	C32903	1613	JMP RSTOR ; RESTORE REGISTERS AND BEGIN EXECUTION
		1614	; (RSTOR IS IN KEYBOARD MONITOR)
		1615	;
		1616	;
		1617	*****
		1618	;
		1619	;
		1620	; FUNCTION: ICMD
		1621	; INPUTS: NONE
		1622	; OUTPUTS: NONE
		1623	; CALLS: ERROR, ECHO, GETCH, VALDL, VALDG, CHVBN, STHLF, GETNM, CROUT
		1624	; DESTROYS: A, B, C, D, E, H, L, F/F'S
		1625	; DESCRIPTION: ICMD IMPLEMENTS THE INSERT CODE INTO MEMORY (I) COMMAND.
		1626	;
		1627	ICMD:
04D5	0E01	1628	MVI C,1
04D7	CD6806	1629	CALL GETIN ; GET SINGLE NUMBER FROM INPUT STREAM
04D9	3EFF	1630	MVI A,UPPER
04DC	32FD20	1631	STA TEMP ; TEMP WILL HOLD THE UPPER/LOWER HALF BYTE FLAG
04DF	D1	1632	POP D ; ADDRESS OF START TO DE
		1633	ICM05:
04E0	CD2C06	1634	CALL GETCH ; GET A CHARACTER FROM INPUT STREAM
04E3	4F	1635	MOV C,A
04E4	CD0506	1636	CALL ECHO ; ECHO IT
04E7	79	1637	MOV A,C ; PUT CHARACTER BACK INTO A
04E8	FE18	1638	CPI TERM ; SEE IF CHARACTER IS A TERMINATING CHARACTER
04EA	CD1605	1639	JZ ICM25 ; IF SO, ALL DONE ENTERING CHARACTERS
04ED	CD7E07	1640	CALL VALDL ; ELSE, SEE IF VALID DELIMITER
		1641	TRUE ICM05 ; IF SO SIMPLY IGNORE THIS CHARACTER
04F0	D9E004	1642+	JC ICM05
04F3	CD6707	1643	CALL VALDG ; ELSE, CHECK TO SEE IF VALID HEX DIGIT
		1644	FALSE ICM20 ; IF NOT, BRANCH TO HANDLE ERROR CONDITION
04F5	D21005	1645+	JNC ICM20
04F9	CD0B05	1646	CALL CHVBN ; CONVERT DIGIT TO BINARY
04FC	4F	1647	MOV C,A ; MOVE RESULT TO C
04FD	CD4407	1648	CALL STHLF ; STORE IN APPROPRIATE HALF WORD
0500	32FD20	1649	LDA TEMP ; GET HALF BYTE FLAG
0503	87	1650	CMA A ; SET F/F'S
0504	C20905	1651	JNZ ICM10 ; BRANCH IF FLAG SET FOR UPPER
0507	13	1652	INX D ; IF LOWER, INC ADDRESS OF BYTE TO STORE IN

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II 8088/8085 MACRO ASSEMBLER, V3.0

MONTR PAGE 32

LOC	OBJ	LINE	SOURCE STATEMENT
		1653	ICM10:
0508	EEFF	1654	XRI INVRT ; TOGGLE STATE OF FLAG
050A	32FD20	1655	STA TEMP ; PUT NEW VALUE OF FLAG BACK
050D	C3E004	1656	JMP ICM05 ; PROCESS NEXT DIGIT
		1657	ICM20:
0510	CD3907	1658	CALL STHF0 ; ILLEGAL CHARACTER
0513	C31E06	1659	JMP ERROR ; MAKE SURE ENTIRE BYTE FILLED THEN ERROR
		1660	ICM25:
0516	CD3907	1661	CALL STHF0 ; HERE FOR ESCAPE CHARACTER - INPUT IS DONE
0519	CDFF05	1662	CALL CROUT ; ADD CARRIAGE RETURN
051C	C35704	1663	JMP GETCM
		1664 ;	
		1665 ;	
		1666 ;	*****
		1667 ;	
		1668 ;	
		1669 ;	FUNCTION: MCMD
		1670 ;	INPUTS: NONE
		1671 ;	OUTPUTS: NONE
		1672 ;	CALLS: GETCM, HILO, GETNM
		1673 ;	DESTROYS: A, B, C, D, E, H, L, F/F'S
		1674 ;	DESCRIPTION: MCMD IMPLEMENTS THE MODE DATA IN MEMORY (M) COMMAND.
		1675 ;	
		1676	MCMD:
051F	0E03	1677	MVI C, 3
0521	CD6806	1678	CALL GETNM ; GET 3 NUMBERS FROM INPUT STREAM
0524	C1	1679	POP B ; DESTINATION ADDRESS TO BC
0525	E1	1680	POP H ; ENDING ADDRESS TO HL
0526	D1	1681	POP D ; STARTING ADDRESS TO DE
		1682	MCMD5:
0527	E5	1683	PUSH H ; SAVE ENDING ADDRESS
0528	62	1684	MOV H, D
0529	6B	1685	MOV L, E ; SOURCE ADDRESS TO HL
052A	7E	1686	MOV A, H ; GET SOURCE BYTE
052B	60	1687	MOV H, B
052C	69	1688	MOV L, C ; DESTINATION ADDRESS TO HL
052D	77	1689	MOV M, A ; MOVE BYTE TO DESTINATION
052E	03	1690	INX B ; INCREMENT DESTINATION ADDRESS
052F	78	1691	MOV A, B
0530	01	1692	ORA C ; TEST FOR DESTINATION ADDRESS OVERFLOW
0531	CA5704	1693	JZ GETCM ; IF SO, CAN TERMINATE COMMAND
0534	13	1694	INX D ; INCREMENT SOURCE ADDRESS
0535	E1	1695	POP H ; ELSE, GET BACK ENDING ADDRESS
0536	CDAD06	1696	CALL HILO ; SEE IF ENDING ADDR=SOURCE ADDR
		1697	FALSE GETCM ; IF NOT, COMMAND IS DONE
0539	D25704	1698+	JNC GETCM
053C	C32705	1699	JMP MCM05 ; MOVE ANOTHER BYTE
		1700 ;	
		1701 ;	
		1702 ;	*****
		1703 ;	
		1704 ;	
		1705 ;	FUNCTION: SCMD
		1706 ;	INPUTS: NONE
		1707 ;	OUTPUTS: NONE

ORIGINAL PAGE IS
OF POOR QUALITY

LOC	OBJ	LINE	SOURCE STATEMENT
		1708	; CALLS: GETHX,GETCM,NNOUT,ECHO
		1709	; DESTROYS: A,B,C,D,E,H,L,F/F'S
		1710	; DESCRIPTION: SCMD IMPLEMENTS THE SUBSTITUTE INTO MEMORY (S) COMMAND.
		1711	;
		1712	SCMD:
053F	CD3306	1713	CALL GETHX ; GET A NUMBER, IF PRESENT, FROM INPUT
0542	C5	1714	PUSH B
0543	E1	1715	POP H ; GET NUMBER TO HL - DENOTES MEMORY LOCATION
		1716	SCM05:
0544	7A	1717	MOV A,D ; GET TERMINATOR
0545	FE20	1718	CPI ' ' ; SEE IF SPACE
0547	CA4F05	1719	JZ SCM10 ; YES - CONTINUE PROCESSING
0548	FE2C	1720	CPI ',' ; ELSE, SEE IF COMMA
054C	C25704	1721	JNZ GETCM ; NO - TERMINATE COMMAND
		1722	SCM10:
054F	7E	1723	MOV A,H ; GET CONTENTS OF SPECIFIED LOCATION TO A
0550	CD0406	1724	CALL NNOUT ; DISPLAY CONTENTS ON CONSOLE
0553	0E2D	1725	MVI C,'-'
0555	CD0506	1726	CALL ECHO ; USE DASH FOR SEPARATOR
0558	CD3306	1727	CALL GETHX ; GET NEW VALUE FOR MEMORY LOCATION, IF ANY
		1728	FALSE SCM15 ; IF NO VALUE PRESENT, BRANCH
055B	025F05	1729+	JNC SCM15
055E	71	1730	MOV M,C ; ELSE, STORE LOWER 8 BITS OF NUMBER ENTERED
		1731	SCM15:
055F	22	1732	INX H ; INCREMENT ADDRESS OF MEMORY LOCATION TO VIEW
0560	CD4405	1733	JMP SCM05
		1734	;
		1735	;
		1736	*****
		1737	;
		1738	;
		1739	; FUNCTION: XCMD
		1740	; INPUTS: NONE
		1741	; OUTPUTS: NONE
		1742	; CALLS: GETCH,ECHO,REGDS,GETCM,ERROR,ROADR,NNOUT,CROUT,GETHX
		1743	; DESTROYS: A,B,C,D,E,H,L,F/F'S
		1744	; DESCRIPTION: XCMD IMPLEMENTS THE REGISTER EXAMINE AND CHANGE (X) COMMAND.
		1745	;
		1746	;
		1747	XCMD:
0563	CD2C06	1748	CALL GETCH ; GET REGISTER IDENTIFIER
0566	4F	1749	MOV C,A
0567	CD0506	1750	CALL ECHO ; ECHO IT
056A	79	1751	MOV A,C
056B	FE0D	1752	CPI CR
056D	C27605	1753	JNZ XCM05 ; BRANCH IF NOT CARRIAGE RETURN
0570	CD0F06	1754	CALL REGDS ; ELSE, DISPLAY REGISTER CONTENTS
0573	C35704	1755	JMP GETCM ; THEN TERMINATE COMMAND
		1756	XCM05:
0576	4F	1757	MOV C,A ; GET REGISTER IDENTIFIER TO C
0577	CD2007	1758	CALL ROADR ; CONVERT IDENTIFIER INTO RTAB TABLE ADDR
057A	C5	1759	PUSH B
057B	E1	1760	POP H ; PUT POINTER TO REGISTER ENTRY INTO HL
057C	0E2D	1761	MVI C,' '
057E	CD0506	1762	CALL ECHO ; ECHO SPACE TO USER

ORIGINAL PAGE IS
OF POOR QUALITY

1515-II 8080/8085 MACRO ASSEMBLER, V3.0

MONITR PAGE 34

LOC	OBJ	LINE	SOURCE STATEMENT
0591	79	1763	MOV A,C
0592	32FD20	1764	STA TEMP ; PUT SPACE INTO TEMP AS DELIMITER
		1765	XCM10:
0595	3AFD20	1766	LDA TEMP ; GET TERMINATOR
0598	FE20	1767	CPI ' ' ; SEE IF BLANK
059A	CA9205	1768	JZ XCM15 ; YES - GO CHECK POINTER INTO TABLE
059D	FE2C	1769	CPI ',' ; NO - SEE IF COMMA
059F	C25704	1770	JNZ GETCH ; NO - MUST BE CARRIAGE RETURN TO END COMMAND
		1771	XCM15:
0592	7E	1772	MOV A,M
0593	87	1773	ORA A ; SET F/F'S
0594	C29005	1774	JNZ XCM18 ; BRANCH IF NOT AT END OF TABLE
0597	CDFF05	1775	CALL CROUT ; ELSE, OUTPUT CARRIAGE RETURN LINE FEED
059A	C35704	1776	JMP GETCH ; AND EXIT
		1777	XCM18:
059D	E5	1778	PUSH H ; PUT POINTER ON STACK
059E	5E	1779	MOV E,M
059F	1620	1780	MVI D, RAMST SHR 8 ; ADDRESS OF SAVE LOCATION FROM TABLE
05A1	23	1781	INX H
05A2	46	1782	MOV B,M ; FETCH LENGTH FLAG FROM TABLE
05A3	05	1783	PUSH D ; SAVE ADDRESS OF SAVE LOCATION
05A4	05	1784	PUSH D
05A5	E1	1785	POP H ; MOVE ADDRESS TO HL
05A6	C5	1786	PUSH B ; SAVE LENGTH FLAG
05A7	7E	1787	MOV A,M ; GET 8 BITS OF REGISTER FROM SAVE LOCATION
05A8	CD0406	1788	CALL NINOUT ; DISPLAY IT
05AB	F1	1789	POP PSW ; GET BACK LENGTH FLAG
05AC	F5	1790	PUSH PSW ; SAVE IT AGAIN
05AD	87	1791	ORA A ; SET F/F'S
05AE	CA8605	1792	JZ XCM20 ; IF 8 BIT REGISTER, NOTHING MORE TO DISPLAY
05B1	2B	1793	DCX H ; ELSE, FOR 16 BIT REGISTER, GET LOWER 8 BITS
05B2	7E	1794	MOV A,M
05B3	CD0406	1795	CALL NINOUT ; DISPLAY THEM
		1796	XCM20:
05B6	0E2D	1797	MVI C, '-'
05B9	CD9506	1798	CALL ECHO ; USE DASH AS SEPARATOR
05BB	CD3306	1799	CALL GETHX ; SEE IF THERE IS A VALUE TO PUT INTO REGISTER
		1800	FALSE XCM30 ; NO - GO CHECK FOR NEXT REGISTER
05BE	D2D605	1801+	JNC XCM20
05C1	7A	1802	MOV A,D
05C2	32FD20	1803	STA TEMP ; ELSE, SAVE THE TERMINATOR FOR NOW
05C5	F1	1804	POP PSW ; GET BACK LENGTH FLAG
05C6	E1	1805	POP H ; PUT ADDRESS OF SAVE LOCATION INTO HL
05C7	87	1806	ORA A ; SET F/F'S
05C8	CACD05	1807	JZ XCM25 ; IF 8 BIT REGISTER, BRANCH
05CB	70	1808	MOV M,B ; SAVE UPPER 8 BITS
05CC	2B	1809	DCX H ; POINT TO SAVE LOCATION FOR LOWER 8 BITS
		1810	XCM25:
05CD	71	1811	MOV M,C ; STORE ALL OF 8 BIT OR LOWER 1/2 OF 16 BIT REG
		1812	XCM27:
05CE	110700	1813	LXI D, RTABS ; SIZE OF ENTRY IN RTAB TABLE
05D1	E1	1814	POP H ; POINTER INTO REGISTER TABLE RTAB
05D2	19	1815	DAD D ; ADD ENTRY SIZE TO POINTER
05D3	C28505	1816	JMP XCM10 ; DO NEXT REGISTER
		1817	XCM30:

ORIGINAL PAGE IS
OF POOR QUALITY

LOC	OBJ	LINE	SOURCE STATEMENT
05D6	7A	1818	MOV A,D ; GET TERMINATOR
05D7	32FD20	1819	STA TEMP ; SAVE IN MEMORY
05DA	01	1820	POP D ; CLEAR STACK OF LENGTH FLAG AND ADDRESS
05DB	01	1821	POP D ; /OF SAVE LOCATION
05DC	03CE05	1822	JMP XCM27 ; GO INCREMENT REGISTER TABLE POINTER
		1823 ;	
		1824 ;	
		1825 ;	*****
		1826 ;	
		1827 ;	
		1828 ;	UTILITY ROUTINES
		1829 ;	
		1830 ;	
		1831 ;	*****
		1832 ;	
		1833 ;	
		1834 ;	FUNCTION: CI
		1835 ;	INPUTS: NONE
		1836 ;	OUTPUTS: A CHARACTER FROM TTY
		1837 ;	CALLS: NOTHING
		1838 ;	DESTROYS: A,F,F'S
		1839 ;	DESCRIPTION: CI WAITS UNTIL A CHARACTER HAS BEEN ENTERED AT THE
		1840 ;	TTY AND THEN RETURNS THE CHARACTER, VIA THE H
		1841 ;	REGISTER, TO THE CALLING ROUTINE. THIS ROUTINE
		1842 ;	IS CALLED BY THE USER VIA A JUMP TABLE IN RAM.
		1843 ;	
		1844	CI:
05DF	DBDD	1845	IN CSTAT ; GET STATUS OF CONSOLE
05E1	E540	1846	ANI RBF ; CHECK FOR RECEIVER BUFFER FULL
05E3	0ADF05	1847	JZ CI ; NOT READY YET - WAIT
05E6	D5DC	1848	IN CNIN ; READY, GET CHARACTER
05E8	E67F	1849	ANI 7FH ; AND IN 01111111 TO KILL PARITY BIT
05EA	C9	1850	RET ; THAT'S IT
		1851 ;	
		1852 ;	
		1853 ;	*****
		1854 ;	
		1855 ;	
		1856 ;	FUNCTION: CNVN
		1857 ;	INPUTS: C - ASCII CHARACTER '0' - '9' OR 'A' - 'F'
		1858 ;	OUTPUTS: A - 0 TO F HEX
		1859 ;	CALLS: NOTHING
		1860 ;	DESTROYS: A,F,F'S
		1861 ;	DESCRIPTION: CNVN CONVERTS THE ASCII REPRESENTATION OF A HEX
		1862 ;	DIGIT INTO ITS CORRESPONDING BINARY VALUE. CNVN
		1863 ;	DOES NOT CHECK THE VALIDITY OF ITS INPUT.
		1864 ;	
		1865	CNVN:
05EB	79	1866	MOV A,C
05EC	0630	1867	SUI '8' ; SUBTRACT CODE FOR '0' FROM ARGUMENT
05EE	FE08	1868	CPI 10 ; WANT TO TEST FOR RESULT 0 TO 9
05F0	F9	1869	RM ; IF SO, THEN ALL DONE
05F1	0607	1870	SUI 7 ; ELSE, RESULT BETWEEN 17 AND 23 DECIMAL
05F3	C9	1871	RET ; SO RETURN AFTER SUBTRACTING BIAS OF 7
		1872 ;	

ORIGINAL PAGE IS
OF POOR QUALITY

LS15-II 0050/0055 MACRO ASSEMBLER, V3.0

MONITR PAGE 36

LDC OBJ	LINE	SOURCE STATEMENT
	1873 ;	
	1874 ;	*****
	1875 ;	
	1876 ;	
	1877 ;	FUNCTION: CO
	1878 ;	INPUTS: C - CHARACTER TO OUTPUT TO TTY
	1879 ;	OUTPUTS: C - CHARACTER OUTPUT TO TTY
	1880 ;	CALLS: NOTHING
	1881 ;	DESTROYS: A,F/F'S
	1882 ;	DESCRIPTION: CO SENDS ITS INPUT ARGUMENT TO THE TTY.
	1883 ;	
	1884 CO:	
05F4 0E00	1885	IN CSTAT ; GET STATUS OF CONSOLE
05F6 E300	1886	ANI TBE ; SEE IF TRANSMITTER READY
05F8 CAF405	1887	JZ CO ; NOT READY - WAIT
05FB 79	1888	MOV A,C ; LOAD A WITH CHARACTER
05FC D30C	1889	OUT COUT ; SEND CHARACTER
05FE C9	1890	RET ; ALL DONE
	1891 ;	
	1892 ;	
	1893 ;	*****
	1894 ;	
	1895 ;	
	1896 ;	FUNCTION CROUT
	1897 ;	INPUTS: NONE
	1898 ;	OUTPUTS: NONE
	1899 ;	CALLS: ECHO
	1900 ;	DESTROYS: A,B,C,F/F'S
	1901 ;	DESCRIPTION: CROUT SENDS A CARRIAGE RETURN (AND HENCE A LINE
	1902 ;	FEED) TO THE CONSOLE
	1903 ;	
	1904 CROUT:	
05FF 0E00	1905	MVI C,CR
0601 CD0506	1906	CALL ECHO
0604 C9	1907	RET
	1908 ;	
	1909 ;	
	1910 ;	*****
	1911 ;	
	1912 ;	
	1913 ;	FUNCTION: ECHO
	1914 ;	INPUTS: C - CHARACTER TO ECHO TO TERMINAL
	1915 ;	OUTPUTS: C - CHARACTER ECHOED TO TERMINAL
	1916 ;	CALLS: CO
	1917 ;	DESTROYS: A,B,F/F'S
	1918 ;	DESCRIPTION. ECHO TAKES A SINGLE CHARACTER AS INPUT AND, VIA
	1919 ;	THE MONITOR, SENDS THAT CHARACTER TO THE USER
	1920 ;	TERMINAL. A CARRIAGE RETURN IS ECHOED AS A CARRIAGE
	1921 ;	RETURN LINE FEED, AND AN ESCAPE CHARACTER IS ECHOED AS \$.
	1922 ;	
	1923 ECHO:	
0605 41	1924	MOV B,C ; SAVE ARGUMENT
0606 3E19	1925	MVI A,ESC
0608 B8	1926	CMP B ; SEE IF ECHOING AN ESCAPE CHARACTER
0609 C20E26	1927	JNZ ECH05 ; NO - BRANCH

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-11 8080/8085 MACRO ASSEMBLER, V2.0 MONTR PAGE 27

LOC	OBJ	LINE	SOURCE STATEMENT
0600	0E24	1928	MVI C,'\$' ; YES - ECHO AS \$
		1929	ECH05:
060E	0DF405	1930	CALL C0 ; DO OUTPUT THROUGH MONITOR
0611	3E00	1931	MVI A,CR
0613	B9	1932	CMP B ; SEE IF CHARACTER ECHOED WAS A CARRIAGE RETURN
0614	021006	1933	JNZ ECH10 ; NO - NO NEED TO TAKE SPECIAL ACTION
0617	0E0A	1934	MVI C,LF ; YES - WANT TO ECHO LINE FEED, TOO
0619	0DF405	1935	CALL C0
		1936	ECH10:
061C	48	1937	MOV C,B ; RESTORE ARGUMENT
061D	C9	1938	RET ; RETURN
		1939 ;	
		1940 ;	
		1941 ;	*****
		1942 ;	
		1943 ;	
		1944 ;	FUNCTION: ERROR
		1945 ;	INPUTS: NONE
		1946 ;	OUTPUTS: NONE
		1947 ;	CALLS: ECHO CR0UT,GETCH
		1948 ;	DESTROYS: A,B,C,F'F'S
		1949 ;	DESCRIPTION: ERROR PRINTS THE ERROR CHARACTER (CURRENTLY AN ASTERISK)
		1950 ;	ON THE CONSOLE, FOLLOWED BY A CARRIAGE RETURN LINE FEED,
		1951 ;	AND THEN RETURNS CONTROL TO THE COMMAND RECOGNIZER.
		1952 ;	
		1953	ERROR:
061E	0E2A	1954	MVI C,'*' ; LOAD ASTERISK INTO REGISTER C
0620	0D0E06	1955	CALL ECHO ; SEND * TO CONSOLE
0623	0DFF05	1956	EXIT: CALL CR0UT ; SKIP TO BEGINNING OF NEXT LINE
0626	C35704	1957	JMP GETCH ; TRY AGAIN FOR ANOTHER COMMAND
		1958 ;	
		1959 ;	
		1960 ;	*****
		1961 ;	
		1962 ;	
		1963 ;	FUNCTION: FRET
		1964 ;	INPUTS: NONE
		1965 ;	OUTPUTS: CARRY - ALWAYS 0
		1966 ;	CALLS: NOTHING
		1967 ;	DESTROYS: CARRY
		1968 ;	DESCRIPTION: FRET IS JUMPED TO BY ANY ROUTINE THAT WISHES TO
		1969 ;	INDICATE FAILURE ON RETURN. FRET SETS THE CARRY
		1970 ;	FALSE, DENOTING FAILURE, AND THEN RETURNS TO THE
		1971 ;	CALLER OF THE ROUTINE INVOKING FRET.
		1972 ;	
		1973	FRET:
0629	27	1974	STC ; FIRST SET CARRY TRUE
062A	3F	1975	CMC ; THEN COMPLEMENT IT TO MAKE IT FALSE
062B	C9	1976	RET ; RETURN APPROPRIATELY
		1977 ;	
		1978 ;	
		1979 ;	*****
		1980 ;	
		1981 ;	
		1982 ;	FUNCTION: GETCH

ORIGINAL PAGE IS
OF POOR QUALITY

```

L3C 08J      LINE      SOURCE STATEMENT
1983 ; INPUTS: NONE
1984 ; OUTPUTS: D - NEXT CHARACTER IN INPUT STREAM
1985 ; CALLS: CI
1986 ; DESTROYS: D, E, F, F'S
1987 ; DESCRIPTION: GETCH RETURNS THE NEXT CHARACTER IN THE INPUT STREAM
1988 ;                TO THE CALLING PROGRAM.
1989 ;
1990 GETCH:
062C 000F05 1991 CALL CI ; GET CHARACTER FROM THE TERMINAL
062F E57F   1992 ANI PRTY0 ; TURN OFF PARITY BIT IN CASE SET BY CONSOLE
0631 4F     1993 MOV C, A ; PUT VALUE IN C REGISTER FOR RETURN
0632 09     1994 RET ; RETURN
1995 ;
1996 ;
1997 ; *****
1998 ;
1999 ;
2000 ; FUNCTION: GETHX
2001 ; INPUTS: NONE
2002 ; OUTPUTS: BC - 16 BIT INTEGER
2003 ;         D - CHARACTER WHICH TERMINATED THE INTEGER
2004 ;         CARRY - 1 IF FIRST CHARACTER NOT DELIMITER
2005 ;         - 0 IF FIRST CHARACTER IS DELIMITER
2006 ; CALLS: ECHO, GETCH, VALDL, VALDG, CHVEN, ERROR
2007 ; DESTROYS: A, B, C, D, E, F, F'S
2008 ; DESCRIPTION: GETHX ACCEPTS A STRING OF HEX DIGITS FROM THE INPUT
2009 ;                STREAM AND RETURNS THIER VALUE AS A 16 BIT BINARY
2010 ;                INTEGER. IF MORE THAN 4 HEX DIGITS ARE ENTEPED,
2011 ;                ONLY THE LAST 4 ARE USED. THE NUMBER TERMINATES WHEN
2012 ;                A VALID DELIMITER IS ENCOUNTERED. THE DELIMITER IS
2013 ;                ALSO RETURNED AS AN OUTPUT OF THE FUNCTION. ILLEGAL
2014 ;                CHARACTERS (NOT HEX DIGITS OR DELIMITER) CAUSE AN
2015 ;                ERROR INDICATION. IF THE FIRST (VALID CHARACTER
2016 ;                ENCOUNTERED) IN THE INPUT STREAM IS NOT A DELIMITER,
2017 ;                GETHX WILL RETURN WITH THE CARRY BIT SET TO 1;
2018 ;                OTHERWISE, THE CARRY BIT IS SET TO 0 AND THE CONTENTS
2019 ;                OF BC ARE UNDEFINED.
2020 ;
2021 GETHX:
0633 E5     2022 PUSH H ; SAVE HL
0634 210000 2023 LXI H, 0 ; INITIALIZE RESULT
0637 1E00   2024 MVI E, 0 ; INITIALIZE DIGIT FLAG TO FALSE
2025 GHX05:
0639 0D2006 2026 CALL GETCH ; GET A CHARACTER
063C 4F     2027 MOV C, A
063D 000506 2028 CALL ECHO ; ECHO THE CHARACTER
0640 0D7E07 2029 CALL VALDL ; SEE IF DELIMITER
2030 FALSE GHX10 ; NO - BRANCH
0643 025206 2031+ JNC GHX10
0646 51     2032 MOV D, C ; YES - ALL DONE, BUT WANT TO RETURN DELIMITER.
0647 E5     2033 PUSH H
0648 C1     2034 POP B ; MOVE RESULT TO BC
0649 E1     2035 POP H ; RESTORE HL
064A 7B     2036 MOV A, E ; GET FLAG
064B B7     2037 ORA A ; SET F, F'S

```

ORIGINAL PAGE IS
OF POOR QUALITY

LOC	OBJ	LINE	SOURCE STATEMENT
064C	C23707	2038	JNZ SRET ; IF FLAG NON-0, A NUMBER HAS BEEN FOUND
064F	CA2996	2039	JZ FRET ; ELSE, DELIMITER WAS FIRST CHARACTER.
		2040	GHX10:
0652	CD6307	2041	CALL VALDG ; IF NOT DELIMITER, SEE IF DIGIT
		2042	FALSE ERROR ; ERROR IF NOT A VALID DIGIT, EITHER
0655	D21E86	2043+	JNC ERROR
0659	CDE985	2044	CALL CH2BN ; CONVERT DIGIT TO ITS BINARY VALUE
065B	1EFF	2045	MVI E,0FFH ; SET DIGIT FLAG NON-0
065D	29	2046	DAD H ; *2
065E	29	2047	DAD H ; *4
065F	29	2048	DAD H ; *8
0660	29	2049	DAD H ; *16
0661	0600	2050	MVI B,0 ; CLEAR UPPER 8 BITS OF BC PAIR
0663	4F	2051	MOV C,A ; BINARY VALUE OF CHARACTER INTO C
0664	09	2052	DAD B ; ADD THIS VALUE TO PARTIAL RESULT
0665	C33906	2053	JMP GHX05 ; GET NEXT CHARACTER.
		2054 ;	
		2055 ;	
		2056 ;	*****
		2057 ;	
		2058 ;	
		2059 ;	FUNCTION: GETNM.
		2060 ;	INPUTS: C - COUNT OF NUMBERS TO FIND IN INPUT STREAM
		2061 ;	OUTPUTS: TOP OF STACK - NUMBERS FOUND IN REVERSE ORDER (LAST ON TOP
		2062 ;	OF STACK)
		2063 ;	CALLS: GETHX,H10,ERROR
		2064 ;	DESTROYS: A,B,C,D,E,H,L,F/F'S
		2065 ;	DESCRIPTION: GETNM FINDS A SPECIFIED COUNT OF NUMBERS, BETWEEN 1
		2066 ;	AND 3, INCLUSIVE, IN THE INPUT
		2067 ;	STREAM AND RETURNS THEIR VALUES ON THE STACK. IF 2
		2068 ;	OR MORE NUMBERS ARE REQUESTED, THEN THE FIRST MUST BE
		2069 ;	LESS THAN OR EQUAL TO THE SECOND. OR THE FIRST AND
		2070 ;	SECOND NUMBERS WILL BE SET EQUAL. THE LAST NUMBER
		2071 ;	REQUESTED MUST BE TERMINATED BY A CARRIAGE RETURN
		2072 ;	OR AN ERROR INDICATION WILL RESULT.
		2073 ;	
		2074	GETNM:
0668	2E03	2075	MVI L,3 ; PUT MAXIMUM ARGUMENT COUNT INTO L
066A	79	2076	MOV A,C ; GET THE ACTUAL ARGUMENT COUNT
066B	E503	2077	ANI 3 ; FORCE TO MAXIMUM OF 3
066D	C8	2078	RZ ; IF 0, DON'T BOTHER TO DO ANYTHING
066E	67	2079	MOV H,A ; ELSE, PUT ACTUAL COUNT INTO H
		2080	GHN05:
066F	CD3206	2081	CALL GETHX ; GET NUMBER FROM INPUT STREAM
		2082	FALSE ERROR ; ERROR IF NOT THERE - TOO FEW NUMBERS
0672	D21E86	2083+	JNC ERROR
0675	C5	2084	PUSH B ; ELSE, SAVE NUMBER ON STACK
0676	2D	2085	DCR L ; DECREMENT MAXIMUM ARGUMENT COUNT
0677	25	2086	DCR H ; DECREMENT ACTUAL ARGUMENT COUNT
0678	CA9496	2087	JZ GNM10 ; BRANCH IF NO MORE NUMBERS WANTED
067B	7A	2088	MOV A,D ; ELSE, GET NUMBER TERMINATOR TO A
067C	F20D	2089	CPI CR ; SEE IF CARRIAGE RETURN
067E	CA1E85	2090	JZ ERROR ; ERROR IF SO - TOO FEW NUMBERS
0681	C36F86	2091	JMP GHN05 ; ELSE, PROCESS NEXT NUMBER
		2092	GNM10:

ORIGINAL PAGE IS
OF POOR QUALITY

LOC	OBJ	LINE	SOURCE STATEMENT
0684	7A	2093	MOV A,D ; WHEN COUNT 0, CHECK LAST TERMINATOR
0685	FE0D	2094	CPI CR
0687	C21E06	2095	JNZ ERROR ; ERROR IF NOT CARRIAGE RETURN
068A	01FFFF	2096	LXI B,0FFFFH ; HL GETS LARGEST NUMBER
068D	7D	2097	MOV A,L ; GET WHAT'S LEFT OF MAXIMUM ARG COUNT
068E	B7	2098	ORA A ; CHECK FOR 0
068F	CA9706	2099	JZ GNM20 ; IF YES, 3 NUMBERS WERE INPUT
		2100	GNM15:
0692	C5	2101	PUSH B ; IF NOT, FILL REMAINING ARGUMENTS WITH 0FFFFH
0693	2D	2102	DCR L
0694	C29206	2103	JNZ GNM15
		2104	GNM20:
0697	C1	2105	POP B ; GET THE 3 ARGUMENTS OUT
0698	D1	2106	POP D
0699	E1	2107	POP H
069A	CDAD06	2108	CALL HILO ; SEE IF FIRST > SECOND
		2109	FALSE GNM25 ; NO - BRANCH
069D	02A206	2110+	JNC GNM25
06A0	54	2111	MOV D,H
06A1	5D	2112	MOV E,L ; YES - MAKE SECOND EQUAL TO THE FIRST
		2113	GNM25:
06A2	E3	2114	XTHL ; PUT FIRST ON STACK - GET RETURN ADDR
06A3	05	2115	PUSH D ; PUT SECOND ON STACK
06A4	C5	2116	PUSH B ; PUT THIRD ON STACK
06A5	E5	2117	PUSH H ; PUT RETURN ADDRESS ON STACK
		2118	GNM30:
06A6	3D	2119	DCR A ; DECREMENT RESIDUAL COUNT
06A7	F8	2120	RI ; IF NEGATIVE, PROPER RESULTS ON STACK
06A8	E1	2121	POP H ; ELSE, GET RETURN ADDR
06A9	E3	2122	XTHL ; REPLACE TOP RESULT WITH RETURN ADDR
06AA	C3A606	2123	JMP GNM30 ; TRY AGAIN
		2124 ;	
		2125 ;	
		2126 ;	*****
		2127 ;	
		2128 ;	
		2129 ;	FUNCTION: HILO
		2130 ;	INPUTS DE - 16 BIT INTEGER
		2131 ;	HL - 16 BIT INTEGER
		2132 ;	OUTPUTS: CARRY - 0 IF HL<DE
		2133 ;	- 1 IF HL>=DE
		2134 ;	CALLS: NOTHING
		2135 ;	DESTROYS: F/F'S
		2136 ;	DESCRIPTION: HILO COMPARES THE 2 16 BIT INTEGERS IN HL AND DE. THE
		2137 ;	INTEGERS ARE TREATED AS UNSIGNED NUMBERS. THE CARRY
		2138 ;	BIT IS SET ACCORDING TO THE RESULT OF THE COMPARISON.
		2139 ;	
		2140	HILO:
06AD	C5	2141	PUSH B ; SAVE BC
06AE	47	2142	MOV B,A ; SAVE A IN B REGISTER
06AF	E5	2143	PUSH H ; SAVE HL PAIR
06B0	7A	2144	MOV A,D ; CHECK FOR DE = 0000H
06B1	33	2145	ORA E
06B2	CACE06	2146	JZ HILO5 ; WE'RE AUTOMATICALLY DONE IF IT IS
06B5	23	2147	INX H ; INCREMENT H BY 1

ORIGINAL PAGE IS
OF POOR QUALITY

LOC	OBJ	LINE	SOURCE STATEMENT
0626	7C	2148	MOV A,H ; WANT TO TEST FOR 0 RESULT AFTER
0627	85	2149	ORA L ; /INCREMENTING
0628	CACE06	2150	JZ HIL05 ; IF SO, HL MUST HAVE CONTAINED 0FFFFH
0628	E1	2151	POP H ; IF NOT, RESTORE ORIGINAL HL
062C	05	2152	PUSH D ; SAVE DE
062D	3EFF	2153	MVI A,0FFH ; WANT TO TAKE 2'S COMPLEMENT OF DE CONTENTS
062F	AA	2154	XRR D
0630	57	2155	MOV D,A
06C1	3EFF	2156	MVI A,0FFH
06C3	AB	2157	XRR E
06C4	5F	2158	MOV E,A
06C5	13	2159	INX D ; 2'S COMPLEMENT OF DE TO DE
06C6	7D	2160	MOV A,L
06C7	83	2161	ADD E ; ADD HL AND DE
06C8	7C	2162	MOV A,H
06C9	8A	2163	ADC D ; THIS OPERATION SETS CARRY PROPERLY
06CA	D1	2164	POP D ; RESTORE ORIGINAL DE CONTENTS
06CB	78	2165	MOV A,B ; RESTORE ORIGINAL CONTENTS OF A
06CC	C1	2166	POP B ; RESTORE ORIGINAL CONTENTS OF BC
06CD	C9,	2167	RET ; RETURN
		2168	HIL05:
06CE	E1	2169	POP H ; IF HL CONTAINS 0FFFFH, THEN CARRY CF=1
06CF	78	2170	MOV A,B ; /ONLY BE SET TO 1
06D0	C1	2171	POP B ; RESTORE ORIGINAL CONTENTS OF REGISTERS
06D1	C33707	2172	JMP SPET ; SET CARRY AND RETURN
		2173 ;	
		2174 ;	
		2175 ;	*****
		2176 ;	
		2177 ;	
		2178 ;	FUNCTION: NMOUT
		2179 ;	INPUTS: A - 8 BIT INTEGER
		2180 ;	OUTPUTS: NONE
		2181 ;	CALLS: ECHO,PRVAL
		2182 ;	DESTROYS: A,B,C,F/F'S
		2183 ;	DESCRIPTION: NMOUT CONVERTS THE 8 BIT, UNSIGNED INTEGER IN THE
		2184 ;	A REGISTER INTO 2 ASCII CHARACTERS. THE ASCII CHARACTERS
		2185 ;	ARE THE ONES REPRESENTING THE 8 BITS. THESE TWO
		2186 ;	CHARACTERS ARE SENT TO THE CONSOLE AT THE CURRENT PRINT
		2187 ;	POSITION OF THE CONSOLE.
		2188 ;	
		2189	NMOUT:
06D4	E5	2190	PUSH H ; SAVE HL - DESTROYED BY PRVAL
06D5	F5	2191	PUSH PSW ; SAVE ARGUMENT
06D6	0F	2192	RRC
06D7	0F	2193	RRC
06D8	0F	2194	RRC
06D9	0F	2195	RRC ; GET UPPER 4 BITS TO LOW 4 BIT POSITIONS
06DA	E50F	2196	ANI HCHAR ; MASK OUT UPPER 4 BITS - WANT 1 HEX CHAR
06DC	CD7402	2197	CALL HEXASC ; CONVERT HEX TO ASCII IN A
06DF	4F	2198	MOV C,A ; LOAD C WITH CHARACTER CODE
06E0	CD0506	2199	CALL ECHO ; SEND TO TERMINAL
06E2	F1	2200	POP PSW ; GET BACK ARGUMENT
06E4	E50F	2201	ANI HCHAR ; MASK OUT UPPER 4 BITS - WANT 1 HEX CHAR
06E6	CD7402	2202	CALL HEXASC ; CONVERT HEX TO ASCII IN A

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-11 9090/8085 MACRO ASSEMBLER, V3.0 MONTR PAGE 42

LOC	OBJ	LINE	SOURCE STATEMENT
06E9	4F	2293	MOV C,A ; LOAD C WITH CHARACTER CODE
06EA	00506	2294	CALL ECHO
06ED	E1	2295	POP H ; RESTORE SAVED VALUE OF HL
06EE	C9	2296	RET ; RETURN
		2297 ;	
		2298 ;	
		2299 ;	*****
		2210 ;	
		2211 ;	
		2212 ;	FUNCTION: REGDS
		2213 ;	INPUTS: NONE
		2214 ;	OUTPUTS: NONE
		2215 ;	CALLS: ECHO, NMOUT, ERROR, CROUT
		2216 ;	DESTROYS: A, B, C, D, E, H, F/F'S
		2217 ;	DESCRIPTION: REGDS DISPLAYS THE CONTENTS OF THE REGISTER SAVE
		2218 ;	LOCATIONS, IN FORMATTED FORM, ON THE CONSOLE. THE
		2219 ;	DISPLAY IS DRIVEN FROM THE TABLE RTAB, WHICH CONTAINS
		2220 ;	THE REGISTER'S PRINT SYMBOL, SAVE LOCATION ADDRESS,
		2221 ;	AND LENGTH (8 OR 16 BITS).
		2222 ;	
		2223	REGDS:
06EF	24E507	2224	LXI H,RTAB ; LOAD HL WITH ADDRESS OF START OF TABLE
		2225	REG05:
06F2	4E	2226	MOV C,M ; GET PRINT SYMBOL OF REGISTER
06F3	79	2227	MOV R,C
06F4	B7	2228	ORA A ; TEST FOR 6 - END OF TABLE
06F5	C2FC06	2229	JNZ REG10 ; IF NOT END, BRANCH
06F8	C0FF05	2230	CALL CROUT ; ELSE, CARRIAGE RETURN/LINE FEED TO END
06FB	C9	2231	RET ; /DISPLAY
		2232	REG10:
06FC	C00506	2233	CALL ECHO ; ECHO CHARACTER
06FF	0E3D	2234	MYI C,'='
0701	C00506	2235	CALL ECHO ; OUTPUT EQUALS SIGN, I. E. A=
0704	23	2236	INX H ; POINT TO START OF SAVE LOCATION ADDRESS
0705	5E	2237	MOV E,H ; GET LSP OF SAVE LOCATION ADDRESS TO E
0706	1520	2238	MYI D,RAMST SHR 8 ; PUT MSP OF SAVE LOC ADDRESS INTO D
0708	23	2239	INX H ; POINT TO LENGTH FLAG
0709	1A	2240	LDAX D ; GET CONTENTS OF SAVE ADDRESS
070A	C0D406	2241	CALL NMOUT ; DISPLAY ON CONSOLE
070D	7E	2242	MOV A,H ; GET LENGTH FLAG
070E	B7	2243	ORA A ; SET SIGN F/F
070F	C01707	2244	JZ REG15 ; IF 0, REGISTER IS 8 BITS
0712	1B	2245	DCX D ; ELSE, 16 BIT REGISTER SO MORE TO DISPLAY
0713	1A	2246	LDAX D ; GET LOWER 8 BITS
0714	C0D406	2247	CALL NMOUT ; DISPLAY THEM
		2248	REG15:
0717	0E20	2249	MYI C,' '
0719	C00506	2250	CALL ECHO
071C	23	2251	INX H ; POINT TO START OF NEXT TABLE ENTRY
071D	C3F206	2252	JMP REG05 ; DO NEXT REGISTER
		2253 ;	
		2254 ;	
		2255 ;	*****
		2256 ;	
		2257 ;	

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II 9090/9085 MACRO ASSEMBLER, V3.0 MONITR PAGE 43

LOC	OPT	LINE	SOURCE STATEMENT
		2258	; FUNCTION: RQADR.
		2259	; INPUTS: C - CHARACTER DENOTING REGISTER
		2260	; OUTPUTS: EC - ADDRESS OF ENTRY IN RTAB CORRESPONDING TO REGISTER
		2261	; CALLS: ERROR
		2262	; DESTROYS: A, B, C, D, E, H, L, F/F'S
		2263	; DESCRIPTION: RQADR TAKES A SINGLE CHARACTER AS INPUT. THIS CHARACTER
		2264	DENOTES A REGISTER. RQADR SEARCHES THE TABLE RTAB
		2265	FOR A MATCH ON THE INPUT ARGUMENT. IF ONE OCCURS,
		2266	RQADR RETURNS THE ADDRESS OF THE ADDRESS OF THE
		2267	SAVE LOCATION CORRESPONDING TO THE REGISTER. THIS
		2268	ADDRESS POINTS INTO RTAB. IF NO MATCH OCCURS, THEN
		2269	THE REGISTER IDENTIFIER IS ILLEGAL AND CONTROL IS
		2270	PASSED TO THE ERROR ROUTINE.
		2271	;
		2272	RQADR:
0720	218007	2273	LXI H, RTAB ; HL GETS ADDRESS OF TABLE START
0723	119300	2274	LXI D, RTABS ; DE GETS SIZE OF A TABLE ENTRY
		2275	RQA05:
0725	7E	2276	MOV A, M ; GET REGISTER IDENTIFIER
0727	B7	2277	ORA A ; CHECK FOR TABLE END (IDENTIFIER IS 0)
0728	0A1E06	2278	JZ ERROR ; IF AT END OF TABLE, ARGUMENT IS ILLEGAL
0728	B9	2279	CMP C ; ELSE, COMPARE TABLE ENTRY AND ARGUMENT
0720	0A2307	2280	JZ RQA10 ; IF EQUAL, WE'VE FOUND WHAT WE'RE LOOKING FOR
072F	13	2281	INR D ; ELSE, INCREMENT TABLE POINTER TO NEXT ENTRY
0730	032507	2282	JMP RQA05 ; TRY AGAIN
		2283	RQA10:
0733	23	2284	INX H ; IF A MATCH, INCREMENT TABLE POINTER TO
0734	44	2285	MOV B, H ; /SAVE LOCATION ADDRESS
0735	40	2286	MOV C, L ; RETURN THIS VALUE
0736	09	2287	RET ; RETURN
		2288	;
		2289	;
		2290	*****
		2291	;
		2292	;
		2293	; FUNCTION: SRET
		2294	; INPUTS: NONE
		2295	; OUTPUTS: CARRY = 1
		2296	; CALLS: NOTHING
		2297	; DESTROYS: CARRY
		2298	; DESCRIPTION: SRET IS JUMPED TO BY ROUTINES WISHING TO RETURN SUCCESS.
		2299	SRET SETS THE CARRY TRUE AND THEN RETURNS TO THE
		2300	CALLER OF THE ROUTINE INVOKING SRET.
		2301	;
		2302	SRET:
0737	37	2303	STC ; SET CARRY TRUE
0738	09	2304	RET ; RETURN APPROPRIATELY
		2305	;
		2306	;
		2307	*****
		2308	;
		2309	;
		2310	; FUNCTION: STH0
		2311	; INPUTS: DE - 16 BIT ADDRESS OF BYTE TO BE STORED INTO
		2312	; OUTPUTS: NONE

ORIGINAL PAGE IS
OF POOR QUALITY

IS15-1: 0000/0005 MACRO ASSEMBLER, V3.0 MONTR PAGE 44

LOC	OBJ	LINE	SOURCE STATEMENT
		2313	; CALLS: STHLF
		2314	; DESTROYS: A,B,C,H,L,F/F'S
		2315	; DESCRIPTION: STHF0 CHECKS THE HALF BYTE FLAG IN TEMP TO SEE IF
		2316	; IT IS SET TO LOWER. IF SO, STHF0 STORES A 0 TO
		2317	; PAD OUT THE LOWER HALF OF THE ADDRESSED BYTE;
		2318	; OTHERWISE, THE ROUTINE TAKES NO ACTION.
		2319	;
		2320	STHF0:
0739	3AFD20	2321	LDA TEMP ; GET HALF BYTE FLAG
073C	87	2322	ORA A ; SET F/F'S
073D	C0	2323	RNZ ; IF SET TO UPPER, DON'T DO ANYTHING
073E	0E00	2324	MVI C,0 ; ELSE, WANT TO STORE THE VALUE 0
0740	CD4407	2325	CALL STHLF ; DO IT
0743	C9	2326	PET ; RETURN
		2327	;
		2328	;
		2329	*****
		2330	;
		2331	;
		2332	; FUNCTION: STHLF
		2333	; INPUTS: C - 4 BIT VALUE TO BE STORED IN HALF BYTE
		2334	; DE - 16 BIT ADDRESS OF BYTE TO BE STORED INTO
		2335	; OUTPUTS: NONE
		2336	; CALLS: NOTHING
		2337	; DESTROYS: A,B,C,H,L,F/F'S
		2338	; DESCRIPTION: STHLF TAKES THE 4 BIT VALUE IN C AND STORES IT IN
		2339	; HALF OF THE BYTE ADDRESSED BY REGISTERS DE. THE
		2340	; HALF BYTE USED (EITHER UPPER OR LOWER) IS DENOTED
		2341	; BY THE VALUE OF THE FLAG IN TEMP. STHLF ASSUMES
		2342	; THAT THIS FLAG HAS BEEN PREVIOUSLY SET
		2343	; (NOMINALLY BY ICHD).
		2344	;
		2345	STHLF:
0744	05	2346	PUSH D
0745	E1	2347	POP H ; MOVE ADDRESS OF BYTE INTO HL
0746	79	2348	MOV A,C ; GET VALUE
0747	E50F	2349	ANI 0FH ; FORCE TO 4 BIT VALUE
0749	4F	2350	MOV C,A ; PUT VALUE BACK
074A	3AFD20	2351	LDA TEMP ; GET HALF BYTE FLAG
074D	87	2352	ORA A ; CHECK FOR LOWER HALF
074E	C25707	2353	JNZ STH05 ; BRANCH IF NOT
0751	7E	2354	MOV A,H ; ELSE, GET BYTE
0752	E6F0	2355	ANI 0F0H ; CLEAR LOWER 4 BITS
0754	81	2356	ORA C ; OR IN VALUE
0755	77	2357	MOV H,A ; PUT BYTE BACK
0756	C9	2358	PET ; RETURN
		2359	STH05:
0757	7E	2360	MOV A,H ; IF UPPER HALF, GET BYTE
0758	E60F	2361	ANI 0FH ; CLEAR UPPER 4 BITS
075A	47	2362	MOV B,A
075B	79	2363	MOV A,C ; GET VALUE
075D	0F	2364	RRC
075E	0F	2365	RRC
075E	0F	2366	RRC
075F	0F	2367	RRC ; ALIGN TO UPPER 4 BITS

ORIGINAL PAGE IS
OF POOR QUALITY.

IS15-11 8060/8095 MACRO ASSEMBLER V3.0 MONTR PAGE 45

LOC	OBJ	LINE	SOURCE STATEMENT
0750	B0	2368	ORA B ; OR IN ORIGINAL 4 BITS
0751	77	2369	MOV M,A ; PUT NEW CONFIGURATION BACK
0752	C9	2370	RET ; RETURN
		2371 ;	
		2372 ;	
		2373 ;	*****
		2374 ;	
		2375 ;	
		2376 ;	FUNCTION: VALDG
		2377 ;	INPUTS: C - ASCII CHARACTER
		2378 ;	OUTPUTS: CARRY - 1 IF CHARACTER REPRESENTS VALID HEX DIGIT
		2379 ;	- 0 OTHERWISE
		2380 ;	CALLS: NOTHING
		2381 ;	DESTROYS: A,F/F'S
		2382 ;	DESCRIPTION: VALDG RETURNS SUCCESS IF ITS INPUT ARGUMENT IS
		2383 ;	AN ASCII CHARACTER REPRESENTING A VALID HEX DIGIT
		2384 ;	(0-9,A-F), AND FAILURE OTHERWISE.
		2385 ;	
		2386	VALDG:
0757	79	2387	MOV A,C
0754	FE30	2388	CPI '0' ; TEST IF CHARACTER IS A '0'
0755	FA2906	2389	JM FRET ; IF ASCII CODE LESS, CANNOT BE VALID DIGIT
0759	FE39	2390	CPI '9' ; ELSE, SEE IF IN RANGE '0'-'9'
0760	FA3707	2391	JM SRET ; CODE BETWEEN '0' AND '9'
076E	CA3707	2392	JZ SRET ; CODE EQUAL '9'
0771	FE41	2393	CPI 'A' ; NOT A DIGIT - TRY FOR A LETTER
0772	FA2906	2394	JM FRET ; NO - CODE BETWEEN '9' AND 'A'
0776	FE47	2395	CPI 'G'
0778	F22906	2396	JP FRET ; NO - CODE GREATER THAN 'F'
077B	C33707	2397	JMP SRET ; OKAY - CODE IS 'A' TO 'F', INCLUSIVE
		2398 ;	
		2399 ;	
		2400 ;	*****
		2401 ;	
		2402 ;	
		2403 ;	FUNCTION: VALDL
		2404 ;	INPUTS: C - CHARACTER
		2405 ;	OUTPUTS: CARRY - 1 IF INPUT ARGUMENT VALID DELIMITER
		2406 ;	- 0 OTHERWISE
		2407 ;	CALLS: NOTHING
		2408 ;	DESTROYS: A,F/F'S
		2409 ;	DESCRIPTION: VALDL RETURNS SUCCESS IF ITS INPUT ARGUMENT IS A VALID
		2410 ;	DELIMITER CHARACTER (SPACE, COMMA, CARRIAGE RETURN) AND
		2411 ;	FAILURE OTHERWISE
		2412 ;	
		2413	VALDL:
077E	79	2414	MOV A,C
077F	FE2C	2415	CPI ',' ; CHECK FOR COMMA
0781	CA3707	2416	JZ SRET
0784	FE8D	2417	CPI CR ; CHECK FOR CARRIAGE RETURN
0786	CA3707	2418	JZ SRET
0789	FE20	2419	CPI ' ' ; CHECK FOR SPACE
078B	CA3707	2420	JZ SRET
078E	C22906	2421	JMP FRET ; ERROR IF NONE OF THE ABOVE
		2422 ;	

ORIGINAL PAGE IS
OF POOR QUALITY

1515-11 9080/8085 MACRO ASSEMBLER, V3.0 MONITR PAGE 46

```

LOC OBJ      LINE      SOURCE STATEMENT
2423 ;
2424 ;*****
2425 ;
2426 ; DUMMY INTERRUPT ROUTINE ENTRY POINTS
2427 ;
2428 TRAPPR:
2429 RESET5:
2430 RESET6:
2431 RESET65:
2432 RESET7:
2433 RESET75:
0791 FB      2434 EI ; ENABLE INTERRUPTS AGAIN
0792 C9      2435 RET ; RETURN TO VECTOR POINT
2436 ;
2437 ;*****
2438 ;
2439 ;
2440 ;
2441 ;
2442 ;
2443 ;*****
2444 ;
2445 ;
2446 SIGNON:      ; SIGNON MESSAGE
0793 00      2447 DB CR,LF,'SDMON  VER 1.0',CR,LF
0794 0A
0795 52544440
0799 4F4E2020
079D 20564552
07A1 20212E20
07A5 00
07A6 0A
0014      2448 L$IGNON EQU $-SIGNON ; LENGTH OF SIGNON MESSAGE
2449 ;
2450 CADR:      ; TABLE OF ADDRESSES OF COMMAND ROUTINES
07A7 0000      2451 DW 0 ; DUMMY
07A9 5005      2452 DW XCMD
07AB 3F05      2453 DW SCMD
07AD 1F05      2454 DW IACMD
07AF 0504      2455 DW ICMD
07B1 5724      2456 DW GCMD
07B2 9604      2457 DW DCMD
2458 ;
2459 CTAB:      ; TABLE OF VALID COMMAND CHARACTERS
07B5 44      2460 DB 'D'
07B6 47      2461 DB 'G'
07B7 49      2462 DB 'I'
07B8 40      2463 DB 'M'
07B9 53      2464 DB 'S'
07BA 59      2465 DB 'X'
0006      2466 NCMDE EQU $-CTAB ; NUMBER OF VALID COMMANDS
2467 ;
2468 RTAB:      ; TABLE OF REGISTER INFORMATION
07B5 41      2469 DB 'R' ; REGISTER IDENTIFIER
07BC EE      2470 DB RSRV AND 0FFH ; ADDRESS OF REGISTER SAVE LOCATION

```

ORIGINAL PAGE IS
OF POOR QUALITY

LOC	ORG	LINE	SOURCE STATEMENT
07E0	00	2471	DB 0 ; LENGTH FLAG - 0=8 BITS, 1=16 BITS
0802		2472	STABE EQU \$-STAB ; SIZE OF AN ENTRY IN THIS TABLE
07E3	4E	2473	DB 'B'
07E4	51	2474	DB BSRV AND 0FFH
07C9	00	2475	DB 0
07C1	45	2476	DB 'C'
07C2	EB	2477	DB CSRV AND 0FFH
07C3	00	2478	DB 0
07C4	44	2479	DB 'D'
07C5	EA	2480	DB DSRV AND 0FFH
07C6	00	2481	DB 0
07C7	45	2482	DB 'E'
07C8	E9	2483	DB ESRV AND 0FFH
07C9	00	2484	DB 0
07CA	46	2485	DB 'F'
07CB	ED	2486	DB FSRV AND 0FFH
07CC	00	2487	DB 0
07CD	49	2488	DB 'I'
07CE	F1	2489	DB ISRV AND 0FFH
07CF	00	2490	DB 0
07D0	48	2491	DB 'H'
07D1	F0	2492	DB HSRV AND 0FFH
07D2	00	2493	DB 0
07D3	4C	2494	DB 'L'
07D4	EF	2495	DB LSRV AND 0FFH
07D5	00	2496	DB 0
07D6	4D	2497	DB 'M'
07D7	F0	2498	DB MSRV AND 0FFH
07D8	01	2499	DB 1
07D9	53	2500	DB 'S'
07DA	F5	2501	DB SSRV+1 AND 0FFH
07DB	01	2502	DB 1
07DC	50	2503	DB 'P'
07DD	F7	2504	DB PSRV+1 AND 0FFH
07DE	01	2505	DB 1
07DF	55	2506	DB 0 ; END OF TABLE ENTRIES
07E0	00	2507	DB 0
		2508	;
0800		2509	ORG BYTE ; BRANCH TABLE FOR USER ACCESSIBLE ROUTINES
		2510	;
0920	02F405	2511	JMP 00 ; TTY CONSOLE OUTPUT
0923	030F05	2512	JMP 01 ; TTY CONSOLE INPUT
		2513	;
		2514	;
0927		2515	TTYDEV EQU 27H
		2516	;
		2517	;
		2518	;
		2519	CONVION/CLOCK/ FLAG1, FLAG2, FLAG3, TIME1B, TIME2B, BYTE
		2520	;
		2521	CLOCK FLAGS AND COUNTERS
		2522	;
0901		2523	ORG USER-5 ; 200K
0902	00	2524	DB 0 ; 1 USEC FLAG
0903	00	2525	DB 0 ; 50 USEC FLAG

ORIGINAL PAGE IS
OF POOR QUALITY

11712-11 3080 6635 HRCPO ASSEMBLER, V2.0 MONTR PAGE 48

```

LOC 00:      LINE      SOURCE STATEMENT

2004 00      2526 DB 0 ; 1 SEC FLAG
2005 00      2527 DB 0 ; SECOND COUNT LSB
2006 00      2528 DB 0 ; SECOND COUNT MSB
2007 00      2529 DB 0 ; NOT USED
                2530 ;
                2531 ;*****
                2532 ;
                2533 ; IN THE FOLLOWING LOCATIONS, THE USER MAY PLACE JUMP INSTRUCTIONS TO
2534 ; ROUTINES FOR HANDLING THE FOLLOWING:-
                2535 ;     A) RST 5, 6 & 7
                2536 ;     B) HARDWIRED USER INTERRUPT (RST 6.5)
                2537 ;     C) KEYBOARD "VECTORED INTERRUPT" KEY (RST 7.5)
                2538 ;
2008          2529 ORG USR6R ; START OF USER BRANCH LOCATIONS
                2540 ;
2009 00      2541 RSET5: DB 0,0,0 ; JUMP TO RST 5 ROUTINE
2009 00
2009 00
2009 00
2009 00      2542 RSET6: DB 0,0,0 ; JUMP TO RST 6 ROUTINE
2009 00
2009 00
2009 00      2543 RST55: DB 0,0,0 ; JUMP TO RST 6.5 (HARDWIRED USER INTERRUPT)
2009 00
2009 00
2009 00
2001          2544 TRAPEP EQU $
2001 00      2545 RSET7: DB 0,0,0 ; JUMP TO RST 7 ROUTINE
2002 00
2003 00
2004 00      2546 USINT: DB 0,0,0 ; JUMP TO "VECTORED INTERRUPT" KEY ROUTINE
2005 00
2006 00
                2547 ;
                2548 ;*****
                2549 ;
                2550 SPACE IS RESERVED HERE FOR THE MONITOR STACK
                2551 ;
                2552 ;*****
                2553 ;
20E3          2554 ORG MNSTK ; START OF MONITOR STACK
                2555 ;
                2556 ;     SAVE LOCATIONS FOR USER REGISTERS
                2557 ;
20E3 00      2558 ESAY: DB 0 ; E REGISTER
20E4 00      2559 DRAY: DB 0 ; D REGISTER
20E5 00      2560 CRAY: DB 0 ; C REGISTER
20E6 00      2561 BRAY: DB 0 ; B REGISTER
20E7 00      2562 FRAY: DB 0 ; FLAGS
20E8 00      2563 ARAY: DB 0 ; A REGISTER
20E9 00      2564 LRAY: DB 0 ; L REGISTER
20EA 00      2565 HRAY: DB 0 ; H REGISTER
20EB 00      2566 ISPV: DB 0 ; INTERRUPT MASK
20EC 00      2567 PSRV:      ; PROGRAM COUNTER
20ED 00      2568 POLSV: DB 0 ; LOW ORDER BYTE OF PC
20EE 00      2569 POHSV: DB 0 ; HIGH ORDER BYTE OF PC
20EF 00      2570 SSAY:      ; STACK POINTER

```

ORIGINAL PAGE IS
OF POOR QUALITY

1575-11 8080/8085 MFC80 ASSEMBLER, V3.0 MONTR PAGE 49

```

LOC  CFI  LINE  SOURCE STATEMENT
25F4 00    2571 SFPSV: DB 0 ; LOW ORDER BYTE OF STACK POINTER
25F5 00    2572 SFPSV: DB 0 ; HIGH ORDER BYTE OF STACK POINTER
2573 ;
2574 ; *****
2575 ;
2576 ; MONITOR STORAGE LOCATIONS
2577 ;
25F6 0000  2578 CURAD: DW 0 ; CURRENT ADDRESS
25F8 00    2579 CURDY: DB 0 ; CURRENT DATA
25F9      2580 OBUFF: DS 4 ; OUTPUT BUFFER
2581 TEMP:      ; TEMPORARY LOCATION FOR TTY MONITOR
2582      ; TEMPORARY LOCATION FOR SINGLE STEP ROUTINE
25FD 00    2583 RGPTR: DB 0 ; REGISTER POINTER
25FE 00    2584 IBUFF: DB 0 ; INPUT BUFFER
25FF 00    2585 USCSR: DB 0 ; USER SHOULD STORE IMAGE OF CSR HERE FOR EACH TIME STEP
2586      ; /CSR IS CHANGED, OTHERWISE, SINGLE STEP
2587      ; /ROUTINE WILL DESTROY CSR CONTENTS
2588 END

```

PUBLIC SYMBOLS

CI	A 050F	CMVEN	A 05EB	CO	A 05F4	DELAY	A 0308	DISP1	A 02AB	GO	A 0449	HEXASC	A 0274
MONTR	A 0000	MSEC1H	A 039D	MSEC20	A 03A3	MSEC2H	A 0397	OUTPT	A 029E	RDKEY	A 0200	SECDT	A 0391

INTERNAL SYMBOLS

INTPT E 0000

USER SYMBOLS

ADCP04	A 02F8	ADFLD	A 0000	ADISP	A 0099	ASAV	A 20EE	BLANK	A 00A9	BLANKS	A 030B	BLNKS	H 030F
BACKR	A 001B	BRTAB	A 0320	BSAV	A 20EC	CROR	A 07A7	CDATA	A 000C	CI	A 050F	CLEAR	A 0005
CLDIS	A 0106	CLDST	A 010C	CLEAR	A 010D	CM010	A 0087	CM015	A 0093	CM0AD	A 029A	CM0TB	A 03B5
CMAND	A 0024	CMIN	A 00DC	CMOUT	A 00DC	CNTRL	A 0001	CMVEN	A 05EB	CO	A 05F4	COLCNT	A 02E2
CONMA	A 0011	CONCP	A 000D	CONSCP	A 000E	CR	A 0000	CRUT	A 05FF	CSAV	A 20EE	CSNIT	H 0000
CSR	A 0020	CSTAT	A 000D	CTAB	A 07E5	CURAD	A 20F6	CURDT	A 20F8	DCH05	A 049D	DCH10	A 0498
DCH15	A 049D	DCMD	A 0486	DDISP	A 0094	DELAY	A 0308	DELENT	A 039A	DISP1	A 029E	DISPC	A 01EB
DOT	A 0001	DSAV	A 20EA	DSFDT2	A 0390	DSFDT4	A 0373	DSPLY	A 00D9	DSPNUM	A 03C4	DSPTB	A 03C4
EFLD	A 0001	ECH05	A 058E	ECH10	A 061C	ECH0	A 0605	EIGHT	A 00F8	EMPTY	A 0000	ENCODR	H 02F3
ERMSG	A 03E3	ERR	A 01FF	ERROR	A 061E	ESAV	A 20E9	ESC	A 001B	EXAM	A 009E	EXIT	A 0623
EXM05	A 00AF	EXM10	A 00C8	EXMSG	A 03E7	FALSE	+ 0001	FIVE	A 0005	FRET	A 0503	FSAV	A 20ED
G10	A 00FA	GCM05	A 040C	GCM10	A 0402	GCMD	A 0487	GETCH	A 062C	GETCH	A 0457	GETHX	A 0633
GETHM	A 0668	GHX05	A 0539	GHX10	A 0632	GXM05	A 066F	GXM10	A 0684	GXM15	A 0692	GXM20	H 0697
GXM25	A 06A2	GXM30	A 06A6	GO	A 0449	GUCMD	A 000B	GTC03	A 0462	GTC05	A 0470	GTC10	H 047C
GTH05	A 0214	GTH10	A 0231	GTH20	A 0237	GTH25	A 0248	GTH5X	A 0200	HCHAR	A 000F	HEX05	A 027E
HEXASC	A 0274	HIL05	A 06CE	HILO	A 06AD	HSAY	A 20F0	HYD5P	A 024E	HYD5P2	A 0260	IBUFF	A 20FE
ICH05	A 04E0	ICH10	A 0508	ICH20	A 0510	ICH25	A 0516	ICMD	A 04D5	ININT	A 0291	INITUT	H 0000
INSDG	A 0286	INTPT	E 0000	INVRT	A 00FF	ISAV	A 20F1	LETRA	A 00C1	LETRB	A 00C2	LETRC	A 00C3
LETRD	A 00C4	LETR	A 00C5	LETRF	A 00C6	LETRH	A 00C8	LETRI	A 00C9	LETRL	A 00CA	LETRP	A 00CB
LETRR	A 00D2	LETRS	A 00D3	LF	A 000A	LOHER	A 0009	LSAV	A 20EF	LSGNON	A 0014	MCM05	A 0527
MCMD	A 051F	MNSTK	A 20E9	MONTR	A 0000	MONPRK	A 007E	MSEC1H	A 039D	MSEC20	A 03A3	MSEC2H	A 0397
MSECDT	A 0396	MSGL	A 044E	NCMDS	A 0005	NEHLN	A 000F	NMOUT	A 00D4	INITEL	A 0408	NOOUT	A 0000
NKEY	A 0074	NUMC	A 0005	NUMFG	A 000D	NXTCOL	A 02C4	NXTRG	A 029F	OBUFF	A 20F9	OUT05	A 02A0
OUTPT	A 029E	PCHSV	A 20F3	PELEV	A 20F2	PERIO	A 0019	PRMPT	A 00F0	PSY0	A 0075	PSAV	H 20F2
RAMST	A 2000	REF	A 0040	RDKEY	A 0200	RDYBL	A 03F3	REG05	A 00F2	REG10	A 05FC	REG15	A 0717
REGDS	A 05EF	RES10	A 003F	RESETS	A 0791	RESET6	A 0791	RESET7	A 0791	SETF	A 030B	SETT	A 030B
RGA05	A 0725	RGA10	A 0732	RGA0R	A 0720	RGL0C	A 030D	RGNAM	A 031A	RGPTB	A 03F8	RGPTR	A 20FD

ORIGINAL PAGE IS
OF POOR QUALITY

ISIS-II 0000/0005 MACRO ASSEMBLER, V3.0

MONITR PAGE 50

RGTBL	A 0430	RKXIT	A 02FE	RNUSE	A 0017	RONCNT	A 02EA	REETS	A 2003	REETS	A 2008	REETS5	A 0791
RSET7	A 2001	RSET75	A 0791	REP05	A 0330	RSR10	A 0341	RST65	A 200E	RET05	A 0328	RTAB	A 0798
RTAB5	A 0003	RTAB5	A 0544	SCM10	A 054F	SCM15	A 055F	SCMD	A 052F	SEDOT	A 0391	SETR6	A 0354
SCMCH	A 0793	SKLN	A 0012	SHSG	A 03EF	SPHSV	A 20F5	SPLSV	A 20F4	SPET	A 0737	SHV	A 20F4
SSSTEP	A 0109	STH05	A 0757	STHF0	A 0739	STHLF	A 0744	STP20	A 0120	STP21	A 0142	STP22	A 0149
STP23	A 014C	STP25	A 014F	SUB05	A 0194	SUB10	A 019A	SUB15	A 01C5	SUBST	A 017F	TBE	A 0080
TEMP	A 20FD	TERM	A 001B	TRAFEP	A 2001	TRAPP	A 0791	TRUE	+ 0000	TTYADV	A 0027	UERLN	A 000F
UNMSK	A 000E	UPD0D	A 036F	UPDDT	A 037C	UPPER	A 00FF	URTPC	A 00E0	URTSPC	A 0003	USCSR	A 20FF
USTNT	A 20D4	USRBR	A 20C8	VALDG	A 0763	VALDL	A 077E	XCM05	A 0576	XCM10	A 0585	XCM15	A 0592
XCM18	A 0590	XCM20	A 0586	XCM25	A 05C0	XCM27	A 05CE	XCM30	A 05D6	XCM0	A 0562	YMS0	A 03EB
ZERO	A 00E0												

ASSEMBLY COMPLETE, NO ERRORS

SUBMIT FORTEN(VCSPPG)
SUBMIT FORTEN(VCSUP)
SUBMIT FORTEN(VCSXK)
SUBMIT FORTEN(VCSXNT)
SUBMIT FORTEN(VCSXSG)
SUBMIT FORTEN(VCSXU)
SUBMIT FORTEN(VCSXON)
SUBMIT FORTEN(VCSXNP)
SUBMIT FORTEN(VCSXOZ)
SUBMIT FORTEN(VCSXAP)
SUBMIT ASMBL(VCSUTL)
SUBMIT ASMBL(VCSIOX)
SUBMIT ASMBL(VCSIOD)
SUBMIT ASMBL(INTRPT)
SUBMIT ASMBL(DEFAULT)
SUBMIT ASMBL(TAELES)
SUBMIT ASMBL(DEFTAB)
SUBMIT ASMBL(MONITR)

ORIGINAL PAGE IS
OF POOR QUALITY

REPORTS - FL NO FOR
COPY - FL NO LST TO -LP:
DELETE - FL NO LST

ORIGINAL PAGE IS
OF POOR QUALITY

ASAGA - F1 -> ASH -> MACROFILE 100025
CORP - F1 -> LST -> MLP
DELETE - F1 -> LST


```

LOCATE :F1:VCSLDC.MAP TO :F1:VCSRUM.&
MAP PUBLICS PRINT :F1:VCSLDC.MAP) &
ORDER/DATA STACK CODE MEMORY%
/DATP/2120H) STACK/2E30H) &
/COSE/4000H) MEMORY/00300H) &
/NEST22/10240H) /DEF02E/10000H) &
/NEST2B/10000H) /NEST2L/10000H) &
/DEF01T/10000H) /CLOC07/10000H) &
/DEF02H/10000H) /DEF02B/10000H) &
/DEF02S/10000H) /MOSHEE/10000H) &
/OPSVEG/10000H) &
/ACTIVEC/10014H) &
/OPSVEG/10024H) &
/OPSFMS/10030H) &
/OPSFNT/10060H) &
/ACTT02/10070H) &
/SEIBLJ/10080H) &
/COH01S/10080H) &
/COH01L/10100H) &
/OPV01F/10100H) &
/SEMPNT/10100H) &
/SEMP0L/10200H) &
/TEST00/10504H) &
/TEST01/10504H) &
/WORK/10500H) &
/TEST02/10604H) &
/SAVER/10604H) &
/SEMEM/10700H)
COPY :F1:VCSLDC.MAP TO :LP
DELETE :F1:VCSLDC.MAP

```

ORIGINAL PAGE IS
OF POOR QUALITY

LINK -F1-WCSPG OBJ -F1-WCSEP OBJ &
-F1-WCEXS LIB -F1-WCSDG OBJ &
-F1-MOTAP LIB &
-F1-WCSTG LIB -F1-WCSTGL LIB &
-F1-TABLES OBJ -F1-DETPR OBJ -F1-DEFAULT OBJ &
FSPUN LIB FSPND LIB FFEF LIB &
FNDLL LIB FMSA LIB &
TO -F1-WCSPG LNK

**ORIGINAL PAGE IS
OF POOR QUALITY**

```
DELETE :F1:VCS*.LIB, :F1:DEBUG.LIB, :F1:MONTRB.LIB
LIB
CREATE :F1:VCSSEPS.LIB
ADD :F1:VCSSEUP.OBJ TO :F1:VCSSEPS.LIB
CREATE :F1:VCSICS.LIB
ADD :F1:VCSINP.OBJ TO :F1:VCSICS.LIB
ADD :F1:VCSCON.OBJ TO :F1:VCSICS.LIB
CREATE :F1:MONTRB.LIB
ADD :F1:MONTRB.OBJ TO :F1:MONTRB.LIB
ADD :F1:INTRPT.OBJ TO :F1:MONTRB.LIB
ADD :F1:TABLES.OBJ TO :F1:MONTRB.LIB
ADD :F1:DEFAULT.OBJ TO :F1:MONTRB.LIB
ADD :F1:DEFIN.TAB.OBJ TO :F1:MONTRB.LIB
CREATE :F1:VCSSEXS.LIB
ADD :F1:VCSSEHT.OBJ TO :F1:VCSSEXS.LIB
ADD :F1:VCSSEVM.OBJ TO :F1:VCSSEXS.LIB
ADD :F1:VCSSTAP.OBJ TO :F1:VCSSEXS.LIB
CREATE :F1:DEBUG.LIB
ADD :F1:VCSDBG.OBJ TO :F1:DEBUG.LIB
CREATE :F1:VCSICL.LIB
ADD :F1:VCSICL0.OBJ TO :F1:VCSICL.LIB
ADD :F1:VCSICL1.OBJ TO :F1:VCSICL.LIB
ADD :F1:VCSICL2.OBJ TO :F1:VCSICL.LIB
ADD :F1:VCSICL3.OBJ TO :F1:VCSICL.LIB
ADD :F1:VCSICL4.OBJ TO :F1:VCSICL.LIB
ADD :F1:VCSICL5.OBJ TO :F1:VCSICL.LIB
ADD :F1:VCSICL6.OBJ TO :F1:VCSICL.LIB
ADD :F1:VCSICL7.OBJ TO :F1:VCSICL.LIB
ADD :F1:VCSICL8.OBJ TO :F1:VCSICL.LIB
ADD :F1:VCSICL9.OBJ TO :F1:VCSICL.LIB
EXIT
```

ORIGINAL PAGE IS
OF POOR QUALITY

```

DELETE 01 WSTOL LIS
LIE
CREATE 01 WSTOL LIS
ADD 01 WSTOL 001 TO 01 WSTOL LIS
ADD 01 WSTOL 001 TO 01 WSTOL LIS
ADD 01 WSTOL 001 TO 01 WSTOL LIS
ADD 01 WSTOL 001 TO 01 WSTOL LIS
ADD 01 WSTOL 001 TO 01 WSTOL LIS
EXIT

```

ORIGINAL PAGE IS
OF POOR QUALITY