

Monitoring of current density distribution

I. Biswas, D. Garcia Sanchez, M. Schulze

German Aerospace Center (DLR)
Institute of Engineering Thermodynamics
Electrochemical Energy Technology
Stuttgart, Germany



Knowledge for Tomorrow



Outline

- Current Density
- Local current density monitoring – technology principles and origins in fuel cell technology
- INSIDE – Diagnostics in Electrolysis
- Application examples
- Outlook



Knowledge for Tomorrow


Current Density

- Key point indicator for electrolysers and fuel cells: efficiency of used materials (PGMs, etc.)
- Faraday's Law:
Current density equals chemical turnover
- Local electrochemical turnover is determined by
 - local* catalytic activity
 - local* transport limitations
 - local* degradation
 - local* temperature
 - local*...




Technology: Segmented Printed circuit boards

- Origin: PEM Fuel cells
- PCB mimicks bipolar plate
- Endplate contact possible
- Gas tightness
- Current take up 8 A/cm^2
- Resistor shunt
- Recording of shunt voltage
- Additional T sensors (local)
- Local EIS (single segment readout)
- Operating temperature max 200°C




Technology: Segmented Printed circuit boards


- Milling of flow fields possible
- Limit to local resolution by
 - Flow field
 - PCB layout / thickness / connectors
 - Data acquisition



Technology: Segmented Printed circuit boards



Lab scale single test cell
25 cm², 49 segments




Fuel cell stack size
>150 cm², 108 segments



Technology: Segmented Printed circuit boards

Application

- Systematic studies on fuel cell
- Optimization of Performance
- Malfunctioning
- Humidification
- Heat dissipation
- Oscillating chemical reactions
- Flow field evaluation
- GDL enhancement



Flooding event in PEMFC



INSIDE – In-situ Diagnostics for Water Electrolyzers

R&D Project funded by FCH JU:
Adaptation of segmented PCB to

- PEMWE
- AWE
- AEMWE

Consortium: 5 partners

- Deutsches Zentrum für Luft- und Raumfahrt e.V. (DLR)
- NEL Hydrogen ASA, Norway
- Heliocentris Italy S.r.l., Italy
- CNRS / Université de Strasbourg, France
- Hochschule Esslingen, Germany



nel

Heliocentris



Hochschule Esslingen
University of Applied Sciences



INSIDE – In-situ Diagnostics for Water Electrolysers

PEMWE

AEMWE

AWE



Targetted
development



Grid stabilisation:

- Supply based operation
- Flexibility (KPI 5)
- Durability (KPI 3, 4)

Industry:

- Demand based operation
- Efficiency (KPI 1, 2)




INSIDE – In-situ Diagnostics for Water Electrolysers

Objectives

Provide in-operando monitoring for

- Harvesting of hidden performance
- Revealing hidden deficiencies
- Enhancing durability
- Preventing critical operation
- Targeted developments
- Evaluation of modelling
- Evaluation of AST



INSIDE – In-situ Diagnostics for Water Electrolysers

Challenges & Achievements

Contact Resistance: PCB – instead of BPP

Carbon GDLs vs. metal foams/felts


→ Increase of gold coating thickness

→ graphitic coating (under development)

Differential Pressure

→ adjust PCB thickness

→ add regular BPP



INSIDE – In-situ Diagnostics for Water Electrolyzers

Challenges & Achievements


Number of data recording channels

Space requirements:

PCB circuits compete with hardware

→ More complex layouting

→ More PCB layers





INSIDE – In-situ Diagnostics for Water Electrolysers

Challenges & Achievements

AEMWE prototype:

Gas & electrolyte tightness

- Pressure
 - adapt sealing concept
- Surfaces
 - metal coating




Prototype for AEMWE



INSIDE – In-situ Diagnostics for Water Electrolysers

Challenges: Corrosion

- AWE conditions (30%KOH, $>60^{\circ}\text{C}$)
Sealings barely stop KOH lye
Lye migrates along copper lines when accessible
- PCB material itself (FR4 epoxy) can be attacked
Invasion between laminated layers
 - avoid exposure
 - or seal edges of PCB



INSIDE – In-situ Diagnostics for Water Electrolysers

Data acquisition

- Voltage recording
- Modular setup
- Multiplexer for up to 560 channels
- USB interface
- Labview TM compatibility



Data acquisition : Keysight (HP/Agilent) 34980A



Intuitive front panel with self-guiding menus

See results on bright, multiline display

6 1/2 digit DMM measurements with 11 functions

Scan multiple channels, close specified channel list, or monitor results on a single channel

Store up to 500,000 readings with timestamp

Use keypad to enter channel number or knob to scroll

Configure measurements by channel

Set up scan lists





INSIDE – In-situ Diagnostics for Water Electrolysers

Data acquisition & visualisation

Overall values




Local current densities



Examples for Application (25 cm² test cells): Contact resistance and pressure


Homogeneous torques



● 2.2Nm
● 0.5Nm

Homogeneous current distribution

Non-homogeneous torques



Non-homogeneous current distribution

A/cm²




D.G.Sanchez M Gnilka
(Manuscript in
preparation)

MEA: Greenerity E400E (Nafion 115)

Anode GDL: Sinter titanium Cathode GDL: Carbon paper




Examples for Application: Flow field evaluation




WP4 – PEM electrolyzers

Examples for Application: Water starvation




Examples for Application: Irreversible Degradation



1 day




2 day



3 day



Local post-mortem investigations (XPS):
 Mo traces in cathode catalyst layer,
 correlating with local irreversible degradation




— A1 Kathode — D4 Kathode — G7 Kathode



Summary and Outlook

- *In-operando* Diagnostics
- Visualisation
- Little disturbance
- Costs depend on upscaling & data acquisition
- Application:
 - Development (Materials, Designs)
 - Monitoring
 - Steady monitoring
 - Response to diagnostic cycles
- Evaluation of numerical modelling
- Evaluation of testing protocols & ASTs



Acknowledgements

INSIDE consortium

Magnus Thomassen
Anders Søreng
Chiara Emiliani
Siegfried Limmer
Elena Savinova
Viktoriia Saveleva
Renate Hiesgen
Tobias Morewietz
Mathias Schulze



EWII

Laila Grahl-Madsen
Theiss Stenstrøm
Bertil Sieborg



People at DLR

Daniel Garcia Sanchez
Olivier Garrot
Michael Gnilka

FCH JU

The research leading to these results has received funding from the European Union's Seventh Framework Programme (FP7/2007-2013) for Fuel Cell and Hydrogen Joint Technology Initiative under Grant No. 621237 (INSIDE).



Thank you for your attention!

Knowledge for Tomorrow

