

25/5/16

Centro Láser
UPM

High volume transfer of high viscosity silver pastes using Laser Direct-Write Processing for metallization of c-Si cells

M. Morales, Y. Chen, D. Munoz-Martin,
S. Lauzurica, C. Molpeceres



Centro Láser
UPM

Outlook


1. Introduction: metallization of solar cells
2. Laser-Induced Forward Transfer (LIFT)
3. Experimental setup
4. Parameterization of the LIFT process
5. LIFT printing of long lines
6. Large area metallization
7. Summary
8. Acknowledgements

Centro Láser
UPM

Metallization of Solar Cells

Front-side Metallization: key process for enhancing efficiency in a cost effective way

- Screen-printing




Luque & Hegedus, Handbook of Photovoltaic Science and Engineering (2003)

Centro Láser
UPM

Metallization of Solar Cells

Front-side Metallization: key process for enhancing efficiency in a cost effective way

- Screen-printing
- Ink-jet printing



Teng & Vest, IEEE Trans. Compon., Hybrids, Manuf. Technol (1988)

Centro Láser UPM

Metallization of Solar Cells

Front-side Metallization: key process for enhancing efficiency in a cost effective way

- Screen-printing
- Ink-jet printing
- High-efficiency approaches: photolithography / evaporation / plating

Zhao et al, Sol. Energ. Mat. Energ. C. (2001)

Centro Láser UPM

Metallization of Solar Cells

Front-side Metallization: key process for enhancing efficiency in a cost effective way

- Screen-printing
- Ink-jet printing
- High-efficiency approaches: photolithography / evaporation / plating
- **Laser Printing based on Laser-Induced Forward Transfer (LIFT)**

Centro Láser UPM

LIFT

LIFT: Laser-Induced Forward Transfer

Some materials deposited using LIFT:

- Metals, Oxides, Nanopowders
- Organic polymers, Biomaterials & living cells
- Conductive inks, Ag nanoparticles pastes

Brown et al, Microfluid Nanofluid. (2011)

Centro Láser UPM

Experimental setup


- Low temperature screen-printing Ag pastes.
- Deposition onto donor substrate using a commercial paint coater.
- Basic LIFT configuration (no intermediate absorbing layer or assisting liquid matrix).
- Diode Pumped Solid State Laser (Spectra Physics Explorer)
 - Nd:YVO4 emitting 532 nm
 - Pulse duration 14 ns
- Optical Scanner (ScanLab HurryScan)
 - F-Theta Lens, focal 250 mm
 - Focused beam diameter 22-25 μm

Centro Láser UPM



Silver paste

Dupont PV17F

Viscosity (Brookfield HBT, 10 rpm SC4-14.68 utility cap and spindle, 23°C)	280 - 400 Pa·s
Solid Content at 750 °C	89.5 - 91.0 %
Resistivity	< 5 mΩ/sq/μm
Silver grain	1-5 μm
Organic carrier	N,N'-Ethane-1,2-diylbis(decanamide) 12-Hydroxy-N-[2-(1-oxo-decylamino)ethyl]octadecanamide N,N'-Ethane-1,2-diylbis(12-hydroxyoctadecanamide)
Thinner	9450




Non-newtonian, pseudoplastic, thixotropic fluids


Centro Láser UPM

Deposition onto donor substrate

Commercial paint coater (RK PrintCoat Instruments).
Incorporates spreading blade adjustable using micrometers



Thickness, roughness (~ 2 μm) and waviness (~ 5-8 μm) are measured for every experiment by means of confocal microscopy




Centro Láser UPM


LIFT configuration

Laser system

Spectra Physics Explorer	
DPSS Nd:YVO4	532 nm
Pulse duration FWHM	14 ns
Frequency	20 - 150 kHz
Power	2 W @ 50 kHz
Energy attenuator	
Scanner	
Processing area	120 mm x 120 mm



Experimental scheme







Centro Láser UPM

LIFT parameterization

Laser	Explorer@532nm
Laser frequency	20 kHz
Pulse duration	14 ns
Pulse energy	0.1 - 35 uJ
Paste thickness	30 μm, 50 μm, 80 μm
GAP	50 μm
Receiving substrate	Monocrystalline Silicon wafer (520 μm)

Matrix of spots

1 pulse (14 ns) @ 20kHz		Energy uJ	
34.2	22.6	14.4	6.5
33.4	23.0	12.4	5.2
32.0	20.5	10.7	4.1
30.3	18.3	9.2	3.2
28.0	16.5	7.7	2.3



Centro Láser UPM

LIFT parameterization

Parameter	Value
Laser	Explorer@532nm
Spot diameter	25 μm
Paste thickness	50 μm
GAP	50 μm
Pulse energy	34.7 μJ

- Explosive transfer but with heights higher than particle size
- All the paste is removed from the donor substrate

Acceptor substrate

W: 211 μm
H: 9 μm

Donor substrate

W: 136 μm
H: 56 μm

Centro Láser UPM

LIFT printing of long lines

Parameter	Value
Laser	Explorer@532nm
Laser frequency	20 kHz, 50 kHz
Pulse duration	14 ns
Pulse energy	0.1 – 35 μJ
Paste thickness	80 μm
GAP	50 μm
Receiving substrate	Monocrystalline Silicon wafer (520 μm)
Process speed	20 – 2000 mm/s

Centro Láser UPM

LIFT printing of long lines

Parameter	Value
Laser	Explorer@532nm
Spot diameter	25 μm
Paste thickness	80 μm
GAP	50 μm
Pulse energy	14.5 μJ
Process speed	2 m/s
Laser frequency	20 kHz

Centro Láser UPM

LIFT printing of long lines

H: 65 μm
W: 89 μm

H: 54 μm
W: 142 μm

Height: 55 μm
 Width: 90 μm – 150 μm
 Aspect Ratio: 0.36 – 0.61

Centro Láser UPM

LIFT printing of long lines

- The LIFT process generates a column of paste that connects both substrates.
- When the glass substrate is removed the paste is stretched until the final shape is obtained.
- This could explain the high aspect ratio and high transferred volume.
- The paste thickness and the gap are key variables in the transfer of high viscosity pastes

Centro Láser UPM

LIFT printing of long lines

Parameter	Value
Spot diameter	25 μm
Paste thickness	80 μm
GAP	50 μm
Pulse energy	14.5 μJ
Laser frequency	20 kHz
Process speed	2 m/s
Line length	3 cm

Aspect Ratio $\approx 0.25 - 0.40$
Voxel $\approx 300 \text{ pL}$

Centro Láser UPM

Large area metallization

Parameter	Value
Spot diameter	25 μm
Paste thickness	80 μm
GAP	50 μm
Pulse energy	14.5 μJ
Process speed	2 m/s
Line length	3 cm

- Optical scanners allows fast processing and flexible design to print large areas.
- Good predeposited conditions are needed.

Centro Láser UPM

Summary

- The minimum energy required to transfer the paste increases with the thickness of the paste.
- Viscosity of the paste plays a fundamental role. Thinner additives are needed for controlling the paste viscosity.
- The paste thickness and the gap are identified as key variables in the transfer of high viscosity pastes.
- Lines with higher height than the gap suggest that the paste forms a union with the acceptor substrate and the final shape is reached once the donor substrate is removed.
- Lines deposited using best parameters have good shape and large aspect ratios (~ 0.3). The volume transferred per pulse (voxel) is quite large ($\sim 300 \text{ pL}$).
- Optical scanners allows fast processing and flexible design to print large areas.
- LIFT is a promising technique for the metallization of PV devices using commercial screen-printing pastes.

Centro Láser UPM Acknowledgments





Centro Láser UPM Acknowledgments

This work has been supported by the Spanish MINECO projects SIMLASPV (ENE2011-23359), HELLO (ENE2013-48629-C4-3-R) and EUROPEAN COMMISSION APPOLO FP7-2013-NMP-ICT-FOF. 609355



Prof. M. Morales D. Canteli J.M. López Prof. C. Molpeceres
 PhD. D. Muñoz C. Yu PhD. S. Lauzurica J.J. García-Ballesteros



Centro Láser UPM Laser sintering

Metallization comprise different steps:

1. Pre-metallization processes
2. Metallization
3. Curing, sintering and firing

All-laser based process:
Laser heating using a CW source.

Experimental setup:

- DPSS Laser (Spectra Physics Millennia)
 - Nd:YVO4 emitting 532 nm
 - CW, power up to 20W
- Optical Scanner (ScanLab HurryScan)
 - F-Theta Lens, focal 250 mm
 - Focused beam diameter 20 μm

