SPECIAL ISSUE PAPER

Andrea Ulrich · Adrian Wichser

Analysis of additive metals in fuel and emission aerosols of diesel vehicles with and without particle traps

Received: 24 February 2003 / Revised: 5 May 2003 / Accepted: 7 May 2003 / Published online: 19 July 2003 © Springer-Verlag 2003

Abstract Fuel additives used in particle traps have to comply with environmental directives and should not support the formation of additional toxic substances. The emission of metal additives from diesel engines with downstream particle traps has been studied. Aspects of the optimisation of sampling procedure, sample preparation and analysis are described. Exemplary results in form of a mass balance calculation are presented. The results demonstrate the high retention rate of the studied filter system but also possible deposition of additive metals in the engine.

Keywords Particle trap · Vehicle emission · Diesel · Aerosol · Inductively coupled plasma mass spectrometry · ICP-MS · Inductively coupled plasma emission spectrometry · ICP-OES · Microwave digestion

Introduction

Diesel engines are essential for transportation and other heavy-duty industries but a major drawback is their pollutants. Even the latest diesel engines emit fine soot particles which can cause serious respiratory and cardiovascular health problems [1, 2, 3, 4, 5]. Several countries regulate particulate emissions and give directives for implementation and compliance. Some of these countries, e.g. Switzerland [6] and Germany [7], legislate special directives for heavy-duty vehicles in working areas like tunnel construction sites, based on the results of the VERT studies ("Verminderung der Emissionen von Real-Dieselmotoren im Tunnelbau", i.e. reduction of diesel engine emissions at tunnel construction sites) [8, 9].

Particle traps are suitable tools for minimising soot emissions. Different types are already available and many are appropriate for retrofitting of heavy-duty vehicles [10]. Suitable filter systems must fulfil strict requirements. For example pore size must allow optimal retention of ultrafine particles with minimal clogging of the filter system. A technical challenge is the regeneration of clogged filters. Online regeneration demands a minimum temperature of 550 °C and an oxygen content of 5%, which cannot be attained without additional burners or catalytic combustion [9]. Transition or noble metals (e.g. Ce, Fe, Cu, Sr or Pt) in the form of fuel additives or coatings can substantially lower the soot ignition temperature. At concentrations of 10-50 mg/kg the additives can be mixed with the fuel in the form of organometallic compounds or as oxides which give a colloidal suspension with the fuel. The additives should give a stable mixture with the diesel and must be well distributed within each micro-droplet during the combustion process.

Particle reduction must not provoke an increase of toxic components. Therefore the assessment of secondary emissions is an important criterion for the suitability of particle filters. An appropriate test should ensure suitability and toxic innocuousness of the particle trap. As one of the VERT partners, the EMPA studied both the trap-induced formation of hazardous organic compounds [11, 12] and the emission and penetration of additive metals which are presented here. The interest in online regeneration and potential supporting additives increased recently. A combination of cerium and iron was used in this study. Filter retention of ultra-fine particles and possible penetration of additive metals have been studied for a SiC wall-flow filter system in different driving situations. Emission rates were compared for the engine with and without a particle trap.

Experimental

Instrumentation

All fuel and filter samples were digested in an MLS 1200 Mega High-Performance Microwave Digestion Unit (MSL GmbH) upgraded with a temperature control unit. The spectrometers used in the analysis of aqueous digestion solutions were a quadrupole ICP-MS ELAN 6000 (Perkin Elmer/Sciex) and a magnetic sector field ICP-MS ELEMENT II (Thermofinnigan), both operated under

Table 1 Operating conditions for the ICP-MS and ICP-OES

Parameter	Perkin Elmer ELAN 6000	Thermo-Finnigan ELEMENT II	ARL 3580 B (Minitorch)	VARIAN VistaPro	
Power (W)	1100	1100	750	1500	
Plasma gas flow (L/min)	15	15	12	15	
RF generator (MHz)	40.86 (free-running)	27,12 (solid state)	27.12 (solid state)	40.86 (free-running)	
Aux. gas flow (L/min)	1.00	1.00	1.00	2.25	
Nebulizer gas flow (L/min)	0.92	0.89	0.70	0.70	
Nebulizer	Crossflow	Meinhard K-type	Meinhard K-type	Meinhard K-type	
Spray chamber	Scott-type (Ryton)	Scott type	Cooled conic quartz chamber (-1 °C)	Cooled quartz chamber	
Resolution	about 0.75 amu	Low≈300 Medium≈4000 High≈10,000	about 9–10 pm (at 267.7 nm)	about 10 pm (at 267.7 nm)	
Dynamic range	10 ⁹ (Dual-mode ETP)	10 ⁹ (Dual-mode ETP)	10^{6}	10 ⁶ (CCD, 70,000 pixels)	
Wavelength range			167–785 nm	167–785 nm	

standard plasma conditions (Table 1). Direct determinations of the diesel samples were performed with a radial ARL 3580 B ICP Analyser (ARL) or a radial VistaPro ICP-OES (Varian). Chlorine and sulphur were determined directly in undiluted samples using a Philips PW-1400 wavelength-dispersive x-ray fluorescence spectrometer (WD-XRF) with typical detection limits of $1-2\,\mu g/g$.

Reagents and chemicals

In aqueous solutions only ultra-pure quality acids (Merck) and highpurity water (18.2 M Ω cm), prepared by a Milli-Q Gradient A10 System (Millipore), were used for sample and standard preparation. Standards were prepared from single- and multi-element standards to ICP quality (Merck and Alfa Aesar). Cleaning and filter digestions were also only performed using acids of ultra-pure quality (Merck) and high-purity water.

Diesel samples were diluted using xylene as a mixture of isomers, "puriss. p.a." (Fluka). Calibration standards were prepared from Conostan organometallic single- and multi-element standards in Natural Basis Oil 75 (Conostan). For diesel digestions suprapure quality acid (Merck) was used.

Direct determination of metals in diesel

A rapid method was needed for monitoring accuracy of additive dosing as well as miscibility and stability of the additive-fuel mixtures. Inductively coupled plasma optical emission spectrometry (ICP-OES) has proved to be a reliable technique for direct element determinations in a variety of organic samples [13]. Oil or fuel samples must usually be diluted using organic solvent to decrease viscosity and to guarantee a reliable quantification. Various organic solvents like MIBK [14, 15, 16], toluene [17], xylene [18, 19, 20, 21] or kerosene [22, 23, 24, 25] were investigated for different applications. Xylene and kerosene showed good plasma stability under similar plasma conditions as for aqueous solutions. In newer publications kerosene was often preferred due to lower costs, toxicity, volatility and less carbon build-up. However a great advantage of xylene appears to be an increase in stability of sample solutions and standards. Moreover, numerous organic petrochemical solutions do not dissolve completely even at high kerosenesample ratios, and those that do are unstable. A main goal was that the final procedure was appropriate for element determination in diesel and lubricants, since both sample types have to be analysed within VERT projects. Prior tests of solubility with different organic solvents showed that xylene has better solubility properties

Table 2 BEC for directly determined diesel samples (diluted 1:5 with xylene) calculated for undiluted samples

Element	Wavelength in nm	ARL 3580 B Minitorch radial	VARIAN Vista Pro radial
Ag	328.068	2.45	2.15
Al	237.312	19.89	14.98
В	249.678	6.28	3.05
Ba	455.403	1.08	1.24
Ca	317.933	4.31	9.94
Cd	226.502	0.88	1.01
Cr	267.716	2.22	1.61
Cu	324.754	2.32	2.11
Fe	259.940	2.27	1.73
Mg	280.270	0.19	0.24
Mn	257.610	0.57	0.28
Mo	202.032	1.91	2.10
Ni	221.648	1.60	7.41
Ni	231.604	13.22	12.48
P	178.222	5.09	11.77
Pb	220.353	12.20	15.77
Si	251.611	8.41	5.29
Ti	337.280	2.02	2.29
V	311.070	2.50	3.55
Zn	213.857	0.72	1.13

for both sample types [26]. A further advantage of xylene is the relatively low background level combined with a good signal-tonoise ratio, which resulted in good background equivalent concentrations (BEC). Therefore xylene was chosen to optimise direct determination using ICP-OES and resulted in the following procedure: all organic samples directly determined using ICP-OES were
diluted 1:5 with xylene; a mixture of xylene isomers was used,
puriss. p.a. (Fluka); calibration standards were prepared from
Conostan organometallic single- and multi-element standards in
concentrations of 2, 10, 50 and if required 250 mg/kg in Conostan
Natural Basis Oil 75; and the same basis oil was used as blank.

For calibration all standards and the blank were diluted 1:5 with xylene. In Table 2 selected BEC values, calculated for undiluted samples, are listed. Usually organic solutions show higher

background levels than aqueous solutions. Therefore the use of BEC levels for organic solutions is advantageous over detection limits because BECs are calculated without background-corrected values. BEC level is defined as follows:

BEC =
$$1/[(I_{Standard} - I_{Blank})/c_{Standard}]*I_{Blank}$$

where $I_{Standard}$ =intensity standard (background not corrected), I_{Blank} =intensity blank (background not corrected) and $c_{Standard}$ =concentration standard.

In this paper only the results of iron (direct determination) and cerium (determination after digestion) will be discussed, but the BEC list also includes other elements which are characteristic of diesel or lubricants (e.g. abrasion) and were studied within the project.

Decomposition of diesel

For some elements like cerium the direct determination method was not applicable as no organic standards were available. Therefore digestion was optimised using an MLS 1200 Mega High-Performance Microwave Digestion Unit (MSL GmbH). Wet-acid digestions of organic samples present safety hazards [27, 28, 29, 30]. Therefore a slow procedure was developed where the diesel samples were digested with nitric acid and peroxide. About 100-200 mg of sample was weighed into quartz vessels and 3 ml of nitric acid (HNO_{3:} Merck ultra-pure 60%) was added. The quartz vessels were covered and slowly heated on a Schott Ceran hotplate to ensure a smooth pre-reaction. When the reaction started the colour changed from yellow to brown and the formation of NO_x was observed. After 12 h reaction time and cooling, 1 ml hydrogen peroxide (H₂O₂; Merck supra-pure 30%) was added to the solutions. The digestion vessels were placed into medium-pressure decomposition vessels, which were filled with 5 ml ultra-pure water and 1 ml H₂O₂ (Merck supra-pure 30%), and microwave digestion was performed. Finally the solutions were diluted to an end volume of 10 ml. The complete digestion programme is listed in Table 3. Additive elements were determined by ICP-OES and ICP-MS using aqueous calibration solutions.

Filter sample preparation

The emission aerosols were sampled on Nuclepore Track-Etch Membranes IPR-200 (Corning) using a Dekati 12-stage Electrical Low Pressure Impactor (ELPI), Model 95 2E Sn 24/50 (size range $30\,\text{nm}{-}10\,\mu\text{m})$ and a downstream quartz fibre back-up filter.

The ELPI samples showed very low aerosol masses and the concentrations of the additive elements were at the ultra-trace level. The required low detection limits (DL) were only achievable

Table 3 Digestion programme for diesel samples

Pre-digestion pro	gramme
Time	Ceran hotplate level
3 min	1
7 min	2
5 min	0
10 min	3
Cooling down, 12	2 h reaction time before adding H ₂ O ₂

Microwave digestion programme

Step	Time (min)	Power (W)		Temperature inside (°C)
1	6	1000	100	90
2	6	1000	150	130
3	9	1000	210	130
4	12	1000	215	130
5	30	Cooling/venting		

by consequent optimisation of the whole sample preparation procedure. To minimise the contamination risk only fresh acids of ultra-pure quality were used. First results showed that only control of all vessels after cleaning digestion led to appropriate DLs [31]. The quartz vessels were reserved for these applications only. The following procedure was optimised to achieve the best detection limits:

- Cleaning digestion for the vessels using ultra-pure chemicals and filled to an end volume of 10 ml.
- Determination of the vessel background (cleaning solutions of (1)) by ICP-MS.
- (3) Selection of suitable vessels based on the results of (2).
- (4) Vessels with inappropriate background levels have to be cleaned a second time; steps repeated from (1).
- (5) Digestion of the weighed filters (field blanks and samples) using ultra-pure chemicals (acid mixture depends on analyte) and filled to an end volume of 10 ml.
- (6) Digestion of a minimum of five reagent blanks together with (5) to determine the detection limits of the sample preparation procedure using the same acids as in (5).
- (7) Determination using ICP-MS (inductively coupled plasma mass spectrometry – quadrupole or high-resolution (HR)ICP-MS is dependent on the analyte).

The acid mixture for the digestion depends on the elements of interest and the filter type. As an example the decomposition of ELPI filters for the determination of iron and cerium is described here. The absolute aerosol masses on the 12 impactor stages were directly monitored during sampling. This was an advantage because determination by difference weighing (loaded filter–unloaded filter) was not always possible due to condensation on the filter surface.

In this study the whole filter was weighed and placed into a cleaned and background-controlled decomposition vessel. A 3-ml aliquot of HNO $_3$ (Merck ultra-pure 60%) and 1 ml H $_2$ O $_2$ (Merck ultra-pure 30%) were added. The vessels were closed and placed into the outer decomposition vessels, which were filled with 5 ml ultra-pure water and 1 ml H $_2$ O $_2$ (Merck ultra-pure 30%). The microwave decomposition programme is described in Table 4. Finally the solutions were diluted to 10 ml end volume with ultra-pure water.

For the determination, aqueous standards were prepared using single- or multi-element standards of ICP quality (Merck and Alfa Aesar), ultra-pure quality acids (Merck) and high-purity water, prepared using a Milli-Q Gradient A10 System (Millipore).

The selection of an internal standard for the determination of emission aerosols can be challenging because generally recommended elements, such as rhodium, are not always applicable. Further tests, which have yet to be published, showed that emission aerosols of engines equipped with oxidation catalysts and particle traps have sometimes a significantly higher concentration of metals like rhodium, rhenium or yttrium. In such cases, appropriate selection is only possible on the basis of prior semi-quantitative analysis. Elements like indium, molybdenum or probably gallium seemed to be appropriate candidates, but the applicability of an internal standard must be checked in every individual case. In the present study the use of rhodium was possible because no oxidation catalyst was used in combination with the studied particle trap. Cerium and iron were determined using HR ICP-MS.

Back-up filters and filter materials for integral sampling of diesel exhaust emissions were digested with ${\rm HNO_3}$ (Merck ultra-

Table 4 Microwave digestion programme for ELPI filter samples

Step	Time (min)	Power (W)	Temperature outside (°C)	Temperature inside (°C)
1	6	1000	100	80
2	6	1000	150	130
3	10	1000	180	130
4	12	600	180	130
5	30	Cooling/venting		

 $\textbf{Table 5} \quad \text{Background contamination of different filter materials in } \mu\text{g/m}^2$

Filter diameter in cm	7.1 39.6	7.0 38.5	4.8 18.1	7.0 38.5	5.1 20.4	2.5 4.9	
Analyte	Pall	Pallflex EMFAB	Pallflex EMFAB	Macherey-Nagel	Munktell	ELPI Filter	NWG
1 2111111 10	T60A21	TX40HI20-WW	TX40HI20-WW		MK361		
	μg/m²	μg/m²	μg/m²	μg/m²	μg/m²	μg/m²	μg/m²
Li	10	2.1E+02	2.3E+02	2.0E+02	<dl< td=""><td>0.5</td><td>0.1</td></dl<>	0.5	0.1
Na	3.1E+05	2.0E+05	4.4E+05	2.3E+05	3.3E+02	7.7E+02	47
K	1.1E+05	7.2E+04	1.6E+05	4.1E+05	<dl< td=""><td><dl< td=""><td>38</td></dl<></td></dl<>	<dl< td=""><td>38</td></dl<>	38
Rb	1.5E+02	54	1.3E+02	4.3E+02	0.1	0.2	0.1
Cs	1	3	5	4	<dl< td=""><td>0.5</td><td>0.1</td></dl<>	0.5	0.1
Group 1 (alkali metals)	4.3E+05	2.8E+05	6.1E+05	6.5E+05	3.3E+02	7.7E+02	85
Be	<dl< td=""><td>1.4</td><td>1</td><td><dl< td=""><td><dl< td=""><td>0.5</td><td>0.2</td></dl<></td></dl<></td></dl<>	1.4	1	<dl< td=""><td><dl< td=""><td>0.5</td><td>0.2</td></dl<></td></dl<>	<dl< td=""><td>0.5</td><td>0.2</td></dl<>	0.5	0.2
Mg	3.2E+03	7.8E+04	7.6E+04	1.3E+04	1.3E+02	67	2.0
Ca	3.3E+04	5.4E+05	5.0E+05	4.4E+05	1.3E+03	2.9E+03	56
Sr	2.0E+03	7.7E+03	1.1E+04	1.6E+04	7	1.4	0.1
Ba	2.0E+05	4.4E+04	2.7E+05	2.9E+05	81	8	1.1
Group 2 (alkaline earth metals)	2.4E+05	6.7E+05	8.6E+05	7.6E+05	1.5E+03	3.0E+03	60
В	4.8E+04	5.7E+04	1.1E+05	3.8E+05	1.5E+03	1.1E+04	38
Al	1.9E+04	1.4E+05	2.1E+05	2.2E+05	3.9E+02	2.3E+02	2
Ga	10	98	1.0E+02	79	<dl< td=""><td>1.3</td><td>0.1</td></dl<>	1.3	0.1
Ge	<dl< td=""><td>0.5</td><td>0.5</td><td>0.3</td><td><dl< td=""><td>1.1</td><td>0.1</td></dl<></td></dl<>	0.5	0.5	0.3	<dl< td=""><td>1.1</td><td>0.1</td></dl<>	1.1	0.1
As	0.6	5	6	15	<dl< td=""><td>3.6E+02</td><td>0.2</td></dl<>	3.6E+02	0.2
Se	<dl< td=""><td><dl< td=""><td><dl< td=""><td>57</td><td><dl< td=""><td><dl< td=""><td>13</td></dl<></td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td>57</td><td><dl< td=""><td><dl< td=""><td>13</td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td>57</td><td><dl< td=""><td><dl< td=""><td>13</td></dl<></td></dl<></td></dl<>	57	<dl< td=""><td><dl< td=""><td>13</td></dl<></td></dl<>	<dl< td=""><td>13</td></dl<>	13
In Sn	<dl 5</dl 	0.3 0.5	0.4 16	0.1 11	<dl <dl< td=""><td><dl 112</dl </td><td>0.1 0.7</td></dl<></dl 	<dl 112</dl 	0.1 0.7
Sb	0.3	0.5	0.4	1	<dl <dl< td=""><td>2</td><td>0.7</td></dl<></dl 	2	0.7
Te	0.5 <dl< td=""><td>0.5 <dl< td=""><td><dl< td=""><td>0.2</td><td><dl <dl< td=""><td>0.2</td><td>0.1</td></dl<></dl </td></dl<></td></dl<></td></dl<>	0.5 <dl< td=""><td><dl< td=""><td>0.2</td><td><dl <dl< td=""><td>0.2</td><td>0.1</td></dl<></dl </td></dl<></td></dl<>	<dl< td=""><td>0.2</td><td><dl <dl< td=""><td>0.2</td><td>0.1</td></dl<></dl </td></dl<>	0.2	<dl <dl< td=""><td>0.2</td><td>0.1</td></dl<></dl 	0.2	0.1
Tl	1.2	0.4	1	3	<dl <dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<></dl 	<dl< td=""><td>0.1</td></dl<>	0.1
Pb	43	1.4E+02	2.0E+02	79	4	5	0.5
Bi	<dl< td=""><td><dl< td=""><td><dl< td=""><td>3</td><td><dl< td=""><td>5</td><td>11</td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td>3</td><td><dl< td=""><td>5</td><td>11</td></dl<></td></dl<></td></dl<>	<dl< td=""><td>3</td><td><dl< td=""><td>5</td><td>11</td></dl<></td></dl<>	3	<dl< td=""><td>5</td><td>11</td></dl<>	5	11
Group 3 (main group elements III-VI)	6.7E+04	2.0E+05	3.2E+05	6.0E+05	1.9E+03	1.2E+04	65
Ti	29	1.7E+03	1.7E+03	1.1E+03	14	31	1
V	2	1.6E+02	1.8E+02	61	<dl< td=""><td>5.6E+02</td><td>0.4</td></dl<>	5.6E+02	0.4
Cr	21	2.3E+02	2.6E+02	3.3E+02	34	2.7E+02	7
Mn	39	1.5E+02	1.8E+02	2.2E+02	15	7	0.1
Fe	7.4E+02	1.0E+04	9.4E+03	6.6E+03	2.6E+02	4.3E+02	41
Co	1	13	14	17	0.2	1	0.1
Ni	<dl< td=""><td>42</td><td>34 4.2F+02</td><td>36</td><td>10</td><td>43</td><td>4</td></dl<>	42	34 4.2F+02	36	10	43	4
Cu	19	28	4.2E+02	92 3.2E+05	<dl< td=""><td>6 1.2E+02</td><td>1 7</td></dl<>	6 1.2E+02	1 7
Zn Zr	3.6E+04 1.3E+02	1.2E+04 1.2E+02	5.2E+04 2.1E+02	3.3E+05 4.1E+02	2.8E+02 4	1.2E+03 2	0.1
Nb	0.1	1.22402	2.1E+02 1	4.1E+02	0.1	<dl< td=""><td>0.1</td></dl<>	0.1
Mo	4	3	5	22	7	1	0.1
Ru	<dl< td=""><td><dl< td=""><td><dl< td=""><td>0.1</td><td><dl< td=""><td><dl< td=""><td>0.3</td></dl<></td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td>0.1</td><td><dl< td=""><td><dl< td=""><td>0.3</td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td>0.1</td><td><dl< td=""><td><dl< td=""><td>0.3</td></dl<></td></dl<></td></dl<>	0.1	<dl< td=""><td><dl< td=""><td>0.3</td></dl<></td></dl<>	<dl< td=""><td>0.3</td></dl<>	0.3
Rh	<dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<></td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<>	<dl< td=""><td>0.1</td></dl<>	0.1
Pd	3	3	6	10	<dl< td=""><td>0.3</td><td>0.1</td></dl<>	0.3	0.1
Ag	0.1	0.2	0.3	0.5	<dl< td=""><td>0.5</td><td>0.1</td></dl<>	0.5	0.1
Cd	0.5	0.5	1	6	<dl< td=""><td>0.1</td><td>0.1</td></dl<>	0.1	0.1
Hf	4	2	6	6	<dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<>	<dl< td=""><td>0.2</td></dl<>	0.2
Ta	0.3	0.1	0.4	1	<dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<>	<dl< td=""><td>0.1</td></dl<>	0.1

Table 5 (continued)

Filter diameter in cm	7.1	7.0	4.8	7.0	5.1	2.5	
Filter area in cm ²	39.6	38.5	18.1	38.5	20.4	4.9	
Analyte	Pall T60A21	Pallflex EMFAB TX40HI20-WW	Pallflex EMFAB TX40HI20-WW	Macherey-Nagel	Munktell MK361	ELPI Filter	NWG
	$\mu g/m^2$	$\mu g/m^2$	μ g/m ²	$\mu g/m^2$	$\mu g/m^2$	$\mu g/m^2$	μg/m²
W	3	<dl< td=""><td>1</td><td>1</td><td><dl< td=""><td><dl< td=""><td>0.3</td></dl<></td></dl<></td></dl<>	1	1	<dl< td=""><td><dl< td=""><td>0.3</td></dl<></td></dl<>	<dl< td=""><td>0.3</td></dl<>	0.3
Re	<dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<></td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<>	<dl< td=""><td>0.1</td></dl<>	0.1
Os	<dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<></td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<>	<dl< td=""><td>0.2</td></dl<>	0.2
Ir	<dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<></td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<>	<dl< td=""><td>0.2</td></dl<>	0.2
Pt	<dl< td=""><td>1</td><td>1</td><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>0.4</td></dl<></td></dl<></td></dl<></td></dl<>	1	1	<dl< td=""><td><dl< td=""><td><dl< td=""><td>0.4</td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td>0.4</td></dl<></td></dl<>	<dl< td=""><td>0.4</td></dl<>	0.4
Au	<dl< td=""><td><dl< td=""><td><dl< td=""><td>0.3</td><td><dl< td=""><td><dl< td=""><td>0.4</td></dl<></td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td>0.3</td><td><dl< td=""><td><dl< td=""><td>0.4</td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td>0.3</td><td><dl< td=""><td><dl< td=""><td>0.4</td></dl<></td></dl<></td></dl<>	0.3	<dl< td=""><td><dl< td=""><td>0.4</td></dl<></td></dl<>	<dl< td=""><td>0.4</td></dl<>	0.4
Hg	<dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>1.5</td></dl<></td></dl<></td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>1.5</td></dl<></td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td><dl< td=""><td><dl< td=""><td>1.5</td></dl<></td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td><dl< td=""><td>1.5</td></dl<></td></dl<></td></dl<>	<dl< td=""><td><dl< td=""><td>1.5</td></dl<></td></dl<>	<dl< td=""><td>1.5</td></dl<>	1.5
Group 4 (transition metals)	3.7E+04	2.4E+04	6.4E+04	3.4E+05	6.2E+02	2.6E+03	65
Sc	<dl< td=""><td>28</td><td>24</td><td>14</td><td><dl< td=""><td>10</td><td>7</td></dl<></td></dl<>	28	24	14	<dl< td=""><td>10</td><td>7</td></dl<>	10	7
Y	38	53	87	2.2E+02	0.2	0.1	0.1
La	16	1.9E+02	1.5E+02	55	3	<dl< td=""><td>0.1</td></dl<>	0.1
Ce	18	4.2E+02	3.2E+02	87	0.4	<dl< td=""><td>0.1</td></dl<>	0.1
Pr	3	57	48	12	<dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<>	<dl< td=""><td>0.1</td></dl<>	0.1
Nd	9	1.9E+02	1.7E+02	37	<dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<>	<dl< td=""><td>0.2</td></dl<>	0.2
Sm	2	34	33	8	<dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<>	<dl< td=""><td>0.2</td></dl<>	0.2
Eu	25	12	36	30	<dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<>	<dl< td=""><td>0.1</td></dl<>	0.1
Gd	2	25	29	8	<dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<>	<dl< td=""><td>0.2</td></dl<>	0.2
Tb	0.4	3	4	1	<dl< td=""><td><dl< td=""><td>0.05</td></dl<></td></dl<>	<dl< td=""><td>0.05</td></dl<>	0.05
Dy	4	15	21	10	<dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<>	<dl< td=""><td>0.1</td></dl<>	0.1
Но	1	2	3	2	<dl< td=""><td><dl< td=""><td>0.05</td></dl<></td></dl<>	<dl< td=""><td>0.05</td></dl<>	0.05
Er	3	4	8	9	<dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<>	<dl< td=""><td>0.1</td></dl<>	0.1
Tm	1	1	1	2	<dl< td=""><td><dl< td=""><td>0.05</td></dl<></td></dl<>	<dl< td=""><td>0.05</td></dl<>	0.05
Yb	4	4	9	12	<dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<>	<dl< td=""><td>0.2</td></dl<>	0.2
Lu	1	1	1	2	<dl< td=""><td><dl< td=""><td>0.1</td></dl<></td></dl<>	<dl< td=""><td>0.1</td></dl<>	0.1
Th	4	55	75	21	<dl< td=""><td><dl< td=""><td>0.2</td></dl<></td></dl<>	<dl< td=""><td>0.2</td></dl<>	0.2
U	2	21	28	8	0.1	<dl< td=""><td>0.1</td></dl<>	0.1
Group 5 (REE, lanthanoids, actinoids)	1.3E+02	1.1E+03	1.0E+03	5.4E+02	4	10	9

pure 60%) and H_2O_2 (Merck ultra-pure 30%) using microwave digestion. The samples were prepared without internal standard. The Totalquant program of the ELAN 6000 was used to determine the background levels of the filters.

Results and discussion

Filter background levels


Metal determination in emission aerosols is limited more by sampling procedure than by the detection limits of analytical methods. The main reason is a high contamination risk during sampling. A consequent optimisation of the complete chain including sampling procedure, sample preparation and analysis is needed to achieve reliable results [31, 32]. The determination of additive metals in extremely low concentrations requires a suitable sampling procedure. Contamination risk and memory effects are not negligible especially for omnipresent metals. A pre-condition for low detection limits is a careful selection of filter material with low background. Therefore several filter types planned for different applications within this research project were controlled for their background level. Three samples of each filter type were microwave digested and determined using the semi-quantitative program of the ICP-MS. Table 5 shows the average results of all filter materials studied, which are listed in Table 6. The three filter samples varied mainly between 5 and 30% depending on filter type, element and concentration. To give a quick overview the results, calculated in concentrations based on filter areas, were summarised in five groups (Fig. 1):

- (1) Sum of alkali metals
- (2) Sum of alkaline earth metals
- (3) Sum of main group elements (III to VI)
- (4) Sum of transition metals
- (5) Sum of rare earth elements, REE

Table 6 Filter materials and properties

Filter type	Diameter	Material	Properties	Application	Package
Pall Gelman Sciences Pallflex membrane filter, Type EMFAB TX40HI20WW-47 mm	47 mm	Boron-silicate glass micro-fibres reinforced with woven glass cloth, PTFE bonded	1. Withstands folding 2. Flushed with DI water to remove water- soluble residue 3. Low air resistance for critical aerosol sampling	High temperature or hot gas air monitoring	Plastic box
Pall Gelman Sciences Pallflex membrane filter, Type EMFAB TX40HI20WW-70 mm	70 mm	Boron-silicate glass micro-fibres reinforced with woven glass cloth, PTFE bonded	1. Withstands folding 2. Flushed with DI water to remove water- soluble residue 3. Low air resistance for critical aerosol sampling	High temperature or hot gas air monitoring	Paperboard box filters in plastic bag
Pall Gelman Sciences Pallflex membrane filter, Type Fiberfilm T60A21–47 mm	47 mm	Heat resistant boron-silicate glass fibre coated with fluorocarbon (TFE)	Heat-treated (HAT) version available for reduction of trace organics	High temperature or hot gas air monitoring; air sampling applica- tions with moisture variations in air or gases	Paperboard box filters in plastic bag
Munktell quartz microfibre filter, Type MK 360/T 293	50 mm	Pure quartz micro- fibre without glass fibre and binder		Emission control up to 900–950 °C	Paperboard
Macherey-Nagel, Type glass fibre filter MN 85/90 BF	70 mm	Glass fibre filter without organic binder		Filter for coulometry	
Corning, Nuclepore Track-Etch Membrane IPR-200	25 mm	Polycarbonate		Films for ELPI Electrical Low Pressure Impactor, fuel testing	Plastic box

Fig. 1 Background levels of different filter materials



ELPI and Munktell filters showed the lowest concentrations and were preferred by the authors. Macherey-Nagel and Pallflex filter types showed higher background levels. The highest levels in group (1) were observed for sodium and potassium. Calcium, barium and magnesium con-

tributed mainly to group (2). Aluminium and boron were dominant in group (3) and zinc followed by iron in group (4). Group (5) was for all filters below $0.1 \,\mu\text{g/m}^2$ The background levels of potential additive or coating metals (Ce, Fe, Sr, Pt, etc.), typical metals originating from oxi-

dation catalysts (Re, Rh, Pt, etc.) and candidates for internal standardisation (e.g. Rh, In, Y, Ga, etc.) are especially relevant to the VERT research projects. However the information about background levels might also be useful for other authors because the filter types are widespread and commonly used products.

Results for a SiC wall-flow filter system driven with cerium and iron additive-containing diesel

The presented results were part of a study within the VERT research programme. Illustrative results for a new SiC wall-flow filter system driven with cerium and iron additive-containing diesel arereported here. All tests were performed on an engine test stand with a LIEBHERR 914 T diesel engine (6.11 litre, 105 kW at 2,000 rpm, turbocharger without charge-air cooling) by the Department of Automotive Engineering in Biel (Switzerland). Besides the investigation on metal penetration several other aspects like the formation of organic emissions were studied. These results will be presented elsewhere. The experimental set-up and the determined parameters are outlined in Fig. 2.

The ISO 8178/4 C1 cycle with eight operating points for construction site engines was the basis for all emission




Fig. 2 Scheme of the experimental set-up for suitability testing of particle trap systems and the determination of secondary emissions




Fig. 3 ISO 8178/4 C1 cycle for construction site engines

measurements (Fig. 3). The cycle simulates different engine operating situations as well as the accumulation and regeneration phases of the particle trap. The cycle was driven in the prescribed sequence beginning with four load-states at a maximum of 2,000 rpm followed by three load-states at an intermediate rpm (60% of the rated rpm) and finally an idling phase. The dwell time of each load/rpm point was 10–15 min. The total cycle time was aggregated to 100 min. The described cycle was driven twice, thus the total sampling time was 200 min. The following five test conditions were used:

- (1) RO: engine driven with reference diesel without fuel additives and without particle trap
- (2) CO: engine driven with cerium and iron additive-containing diesel without particle trap
- (3) CF: engine driven with cerium and iron additive-containing diesel with particle trap
- (4) HCO: engine driven with cerium, iron and chlorine additive-containing diesel without particle trap
- (5) HCF: engine driven with cerium, iron and chlorine additive-containing diesel with particle trap

The engine was operated with a standard diesel fuel as per EN SN 590 (polyaromatics: 3.5 mg/kg, density: 0.832, cetane number: 56.6). Particle traps require diesel with low sulphur content. The reference diesel was delivered in a 200-l barrel and the engine was directly fed from the barrel. The sulphur content was 94 mg/kg. DEA DES/6069 (TBN: 0.55 mg KOH/g) with a sulphur content of 5 mg/kg was used as lubricant. Cerium and iron additives were added to support the particle trap regeneration. The supplementary chlorine additive serves to improve verification of polychlorinated dibenzodioxins/furans (PCDD/F) and increase sensitivity. The additives were dosed in the amounts 12 mg/kg cerium, 5 mg/kg iron and 12 mg/kg chlorine.


The correct dosing of the additives was controlled by the determination procedures described above. Therefore three diesel samples were taken during the motor test phase. The first diesel sample was taken directly from the freshly opened barrel before the tests got started. After RO was finished, the metal additives were well mixed with the fuel in the barrel and a sample of the additive-containing diesel was taken. When the tests CO and CF were finished a chlorine additive was added to support the formation of organic secondary emissions. After chlorine was added, a third diesel sample was taken before the tests HCO and HCF were performed.

Iron was determined directly in a 1:5 xylene dilution using ICP-OES, cerium was quantified after digestion by ICP-OES and chlorine and sulphur were analysed using WD-XRF.

Emissions for the five test conditions described above were sampled using the commercial particle sampler Dekati ELPI. Further descriptions of the ELPI were given by other authors [33, 34] as well as restrictions for the ELPI in diesel particulate measurements [35]. Aerosol samples were taken from the partial dilution tunnel on pure Nuclepore Track-Etch Membranes IPR-200 (Corning). The sampling followed the steps described below:

- (1) The ELPI was equipped with filters before installation at the motor test stand.
- (2) Installation of the ELPI according to Fig. 1, but with absolute filter at inlet.
- (3) Start of the ELPI and adjustment of the flow (100 mbar absolute pressure at outlet).
- (4) Adjustment of the partial dilution tunnel (VT) (total flow=2.09 g/s, dilution air=2.0 g/s); sample flow is defined as total flow VT+flow ELPI (10 l/min) minus dilution air.
- (5) After the engine was conditioned, sampling was started by switching from the absolute filter to VT.
- (6) The flow per stage was measured at each operating point of the ISO 8178/4 C1 cycle using the corona charger to determine number of particles and mass deposition for size distribution.
- (7) Sampling duration: 200 min non-stop.
- (8) Stop of sampling by change from VT to absolute filter.
- (9) Stop of the flows and instrument.
- (10) Change of the filters:
 - Step by step the loaded filters were removed from each impactor stage using clean tweezers and put into unused petri dishes.
 - After careful cleaning of the stages fresh filters were inserted using clean tweezers.
 - The filter change was not performed in the motor house but in a room with separate ventilation system.

The background level was determined using diesel without additive and without particle trap (RO). To assess the total additive amount that finally reached the particle trap the sample CO was taken using additive-containing diesel without particle trap. The efficiency of the trap could be calculated by comparison of the CO and CF test conditions. The tests were repeated with an additional chlorine additive (HCF and HCO) to support the determination of organic compounds.






Fig. 4a, b Size-specific cerium and iron concentrations found on the 12 impactor stages in μg per filter

 Table 7
 Mass balance for cerium additive calculation based on total mass per cycle

Data based on total mass per cycle	Cerium	%
Dosed additive quantity	473 mg	100
Total mass exhaust gas without particle trap (calculation based on measured total mass ELPI)	15.4 mg	3.3
Total mass exhaust gas with trap (calculation based on measured total mass ELPI)	0.3 mg	0.1
Calculated deposition in engine	457 mg	96.7
Calculated deposition in the particle trap	15.1 mg	3.2
Calculated emission into ambient air	0.3 mg	0.1
Total	473 mg	100
Calculated filtration rate engine	96.7%	
Calculated filtration rate particle trap	98.2%	
Calculated total filtration rate system	99.9%	
Emissions factor	0.96 μg/kWh 0.2 μg/nm ³	

The size distribution of particulate diesel exhaust emissions has been studied in other papers [36, 37, 38]. It was also observed that cerium additive-containing diesel emis-

 Table 8
 Mass balance for iron additive calculation based on total mass per cycle

Data based on total mass per cycle	Iron	%
Dosed additive quantity	202 mg	100
Total mass exhaust gas without particle trap (calculation based on measured total mass ELPI)	25.6 mg	12.7
Total mass exhaust gas with trap (calculation based on measured total mass ELPI)	43.2 mg	21.4
Calculated deposition in engine	176 mg	87.1
Calculated deposition in the particle trap	17.6 mg	3.7
Calculated emission into ambient air	43.2 mg	9.1
Total	236.8 mg	100
Calculated filtration rate engine	87.3%	
Calculated filtration rate particle trap	-145%	
Calculated total filtration rate system	78.6%	
Emissions factor	632 μg/kWh 39 μg/nm³	

sions show a bimodal distribution and that different Ce concentrations change the size distribution to smaller size classes [32, 39, 40]. However little is known about metal content in the different size fractions and the behaviour of additives like iron. Figures 4a and b present the size-classified cerium and iron content for the five different test conditions described above as mass per impactor stage. Cerium and iron show slightly different patterns, which might be caused by the different form of the additives (cerium was dosed as colloidal cerium oxide, iron as organic compound). Additionally iron is a ubiquitous element which might originate from other sources (e.g. abrasion).

The cerium content of the no-additive reference fuel sample RO was close to the detection limit. Significant quantities of cerium were detected for the samples CO and HCO from the additive-containing fuel sampled without particle trap. The samples CF and HCF, taken from cleaned gas after the particle trap, only contained extremely low cerium concentrations. The results for iron as

a ubiquitous element were not as definite as for cerium. Iron is present in high concentrations throughout the whole technical system. Under the given test conditions the iron originating from the additive could not be clearly distinguished from iron of other sources such as engine abrasion, fuel, test facility, sampling unit, ambient air, et cetera. A mass balance was deduced by comparing the measured analyte content with the total mass of additive content. Therefore the metal masses on the ELPI foils were extrapolated for the total emissions, based on the dilution ratio during sampling. Tables 7 and 8 give the calculated mass balances of iron and cerium. Table 9 shows the aerosol masses determined during sampling, which indicate a high filtration efficiency for particles. According to the mass balance for cerium no significant penetration rate was observed.

The interpretation of the iron data was more difficult. The mass balance for iron gives no clear results, which is probably caused by too many potential contamination sources adulterating the samples. This is also indicated by a negative filtration rate, with emissions sampled without a trap showing a lower iron content than those sampled with a trap. Also for the background level RO, relatively high iron values were detected which must originate from somewhere in the entire system. The results showed clearly that iron is less useful in suitability investigations or risk assessment with particle traps than cerium. A more useful test for iron would require that the additive iron could be clearly distinguished from iron originating from other sources. The use of a radiotracer-doped additive or of an iron additive compound with a significantly different iron isotope ratio than the natural might be imagined for this task.

It was noticeable that an unexpectedly large amount of additive was retained in the system. Previous investigations had shown that additives were deposited in the engine and the exhaust system. Additionally, the release of cerium from the engine during the conditioning phase was observed during other tests. These observations were explained by memory effects from earlier use of the engine with additive-containing fuel.

Table 9 Aerosol masses of the impactor stages in mg

D 50% (μm)	Stage	RO	CO	НСО	RO	СО	НСО
0.03	1	0.001	0.001	0.0008	0.0011	0.001	0.0013
0.06	2	0.018	0.0125	0.0139	0.0191	0.0186	0.0201
0.108	3	0.0634	0.049	0.058	0.089	0.082	0.084
0.17	4	0.13	0.09	0.09	0.15	0.15	0.15
0.26	5	0.095	0.057	0.066	0.114	0.096	0.112
0.4	6	0.25	0.13	0.17	0.33	0.26	0.28
0.65	7	0.99	0.42	0.76	1.39	0.74	1.07
1	8	2.2	1.35	2.2	3.22	2.29	2.75
1.6	9	5.61	3.17	4.9	7.22	5.14	5.82
2.5	10	18.7	10.6	16.3	25.2	15.6	18.5
4.4	11	70	34.6	54.2	91.8	55.9	67.2
6.8	12	331.7	142.4	243.5	420	247.3	293.5
10	13						

Presumably, saturation is expected after a "deposition conditioning phase" and the additive amount reaching the particle trap might increase. Therefore an increase in test duration or a pre-driven conditioning phase might increase the amount which can be found in stage CO.

Outlook

Further investigations should give information on where additive deposits might occur and if an initial deposition phenomenon does exist. Possible deposition locations might be the tank, the engine itself, the exhaust system, or the test facility with the partial dilution tunnel and tubes. Additionally a further investigation of the long-term stability of additive-fuel mixtures is necessary to guarantee stable solutions for general use. A clarification of the influence of additive type, fuel composition (e.g. the S content) etc. on the mixture stability is also needed. Whether lubricants have any effect on particle-trap efficiency is also still unknown. A study of the emissions under distinct operating conditions like the accumulation and regeneration phases is planned for the near future. Outstanding is also the investigation of the long-term behaviour of particle traps as well as the influence of ageing on penetration and soot retention. Finally, different particle trap concepts like additive/particle traps or special metalcoated particle trap systems, which can be operated without additives, should be compared.

Conclusion

It was clearly shown for cerium that the soot retention of the investigated particle trap was relatively high. According to the demand that appropriate particle traps should not generate significant secondary emissions, the additive release for the additive/particle trap combination described was relatively low for cerium. The interpretation of the iron results was difficult due to too many potential iron sources. It was surprising that only about 10% of the additive reached the particle trap, which might be caused by initial deposition. Differences in the load and regeneration phases and a possible saturation effect of the additive deposition have to be investigated in further studies.

Acknowledgements We would like to thank A. Mayer (TTM Mayer), N. Heeb (EMPA), T. Mosimann (Matter Eng.), Prof. J. Czerwinski with his group (FH Biel) and SAEFL (BUWAL) for co-operation in VERT projects and for optimisation and sampling in this study. D. Bleiner is sincerely acknowledged for his valuable help with the manuscript. Last but not least we are very grateful to the Plasma Winter Conference 2003 organising committee.

References

 Takizawa H, Abe S, Ohtoshi T, Kawasaki S, Takami K, Desaki M, Sugawara I, Hashimoto S, Azuma A, Nakahara K, Kudoh S (2000) Clin Exp Immunol 120(2):356–362

- Steerenberg PA, Zonnenberg JA, Dormans JA (1998) Exp Lung Res 24(1): 5–100
- Davis RJ, Bayram H, Abdelaziz MM, Sapsford RJ, Czarlewski W, Bousquet J (1998) Am J Respir Crit Care Med 157:A743
- 4. Minami M, Endo T, Hamaue N (1999) Res Commun Mol Pathol Pharmacol 105(1–2):67–76
- Brunekreef B, Janssen NA, De Hartog J, Harssema H, Knape M, Van Vliet P (1997) Epidemiology 8:298–303
- 6. SUVA Information zur einführung des partikelfilter-obligatoriums für dieselmotorbetriebene fahrzeuge und maschinen im untertagebau, Luzern, 30 April 2001 http://www.suva.ch/de/ info_partikelfilterobligatorium.pdf
- TRGS 554 Technische Regeln für Gefahrstoffe Dieselmotorenemissionen (DME), March 2001 http://www.umwelt-online.de/recht
- VERT Verminderung der Emissionen von Real-Dieselmotoren im Tunnelbau, Abschlussbericht 1 Jan 1994–29 Mar 2000 http:// www.akpf.org/pub/vert_sum_de.pdf
- SAEFL (2000) Particulate traps for heavy-duty vehicles. Environmental Documentation No. 130, Berne
- VERT-FILTERLISTE Geprüfte und erprobte partikelfilter-systeme für die nachrüstung von dieselmotoren, Version 17. July 2002 http://www.umwelt-schweiz.ch/buwal/de/fachgebiete/fg_luft/vorschriften/industrie_gewerbe/filter/
- Heeb N et al (1998) Influence of particulate trap systems on the composition of diesel engine exhaust gas emissions. EMPA Research Report No.167985
- 12. Heeb N et al (1998) Influence of particulate trap systems on the composition of diesel engine exhaust gas emissions (Part II). EMPA Research Report No.172847
- Nölte J (2003) ICP emission spectrometry a practical guide. Wiley, Weinheim
- 14. Fassel VA, Peterson CA, Abercrombie FN, Knieseley RN (1976) Anal Chem 48:516–519
- 15. Merryfield RN, LLoyd RC (1979) Anal Chem 51:1965-1968
- Boumans PWJM, Lux-Steiner MC (1982) Spectrochim Acta 37B:97–126
- McElroy F, Mennito A, Debrah E, Thomas R (1994) Spectroscopy 13(2):42–53
- 18. Borszeki J, Bartha L (1991) Acta Chim Hung 28(4-5):633-637
- 19. Fabec JL, Ruschak ML (1985) Anal Chem 57:1853–1863
- 20. Broekaert JAC, Keis F, Laqua K (1981) Talanta 28:745–752
- 21. Hauptmann G, Bernhard U, Engelke K, Fuchs A, Hönel E, Polzer G (1988) Schmierungstechnik 19:19–21
- 22. Kuokkanen T, Permämäki P, Völimäki I, Pönklömäki H (2001) Int J Environ Anal Chem 81:89–100
- 23. Brenner IB, Zander AT (2000) Spectrochim Acta B 55:1195–1240
- 24. Krengel-Rothensee K, Richter U, Heitland P (1999) J Anal At Spectrom 14:699–702
- Andreau C, Fredeen KT, Thomsen M, Yates DA (1995)At Spectrosc 16:79–81
- Hassler S, Noelte J, Ulrich A (2003) Alternate solvents for the direct analysis of organic samples by ICP-OES. Poster at the European winter conference on plasma spectrochemistry, Garmisch Partenkirchen, 2003
- 27. Kingston HM, Jassie LB (eds) (1988) Introduction to microwave sample preparation theory and practice. ACS Professional Reference Book, American Chemical Society, Washington
- Babu SP (ed) (1975) Trace elements in fuel. American Chemical Society, Washington
- Sulcek Z, Povondra P (1989) Methods of decomposition in inorganic analysis. CRC, Boca Raton
- Kägler SH (ed) (1987) Neue mineralölanalyse, band 1: spektroskopie. Hüthig, Heidelberg
- Ulrich A, Wichser A (2002) Metal analysis of diesel vehicle emissions. In: Proceedings of 6th conference on nanoparticle measurement, August 2002
- 32. Mayer A, Ulrich A, Czerwinski J, Matter U, Wyser M (2003) SAE paper 2003–01–0287

- 33. Keskinen J, Pietarinen K, Lehtimäki M (1992) J Aerosol Sci 23:353–360
- 34. Marjamäki M, Keskinen J, Chen D, Pui DYH (2000) J Aerosol Sci 31:249–261
- 35. van Gulijk C, Schouten JM, Marijnissen JCM, Makkee M, Moulijn JA (2001) J Aerosol Sci 32(9):1117–1130
- 36. Harris SJ, Maricq MM (2001) J Aerosol Sci 32:749-764
- 37. Bérubé KA, Jones TP, Williamson BJ, Winters C, Morgan AJ, Richards RJ (1999) Atm Env 33(10):1599–1614
- 38. Figler B, Sahle W, Krantz S, Ulfvarson U (1996) Sci Total Env 193(2):77–83
- 39. Matter U, Siegmann K (1997) The influence of particle filter and fuel additives on turbo diesel engine exhaust. J Aerosol Sci 28(1):551–552
- 40. Skillas G, Qian Z, Baltensberger U, Matter U, Burtscher H (2000) The influence of additives on the size distribution and composition of particles produced by diesel engines. Combust Sci Tech 154:259–273