

Utah State University

DigitalCommons@USU

Presentations

Getaway Special (GAS)

3-30-2010

Follow Up Nucleate Boiling On-Flight Experiment

Andrew Fassmann

Utah State University

Follow this and additional works at: https://digitalcommons.usu.edu/gas_presentations



Part of the [Aerospace Engineering Commons](#), [Mechanical Engineering Commons](#), and the [Physics Commons](#)

Recommended Citation

Fassmann, A. (2010, March 30). Follow Up Nucleate Boiling On-Flight Experiment. Presented at the Utah State University Undergraduate Research Day Student Showcase, Logan, UT.

This Presentation is brought to you for free and open access by the Getaway Special (GAS) at DigitalCommons@USU. It has been accepted for inclusion in Presentations by an authorized administrator of DigitalCommons@USU. For more information, please contact digitalcommons@usu.edu.



Follow Up Nucleate Boiling On-flight Experiment

Andrew Fassmann

USU's Get Away Special Team



- The team started with NASA's Get Away Special (GAS) Program.
- After discontinuation of GAS Program, we have still continued looking for options in microgravity research.
- Currently working with NASA's Reduced Gravity Office.
- Also working with Space Adventures to use International Space Station as a resource.

Nucleate Boiling Overview

- Nucleate Boiling is one of 4 types of boiling known for its high heat transfer rate.
- The GAS Team's first experiment was flown on the Shuttle in 2001.
- The first boiling experiment resulted in mostly qualitative and visual data.




Experiment Objectives

- Observe nucleate boiling with varying power input and surface geometry in microgravity.
- Determine effects of varying power and surface geometry on nucleate boiling.
- Develop analytical models for bubble growth on and departure from heating element.

Experiment Overview

- Three heating elements (platinum wire) run through three separate boiling cells.
- Specified current (based on resistance of wire) is run through wire.
- Data is recorded.
- About Five values of power and three surface geometries will be cycled to observe and vary different heat flux values.


Power (W)	Single Current (A)	3 Wire Current (A)	4 Wire Current (A)
1.5	4.23	4.40	3.39
2	4.89	5.08	3.91
2.5	5.47	5.68	4.37
3	5.99	6.22	4.79
3.5	6.47	6.72	5.17
4	6.91	7.19	5.53
4.5	7.33	7.62	5.87
5	7.73	8.03	6.18



Measurements

- Actual Power through Heating Element
 - Measure Voltage Across Known Resistor
- Temperature of the Heating Element
 - Measure Voltage Across the Wire
 - Solve for Resistance Change in Wire
 - Use Resistance Change to Find Temperature of Platinum
- Radial Temperature Distribution
 - 4 Thermocouples Measure Radial Temperature
- Gravity vs. “Bumping” Forces
 - Tri-axis Accelerometer Measurements
- Visual Data
 - 2 HD Video Cameras per Cell (6 Total)

Design Overview




Free Floating Structure



- DAQ System
 - Isolated
 - Power for Lighting (2 x D Cells)
- Boiling Cells
 - Water Tight
 - Mounted cameras and cells in one structure
 - Anderson Power Pole connectors for thermocouples and voltages

Boiling Chamber

- 6.5 fluid ounces
- O-ring Gasket with Clamping System
- Two Windows at 90° Relative to Each Other
- Quick Disconnect Valves for Easy Filling and Draining




Cameras



- Six Cameras under \$1000
- 1 cm Field of View
- Pixel Resolution of 1 pixel to 0.01 mm
- Kodak Zi8 - \$150
 - 1080p Resolution
 - Slightly > 1 cm field of view with 4x magnification


Lighting

- Measureable Bubbles
 - Reduce Glare
 - Soft Rear Box Lighting
 - Harsh Lighting from Underneath Cell




Data Acquisition

- Controller:
 - 800 MHz Processor
 - Serial/USB Interfacing
- Analog Input Module
 - Differential or Referenced Measurements.
- Thermocouple Module
 - 16 Channels @ 75 Samples/sec per channel
- Analog Output Module
- Digital I/O Module



Ground Structure



- 80/20 Aluminum Framing
- Mounting for Power Supplies and Umbilical
- Storage Unit for up to 30 Boiling Cells


Power Supplies

- BK Precision Power Supply
 - +/- 20 Volts
 - 10 Amps
 - Controllable over serial port with LABView.
 - Ability to control multiple supplies at once.



Summary

- The main role of the experiment is to understand boiling in space and on earth.
- Most of the major design and testing is completed, but we are still working.





Questions?