

Effect of the heat-induced corrosion on the mechanical behavior of Eurofer97 derived by instrumented indentations

I. Sacksteder, J.-H. Cherville, T. Weingärtner

Motivation

Further characterizations of the mechanical behavior of **Eurofer97** up to **550 °C** are required. A new instrumented macroindentation device was designed [1] and is currently constructed for that purpose (see Poster Session D 15-267). It is featured by a vacuum chamber to minimize oxidation at the sample during testing at high temperature. The impact of **heat-induced corrosion effects** on the **surface** and the **mechanical properties** is examined here in advance by means of Auger electron spectroscopy-AES, scanning electron microscopy- **SEM**, and **instrumented indentations** at room temperature (the indentation procedure is detailed in [2]).


Sample preparation

Materials: **Eurofer97** (9 wt.-%-Cr)

Polishing: 3 µm diamond suspension

Specimens: **13x4x3 mm³**

(halves of irradiated Charpy V-notched small-sized specimens)



1: vacuum-heated sample
(High vacuum-HV: **10⁻⁵ mbar**)

2: air-heated sample

Sample appellation:


V/A-TTT-H

Heating conditions:

Temperature (T)	250 °C		350 °C		450 °C		550 °C	
Atmosphere:	A	V	A	V	A	V	A	V
-Air (A) - High Vacuum (V)								
Heating time (H)	-	1h-3h	-	1h-3h	-	1h-3h	1h-3h	1h-3h

Sample analyses

AES/SEM analysis



- **Fe₂O₃** and **Cr₂O₃** layers (thinner than **8 nm**) **stable** up to 550°C in vacuum atmosphere (HV)


- **Growth** of **Fe₂O₃** layer (thicker than **250 nm**) for samples heated at 550°C in air-atmosphere

- Aspect of the polished **surface** remains **stable** for samples heated up to 550°C in **HV** atmosphere

- Porous and **non homogenous surface** observed, oxide particles visible for samples heated at 550°C in **air atmosphere**

Sample testing


Vickers hardness test



- Discrepancy up to **7%** between the average hardness of each heated samples

- No clear dependency to the temperature

Ball indentation – Strength assessment



- Discrepancy between all indentation curves, and assessed strengths lower than **6%** and **17 %** resp.

- No clear dependency to the temperature

Conclusions

- The growth of the **oxide layer** observed at high temperature (550°C/3h) remains for both tested atmospheres at the **nanometer scale**
- The heating atmosphere plays a noticeable role in the growth of oxides, at 550°C/3h a **HV** atmosphere helps **decreasing** the formation of a superficial oxide layer by **97 %** for Eurofer97
- No clear trend to hardening** was observed in the assessed mechanical properties that might result from the growth of a hard oxide layer formed by increasing the temperature
- Slight** but not clearly defined **changes** in the mechanical properties are expected to occur during **indenting at high temperature** with the new instrumented indentation device

Literature

- [1] I. Sacksteder, and H.-C. Schneider, *Fus. Eng. Des.*, 2010
- [2] N. Huber et al., *J. Nucl. Mater.*, 377, 2008, 352-358.

This work was carried out within the framework of the European Fusion Development Agreement.