### **Cellular Physiology** and Biochemistry Published online: 21 November 2018

Cell Physiol Biochem 2018;51:746-762 DOI: 10.1159/000495330

Accepted: 13 November 2018

© 2018 The Author(s) Published by S. Karger AG, Basel www.karger.com/cpb

746

Karger pen access

This article is licensed under the Creative Commons Attribution-NonCommercial-NoDerivatives 4.0 International License (CC BY-NC-ND) (http://www.karger.com/Services/OpenAccessLicense). Usage and distribution for commercial purposes as well as any distribution of modified material requires written permission.

**Original Paper** 

# **Osteogenic Effect of Inducible Nitric Oxide** Synthase (iNOS)-Loaded Mineralized Nanoparticles on Embryonic Stem Cells

Jin-Sun Lee Hong Jae Lee Jae Won Lee Sang Cheon Lee Jung Sun Heo

Department of Maxillofacial Biomedical Engineering and Institute of Oral Biology, School of Dentistry, Kyung Hee University, Seoul, South Korea

### **Key Words**

Embryonic stem cells • Inducible nitric oxide synthase • Mineralized nanoparticle • Nitric oxide Osteogenic differentiation

### Abstract

Background/Aims: This study investigated the effect of inducible nitric oxide synthase-loaded mineralized nanoparticles (iNOS-MNPs) on the osteogenic differentiation of mouse embryonic stem cells (ESCs). *Methods:* We prepared iNOS-MNPs using an anionic block copolymer template-mediated calcium carbonate (CaCO<sub>3</sub>) mineralization process in the presence of iNOS. iNOS-MNPs were spherical and had a narrow size distribution. iNOS was stably loaded within MNPs without denaturation. In order to confirm the successful introduction of iNOS-MNPs into the cytosol of ESCs, intracellular levels of nitric oxide (NO) was determined with a fluorometric analysis. A NO effector molecule, cyclic guanosine 3',5' monophosphate (cGMP) was also quantified with a competitive enzyme immunoassay. Cell viability in response to iNOS-MNP treatment was determined using the cell counting kit-8 (CCK-8) assay. Alkaline phosphatase (ALP) activity assay, intracellular calcium quantification assay, and Alizarin red S staining for matrix mineralization were performed to investigate osteogenic differentiation of ESCs. The protein levels of Runt-related transcription factor 2 (RUNX2), osteocalcin (OCN), and osterix (OSX) as osteogenic-related factors were also assessed by immunofluorescence staining and Western blot analysis. The complex pathways associated with iNOS-MNP-derived osteogenic differentiation of ESCs were evaluated by network-based analysis. *Results:* Cells with iNOS-MNPs displayed a significant increase in NO and cGMP concentration compared with the control group. When cells were exposed to iNOS-MNPs, there were no adverse effects on cell viability. Importantly, iNOS-MNP uptake promoted the osteogenic differentiation of ESCs. Using transcriptome profiling, we obtained 1,836 differentially-induced genes and performed functional enrichment analysis with ClueGO and KEGG. These analyses identified significantly enriched and interconnected molecular pathways such as protein kinase activity, estrogen receptor activity, bone morphogenetic protein (BMP) receptor binding, ligand-

Sang Cheon Lee, Ph.D and Jung Sun Heo, D.V.M. Ph.D



Department of Maxillofacial Biomedical Engineering and Institute of Oral Biology, School of Dentistry, Kyung Hee University, 26 Kyunghee-daero, Dongdaemun-gu, Seoul 02447 (South Korea) Tel. +82-2-961-0470, E-Mail schlee@khu.ac.kr; heojs@khu.ac.kr

### Cell Physiol Biochem 2018;51:746-762 and Biochemistry Published online: 21 November 2018 Www.karger.com/cpb

Lee et al.: Effect of iNOS-MNP-Derived NO on ESC Osteogenesis

gated ion channel activity, and phosphatidylinositol 3-phosphate binding. **Conclusion:** These findings suggest that iNOS-MNPs can induce osteogenic differentiation in ESCs by integrating complex signaling pathways.

Published by S. Karger AG, Basel

### Introduction

KARGER

Nitric oxide is a highly reactive free radical produced from a guanidino-nitrogen of L-arginine by three isoforms of nitric oxide synthases (NOS), including endothelial NOS (eNOS), neuronal NOS (nNOS), and inducible NOS (iNOS), depending on tissue location and physiological function [1-3]. Specifically, iNOS and eNOS are expressed in bone marrow stromal cells, osteoblasts, osteocytes, and osteoclasts, whereas nNOS expression is restricted to the bone lining cells and osteoclasts [4]. While all three NOS isoforms have been implicated in the bone healing process [5-7] iNOS is the principal isoform involved in the stimulation of osteoblasts by NO production [8-10].

NO is a signaling molecule that mediates a number of physiological events [11, 12]. NO has been shown to play an important role in bone formation and healing processes and can be generated by many cell types present in the bone milieu, most significantly, the osteoblasts [13]. However, whether NO results in pluripotent stem cell commitment into the osteogenic lineage has not been characterized.

NO-induced cyclic guanosine 3',5' monophosphate (cGMP) plays an important role in the early lineage specification of embryonic stem cells (ESCs) [14, 15]. ESCs treated with high concentrations of a chemical NO donor downregulated pluripotent gene expression and promoted differentiation events [16]. A number of groups have demonstrated that NO encourages the differentiation of bone marrow-derived mesenchymal stem cells (MSCs) into osteoprogenitor cells [17-19]. However, whether NO is associated with the osteogenic differentiation of ESCs *in vitro* remains largely unknown [20, 21].

NO is an important cellular signaling molecule that regulates stem cell fate. However, NO exists as a gas, which limits its use for research. Thus, NO-generating chemical compounds have been developed as NO donors and utilized *in vitro* and *in vivo* [22, 23], but are inconvenient due to their short half-life, cell toxicity, and low stability. In this study, we developed iNOS-loaded nanoparticles, which are manufactured through non-toxic processes using biocompatible polyethylene glycol (PEG)-poly L-aspartic acid (PAsp) block copolymer-induced mineralization for controlled, intracellular NO generation. Intracellular delivery of functional proteins, including enzymes, regulates various cellular events and has therapeutic applications in animal studies [24, 25]. The stable delivery and controlled release of iNOS enzyme in cells and the sustained production of NO molecules may mimic physiological NO production. Therefore, our system can overcome the limitations of current methods of NO application in biological experiments.

Nanomaterials can control stem cell behavior and tissue regeneration. Therefore, organic and inorganic nanoparticles are commonly used in stem cell research [26]. In this way, establishment of nanomaterial-based methodologies for ESC differentiation may provide a real-time toolkit for exploring a role for stem cell differentiation in cell therapy. In the present study, we demonstrate the effective delivery of iNOS-loaded nanoparticles into ESCs. Additionally, using global gene expression profiling for iNOS-MNP-mediated ESC osteogenesis, we assess the pro-osteogenic impact of iNOS-mediated NO production on ESCs and the activation of intracellular NO-related signaling pathways.

Cell Physiol Biochem 2018;51:746-762 DOI: 10.1159/000495330 © 2018 The Author(s). Published by S. Karger AG, Basel

Lee et al.: Effect of iNOS-MNP-Derived NO on ESC Osteogenesis

### **Materials and Methods**

### Materials

Fetal bovine serum (FBS) was purchased from Gibco-BRL (Gaithersburg, MD, USA).  $\alpha$ -Methoxy- $\omega$ -amino-poly(ethylene glycol) (CH<sub>2</sub>O-PEG-NH<sub>2</sub>) with an average molecular weight of 5, 000 g/mol was purchased from IDBIOCHEM Inc. (Seoul, Korea). A poly(ethylene glycol)-b-poly(L-aspartic acid) copolymer (PEG-PAsp) containing 113 EG units and 32 Asp units was synthesized by a modified procedure established in our laboratory [Min KH]. Inducible nitric oxide synthease (iNOS) was purchased from Sigma Co. (St. Louis, MO) and used as received. Reagent grade calcium chloride (CaCl<sub>2</sub>) and sodium carbonate (Na<sub>2</sub>CO<sub>2</sub>) were utilized. Unless otherwise specified, laboratory supplies and chemicals were purchased from SPL Lifescience (Pocheon, Korea) and Sigma Chemical Company.

### Fabrication of iNOS-loaded CaCO<sub>2</sub>-Mineralized Nanoparticles (iNOS-MNPs).

iNOS was loaded into the CaCO<sub>2</sub>-mineralized nanoparticles by the PEG-PAsp-templated mineralization process as follows. To a stirred aqueous PEG-PAsp solution (2.5 mg/mL, pH 8.0), an aqueous solution of calcium chloride (2 mL, 0.037 mmol, pH 8.0) was added at room temperature. After 2 h, an aqueous solution of iNOS (20 UN, pH 8.0) was added into the solution, and the solution mixture was stirred at 500 rpm for 3 h. Then, the aqueous solution of sodium carbonate (0.037 mmol, pH 8.0) was slowly mixed, and the mixture was vigorously stirred at 1,000 rpm at 4°C for 24 h. After centrifugation at 3,000 rpm for 3 min, the supernatant was placed into a membrane bag for dialysis against doubly distilled water (pH 8.0, molecular weight cut-off (MWCO): 100, 000 g/mol) for 12 h, followed by freeze-drying. For calculation of the loading amount of iNOS in the iNOS-MNPs, the iNOS-MNPs were completely dissolved in doubly distilled water (pH 5.0), and the iNOS was quantified using a quantification assay kit for iNOS.

### Characterization of the iNOS-MNPs

Dynamic light scattering measurements were performed using a 90 Plus particle size analyzer (Brookhaven Instruments Corporation) equipped with a vertically-polarized He-Ne laser (632.8 nm). The hydrodynamic diameter (d) and polydispersity factor (PDF) of the iNOS-MNPs were calculated using the Stokes-Einstein equation and the cumulant method, respectively [Harada A]. The morphology of the iNOS-MNPs was examined by transmission electron microscopy (TEM; H-7100, HITACHI, Japan), operating at an acceleration voltage of 100 kV. For the observation of size and morphology of the iNOS-MNPs, a drop of sample solution (concentration = 1 g/L) was placed onto a 200-mesh copper grid coated with carbon. About 5 min after deposition, the grid was tapped with a filter paper to remove surface water, followed by airdrying. Fourier transform infrared (FT-IR) spectra of the iNOS-MNPs were obtained using a Spectrum One System FT-IR spectrometer (Perkin Elmer, New York, USA) in the range of 450 to 2000 cm<sup>-1</sup> at a resolution of 4 cm<sup>-1</sup>.

#### Estimation of pH-dependent catalytic activity of iNOS-MNPs for NO generation

The activities of the iNOS-MNPs for NO generation were evaluated by estimating the nitrite generation in a HEPES-buffered solution (20 mM, 0.5 mM EDTA) at pH 7.4 and 5.0 at 37°C. The iNOS-MNPs were dispersed in buffer solutions (1 mL, 1 mg/mL) at pH 7.4 and 5.0, and the time-dependent nitrite generation was quantified using an ultrasensitive colorimetric assay kit for iNOS (NB78, Oxford Biomedical Research Inc.). The medium was shaken at a speed of 100 rpm at 37°C. At pre-determined time intervals, samples (100 µl) were withdrawn and replaced with an equal volume of the fresh medium. The nitrite concentration was determined by interpolation from the nitrite standard curve.

### pH-dependent dissolution of iNOS-MNPs

To study iNOS release, in vitro dissolution behavior of iNOS-MNPs was estimated in the buffer solutions (pH 7.4 and pH 5.0). The iNOS-MNP solution (1 mg/mL) was placed in a dialysis membrane bag (MWCO: 3, 500 g/mol) and was shaken at 100 rpm at 37°C in the release medium. The release medium (10 mL) was withdrawn at predetermined time intervals and replaced with an equal volume of the fresh medium. The release rate of calcium ions was monitored by diluting 100 µl of sample with the Arsenazo III solution (2



Cell Physiol Biochem 2018;51:746-762

and Biochemistry Published online: 21 November 2018 (© 2018 The Author(s). Published by S. Karger AG, Basel www.karger.com/cpb

Lee et al.: Effect of iNOS-MNP-Derived NO on ESC Osteogenesis

749

mL, 0.2 mM) in HBS (HEPES-buffered saline where [HEPES] = 20 mM and [NaCl] = 150 mM at pH 7.4). The absorbance of Arsenazo III/Ca<sup>2+</sup> complex in the solution was measured at 656 nm, and the concentration of calcium ions was calculated based on the standard curve.

### Mouse ESC culture and embryoid body formation

Mouse ESCs [ES-E14TG2a (ATCC<sup>®</sup> CRL-1821<sup>M</sup>)] were obtained from the American Type Culture Collection (Manassas, VA, USA). The ESCs were cultured in Dulbecco's modified Eagle's medium (DMEM) (Gibco-BRL, USA) supplemented with 17.5 mM glucose, 1.7 mM L-glutamine, 0.1 mM  $\beta$ -mercaptoethanol, 5 ng/ml mouse leukemia inhibitory factor (LIF, Enzo Life Sciences, USA), 15% FBS, and 1% penicillin and streptomycin (Gibco-BRL, USA), without a feeder layer at 37°C in an atmosphere containing 5% CO<sub>2</sub>. To form embryoid bodies (EBs), the cells were dissociated by 0.05% trypsin/EDTA (Gibco-BRL, USA). Then, 2, 000 cells were hung from the lids of 150 mm culture dishes for 2 days in 20 µl DMEM without LIF. EBs were then suspended in additional medium for 3 days. Thus, EBs cultured for 5 days old were used in this experiment.

### Osteogenic differentiation of ESCs

ESC differentiation was performed as previously reported. EBs were plated onto gelatin-coated 60mm dishes (10–15 EBs per well) and maintained in an osteogenic medium consisting of DMEM with 5% FBS, 50  $\mu$ g/mL ascorbic acid, 1  $\mu$ M dexamethasone, and 3 mM  $\beta$ -glycerophosphate for 2 days before the application of iNOS-MNPs. To promote osteogenic differentiation, iNOS-MNPs at different concentrations (0 to 100  $\mu$ g/ml) were added to the osteogenic medium, which was changed every other day.

### Measurement of nitric oxide

4-Amino-5-methylamino-2',7'-difluorofluorescein diacetate (DAF-FM DA) was used for fluorescence microscopy of NO and measurements of NO production. For microscopy studies, EBs were cultured in 6-well plates and treated for the indicated times with different drug concentrations. Cells were washed and phenol red-free media was added, and then cells were incubated with DAF-FM DA (5  $\mu$ M) for 10 min in the dark. Cells were then washed twice with ice-cold phosphate-buffered saline (PBS) and fixed with 2% paraformaldehyde for 3 min and washed twice again with ice-cold PBS. Analysis of NO production was carried out using a fluorescence microscope (Fluoview 300, Olympus, Japan) with the excitation wavelength set at 480 ± 10 nm and the emission wavelength at 505 ± 10 nm. For fluorometry experiments, cells were cultured with DAF-FM DA (5  $\mu$ M) at 37°C. Following incubation for 1 h, NO levels were determined by fluorescence readings using a fluorometer (Triad, DYNEX, Austria) with the excitation and emission wavelengths set at 490 nm and 515 nm, respectively. 'No dye' controls were used as background fluorescence and were subtracted from 'all dye'-containing sample well readings.

### Measurement of cGMP levels

The cells were incubated for 2 days in osteogenic differentiation media containing different concentrations of iNOS-MNPs. Cells were washed three time with PBS and lysed in lysis buffer from the cGMP ELISA kit (CELL BIOLABS, USA.). Total protein content was quantified using the Bradford method [27]. The cGMP content was measured using a cGMP ELISA kit according to the manufacturer's instructions and the absorbance was read at 450 nm using a spectrophotometer. The cGMP content level was expressed as pmol/mg of protein.

### Cell Viability assay

Cell viability was analyzed by using the cell counting kit-8 (CCK-8) assay. Briefly, EBs were seeded into 60-mm culture dishes. After 24 h, cells were changed to DMEM medium containing 5% FBS, and maintained for 24 h. Then, cells were incubated with different concentrations of iNOS-MNPs (0–100  $\mu$ g/ml) for 24 or 48 h. After exposure, CCK-8 solution was added for 1 h and the assay was performed following the manufacturer's instructions. The optical density of each well was determined at a wavelength of 450 nm using an ELISA plate reader (Triad, DYNEX, Austria). The percentage of cell viability was calculated relative to the control.



Cell Physiol Biochem 2018;51:746-762

and Biochemistry DOI: 10.1159/000495330 © 2018 The Author(s). Published by S. Karger AG, Basel Www.karger.com/cpb

Lee et al.: Effect of iNOS-MNP-Derived NO on ESC Osteogenesis

### Measurement of ALP activity

Cells were plated onto gelatin-coated 60-mm dishes (10–15 EBs per well). After 48 h since seeding, cells were changed into osteogenic differentiation medium containing different concentration of iNOS-MNPs (0–100  $\mu$ g/ml). Total cells were lysed in 50 mM Tris-HCl buffer (pH 7.0) containing 1% (v/v) Triton X-100 and 1 mM phenylmethylsulfonyl fluoride (PMSF). Total protein content was quantified using the Bradford assay. ALP activity was evaluated at 4 and 7 days by using *p*-nitrophenylphosphate (pNPP) method. The cell lysate was assayed by adding 200  $\mu$ l of pNPP as a substrate (Sigma) for 30 min at 37°C. The reaction was stopped by adding 3M NaOH, and the result was read at a wavelength of 405 nm using a spectrophotometer. The enzyme activity was expressed as mM/100  $\mu$ g of protein.

### Intracellular calcium quantification assay

Cells were plated onto gelatin-coated 60-mm dishes (10–15 EBs per well). Forty -eight hours after seeding, cells were changed into osteogenic differentiation medium containing different concentration of iNOS-MNPs (0–100  $\mu$ g/ml). After 14 days, cells were washed three times using PBS and lysed in 50 mM Tris-HCl buffer (pH 7.0) containing 1 mM PMSF and 1% (v/v) Triton X-100 without EDTA. Total protein content was quantified using the Bradford method. Intracellular calcium was measured using a calcium assay kit according to the manufacturer's instructions. The absorbance was read at 612 nm using an ELISA plate reader. The calcium content level was expressed as mM/100 mg of protein.

### Alizarin red S staining

Cells were plated onto gelatin-coated 12-well culture plates (5 EBs per well) and incubated in osteogenic medium for 21 days. The culture media was aspirated and washed three times with PBS. Cells were fixed in 4% paraformaldehyde for 20 min, washed three times with ice-cold PBS, and stained with 2% alizarin red S solution (pH 4.2) for 5 min at room temperature. Finally, the alizarin red S solution was aspirated and washed with deionized water. The samples were observed under a light microscope.

#### RNA isolation and real-time reverse transcriptase-polymerase chain reaction (RT-PCR)

Gene expression of Mmp15, Cltb, Atp5s, Cadn4, Wnt9a, Bmp8a, Fgf11, Map4k1 were analyzed by using real-time RT-PCR. Total RNA was extracted from different groups at 4 days by using the TRIzol reagent, following the manufacturer's instructions. cDNA was synthesized using the cDNA synthase kit (Bioneer, Korea) in accordance with the manufacturer's instructions. Real time RT-PCR was performed in the Rotor-Gene 2000 real-time thermal cycling system (Corbett Research, Sydney, Australia) using a QuantiTect SYBR Green RT-PCR kit (Enzo, USA). The mouse primers used were 5'-ATC TGG CGG TCT GGA AGA AC-3' (forward), 5'-AGG CTG CCC AAA ATC CAA TC-3' (reverse) for Mmp15, 5'-CTT TCA CCC CAC AAC TCC TT-3' (forward), 5'-CAC AAT TGA GTG GGC TGA CA-3' (reverse) for Cltb, 5'-TCA CTG CTG GAA TCC ACT GT-3' (forward), 5'-AAA TCC CGG GAA GCC ATA C-3' (reverse) for Atp5s, 5'-CCC TCT CCC CCC ATT ACT G-3' (forward), 5'-GCC CCG TAC AAA AAT GTG TT-3' (reverse) for Cadn4, 5'-TCT TGT GCA GCC TGT GAT TT-3' (forward), 5'-TTC TCT GCA GTC ACT CAG GTT-3' (reverse) for Wnt9a, 5'-CAG CCA AAG AAA ACG AAC GA-3' (forward), 5'-AAC CGT GGC CAT CAA AG-3' (reverse) for Bmp8a, 5'-ACC CCC AAC TCA GCA ATA AG-3' (forward), 5'-GAG GCT CCT CGT TTC CTA AG-3' (reverse) for Fgf11, 5'-ATT GGG ACA CCG TAC TGG AT-3' (forward), 5'-TGT CGC ACA GCT CAT TGT AT-3' (reverse) for Map4k1, 5'-TGC ACC ACC ACC TGC TTA G-3' (forward), 5'-GGA TGC AGG GAT GAT GTT C-3' (reverse) for GAPDH. The reaction mixture contained 1 µg of the total RNA and 0.5 µM of each primer. Real-time RT-PCR was performed using the Rotor-Gene 2000 cycler program: 30 min at 50°C for reverse transcription; 15 min at 95°C for DNA polymerase activation; 15 sec at 95°C for denaturing; and 45 cycles of 15 sec at 94°C, 30 sec at 60°C, and 30 sec at 72°C. Data collection was carried out during the extension step (30 sec at 72°C). RNA expression levels of target genes were normalized to control GAPDH RNA expression. The temperature of the PCR products was increased from 65 to 99°C at a rate of 1°C/5 sec, and the resulting data was analyzed using the software provided by the manufacturer.

### Immunofluorescence staining

Cells were incubated for 4 days in osteogenic differentiation medium containing iNOS-MNPs, washed three times with PBS, fixed for 5 min using 4% paraformaldehyde and permeabilized for 20 min using 0.1% Triton X-100 at room temperature. Then, cells were washed three times and blocked for 1 h using 4% BSA in PBS at room temperature. The cells were treated with primary antibody (1:100, rabbit anti-OCN, rabbit anti-

# Cellular Physiology

Cell Physiol Biochem 2018;51:746-762

and Biochemistry Published online: 21 November 2018 (© 2018 The Author(s). Published by S. Karger AG, Basel www.karger.com/cpb

Lee et al.: Effect of iNOS-MNP-Derived NO on ESC Osteogenesis

RUNX2) and overnight incubation at 4°C. Subsequently, cells were treated with Alexa Fluor 488 or 594 goat anti-rabbit immunoglobulin G (IgG) (1:500, Invitrogen Life Technologies, USA) for 2 h at room temperature. Fluorescence images were obtained using a fluorescence microscope (Fluoview 300, Olympus, Japan).

### Western blot analysis

The cells were incubated for 7 days in osteogenic differentiation medium containing different concentrations iNOS-MNPs. Whole cells were lysed using RIPA buffer with protease inhibitor and protein contents were quantified using the Bradford procedure. Protein extracts ( $30 \mu g$ ) were separated by 10% sodium dodecyl sulfate polyacrylamide gel and blotted onto polyvinylidene difluoride (PVDF) membranes. The blots were washed with 10 mM Tris-HCl (pH 7.6), 150 mM NaCl, 0.05% Tween-20 (TBST), blocked with 5% skim milk for 1 h and incubated with the appropriate primary antibodies (anti-OCN, anti-OSX, and anti- $\beta$ -actin) at the dilutions recommended by the supplier at 4°C overnight. The membranes were then washed and the bound primary antibodies were detected with goat anti-rabbit IgG or goat anti-mouse IgG conjugated to horseradish peroxidase. The blots were developed with enhanced chemiluminescence (Bio-Rad Laboratories, USA) and exposed to X-ray film (Eastman-Kodak, Rochester, NY, USA).

#### RNA isolation and library preparation and sequencing

Total RNA was isolated using TRIzol reagent (Invitrogen). RNA quality was assessed using the Agilent 2100 bioanalyzer with the RNA 6000 Nano Chip (Agilent Technologies, Amstelveen, The Netherlands), and RNA quantification was performed using ND-2000 Spectrophotometer (Thermo Inc., DE, USA). For control and test RNAs, library construction was performed using the SENSE 3' mRNA-Seq Library Prep Kit (Lexogen, Inc., Austria) according to the manufacturer's instructions. Briefly, 500 ng total RNA was used and an oligo-dT primer containing an Illumina-compatible sequence at its 5' end was hybridized to the RNA prior to reverse transcription. After degradation of the RNA template, second strand synthesis was initiated by a random primer containing an Illumina-compatible linker sequence at its 5' end. The double-stranded DNA library was purified by using magnetic beads to remove all reaction components. The library was amplified to add the complete adapter sequences required for cluster generation. The finished library is purified from PCR components. High-throughput sequencing was performed as single-end 75 sequencing using NextSeq 500 (Illumina, Inc., USA).

#### Data analysis

SENSE 3' mRNA-Seq reads were aligned using Bowtie2 version 2.1.0 (Langmead and Salzberg, 2012). Bowtie2 indices were either generated from genome assembly sequences or the representative transcript sequences for aligning to the genome and the transcriptome. The alignment file was used for assembling transcripts, estimating their abundances and detecting differential expression of genes. Differentially expressed genes were determined based on counts from unique and multiple alignments using EdgeR in R version 3.2.2 (R development Core Team, 2011) using BIOCONDUCTOR version 3.0 [28]. The read count (RT) data were processed based on quantile normalization method using the Genowiz ™ version 4.0.5.6 (Ocimum Biosolutions, India). Cytoscape (version 2.7), an open-source bioinformatics platform developed by the Institute of Systems Biology (Seattle, WA) was used to construct network diagrams and to illustrate clustering of the genes in our dataset within specific pathways. Gene classification was based on searches done by DAVID (http://david.abcc.ncifcrf.gov/) and Medline databases (http://www.ncbi.nlm.nih.gov/). Experimental data were integrated and analyzed using ClueGO application within the Cytoscape plug-ins. ClueGO functional analysis was performed using Gene Ontology or using the Kyoto Encyclopedia of Genes and Genomes (KEGG).

#### Statistical analysis

All data are expressed as mean  $\pm$  standard deviation (S.D.). One-way ANOVA was used for multiple comparisons, using SPSS software v. 10.0. *P* values < 0.05 were considered significant.

#### Cellular Physiology and Biochemistry UDI: 10.1159/000495330 Published online: 21 November 2018 Lee et al.: Effect of iNOS-MNP-Derived NO on ESC Osteogenesis

### Results

### Fabrication and characterization of iNOS-loaded mineralized nanoparticles

The iNOS-MNPs were fabricated using a PEG-PAsp-templated CaCO<sub>3</sub> mineralization approach developed in our laboratory [29]. The addition of Ca<sup>2+</sup> and CO<sub>3</sub><sup>2-</sup> ions to a stirred solution of PEG-PAsp induced ionic supersaturation around the anionic moieties of the PAsp blocks. This process induced the nucleation and growth of a crystalline CaCO<sub>3</sub> core, while the PEG block formed the hydrated shell domains. During this mineralization process, iNOS could be loaded *in situ* within the CaCO<sub>3</sub> core through ionic interaction. The mean hydrodynamic diameter of the iNOS-MNPs estimated by dynamic light scattering analyses was 333.9 ± 10.2 nm with a narrow polydispersity factor (0.11) (Fig. 1A). TEM analysis revealed that the iNOS-MNPs have a spherical shape (Fig. 1B). The loading efficiency of iNOS in the iNOS-MNPs was estimated to be 35.1%. For iNOS loading, the loading approach that does not induce the denaturation of iNOS is critical for stable iNOS delivery into ESCs. FT-IR analysis showed that the iNOS-MNPs showed vibration bands at 877 cm<sup>-1</sup>, which was attributed to the v<sub>2</sub> (out-ofplane bending mode) bands of vaterite (Fig. 1C). We also observed the vibrational band at 1420 cm<sup>-1</sup> attributed to v<sub>3</sub> asymmetric stretching mode of the vaterite CaCO<sub>3</sub>.

### pH-dependent catalytic activity of iNOS-MNPs for NO generation

We used the assay kit employing recombinant nitrate reductase for conversion of nitrates to nitrites prior to quantification of nitrite using the Griess reagent, thereby accurately evaluating overall iNOS activity. The pH-dependent catalytic activity of the iNOS-MNPs for



**Fig. 1.** Characteristics of the iNOS-MNPs. (A) Size distribution by dynamic light scattering, (B) TEM image, and (C) FT-IR spectra. (D) pH-dependent profiles of nitrite generation by iNOS-MNPs at pH values of 5.0 and 7.4 (n=3) and (E) kinetics of CaCO<sub>3</sub> dissolution of the iNOS-MNPs at pH 5.0 and 7.4 (n=3).





**Fig. 2.** Effects of iNOS-MNP on intracellular NO generation. The cells were incubated with different iNOS-MNP concentrations (1, 5, 10, 50, and 100  $\mu$ g/ml) for 24, 48, or 72 h. Using the fluorescent indicator, DAF-FM DA, intracellular NO levels were assessed by (A) fluorescence microscopic images and (B) fluorescence intensity assay. (C) cGMP concentrations were analyzed as described in Materials and Methods. A representative result from three independent experiments is shown (scale bar, 100  $\mu$ m). The values reported are the mean ± S.D. of four independent experiments. \*P<0.05 compared to the control value.

NO generation was estimated by evaluating the activity for generation of nitrite at both the extracellular pH (7.4) and the endosomal pH (5.0). Fig. 1D shows the pH-dependent nitrite generation profiles at pH 7.4 and 5.0. It is noteworthy that the nitrite generation at pH 5.0 is more pronounced compared with that at pH 7.4. This enhanced nitrite generation at pH 5.0 indicates that a large amount of iNOS was released from the iNOS-MNPs, thus effectively catalyzing the oxidation of L-arginine to generate NO molecules. The improved activity at endosomal pH may indicate that the iNOS-MNPs can effectively generate NO molecules after internalization into ESCs. This indicates that iNOS was stably loaded within the CaCO, cores and also released, while maintaining its inherent activity. To support the pH-dependent catalytic iNOS activity for NO generation, the kinetics of CaCO, dissolution from the iNOS-MNPs was examined. As shown in Fig. 1E, at endosomal pH, CaCO, dissolution was facilitated, whereas CaCO<sub>2</sub> dissolution was found to be inhibited at an extracellular pH. Accelerated dissolution of the CaCO<sub>2</sub> core at endosomal pH was expected because the solubility of CaCO<sub>2</sub> increases in proportion to the concentration of protons ( $H^+$ ) [30]. Facilitated dissolution of CaCO<sub>2</sub> at the endosomal pH triggered preferential iNOS release within ESCs, thereby resulting in the enhanced NO generation.

### Effect of iNOS-MNPs on intracellular NO levels

To verify whether NO is successfully generated when cells uptake iNOS-MNPs, intracellular NO production is evaluated by using the cell-permeable fluorescent indicator DAF-FM DA for 24, 48, or 72 h. When cells stained with DAF-FM DA were recorded by fluorescence microscopy, fluorescence was much stronger in cells treated with iNOS-MNPs than in the control group (Fig. 2A). Fluorescence intensity was higher in cells treated with iNOS-MNPs compared with control MNP-treated cells (without iNOS) at each time point **KARGER** 

# Cell Physiol Biochem 2018;51:746-762 DOI: 10.1159/000495330 Published online: 21 November 2018 www.karger.com/cpb Lee et al.: Effect of iNOS-MNP-Derived NO on ESC Osteogenesis

(Fig. 2B). Intracellular levels of cGMP, a NO effector molecule were further evaluated. Cells with iNOS-MNPs displayed a significant increase in cGMP concentration compared with the control group (Fig. 2C). These results clearly indicate that cells successfully uptake the iNOS-MNPs and that iNOS-MNPs promote NO production in ESCs.

### Induction of ESC osteogenic differentiation by iNOS-MNPs

Prior to assessment of osteogenic activity of ESCs, cell viability in response to iNOS-MNP treatment was determined. Viability was unaffected in cells treated with different doses of iNOS-MNPs (1, 5, 10, 50, and 100  $\mu$ g/ml) for 24 h (Fig. 3A).



**Fig. 3.** Effect of iNOS-MNP on ESC-osteogenic differentiation. The cells were treated with different doses of iNOS-MNPs (1, 5, 10, 50, and 100  $\mu$ g/ml) for cell viability assessment at 24 h (A) or 7-day osteogenic induction and (B) ALP activity, (C)  $[Ca^{2+}]_{\mu}$  and (D) Alizarin red staining was assessed. The values are reported as mean ± S.D. of three independent experiments; \*P<0.05 compared to the control value.



**Fig. 4.** Effect of iNOS-MNP on osteogenesis-related protein levels. The protein levels of RUNX2, OCN, and OSX were determined by immunofluorescence staining and western blotting. The nuclei were stained with DAPI (shown in blue). A representative result from three independent experiments is shown (scale bar, 100  $\mu$ m).



Lee et al.: Effect of iNOS-MNP-Derived NO on ESC Osteogenesis

To verify the osteogenic effect of iNOS-MNP on ESCs, cells were exposed to  $1-100 \mu g/ml$  of iNOS-MNPs for 7, 14, or 21 days. ALP activity,  $[Ca^{2+}]_{,}$  and mineralization was then determined. Fig. 3B and C demonstrate that ALP activity and  $[Ca^{2+}]_{,}$  were significantly enhanced in ESCs exposed to iNOS-MNPs. Cells treated for 21 days with iNOS-MNPs displayed highly positive Alizarin red S staining, suggesting high calcium nodule formation and matrix mineralization as would be expected as a result of osteogenic differentiation (Fig. 3D). To further identify osteogenic differentiation, we assessed the protein levels of osteogenic markers RUNX2, OCN, and OSX on day 7 of osteogenic induction. Immunofluorescence staining (Fig. 4A, B) and western blot analysis (Fig. 4C) confirmed that the treatment of iNOS-MNPs increased each osteogenic marker protein in ESCs compared with control group. These results suggest that the treatment of ESCs with iNOS-MNPs enhances osteogenic differentiation.

### iNOS-MNPs alter ESC transcription profile

In order to investigate the changes in global gene expression by the iNOS-MNP-induced ESC differentiation, cells were treated with iNOS-MNPs for 14 days and high-throughput RNA-Seq analysis was performed. When a fold-change cut-off of >1.5 and a *P* value of <0.05 was applied to filter the differentially expressed genes in iNOS-MNP-treated cells compared to the control, we classified 730 genes as upregulated and 1, 106 as downregulated, which were clustered using the Euclidean distance correlation and visualized by a heatmap (Fig. 5A, B). Table 1 shows the top 10 upregulated or downregulated genes analyzed by the GO annotations using DAVID (http://david.abcc.ncifcrf.gov/). iNOS-MNP treatment induced the upregulation of genes associated with chemical homeostasis, but downregulated genes associated with regulation of the system process, suggesting that these actions downstream of iNOS-MNPs may control biological function. The gene lists and GO term data are presented in Supplemental Data 1 (For all supplemental material see www.karger. com/10.1159/000495330/).



**Fig. 5.** RNA-Seq analysis of the cells cultured with iNOS-MNPs. (A) Clustering analysis was performed for the significantly regulated probe sets, consisting of the 1,836 genes. The color key indicates gene expression value (red for upregulated and green for downregulated). (B) Numbers of upregulated and downregulated genes in cells treated with iNOS-MNPs compared to those in control conditions with at least a 1.5-fold change in expression level.



Lee et al.: Effect of iNOS-MNP-Derived NO on ESC Osteogenesis

# Identification of genes associated with osteogenic differentiation by iNOS-MNPs

We next identified differentially expressed genes (P < 0.05, with foldchange >1.5) to extract the activation of bone-related molecular pathways by iNOS-MNP treatment, comprising a total of 537 genes, of which 337 were downregulated and 200 were upregulated using GO analysis (https:// www.ebi.ac.uk/QuickGO/) and ExDEGA (Excel-based Differentially Expressed Gene Analysis) version 2.3 tool (ebiogen, Korea) (Supplemental Data 2). Table 2 demonstrates the representative genes which were mapped to 14 different pathways such as cell differentiation, proliferation, extracellular matrix, BMP signaling, calcium ion binding, calciummediated signaling, mitogen-activated protein kinase (MAPK) cascade, Notch **Table 1.** Top 10 annotation clusters for upregulated and downregulated genes in cells treated with iNOS-MNPs compared to those in control conditions with associated *P* values from DAVID GO term analysis

Term	-log10 (p-value)
Top GO term of top 10 annotation clusters for up regulated gene	
G0:0006334~nucleosome assembly	3.63E+00
GO:0032776~DNA methylation on cytosine	2.65E+00
GO:0006335~DNA replication-dependent nucleosome assembly	2.59E+00
GO:0045815~positive regulation of gene expression, epigenetic	2.59E+00
G0:0007275~multicellular organism development	2.31E+00
GO:0051290~protein heterotetramerization	1.93E+00
GO:0006206~pyrimidine nucleobase metabolic process	1.79E+00
GO:0006471~protein ADP-ribosylation	1.71E+00
GO:0006081~cellular aldehyde metabolic process	1.67E+00
G0:0000183~chromatin silencing at rDNA	1.65E+00
Top GO term of top 10 annotation clusters for down regulated gene	1
GO:0034765~regulation of ion transmembrane transport	5.15E+00
G0:0006816~calcium ion transport	3.79E+00
GO:0006811~ion transport	3.77E+00
GO:0032729~positive regulation of interferon-gamma production	a 3.72E+00
GO:0007612~learning	3.57E+00
GO:0006836~neurotransmitter transport	3.45E+00
G0:0051965~positive regulation of synapse assembly	3.36E+00
GO:0050804~modulation of synaptic transmission	3.16E+00
G0:0070588~calcium ion transmembrane transport	3.13E+00
G0:0019233~sensory perception of pain	3.03E+00

signaling, vasculature development, Wnt signaling, cell adhesion, growth factor activity, ossification, and skeletal system development, all of which are related to osteogenic differentiation and bone formation. The RNA-Seq data were validated by evaluating the expression of selected genes (Mmp15, Cltb, Atp5s, Cadn4, Wnt9a, Bmp8a, Fgf11, Map4k1) using real-time RT-PCR analysis. These genes were upregulated in a similar manner as that observed with RNA-Seq analysis, thus validating the RNA-Seq data (Fig. 6).

### Evaluation of the connectivity network between the differentially expressed genes

Network-based analysis within the differentially expressed genes relating to the osteogenic differentiation-related molecular pathways was further extracted by ClueGO. The molecular functions such as protein kinase activity, estrogen receptor activity, BMP receptor binding, ligand-gated ion channel activity, or phosphatidylinositol 3-phosphate binding were shown to be significantly enriched and interconnected (Fig. S1). We next performed pathway enrichment analysis and identified the networks of three significantly enriched KEGG pathways along with the genes shared between these pathways (Fig. S2-A). Fig. S2-B illustrates the number of genes associated with each term in significant KEGG pathways. These analyses identify several pathways and genes with a connection to cellular mechanisms that are associated with NO-mediated ESC-osteogenic differentiation.

Table 2. List of the most representative genes and pathways. red, up-regulated genes; blue, down-regulated
genes

Carding Journel 1, 2010, 2020         Participation         Participation           Cardinal Construction         Training and the participation factor related, locus 3 (Drosophila)         Cell differentiation           Nis2-3         6.667         Nis2 cardinal cardina cardinal cardinal cardinal cardinal cardina cardinal	Can a growh al	Fold shange	Concinence	Dathway
Trad     1830     m Teel listicma, homework     m Teel listicma, homework       112-DM     6.444     h Stat concerption factor related, loca 3 (Drosophila)     Cell differentiation       112-DM     6.444     h Stat concerption factor related, loca 3 (Drosophila)     Cell differentiation       S22     3840     solute carrier family 11, member 1     Cell proliferation       Familia     3.444     framily with sequence similarity 83, member A     Cell proliferation       Assg     9.937     ell pha-2 (FS gytoprotein)     Extracelluar matrix       Rarresz     6.368     supercontext distants     Stat concentration       Null Da     4.804     wingless related bin Mit ingeration site 10 a     BMP signaling pathway       Bingba     4.734     bone morphogenetic protein 8     BMP signaling pathway       Cabris     5.600     calcium ion binding     Calcium ion binding       Bingba     4.734     bone morphogenetic protein 2     BMP signaling pathway       Bingba     4.734     bone morphogenetic protein 2     BMP signaling pathway       Calcium ion binding     frotein 2     intromes and responsed contains and spontains       Bingba     4.734     bone morphogenetic protein 2     Calcium mediated signaling       Bingba     4.734     bone morphogenetic protein 2     Calcium ion binding       Bingba </td <td>Mfrp</td> <td>10 727</td> <td>membrane time friggled related protein</td> <td>Paulway</td>	Mfrp	10 727	membrane time friggled related protein	Paulway
Nuc.26.6.67 NL2 transcription factur related, locus 3 (Drosophila) bistocompubliky 2, dass 1, locus 3M endothelial cell surface expressed chemotasis and apoptosisCell differentiationSize3.840 startace expressed chemotasis and apoptosisSolar Cell proliferationCell proliferationSize 1.113.680 startace expressed chemotasis and apoptosisCell proliferationCell proliferationSize 1.113.680 startace expressed chemotasis and apoptosisCell proliferationCell proliferationMoviol 3.267 Solar Cell Science and Science expression 1Solar Cell Science expressionExtracelluar matrixAssg0.331 retinor cell retrasponder 2 Solar Cell Science expressionExtracelluar matrixSolar Cell Science expressionNucl Cell Science expressionExtracelluar matrixSolar Cell Science expressionScience expressionCalcium inding factor 1Cald Science expressionScience expressionCalcium ion bindingScience expressionScience exp	Tlx2	8 8 1 0	T cell leukemia homeobox 2	
112.0Ma6.444Instactompatibility 2, class 11, locus DMAInterval and the second second apoptotisSk23.840sine oculis-related homeobox 2Sk23.840sine oculis-related homeobox 2Sk23.840family with aquence is multility 183, member AFamilia3.444family with aquence is multility 183, member AFamilia2.667Herraspanin 1Barresca6.331retinuc claft receptor responder 2Familia3.444family with aquence is approximation in the 10-like 1Arresca6.331retinuc claft receptor responder 2Farresca6.331retinuc claft receptor responder 2Lerces5.560incucine rich report containing 55Brapia4.784bone morphogenetic protein 8Card2.387bone morphogenetic protein 1Cabr2Calcium binding protein 2Cabr2Calcium binding protein 2Cabr36.000Cabr45.100 calcium binding protein 2Cabr36.000retarier family 11, member 5Finb55.100 calcium binding protein 1By 2100 calcium binding protein 16By 2100 calcium binding protein 16Cabr22.296junct carrier family 11, member 1By 3calcium binding protein 1By 44.543By 42.632mitingen activated protein intrase 4Map42.632mitingen activated protein intrase 4Map42.633Map42.633Map4 </td <td>Nkx2-3</td> <td>6.667</td> <td>NK2 transcription factor related, locus 3 (Drosophila)</td> <td>Cell differentiation</td>	Nkx2-3	6.667	NK2 transcription factor related, locus 3 (Drosophila)	Cell differentiation
Each5.880endothelial cell surface expressed hemotaxis and apoptosisSiz23.840sine oxular related homebox 2Siz23.840sine oxular related homebox 2Siz1333.650yout carrier family 11, member 1Alsa2.695Molongy fusiema vrna 10-like 1Ahag9.937nipha 2-liS glycoprotinRandza6.340membra 2.10 glycoprotinRandza6.340membra 2.10 glycoprotinRandza6.340membra 2.10 glycoprotinRandza6.340membra 2.10 glycoprotinRandza6.340membra 2.10 glycoprotinRandza6.340wingless related MITV integration site 10aBingBa2.957bone morphogenetic protein 3BingBa1.6722calcium binding protein 2Calcium 100calcium binding protein 2Calcium ion bindingCalcium 26.000calcium icreated family 11, member 1Calcium 1005.000calcium binding protein 2.10Calcium 100sing out and sing 11, member 1sing out and sing 11Sing 113.680mitogen-activated protein kinase kinase in a finase 6MapE42.632mitogen-activated protein kinase kinase in a finase 6MapE42.632mitogen-activated protein kinase kinase in a finase 1MapE42.632mitogen-activated protein kinase kinase kinase 1MapE42.632mitogen-activated protein kinase kinase kinase 1MapE42.632mitogen-activated protein kinase kinase kinase 1MapE42.632mitogen	H2-DMa	6.444	histocompatibility 2, class II, locus DMa	
Sh2 Sh2 111 111 1111 1111 1111 1111 1111 1111 1111 1111 1111Sh2 1111 11111 11111 11111 11111Sh2 1111 11111 11111 11111 111111Sh2 11111 111111 111111 111111 111111 111111Sh2 11111 111111 111111 111111 111111 111111Sh2 111111 111111 111111 111111 111111 111111Sh2 111111 111111 111111 111111 111111Sh2 111111 111111 111111 111111 111111Sh2 111111 111111 111111 111111 111111 111111 111111Sh2 111111 111111 111111 1111111 1111111 1111111 1111111 1111111 1111111 1111111 1111111 11111111 1111111 11111111 11111111 111111111111111 111111111111111111111111111111111111	Ecscr	5.889	endothelial cell surface expressed chemotaxis and apoptosis	
Share and the constrained content of a constrained of the constrained	c: 2	2.040		
Pand 3a3.444family with sequence similarly 33, member A Movi010Cell proliferationMovi0103.267Molency leukani avina 10-like 1Cell proliferationHarres 26.391retinica cal receptor responder 2 same road dismutase 3, extracellular teric retinica cal receptor responder 2 same road dismutase 3, extracellular teric retinica cal receptor responder 2 same road dismutase 3, extracellular teric retinica cal receptor responder 2 same road dismutase 3, extracellular teric retinica cal receptor responder 2 same road dismutase 3, extracellular teric retinica cal receptor responder 2 same road dismutase 3, extracellular teric receptor receptor responder 2 same road dismutase 3, extracellular teric receptor receptor 2 teric receptor 2 teric receptor 2 teric receptor 2 teric receptor 2 teric re	SIXZ Slc11o1	3.840	Sine oculis-related nomeobox 2 solute carrier family 11, member 1	
Mori 01132.67Molong/Jeulemia arrus 10-life.1Case point futureTspan12.695Malong/Jeulemia arrus 10-life.1Case point futureTspan12.695alpha-2-H5 Syloop ruteinExtracelluar matrixRarres26.301superoide dismutase systemExtracelluar matrixWat10a4.804wingless related MMTV integration site 10aBMP signaling pathwayBorgBa4.784bone morphogenetic protein 8aChrd2.287chordinBMP signaling pathwayBorgDa0.567bone morphogenetic protein 7aCalcium ion bindingCaby 216.722calcium binding protein 2Calcium ion bindingCaby 216.722calcium binding protein 1Calcium ion bindingStobal 44.004S100 calcium binding protein 1Calcium ion bindingStobal 44.004S100 calcium binding protein 1Calcium ion bindingStobal 44.004S100 calcium binding protein 1Stobal 4.004Stobal 44.004solutic carrier family 11, member 1MAPK cascadeMap3462.632mitogen-activated protein famase Kinase Kinase 1MAPK cascadeMap442.632mitogen-activated protein famase Kinase Kinase 1MAPK cascadeMap442.632mitogen-activated protein famase Kinase Kinase 1MAPK cascadeMap442.632mitogen-activated protein famase Kinase Kinase Kinase 1MAPK cascadeMap452.631mitogen-activated protein famase Kinase Kinase Kinase 1March signaling pathwayRut 42.	Fam83a	3 4 4 4	family with sequence similarity 83 member A	Cell proliferation
Tspan12.695Letraspan1 1Letraspan1 1Ahsg9.937alpha-115 glycoprotein Rarres26.391retinoic acid receptor responder 2 sage containing 55Extracelluar matrixSold6.361supercode dismutuse 3, extracellular tertS5Extracelluar matrixIrrS55.760leucine rich regate containing 55Extracelluar matrixBmpBa4.784bone morphogenetic protein 8 toroitinBMP signaling pathwayBmp20.567bone morphogenetic protein 2 tert1EMP signaling pathwayBmp20.567bone morphogenetic protein 2 tert1EMP signaling pathwayCahz216.722 	Mov1011	3 2 6 7	Moloney leukemia virus 10-like 1	cen promeration
Aling Rarres29.937 6.391alpha-2.15-gycoprotein retinuic acid receptor responder 2 Sod3Extracelluar matrixRarres26.361 6.368superconde distinues, stratacellular leucine rich repeat containing 55Extracelluar matrixWittlo4.784 4.804bone morphogenetic protein 8a chord in leucine rich repeat containing 55BMP signaling pathwayBinpba4.784 4.784bone morphogenetic protein 2 chord in leucine rich repeat containing factor 11BMP signaling pathwayCabp216.722 (Chord 5caldenin-related family member 5 thorbs 4Calcium ion binding thormohopoint 6Cabp32.0567 (Chord 5junctophilin 2Calcium mediated signaling morpoint 6Jph22.296junctophilin 2Calcium mediated signaling mitogen activated protein kinase kinase 6 alged 2Jph34.197 (Source philin 2Calcium mediated signaling mitogen activated protein kinase kinase kinase 1Hes74.366 (Bairy and enhancer of Spil 7 (Drosophila) in 13Notch signaling pathwayAup149.222 (Source philin 8 caudad type tomobox 2 wingless related MITV integration site 10 wingless related MITV integration site 10<	Tspan1	2.695	tetraspanin 1	
Absg.       9.937       alph3-245-glycoprotein         Rarres2       6.391       retinoic add receptor responder 2         SuB3       6.268       superoxide dismutuse 3, extracellular         ExrtS5       5.760       locatine rich repace ontaining 55         Wm104       4.804       vingless related MMTV integrations for 10         Bmp8a       4.784       bone morphogenetic protein 2         Chrd       2.387       chordin         Bmp2       0.567       bone morphogenetic protein 2         Cabr5       6.000       calcium binding protein 2         Cabr5       5.619       protocalherin related family member 5         Fe(hb5       5.619       protocalherin related family member 5         Fe(hb5       5.619       protocalherin related family member 1         Stol 1       1000 call       for 232         Stol 1       1000 call motogin - activated protein family 11, member 1         May3k6       3.003       mitogen-activated protein famise kinase 6         May1k1       2.618       mitogen-activated protein famise kinase 6         May2k1       2.618       mitogen-activated protein famise kinase 6         May2k1       2.618       mitogen-activated protein famise kinase 6         May2k2       3.020       mi	•		·	
Rarres26.391reflore add receptor responder 2Sol36.368supersoid dismutus8 , settracellularLarres55.760keuter nich repart containing 55Wit1044.804wingless related MPT integration site 100BenpBa4.784bone morphogenetic protein 8aChrd2.387chordinBarp20.567bone morphogenetic protein 2Cabp56.609cacherin binding factor 1Cabp56.619cacherin binding protein 2Pellb356.619furombospondin 4S100a164.004S100 calcium binding protein A16S101a13.660mitogenetic protein klase kinase kinase inase 6Nrg14.197neurgatinNg143.660mitogen-activated protein klase kinase kinase inase 6Map44i2.618mitogen-activated protein klase kinase kinase inase 1Map44i2.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Drok2.337pacetal type consphila)Noth signaling pathwaykinding motif rotein 15Labo13.520hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Drok3.537pacetal growth factor 11Vasculature developmentJohnewox 813Ap19.223endothel cell surface expressed chemotaxis and apoptosisCalciu3.520homemobox 813Paf3.337placetal growth factor 11Wit10a4.804wingless related MMTV integration site 9A <tr< td=""><td>Ahsg</td><td>9.937</td><td>alpha-2-HS-glycoprotein</td><td></td></tr<>	Ahsg	9.937	alpha-2-HS-glycoprotein	
Sold 5.048       Supercode dismitas 4, extractellular       EXTACENULAR         Natiba       4.804       wingless related MMTV integration site 10a         BmpBa       4.784       bone morphogenetic protein 8a         Chrd       2.387       chordin         Bmp2       0.567       bone morphogenetic protein 2         Cabp2       16.722       calcium binding factor 1         Cabp2       16.722       calcium binding protein 2         Cabris       6.000       cadherin related family member 5         Pediabi       5.193       protocadherin beta 5       Calcium ion binding         Stobal       4.004       S100 calcium binding protein 16       Calcium mediated signaling         Nrg1       4.197       neuregulin 1       Scilation 16       Scilation 16         Stobal       3.008       mitogen-activated protein kinase kinase kinase kinase 1       AAPK cascade         Map3k6       3.008       mitogen-activated protein kinase kinase kinase 10       AAPK cascade         Map3k6       3.008       mitogen-activated protein kinase kinase kinase inase 1       APK cascade         Map3k6       3.008       mitogen-activated protein kinase kinase kinase inase inase       AAPK cascade         Map4k1       2.632       mitogen-activated protein kinase kinase kinase inase	Rarres2	6.391	retinoic acid receptor responder 2	<b>F</b>
Links3.500Telefinite repert control in the problem of the prob	Sod3	6.368	superoxide dismutase 3, extracellular	Extracelluar matrix
NationLossHinges of cauce with Thine particular its costBmpBa Chrd2.387chordinBmp20.567bone morphogenetic protein Ba chordinBMP signaling pathwayLef10.288lymphoid enhancer binding factor 1Cabp216.722calcium binding protein 2 calcium binding protein 2 thrombos pondin 4Cabp36.000cadherin-related family member 5 protocatherin beta 5Calcium ion binding thrombos pondin 4S100a164.004S100 calcium binding protein A16Calcium mediated signaling MAPAKMp2163.008 mitogen-activated protein kinase kinase kinase 6 mapatkaMAPK cascadeMap4142.632 mitogen-activated protein kinase kinase kinase 1MAPK cascadeMap4151.734 ubpi216mitogen-activated protein kinase kinase kinase 1MAPK cascadeHes74.636 thairy and enhancer of split 7 (Drosophila) igged 2Noth signaling pathwayBM211.734 ubpi216RNA BNA BNA BNA BNA BNA BNA BNA BNA BNA B	Wnt10a	5.760 4.804	wingless related MMTV integration site 10a	
BmpBa Chri Chri 2.3874.784 	Wiitiba	4.004	wingless related with a integration site roa	
Chrd2.387chordinBMP signaling pathwayBmp20.567bone morphogenetic protein 2DS67Lef10.288lympholi enhancer binding factor 1Cabp216.722calcium binding protein 2Cabr56.000cadherin-related family member 5Pedib55.619protocadherin beta 5Str00a164.004S100 calcium binding protein A16Jph22.296junctophilin 2Sk11a13.680mitogen-activated protein kinase kinase 6Map3k63.008mitogen-activated protein kinase kinase 1Hes74.636hairy and enhancer of split 7 (Drosophila) lagzJag23.912jagzd 2Drok2.225eendothelial cell surfacional of the books 31Wath32.222aquaporin 1 ubiquitin BAap10.222aquaporin 1 ubiquitin BAap12.222aquaporin 1 ubiquitin BAap12.223mitogen-activated protein 15 ubiquitin BAap10.222aquaporin 1 ubiquitin BAap12.222aquaporin 1 ubiquitin BAap12.223wingless-related MNTV integration site 9A calcial trip biomochox 3 axia2Calcial2.642chymotrysin-like elastase family, member 1 ubiquitin BAap10.222aquaporin 1 ubiption BCalcial2.642chymotrysin-like elastase family, member 1 ubiption BAap10.222aquaporin 1 ubiption BCalcial2.642chymotrysin-like elastase family, member 1 ubiptio	Bmp8a	4.784	bone morphogenetic protein 8a	
Binp2     0.567     bone morphogenetic protein 2     Determine planting planting       Left     0.288     lymphole chanace binding factor 1       Cabp2     16.722     calcium binding protein 2       Cabr5     6.000     cadherin-related family member 5       Profhb5     5.619     protocadherin beta 5       S100a16     4.004     S100 calcium binding protein A16       Iph2     2.296     junctophilin 2     Calcium mediated signaling       Nrg1     4.197     neuregulin 1     MAPK cascade       Map346     3.008     mitogen-activated protein kinase kinase 6     MAPK cascade       Map44     2.618     mitogen-activated protein kinase kinase 4     MAPK cascade       Map44     2.618     mitogen-activated protein kinase kinase 4     MAPK cascade       Map44     2.618     mitogen-activated protein kinase kinase 4     MAPK cascade       Map44     2.618     mitogen-activated protein kinase 4     MAPK cascade       Map45     3.912     jagged 2     Notch signaling pathway       Rbm15     1.734     RNA binding motif protein 15     Notch signaling pathway       Rbm15     5.839     calual type homeobox 2     Vasculature development       Hox1     1.644     ubiquitin 8     Appl       Ap21     9.222     aquaporin 1 <td>Chrd</td> <td>2.387</td> <td>chordin</td> <td>BMP signaling nathway</td>	Chrd	2.387	chordin	BMP signaling nathway
Lef10.288(hymphoid enhancer binding factor 1Cabp216.722calcium binding protein 2Cabr56.000cadherin related family member 5Pedhab5.619protocadherin beta 5Tibbs44.545thromosopandin 4Jph22.296junctophilin 2Calcium mediated signalingNig1Jph22.296junctophilin 2Sici 1a13.680solute carrier family 11, member 1Map3k63.000mitogen-activated protein kinase kinase 6Map4k12.613mitogen-activated protein kinase kinase 1Hes74.636hairy and enhancer of split 7 (Drosophila) jaged 2Jpk23.912jaged 2Dr22.1855deltex 2 homolog (Drosophila) ubiquin BApp10.222aquaporin 1 econda 10 (protein 15Libah3.520endetex 2 homolos 13 ubiquin BAp10.222aquaporin 1 econda 10 (prosophila) ubiquin BAp10.222aquaporin 1 econda 10 (prosophila) ubiquin BAp10.222 axin2vingless-related MMTV integration site 0A ubiquin BAp10.222 axin2wingless-related MMTV integration site 9A colaCalcium cola1.558 axin2cell antiper stress 4Calcium cola0.667NK2 transcription factor related, locus 3 (Drosophila) protocatherin beta 5Pg10.503 axin2cell antiper stress 4Calcium cola0.667NK2 transcription factor related, locus 3 (Drosophila) protocatherin beta 5Pg1 <td>Bmp2</td> <td>0.567</td> <td>bone morphogenetic protein 2</td> <td>Divit Signaling pathway</td>	Bmp2	0.567	bone morphogenetic protein 2	Divit Signaling pathway
Cabp2 Cabr516.722 Cadberin related family member 5 protocadherin related family member 5 protocadherin related family member 5 protocadherin beta 5 thrombospondin 4Calcium ion binding calcium ion binding protocadherin beta 5 thrombospondin 4100a164.004\$100 calcium binding protein A16Calcium mediated signalingNrg1 Mapk44.197 3.608neuregulin 1 mitogen-activated protein kinase kinase 6 mitogen-activated protein kinase kinase 6 maged 2 mitogen-activated protein kinase 4 maged 2MAPK cascadeHes7 Hes7 Las5 Las5 Calcium mediated signaling motiper cativated protein kinase kinase kinase 1Notch signaling pathway RMAPK cascadeHes7 Las5 Las5 Calcium mediated signaling moti protein 15 ubit 1.734Notch signaling pathway RMA binding motif protein 15 ubiquitin BAqp1 Casca Las52 Calcium mediated signaling motif protein 15 ubit 1.544aquaporin 1 ubiquitin BAqp1 Casca Calcium mediated signaling pathway RMA 1534Agal aquaporin 1 caudal type homeobox 13 pacental growth factorWnt10a Calcium 2.352 Wnt2 transcription factor related, Iocus 3 (Drosophila) H2 oba Calcium 2.352 Canda 1 to 2.052 Canda 1 to 2.052 <br< td=""><td>Lef1</td><td>0.288</td><td>lymphoid enhancer binding factor 1</td><td></td></br<>	Lef1	0.288	lymphoid enhancer binding factor 1	
Call of SourceColorCalcium ion bindingCalcium ion bindingProtocadHum binding orbitsCalcium ion bindingThib44545junctophilin 2Calcium mediated signalingJph22.296junctophilin 2Calcium mediated signalingNrg14.197neuregulin 1Sic11a13.680mitogen-activated protein kinase kinase ionase 6MAPK cascadeMap3k63.008mitogen-activated protein kinase kinase kinase ionase 6MAPK cascadeMap4k12.618mitogen-activated protein kinase kinase kinase ionase 6MAPK cascadeMap4k22.618mitogen-activated protein kinase kinase kinase kinase ionase 6MAPK cascadeJbk23.912jagged 2Jagged 2Dx21.855deltex 2 homolog (Drosophila)Notch signaling pathwayRbm151.734RNA binding motif protein 15Vasculature developmentHoxb133.520homebox 21Vasculature developmentHoxb133.520placental growth factorWnt signaling pathwayWnt0a4.804wingless-repter MMTV integration site 10aWnt signaling pathwayKm10a4.804wingless-repter MMTV integration site 10aMot signaling pathwayKm10a4.804wingless-repter MMTV integration site 10aMot signaling pathwayAsiz1.558calcium protein factor related, locus 3 (Drosophila)Art signaling pathwayKm10a4.804wingless-related MMTV integration site 10aGrowth factor activityJmse6.667NKZ transcription factor	Cabp?	16722	calcium hinding protein 2	
Pedhbs5.719Improtecatherin beta 5Calcium ion bindingThbs445.45thrombospondin 4S100S100a164.004S100 calcium binding protein A16Jph22.296junctophilin 2Calcium mediated signalingNrg14.197neuregulin 1Stc11a13.680solute carrie framily 11, member 1Map3463.008mitogen-activated protein kinase kinase kinase 6Map3472.618mitogen-activated protein kinase kinase kinase 1Hes74.636hairy and enhancer of split 7 (Drosophila)jag23.912jagged 2Dt21.855deltex 2 homolog (Drosophila)Notch signaling pathwayRNA binding motif protein 15Ubb1.544ubiquitin BAap19.222eendothelial cell surface expressed chemotaxis and apoptosisCdc23.545cdat12.042chym4.804wingless-type karderwingless-type kardercdat12.042chym0.620cordin0.620cordin DiNote signaling pathwayKin26.667NicoKarderMap345.619Protocalter in bace stressed chemotaxis and apoptosisCdh56.600Cdh56.600Cdh56.600Cdh56.600Cdh56.601Nico4.804wingles-type kilke elastase family, member 1windsaStoop filke donains 2Cell abesion </td <td>Cdhr5</td> <td>6.000</td> <td>cadherin-related family member 5</td> <td></td>	Cdhr5	6.000	cadherin-related family member 5	
This44.545'thrombospondin 4\$100a164.004\$100 calcium binding protein A16Jph22.296junctophilin 2Calcium mediated signalingNrg14.197neuregulin 1\$1c11a13.600mitogen-activated protein kinase kinase 6MAPK cascadeMap3k63.008mitogen-activated protein kinase kinase 6MAPK cascadeMap4k12.632mitogen-activated protein kinase kinase 6MAPK cascadeMapk42.633mitogen-activated protein kinase kinase 6MAPK cascadeJag23.912jagged 2Distase kinase 6Dix21.855deltez 2 homolog (Drosophila)Notch signaling pathwayRbm151.734RNA binding motif protein 15Uibuitin BAqp19.222endothelial cel surface expressed chemotaxis and apoptosiscadal type homeobox 2Cdx23.545placental growth factorVasculature developmentWnt10a4.804wingless related MMTV integration site 10aWint signaling pathwayWnt2a2.558cadad Uye homeobox 2Vasculature developmentHoxh133.520bromopathifu y.cus 10/000castase family member 1Wnt10a4.804wingless related MMTV integration site 10aYut signaling pathwayAxin21.558castase family member 5Cell adhesionCdrid0.6667NKZ transcription factor related, locus 3 (Drosophila)factor activityAxin20.566LIM and senescent cell antigen like domains 2Cell adhesionCdrid5.0677	Pcdhb5	5.619	protocadherin beta 5	Calcium ion binding
S100a164.004S100 calcium binding protein A16Jph22.296junctophilin 2Calcium mediated signalingNrg14.197neuregulin 1Solute carrier family 11, member 1MAPK cascadeMap3K63.008mitogen-activated protein kinase kinase kinase 6MAPK cascadeMap4K12.618mitogen-activated protein kinase kinase kinase kinaseMAPK cascadeJag23.912jagged 2Notch signaling pathwayRbm151.734Geltex 2 homolog (Drosophila)Notch signaling pathwayRbm151.734Geltex 2 homolog (Drosophila)Notch signaling pathwayRbm151.734Geltex 2 homolog (Drosophila)Notch signaling pathwayRbm151.734Geltex 2 homolog (Drosophila)Vasculature developmentHox133.537geltex expressed chemotaxis and apoptosisVasculature developmentGdx23.545caudal type homeobox 2Wart signaling pathwayWnt0a4.804wingless related MMTV integration site 10aWnt signaling pathwayVmr0a2.333wingless related MITV integration site 10aCell adhesionCela12.042Chymotrypsin-like elastase family, member 1Cell adhesionCela22.545Georem related family member 5Cell adhesionCela36.464NK2 transcription factor related, locus 3 (Drosophila)Cell adhesionCela46.444bore morphogenetic protein 8aCell adhesionChrist6.036LIM and senseorent cell antigen like domains 2Cell adhesion<	Thbs4	4.545	thrombospondin 4	
Jph22.296junctophilin 2Calcium mediated signalingNrg14.197neuregulin 1Sk11a13.680mitogen-activated protein kinase kinase kinase 6MAPK cascadeMap3k63.008mitogen-activated protein kinase	S100a16	4.004	S100 calcium binding protein A16	
$\begin{tabular}{ c c c c } & 1 & 1 & 1 & 1 & 1 & 1 & 1 & 1 & 1 & $	Jph2	2.296	junctophilin 2	Calcium mediated signaling
Nrg14.197neureguin 1Sici La13680solute carrier family 11, member 1Map3K63.008mitogen-activated protein kinase kinase kinase 6Mapk42.632mitogen-activated protein kinase kinase kinase 1Hes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Dtx21.855deltex 2 homolog (Drosophila)Notch signaling pathwayRbm151.734RNA binding motif protein 15Notch signaling pathwayUbb1.544ubiquitin BAccil 1.543Vasculature developmentAqp19.222aquaporin 1EscrS.889endothelial cell surface expressed chemotaxis and apoptosisCdx23.545caudal type homoebox 2Vasculature developmentHoxb133.520homeobox B13Pacetal growth factorWn10a4.804wingless related MMTV integration site 9AWnt signaling pathwayAxin21.558caudal type homoebox 2Vasculature developmentAxin21.558caudal type homeobox 3Cell adhesionCad10.620cyclin D1Wnt signaling pathwayAxin21.558caudal type homoebox 5Cell adhesionFgf115067NK2 transcription factor related, locus 3 (Drosophila)Growth factor activityNrg14.794bone morphogenetic protein 8aGrowth factor activityThy3alpha-2-HS-glycoproteinBapped 2Spg8a9.937alpha-2-HS-glycoprotein 8aAgr22.818chordin <t< td=""><td></td><td></td><td></td><td>0 0</td></t<>				0 0
Sh:11a13.680solute carrier tamily 11, member 1Map3k63.008mitogen-activated protein kinase kinase kinase (anse 6)MAPK cascadeMap4k12.613mitogen-activated protein kinase kinase kinase (anse kinase kinase)MAPK cascadeHes74.636hairy and enhancer of split 7 (Drosophila)Notch signaling pathwayJag23.912jagged 2Dx21855deltex 2 homolog (Drosophila)Notch signaling pathwayRbm151.734RNA binding motif protein 15Notch signaling pathwayRbm151.734aquaporin 1EccarEccar5.889endothelial cell surface expressed chemotaxis and apoptosisCascalCdx23.545caudal type homeobox 2Vasculature developmentHoxb133.520homeobox 813PgfYm10a4.804wingless related MIV integration site 10aWnt signaling pathwayWnt10a4.804wingless related MIV integration site 9ACela1Cela12.042chymotrypsin-like elastase family, member 1Wnt signaling pathwayAxin26.667NK2 transcription factor related, locus 3 (Drosophila)Fgf111R2-DMa6.444histocompatibility 2, class 11, locus DMaCell adhesionCdrbr 56.000cadherin-related family member 5Cell adhesionFgf115.067fibroblast growth factor 11Growth factor activityNrg14.197neuregulin 1Jagged 2Jag23.912jagged 2OssificationAhsg9.937alph	Nrg1	4.197	neuregulin 1	
Mapka 3.000 minugen-activated protein kinase kinase kinase o PiAPA Cascable mitugen-activated protein kinase kinase kinase inase kinase	SICI121	3.680	solute carrier family 11, member 1	MADK assasds
Image Product mapped2.552 mitogen activated protein kinaske 4 mitogen activated protein kinaske kinase kinase kinaseHes74.636 startHes74.644 startHomebox 2 startVasculature development homebox 813 placental growth factorWh10a4.804 startWin19a start2.323 startWin10a4.804 startWin19a start2.337 startPgf3.337 startPgf3.337 startWin10a start4.804 startWin10a start4.804 startWin10a start4.804 startWin10a start4.804 startWin10a start4.804 startWin10a start4.804 startWin10a start4.804 start<	Map3K6 Mapk4	3.008	mitogen-activated protein kinase kinase k	MAPK cascade
Hes74.636hairy and enhancer of split 7 (Drosophila) jag2Notch signaling pathwayHes74.636hairy and enhancer of split 7 (Drosophila) jag2 3012Notch signaling pathwayBm151.734RNA binding motif protein 15Notch signaling pathwayUbb1.544ubiquitin BAqp19.222aquaporin 1 ecserSecondEcser5.899endothelial cell surface expressed chemotaxis and apoptosis 	Map4k1	2.618	mitogen-activated protein kinase kinase kinase 1	
Hes74.636hairy and enhancer of split 7 (Drosophila) jagged 2Jag23.912jagged 2Dx21.855deltex 2 homolog (Drosophila) ubiquitin BNotch signaling pathwayRbm151.734RNA binding motif protein 15 ubiquitin BNotch signaling pathwayAqp19.222aquaporin 1 ecscrS.849Cdx23.545caudal type homeobox 2 homeobox B13Vasculature developmentHoxb133.520homeobox B13 placental growth factorVasculature developmentWn10a4.804wingless related MTV integration site 10a wingless related MTV integration site 9A cela1Wnt signaling pathwayKain21.558axin2 cyclin D1Wnt signaling pathwayNkx2-36.667NK2 transcription factor related, locus 3 (Drosophila) thist while cause family, member 1 cyclin D1Cell adhesion cadherin-related family member 5 colorNkx2-36.667NK2 transcription factor related, locus 3 (Drosophila) thist while advelopment bit of 2 call antigen ike domains 2Cell adhesion cadherin-related family member 5Fgf115.067fibroblast growth factor 11 protocadherin related family member 5 protocadherin beta 5Growth factor activity Nrg1Jag23.912jagged 2Asig casaloglycoprotein 8a Asgr2Casaloglycoprotein 8a chordinBmp8a4.784bone morphogenetic protein 8a chordinSkeletal system development chordinStods1.646Shwachman-Bodian-Diamond syndrome homolog (human)Skeletal system development Skeletal system developm	· · · · P · · · ·			
Jag2 3.912 jagged 2 Dx2 1.855 deltex 2 homolog (Drosophila) Notch signaling pathway Rbm15 1.734 RNA binding motif protein 15 Ubb 1.544 Ubiquitin B Aqp1 9.222 aquaporin 1 Eccr 5.889 endothelial cell surface expressed chemotaxis and apoptosis Cdx2 3.545 caudal type homeobox 2 Vasculature development Hoxb13 3.520 homeobox B13 Pgf 3.337 placental growth factor Wn10a 4.804 Wingless related MMTV integration site 10a Wn9a 2.323 wingless-type MMTV integration site 9A Cela1 2.042 chymotrypsin-like elastase family, member 1 Chrd1 0.620 cyclin D1 Nkx2-3 6.667 NK2 transcription factor related, locus 3 (Drosophila) H2-DMa 6.444 histocompatibility 2, class II, locus DMa Lims2 6.036 LIM and senescent cell antigen like domains 2 Cell adhesion Cathr5 6.000 cadherin-related family member 5 Pcdh5 5.619 protocadherin beta 5 Fgf11 5.067 fibroblast growth factor 11 Bmp8a 4.784 bone morphogenetic protein 8a Thbs4 4.545 thrombospondin 4 Growth factor activity Nrg1 4.197 neuregulin 1 Jagged 2 Ahsg 9.937 alpha-2-HS-glycoprotein Bmp8a 4.784 bone morphogenetic protein 8a Thbs4 1.646 Shwachman-Bodian-Diamond syndrome homolog (human) Bmp8a 4.784 bone morphogenetic protein 8a Thbs4 1.646 Shwachman-Bodian-Diamond syndrome homolog (human) Bmp8a 4.784 bone morphogenetic protein 8a Hes7 4.636 hairy and enhancer of split 7 (Drosophila) Jag2 3.912 jagged 2 Skeletal system development Skeletal system development for the fa S Skeletal system development for the factor the factor fa S Skeletal system development for the factor fa S Skeletal system development factor fa S Skeletal system development fact	Hes7	4.636	hairy and enhancer of split 7 (Drosophila)	
Dix21.855defex 2 monolog Urosophila)Noten signaling pathwayRbm151.734RNA binding multi protein 15Ubb1.544ubiquitin BAqp19.222aquaporin 1Ecscr5.889endothelial cell surface expressed chemotaxis and apoptosisCdx23.545caudal type homeobox 2Vasculature developmentHoxb133.520homeobox B13Pgf3.337placental growth factorWn10a4.804wingless related MMTV integration site 10aWn19a2.323wingless related MMTV integration site 9ACela12.042chymotrypsin-like elastase family, member 1Wnt signaling pathwayAxin21.558Cend10.620cyclin D1Nk2-36.667NK2 transcription factor related, locus 3 (Drosophila)H2-DMa6.444histocompatibility 2, class II, locus DMaLims26.036LIM and sensecent cell antigen like domains 2Cell adhesioncadherin -related family member 5Pcdtb55.619protocadherin beta 5Fgf115.067Bmp8a4.784bone morphogenetic protein 8aThs44.545thrombospondin 4Growth factor activityNrg14.197agged 2Ahsg9.937alpha-2-HS-glycoprotein 8aHasp4.784bone morphogenetic protein 8aAggr22.818asialoglycoprotein receptor 2 <tr< td=""><td>Jag2</td><td>3.912</td><td>Jagged 2</td><td>Natala si su alima u atlauras</td></tr<>	Jag2	3.912	Jagged 2	Natala si su alima u atlauras
Numins1.73* LANKKNA binding induit protein 15 ubiquitin BAqp19.222 endothelial cell surface expressed chemotaxis and apoptosis caudal type homeobox 2 bomeobox 21Vasculature developmentAqp19.222 stassaquaporin 1 caudal type homeobox 2 placental growth factorVasculature developmentHoxb133.520 placental growth factorhomeobox B13 placental growth factorVasculature developmentWnt10a4.804 wingless related MMTV integration site 10a Wnr9a 2.323 chymotypsin-like elastase family, member 1 wtr signaling pathway Axin2 Ccfal1Wnt signaling pathway axin2 ccraftCcfal12.042 chymotrypsin-like elastase family, member 1 wtr signaling pathway axin2 ccraftWnt signaling pathway axin2 ccraftNkx2-36.667 6.667NK2 transcription factor related, locus 3 (Drosophila) histocompatibility 2, class II, locus DMa protocatherin related family member 5 protocatherin heta 5Cell adhesion coll adhesion catherin-related family member 5Fgf115.067 more fibroblast growth factor 11 Bmp8a 4.784 bone morphogenetic protein 8a Hbs4Growth factor activity neuregulin 1 jagged 2Ahsg9.937 alpha-2-HS-glycoprotein asiloglycoprotein receptor 2 chordinOssification OssificationChrid2.387 chordinchordin siloglycoprotein receptor 2 chordinOssification OssificationHms6a tHs24.784 bone morphogenetic protein 8a Hes7 chordinSkeletal system development siloglycoprotein receptor 2 Skeletal system development sizaBmp8a Hes7 <br< td=""><td>Dtx2 Dhm15</td><td>1.855</td><td>deltex 2 nomolog (Drosophila)</td><td>Notch signaling pathway</td></br<>	Dtx2 Dhm15	1.855	deltex 2 nomolog (Drosophila)	Notch signaling pathway
Appl9.222 endothelial cell surface expressed chemotaxis and apoptosis Caudal type homeobox 2 homeobox B13 	Ubb	1.544	ubiquitin B	
Aqp19.222aquaporin 1Ecscr5.869endothelial cell surface expressed chemotaxis and apoptosisCdz23.545caudal type homeobox 2Vasculature developmentHoxb133.520homeobox B13Pgf3.337placental growth factorWn10a4.804wingless related MMTV integration site 10aWnt9a2.323wingless-type MMTV integration site 9ACela12.042chymotrypsin-like elastase family, member 1Wnt signaling pathwayAxin21.558axin2Cond10.620cyclin D1Nkx2-36.667NK2 transcription factor related, locus 3 (Drosophila)H2-DMa6.444histocompatibility 2, class II, locus DMaLims26.036LIM and sensecent cell antigen like domains 2Cell adhesionCdhr56.000cadherin-related family member 5Cell adhesionPcdhb55.619protocadherin beta 5Fgf115.067Fgf115.067fibroblast growth factor 11Bm98a4.784bone morphogenetic protein 8athrombospondin 4Growth factor activityNrg14.197neuregulin 1jagged 2Ahsg9.937alpha-2-HS-glycoproteinOssificationBm98a4.784bone morphogenetic protein 8aAsgr2Asgr22.818asialoglycoprotein receptor 2OssificationChrd2.387chordianSkeletal system developmentSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Skeletal system developm				
Leser5.889endothelial cell surface expressed chemotaxis and apoptosisCdx23.545caudal type homeobox 2Vasculature developmentHoxb133.520homeobox B13Pgf9gf3.337placental growth factorWn10a4.804wingless-type MMTV integration site 10aWn19a2.323wingless-type MMTV integration site 9ACela12.042chymotrypsin-like elastase family, member 1Wnt signaling pathwayAxin21.558axin2Cend10.620cyclin D1Nkx2-36.667NK2 transcription factor related, locus 3 (Drosophila)H2-DMa6.444histocompatibility 2, class II, locus DMaLims26.036LIM and senescent cell antigen like domains 2Celh555.619protocadherin beta 5Fgf115.067fibroblast growth factor 11Bmp8a4.784bone morphogenetic protein 8aArg23.912jagged 2Ahsg9.937alpha-2-HS-glycoproteinBmp8a4.784bone morphogenetic protein 8aAsgr22.818asialoglycoprotein receptor 2OssificationChrd2.387chordinSkeletal system developmentStds1.646Shwachman-Bodian-Diamod syndrome homolog (human)Skeletal system developmentStx23.840sine oculis-related homeobox 2Kkeletal system development	Aqp1	9.222	aquaporin 1	
Lax23.545Caddal type holeobox 2Vasculature developmentHoxb133.520homeobox B13Pgf3.337placental growth factorWnt10a4.804wingless related MMTV integration site 10aWnt9a2.323wingless-type MMTV integration site 9ACela12.042chymotrypsin-like elastase family, member 1Wnt signaling pathwayAxin21.558axin2Crnd10.620cyclin D1Nkx2-36.667NK2 transcription factor related, locus 3 (Drosophila)H2-DMa6.444histocompatibility 2, class II, locus DMaLims26.036LIM and senescent cell antigen like domains 2Cell adhesionCdhr56.000cadherin-related family member 5Cell adhesionPchb55.619protocadherin beta 5Growth factor activityNrg15.067fibroblast growth factor 11Bmp8a4.784bone morphogenetic protein 8afactor activityNrg14.197neuregulin 1gaged 2Ahsg9.937alpha-2-HS-glycoproteinOssificationBmp8a4.784bone morphogenetic protein 8aforditionArg22.818asialoglycoprotein receptor 2OssificationChrd2.387chordin -Diamond syndrome homolog (human)Skeletal system developmentSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Skeletal system developmentSka3.912jagged 2Skeletal system developmentSka3.912jagged 2Skel	Ecscr	5.889	endothelial cell surface expressed chemotaxis and apoptosis	V
Inductory3.320Inductory B13Pgf3.337placental growth factorWnt10a4.804wingless related MMTV integration site 10aWnt9a2.323wingless type MMTV integration site 9ACela12.042chymotrypsin-like elastase family, member 1Wnt signaling pathwayAxin21.558axin2Cend10.620cyclin D1Nkx2-36.667NK2 transcription factor related, locus 3 (Drosophila)H2-DMa6.444histocompatibility 2, class II, locus DMaLims26.036LIM and senescent cell antigen like domains 2Cell adhesionCdhr56.600cadherin-related family member 5Protocadherin beta 5Fgf115.067fibroblast growth factor 11Bmp8a4.784bone morphogenetic protein 8aThbs44.545thrombospondin 4Growth factor activityjagged 2Ahsg9.937alpha-2-HS-glycoproteinBmp8a4.784bone morphogenetic protein 8aAgr22.818asialoglycoprotein receptor 2OssificationChrd2.387chordinSkeletal system developmentSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Skeletal system developmentBmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Skeletal system developmentSkeletal system developmentSiz23.840sine occulis-related homeobox 2 <t< td=""><td>Uaxb12</td><td>3.545</td><td>caudal type nomeobox 2</td><td>vasculature development</td></t<>	Uaxb12	3.545	caudal type nomeobox 2	vasculature development
Part of the second se	Pof	3.520	nlacental growth factor	
Wnt10a4.804wingless related MMTV integration site 10aWnt9a2.323wingless-type MMTV integration site 9ACela12.042chymotrypsin-like elastase family, member 1Wnt signaling pathwayAxin21.558axin2Cend10.620cyclin D1Nkx2-36.667NK2 transcription factor related, locus 3 (Drosophila)H2-DMa6.444histocompatibility 2, class II, locus DMaLims26.036LIM and senescent cell antigen like domains 2Cell adhesionCdhr56.000cadherin-related family member 5Cell adhesionCdhr55.619protocadherin beta 5Growth factor activityNg115.067fibroblast growth factor 11Bmp8a4.784bone morphogenetic protein 8aHbs44.545thrombosspondin 4Growth factor activityNrg14.197neuregulin 1Jag23.912jagged 2Ahsg9.937alpha-2-HS-glycoproteinBmp8a4.784bone morphogenetic protein 8aAsgr22.818asialoglycoprotein receptor 2OssificationChrd2.387chord inchord inSds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Keletal system developmentBmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Skeletal system developmentsize 2Skeletal system developmentsize 3Meskel synd	i gi	5.557		
Wnt9a2.323wingless-type MMTV integration site 9ACela12.042chymotrypsin-like elastase family, member 1Wnt signaling pathwayAxin21.558axin2Cend10.620cyclin D1Nkx2-36.667NK2 transcription factor related, locus 3 (Drosophila)H2-DMa6.444histocompatibility 2, class II, locus DMaLims26.036LIM and senescent cell antigen like domains 2Cell adhesionCdhr56.000cadherin-related family member 5Cell adhesionPcdhb55.619protocadherin beta 5Fgf11Snop5.067fibroblast growth factor 11Bmp8a4.784bone morphogenetic protein 8aThbs44.545thrombospondin 4Arg23.912jagged 2Ahsg9.937alpha-2-HS-glycoproteinBmp8a4.784bone morphogenetic protein 8aAsgr22.818asialoglycoprotein receptor 2OssificationChrd2.387chordinSkeletal system developmentSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Skeletal system developmentSix23.840sine oculis-related homeobox 2Meckel syndrome, type 1	Wnt10a	4.804	wingless related MMTV integration site 10a	
Cela12.042chymotrypsin-like elastase family, member 1Wnt signaling pathwayAxin21.558axin2Ccnd10.620cyclin D1Nkx2-36.667NK2 transcription factor related, locus 3 (Drosophila)H2-DMa6.444histocompatibility 2, class II, locus DMaLims26.036LIM and senescent cell antigen like domains 2Cell adhesionCdhr56.000cadherin-related family member 5Cell adhesionPcdhb55.619protocadherin beta 5Fgf11Smp8a4.784bone morphogenetic protein 8aGrowth factor activityNrg14.197neuregulin 1growth factor activityJag23.912jagged 2OssificationChrd2.387chordinSteletal system developmentStds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Skeletal system developmentBmp8a4.784bone morphogenetic protein 8aFarstHes74.636hairy and enhancer of split 7 (Drosophila)Skeletal system developmentJag23.912jagged 2Skeletal system developmentSix23.840sine oculis-related homeobox 2Meckel syndrome, type 1	Wnt9a	2.323	wingless-type MMTV integration site 9A	
Axin21.558axin2Ccnd10.620cyclin D1Nkx2-36.667NK2 transcription factor related, locus 3 (Drosophila)H2-DMa6.444histocompatibility 2, class II, locus DMaLims26.036LIM and senscent cell antigen like domains 2Cell adhesionCdhr56.000cadherin-related family member 5Cell adhesionPcdhb55.619protocadherin beta 5Fgf11Bmp8a4.784bone morphogenetic protein 8aThbs44.545thrombospondin 4Nrg14.197neuregulin 1Jag23.912jagged 2Ahsg9.937alpha-2-HS-glycoprotein 8aBmp8a4.784bone morphogenetic protein 8aAsgr22.818asialoglycoprotein receptor 2OssificationChrd2.387chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Skeletal system developmentBmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Skeletal system developmentSkeletal system developmentSix23.840sine oculis-related homeobox 2Mks12.835Meckel syndrome, type 1	Cela1	2.042	chymotrypsin-like elastase family, member 1	Wnt signaling pathway
Ccd10.620cyclin D1Nkx2-36.667NK2 transcription factor related, locus 3 (Drosophila)H2-DMa6.444histocompatibility 2, class II, locus DMaLims26.036LIM and senescent cell antigen like domains 2Cell adhesionCdhr56.000cadherin-related family member 5Protocadherin beta 5Pcdhb55.619protocadherin beta 5Fgf115.067fibroblast growth factor 11Bmp8a4.784bone morphogenetic protein 8aThbs44.545thrombospondin 4Nrg14.197neuregulin 1Jag23.912jagged 2Ahsg9.937alpha-2-HS-glycoproteinBmp8a4.784bone morphogenetic protein 8aAsgr22.818asialoglycoprotein receptor 2OssificationChrd2.387chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Skeletal system developmentBmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Six23.840sine oculis-related homeobox 2Mks12.835Meckel syndrome, type 1	Axin2	1.558	axin2	
Nk22-36.667NK2 transcription factor related, locus 3 (Drosophila) histocompatibility 2, class II, locus DMaH2-DMa6.444histocompatibility 2, class II, locus DMaLims26.036LIM and senescent cell antigen like domains 2Cell adhesionCdhr56.000cadherin-related family member 5Cell adhesionPcdhb55.619protocadherin beta 5Fgf11Bmp8a4.784bone morphogenetic protein 8a4.784bone morphogenetic protein 8aYng14.197neuregulin 1Jag23.912jagged 2Ahsg9.937alpha-2-HS-glycoprotein chordinBmp8a4.784bone morphogenetic protein 8aAsgr22.818asialoglycoprotein receptor 2 chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Bmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of spli 7 (Drosophila)Jag23.912jagged 2Skeletal system developmentSix23.840sine oculis-related homeobox 2Ms12.835Meckel syndrome, type 1	Cend1	0.620	cyclin D1	
H2-DMa6.444histocompatibility 2, class II, locus DMaLims26.036LIM and senescent cell antigen like domains 2Cell adhesionCdhr56.000cadherin-related family member 5Cell adhesionPcdhb55.619protocadherin beta 5Fgf11Bmp8a4.784bone morphogenetic protein 8aGrowth factor activityNrg14.197neuregulin 1Jag23.912jagged 2Ahsg9.937alpha-2-HS-glycoprotein 8aAsgr22.818asialoglycoprotein receptor 2 chordinOssificationChrd2.387chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Skeletal system developmentBmp8a4.784bone morphogenetic protein 8a hes74.636 hairy and enhancer of split 7 (Drosophila) jagged 2Skeletal system developmentSix23.840sine oculis-related homeobox 2 Mexkel syndrome, type 1Skeletal system development	Nkx2-3	6.667	NK2 transcription factor related, locus 3 (Drosophila)	
Lims26.036LIM and senescent cell antigen like domains 2Cell adhesionCdhr56.000cadherin-related family member 5Cell adhesionPcdhb55.619protocadherin beta 5Cell adhesionFgf115.067fibroblast growth factor 11Bmp8a4.784bone morphogenetic protein 8aThbs44.545thrombospondin 4Nrg14.197neuregulin 1Jag23.912jagged 2Ahsg9.937alpha-2-HS-glycoproteinBmp8a4.784bone morphogenetic protein 8aAsgr22.818asialoglycoprotein receptor 2OssificationChrd2.387chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Skeletal system developmentBmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Skeletal system developmentJag23.912jagged 2Skeletal system developmentSix23.840sine oculis-related homeobox 2Meckel syndrome, type 1	H2-DMa	6.444	histocompatibility 2, class II, locus DMa	
Cdhr56.000cadherin-related family member 5Pcdhb55.619protocadherin beta 5Fgf115.067fibroblast growth factor 11Bmp8a4.784bone morphogenetic protein 8aThbs44.545thrombospondin 4Nrg14.197neuregulin 1Jag23.912jagged 2Ahsg9.937alpha-2-HS-glycoproteinBmp8a4.784bone morphogenetic protein 8aAsgr22.818asialoglycoprotein receptor 2Chrd2.387chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Bmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Skeletal system developmentSix23.840sine oculis-related homeobox 2Mss12.835Meckel syndrome, type 1	Lims2	6.036	LIM and senescent cell antigen like domains 2	Cell adhesion
Pcdhb55.619protocadherin beta 5Fgf115.067fibroblast growth factor 11Bmp8a4.784bone morphogenetic protein 8aThbs44.545thrombospondin 4Nrg14.197neuregulin 1Jag23.912jagged 2Ahsg9.937alpha-2-HS-glycoproteinBmp8a4.784bone morphogenetic protein 8aAsgr22.818asialoglycoprotein receptor 2Chrd2.387chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Bmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Skeletal system developmentSix23.840sine oculis-related homeobox 2Mks12.835Meckel syndrome, type 1	Cdhr5	6.000	cadherin-related family member 5	
Fgf115.067fibroblast growth factor 11Bmp8a4.784bone morphogenetic protein 8aThbs44.545thrombospondin 4Nrg14.197neuregulin 1Jag23.912jagged 2Ahsg9.937alpha-2-HS-glycoproteinBmp8a4.784bone morphogenetic protein 8aAsgr22.818asialoglycoprotein receptor 2Chrd2.387chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Bmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Six23.840sine oculis-related homeobox 2Mss12.835Meckel syndrome, type 1	Pcdhb5	5.619	protocadherin beta 5	
Binp8a4.784bone morphogenetic protein 8aThbs44.545thrombospondin 4Growth factor activityNrg14.197neuregulin 1jagged 2Jag23.912jagged 2Ahsg9.937alpha-2-HS-glycoproteinBmp8a4.784bone morphogenetic protein 8aAsgr22.818asialoglycoprotein receptor 2OssificationChrd2.387chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Bmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Six23.840sine oculis-related homeobox 2Mks12.835Meckel syndrome, type 1	Fgf11	5.067	fibroblast growth factor 11	
Thbs44.545thrombospondin 4 neuregulin 1 jagged 2Growth factor activity neuregulin 1 jagged 2Ahsg9.937alpha-2-HS-glycoprotein Bmp8a4.784Asgr 22.818asialoglycoprotein receptor 2 chordinOssification ChrdChrd2.387chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Skeletal system developmentBmp8a4.784bone morphogenetic protein 8a chordinJagged 2Stas3.912gagged 2Skeletal system developmentSiz23.912jagged 2Skeletal system developmentSiz23.840sine oculis-related homeobox 2Meckel syndrome, type 1	Bmp8a	4.784	bone morphogenetic protein 8a	
Nrg14.197neuregulin 1Jag23.912jagged 2Ahsg9.937alpha-2-HS-glycoproteinBmp8a4.784bone morphogenetic protein 8aAsgr 22.818asialoglycoprotein receptor 2OsrificationChordinChrd2.387chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Bmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Six23.840sine oculis-related homeobox 2Mks12.835Meckel syndrome, type 1	Thbs4	4.545	thrombospondin 4	Growth factor activity
Jag23.912jagged 2Ahsg9.937alpha-2-HS-glycoproteinBmp8a4.784bone morphogenetic protein 8aAsgr 22.818asialoglycoprotein receptor 2OssificationchordinChrd2.387chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Bmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Skeletal system developmentSiz23.840sine oculis-related homeobox 2Mks12.835Meckel syndrome, type 1	Nrg1	4.197	neuregulin 1	
Ahsg9.937alpha-2-HS-glycoproteinBmp8a4.784bone morphogenetic protein 8aAsgr22.818asialoglycoprotein receptor 2OssificationChrd2.387chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Bmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Six23.840sine oculis-related homeobox 2Mks12.835Meckel syndrome, type 1	Jag2	3.912	jagged 2	
Bmp8a4.784bone morphogenetic protein 8aAsgr22.818asialoglycoprotein receptor 2OssificationChrd2.387chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Bmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Six23.840sine oculis-related homeobox 2Mks12.835Meckel syndrome, type 1	Ahsg	9.937	alpha-2-HS-glycoprotein	
Asgr22.818asialoglycoprotein receptor 2OssificationChrd2.387chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Bmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Six23.840sine oculis-related homeobox 2Mks12.835Meckel syndrome, type 1	Bmp8a	4.784	bone morphogenetic protein 8a	
Chrd2.387chordinSbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Bmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Six23.840sine oculis-related homeobox 2Mks12.835Meckel syndrome, type 1	Asgr2	2.818	asialoglycoprotein receptor 2	Ossification
Sbds1.646Shwachman-Bodian-Diamond syndrome homolog (human)Bmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Six23.840sine oculis-related homeobox 2Mks12.835Meckel syndrome, type 1	Chrd	2.387	chordin	
Bmp8a4.784bone morphogenetic protein 8aHes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Six23.840sine oculis-related homeobox 2Mks12.835Meckel syndrome, type 1	Sbds	1.646	Shwachman-Bodian-Diamond syndrome homolog (human)	
Hes74.636hairy and enhancer of split 7 (Drosophila)Jag23.912jagged 2Skeletal system developmentSix23.840sine oculis-related homeobox 2Meckel syndrome, type 1	Bmp8a	4.784	bone morphogenetic protein 8a	
Jag23.912jagged 2Skeletal system developmentSix23.840sine oculis-related homeobox 2Mks12.835Meckel syndrome, type 1	Hes7	4.636	hairy and enhancer of split 7 (Drosophila)	
Six2         3.840         sine oculis-related homeobox 2           Mks1         2.835         Meckel syndrome, type 1	Jag2	3.912	jagged 2	Skeletal system development
Mks1         2.835         Meckel syndrome, type 1	Six2	3.840	sine oculis-related homeobox 2	
	Mks1	2.835	Meckel syndrome, type 1	



 

 Cellular Physiology and Biochemistry
 Cell Physiol Biochem 2018;51:746-762

 DOI: 10.1159/000495330
 © 2018 The Author(s). Published by S. Karger AG, Basel

 Published online: 21 November 2018
 www.karger.com/cpb

Lee et al.: Effect of iNOS-MNP-Derived NO on ESC Osteogenesis



**Fig. 6.** Real-time RT-PCR validation for RNA-seq data. Eight genes (Mmp15, Cltb, Atp5s, Cadn4, Wnt9a, Bmp8a, Fgf11, Map4k1) were evaluated by real time RT-PCR and show similar pattern of expression as predicted by the RNA-seq. The values are reported as means ± SD of three independent experiments; \*P<0.05 compared to the control value.

### Discussion

The present study determined the performance of iNOS-loaded nanoparticles on osteogenic differentiation and molecular function assessed using a genome-wide approach in ESCs. We first demonstrated successful intracellular iNOS/NO pathway induction by iNOS-MNP uptake and considerable effect of iNOS-MNPs-derived NO levels on differentiation of ESCs into osteogenic lineage, suggesting that NO can be a significant osteogenic cue in ESCs. NO plays an important role in osteogenesis, bone remodeling, and other metabolic mechanisms [13, 31, 32]. Several studies reported that NO stimulates the proliferation and differentiation of mesenchymal stem cells and calvarial osteoblasts [33, 34]. Treatment with a NO donor upregulates proliferation in human osteoblast cells and fetal calvarial osteoblasts [35, 36]. The crucial role of NO and NOS isoforms on ESC-osteogenic differentiation was previously reported and is comparable to our findings [20]. NO involvement in osteogenic development has been extensively explored, but how NO bioavailability impinges on the osteogenic program at the transcriptional levels has not been precisely elucidated.

We demonstrated that the increased NO levels induced by iNOS-MNPs influenced an extensive transcriptomic effect during the osteogenic differentiation process. Transcriptional analysis described differentially regulated pathways that may play important roles in NO-mediated osteogenic differentiation of ESCs. Among the activated pathways, MAPK signaling pathways promote the osteogenesis of stem cells in other experimental systems. Osteogenesis in human mesenchymal stem cells was improved by bioflavonoid treatment through the activation of c-Jun N-terminal kinase (JNK) and p38 MAPK pathways [37]. Inorganic nanoparticles such as those composed of gold or iron stimulate the osteogenesis of human periodontal ligament stem cells (PDLSCs) or human bone marrow stromal cells (BMSCs) in vitro via the p38 MAPK or extracellular signal-regulated kinase 1/2 (ERK1/2) activation [38, 39]. Similar to our results, co-activation of NO, BMP2, and MAPK pathways are involved in osteoblast proliferation and differentiation downstream of phytoestrogeninduced osteogenesis [40]. NO is known to induce osteogenesis of ESCs through activation of canonical Wnt signaling [21]. More recently, our group has reported that Wnt signaling is associated with the osteogenic differentiation of stem cells under various experimental conditions [41-43]. Based on previous studies and our present data, we suggest that NO can activate wide spectrum of signaling pathways involved in the osteogenic differentiation of stem cells.



Lee et al.: Effect of iNOS-MNP-Derived NO on ESC Osteogenesis

This study also provides molecular insights into the network of differentially expressed genes that may act downstream of NO to induce osteogenesis in ESCs. Through functional enrichment, we identified that NO can induce multiple molecular pathways such as protein kinase activity, estrogen receptor activity, BMP receptor binding, ligand-gated ion channel activity, or phosphatidylinositol 3-phosphate binding. Consistent with our results, many studies have demonstrated the relationship between NO and estrogen receptor signaling in several biological processes including osteogenic development [44-46]. Moreover, BMP signaling-induced NO production stimulated bone calcification in zebrafish [47]. BMP receptor type II ligands (i.e., BMP-2 and BMP-4) can stimulate NOS activity [48]. Ultimately, when differentially expressed genes were assigned to pathways using the KEGG mapper, we found three NO-driven pathways, namely the Rap1 and PI3K-Akt signaling pathways, and focal adhesion, which links different pathways in osteoblastic activity [49-52]. Thus, we suggest that the NO signaling molecule can drive genetic and molecular pathways with implicated roles in ESC-osteogenic differentiation.

### Conclusion

Our study demonstrated that the application of iNOS-loaded nanoparticles promoted ESC differentiation into the osteogenic lineage and identified putative genes and pathway networks involved in this osteoinduction. These findings provide a framework for identifying novel mechanisms by which iNOS/NO induces ESC-osteogenic differentiation. In addition, manipulating iNOS-derived NO signaling pathways using nanomaterials represent novel tools for the generation of lineage-committed cells for use in regenerative cell therapies.

### Abbreviations

iNOS-MNPs (Nitric oxide synthase-loaded mineralized nanoparticles); ESCs (Embryonic stem cells); NO (Nitric oxide); cGMP (cyclic guanosine 3',5' monophosphate); ALP (Alkaline phosphatase); [Ca<sup>2+</sup>]<sub>i</sub> (Intracellular calcium levels); RUNX2 (Runt-related transcription factor 2); OCN (Osteocalcin); OSX (osterix); KEGG (Kyoto Encyclopedia of Genes and Genomes); BMP (Bone morphogenetic protein).

### Acknowledgements

This work was supported by a National Research Foundation of Korea (NRF) grant funded by the Korea government (MSIP) (No. 2015R1A2A2A01006490) and the Bio & Medical Technology Development Program of the NRF funded by the Korea government (MSIP&MOHW) (No. 2017M3A9E4048170).

### **Disclosure Statement**

All of the authors declare that there are no competing interests.

### References

- 1 Bredt DS: Endogenous nitric oxide synthesis: biological functions and pathophysiology. Free Radic Res 1999;31:577-596.
- 2 Förstermann U, Gath I, Schwarz P, et al: Isoforms of nitric oxide synthase. Properties, cellular distribution and expressional control. Biochem Pharmacol 1995;50:1321-1332.



### Cell Physiol Biochem 2018;51:746-762 and Biochemistry Cell Physiol Biochem 2018;51:746-762 DOI: 10.1159/000495330 © 2018 The Author(s). Published by S. Karger AG, Basel www.karger.com/cpb

Lee et al.: Effect of iNOS-MNP-Derived NO on ESC Osteogenesis

- Wang FS, Kuo YR, Wang CJ, Yang KD, Chang PR, Huang YT, Huang HC, Sun YC, Yang YJ, Chen YJ: Nitric oxide mediates ultrasound-induced hypoxia-inducible factor-1alpha activation and vascular endothelial growth factor-A expression in human osteoblasts. Bone 2004;35:114-123.
- 4 Saura M, Tarin C, Zaragoza C: Recent insights into the implication of nitric oxide in osteoblast differentiation and proliferation during bone development. Scientific World Journal 2004;10:624-632.
- 5 Corbett SA, Hukkanen M, Batten J, et al: Nitric oxide in fracture repair. Differential localisation, expression and activity of nitric oxide synthases. J Bone Joint Surg Br 1999;81-B:531-537.
- 6 Diwan AD, Wang MX, Jang D, et al: Nitric oxide modulates fracture healing. J Bone Miner Res 2000;15:342-351.
- 7 Zhu W, Murrell GA, Lin J, et al: Localization of nitric oxide synthases during fracture healing. J Bone Miner Res 2002;17:470-477.
- 8 Hukkanen M, Hughes FJ, Buttery LD, et al: Cytokine-stimulated expression of inducible nitric oxide synthase by mouse, rat, and human osteoblast-like cells and its functional role in osteoblast metabolic activity. Endocrinology 1995;136:5445-5453.
- 9 Wimalawansa SJ: Nitric oxide and bone. Ann N Y Acad Sci 2010;1192:391-403.
- 10 Baldik Y, Diwan AD, Appleyard RC, et al: Deletion of iNOS gene impairs mouse fracture healing. Bone 2005;37:32-36.
- 11 Bryan NS, Bian K, Murad F: Discovery of nitric oxide signaling pathways and targets for drug development. Front Biosci 2009;14:1-18.
- 12 Murad F: Shattuck lecture: nitric oxide and cyclic GMP in cell signaling and drug development. N Engl J Med 2006;355:2003-2011.
- 13 Evans DM, Ralston SH: Nitric oxide and bone. J Bone Miner Res 1996;11:300-305.
- 14 Krumenacker JS, Kots A, Murad F: Differential expression of genes involved in cGMP-dependent nitric oxide signaling in murine embryonic stem (ES) cells and ES cell-derived cardiomyocytes. Nitric Oxide 2006;14:1-11.
- 15 Mujoo K, Sharin VG, Bryan NS, Krumenacker JS, Sloan C, Parveen S, Nikonoff LE, Kots A Y, Murad F: Role of nitric oxide signaling components in differentiation of embryonic stem cells into myocardial cells. Proc Natl Acad Sci USA 2008;105:18924-18929.
- 16 Mora-Castilla S, Tejedo JR, Hmadcha A, Cahuana GM, Martı'n F, Soria B, Bedoya FJ: Nitric oxide repression of Nanog promotes mouse embryonic stem cell differentiation. Cell Death Differ 2010;17:1025-1033.
- 17 Ocarino NM, Boeloni JN, Goes AM, Silva JF, Marubayashi U, Serakides R: Osteogenic differentiation of mesenchymal stem cells from osteopenic rats subjected to physical activity with and without nitric oxide synthase inhibition. Nitric Oxide 2008;19:320-325.
- 18 Joiner DM, Tayim RJ, Kadado A, Goldstein SA: Bone marrow stromal cells from aged male rats have delayed mineralization and reduced response to mechanical stimulation through nitric oxide and ERK1/2 signaling during osteogenic differentiation. Biogerontology 2012;13:467-478.
- 19 Zhang W, Liu J, Shi H, Yang K, Wang P, Wang G, Liu N, Wang H, Ji J, Chu PK: Communication between nitric oxide synthase and positively-charged surface and bone formation promotion. Colloids Surf B Biointerfaces 2016;148:354-362.
- 20 Ehnes DD, Geransar RM, Rancourt DE, Zur Nieden NI: Exogenous nitric oxide enhances calcification in embryonic stem cell-derived osteogenic cultures. Differentiation 2015;89:97-103.
- 21 Ding H, Keller KC, Martinez IK, Geransar RM, zur Nieden KO, Nishikawa SG, Rancourt DE, zur Nieden NI: NO-β-catenin crosstalk modulates primitive streak formation prior to embryonic stem cell osteogenic differentiation. J Cell Sci 2012;125:5564-5577.
- 22 Nakagawa H: Photocontrollable NO-releasing compounds and their biological applications. Journal of clinical biochemistry and nutrition 2016;58:2-6.
- 23 Kang Y, Kim J, Lee YM, Im S, Park H, Kim WJ: Nitric oxide-releasing polymer incorporated ointment for cutaneous wound healing. Journal of Controlled Release 2015;220:624-630.
- 24 Hawiger J: Cellular import of functional peptides to block intracellular signaling. Curr Opin Immunol 1997;9:189e94.
- 25 Noda T, Kawamura R, Funabashi H, Mie M, Kobatake E: Transduction of neuroD2 protein induced neural cell differentiation. J Biotechnol 2006;126:230e6.
- 26 Lock J, Liu H: Nanomaterials enhance osteogenic differentiation of human mesenchymal stem cells similar to a short peptide of BMP-7. Int J Nanomedicine 2011;6:2769-2777.



### Cell Physiol Biochem 2018;51:746-762 and Biochemistry Cell Physiol Biochem 2018;51:746-762 ODI: 10.1159/000495330 Published online: 21 November 2018 www.karger.com/cpb

Lee et al.: Effect of iNOS-MNP-Derived NO on ESC Osteogenesis

- 27 Bradford MM: A rapid and sensitive method for the quantitation of microgram quantities of protein utilizing the principle of protein-dye binding. Anal Biochem 1976;72:248-254.
- 28 Gentleman RC, Carey VJ, Bates DM, Bolstad B, Dettling M, Dudoit S, Ellis B, Gautier L, Ge Y, Gentry J, Hornik K, Hothorn T, Huber W, Iacus S, Irizarry R, Leisch F, Li C, Maechler M, Rossini AJ, Sawitzki G et al.: Bioconductor: open software development for computational biology and bioinformatics. Genome Biol 2004;5:R8.
- Lee HJ, Kim da E, Park DJ, Choi GH, Yang DN, Heo JS, Lee SC: pH-Responsive mineralized nanoparticles as stable nanocarriers for intracellular nitric oxide delivery. Colloids Surf B Biointerfaces 2016;146:1-8.
- 30 Goss SL, Lemons KA, Kerstetter JE, Bogner RH: Determination of calcium salt solubility with changes in pH and P(CO(2)), simulating varying gastrointestinal environments. J Pharm Pharmacol 2007;59:1485-1492.
- 31 Taylor BC, Schreiner PJ, Zmuda JM, Li J, Moffett SP, Beck TJ, et al: Association of endothelial nitric oxide synthase genotypes with bone mineral density, bone loss, hip structure, and risk of fracture in older women: The SOF study Bone 2006;39:174-180.
- 32 Wang CJ, Yang KD, Ko JY, Huang CC, Huang HY, Wang FS: The effects of shockwave on bone healing and systemic concentrations of nitric oxide (NO), TGF-beta1, VEGF and BMP-2 in long bone non-unions. Nitric Oxide 2009;20:298-303.
- 33 Sosroseno W, Sugiatno E, Samsudin AR, Ibrahim F: The role of nitric oxide on the proliferation of a human osteoblast cell line stimulated with hydroxyapatite. J OralImplantol 2008;34:196-202.
- 34 Orciani M, Trubiani O, Vignini A, Mattioli-Belmonte M, DiPrimio R, Salvolini E: Nitric oxide production during the osteogenic differentiation of human periodontal ligament mesenchymal stem cells. Acta Histochem 2009;111:15-24.
- Lin IC, Smartt JM Jr, Nah HD, Ischiropoulos H, Kirschner RE: Nitric oxide stimulates proliferation and differentiation of fetal calvarial osteoblasts and dural cells. Plast Reconstr Surg 2008;121:1554-1566.
- 36 Sugiatno E, Samsudin AR, Sosroseno W: Effect of exogenous nitric oxide on the proliferation of a human osteoblast (HOS) cell line induced by hydroxyapatite. J Appl Biomater Biomech 2009;7:29-33.
- 27 Zha X, Xu Z, Liu Y, Xu L, Huang H, Zhang J, Cui L, Zhou C, Xu D: Amentoflavone enhances osteogenesis of human mesenchymal stem cells through JNK and p38 MAPK pathways. J Nat Med 2016;70:634-644.
- 38 Niu C, Yuan K, Ma R, Gao L, Jiang W, Hu X, Lin W, Zhang X, Huang Z: Gold nanoparticles promote osteogenic differentiation of human periodontal ligament stem cells via the p38 MAPK signaling pathway. Mol Med Rep 2017;16:4879-4886.
- 39 Wang Q, Chen B, Cao M, Sun J, Wu H, Zhao P, Xing J, Yang Y, Zhang X, Ji M, Gu N: Response of MAPK pathway to iron oxide nanoparticles *in vitro* treatment promotes osteogenic differentiation of hBMSCs. Biomaterials 2016;86:11-20.
- 40 Sheu SY, Tsai CC, Sun JS, Chen MH, Liu MH, Sun MG: Stimulatory effect of puerarin on bone formation through co-activation of nitric oxide and bone morphogenetic protein-2/mitogen-activated protein kinases pathways in mice. Chin Med J (Engl) 2012;125:3646-3653.
- 41 Kwon IK, Lee SC, Hwang YS, Heo JS: Mitochondrial function contributes to oxysterol-induced osteogenic differentiation in mouse embryonic stem cells. Biochim Biophys Acta 2015;1853:561-572.
- 42 Kook SH, Heo JS, Lee JC: Crucial roles of canonical Runx2-dependent pathway on Wnt1-induced osteoblastic differentiation of human periodontal ligament fibroblasts. Mol Cell Biochem 2015;402:213-223.
- 43 Kim SY, Lee JY, Park YD, Kang KL, Lee JC, Heo JS: Hesperetin alleviates the inhibitory effects of high glucose on the osteoblastic differentiation of periodontal ligament stem cells. PLoS One 2013;8:e67504.
- 44 Basudhar D, Somasundaram V, de Oliveira GA, Kesarwala A, Heinecke JL, Cheng RY, Glynn SA, Ambs S, Wink DA, Ridnour LA: Nitric Oxide Synthase-2-Derived Nitric Oxide Drives Multiple Pathways of Breast Cancer Progression. Antioxid Redox Signal 2017;26: 1044-1058.
- 45 Lv H, Che T, Tang X, Liu L, Cheng J: Puerarin enhances proliferation and osteoblastic differentiation of human bone marrow stromal cells via a nitric oxide/cyclic guanosine monophosphate signaling pathway. Mol Med Rep 2015;12:2283-2290.
- 46 Duluc L, Jacques C, Soleti R, Iacobazzi F, Simard G, Andriantsitohaina R: Modulation of mitochondrial capacity and angiogenesis by red wine polyphenols via estrogen receptor, NADPH oxidase and nitric oxide synthase pathways. Int J Biochem Cell Biol 2013;45:783-791.

### Cellular Physiology and Biochemistry Cell Physiol Biochem 2018;51:746-762 DOI: 10.1159/000495330 © 2018 The Author(s). Published by S. Karger AG, Basel Published online: 21 November 2018 www.karger.com/cpb

Lee et al.: Effect of iNOS-MNP-Derived NO on ESC Osteogenesis

- 47 Windhausen T, Squifflet S, Renn J, Muller M: BMP Signaling Regulates Bone Morphogenesis in Zebrafish through Promoting Osteoblast Function as Assessed by Their Nitric Oxide Production. Molecules 2015;20:7586-7601.
- 48 Gangopahyay A, Oran M, Bauer EM, Wertz JW, Comhair SA, Erzurum SC, Bauer PM: Bone morphogenetic protein receptor II is a novel mediator of endothelial nitric-oxide synthase activation. J Biol Chem 2011;286:33134-33140.
- 49 Wu Y, Zhou J, Li Y, Zhou Y, Cui Y, Yang G, Hong Y: Rap1A Regulates Osteoblastic Differentiation via the ERK and p38 Mediated Signaling. PLoS One 2015;10:e0143777.
- 50 Zhai YK, Guo XY, Ge BF, Zhen P, Ma XN, Zhou J, Ma HP, Xian CJ, Chen KM: Icariin stimulates the osteogenic differentiation of rat bone marrow stromal cells via activating the PI3K-AKT-eNOS-NO-cGMP-PKG. Bone 2014;66:189-198.
- 51 Ma P, Gu B, Xiong W, Tan B, Geng W, Li J, Liu H: Glimepiride promotes osteogenic differentiation in rat osteoblasts via the PI3K/Akt/eNOS pathway in a high glucose microenvironment. PLoS One 2014;9:e112243.
- 52 Ma XY, Feng YF, Wang TS, Lei W, Li X, Zhou DP, Wen XX, Yu HL, Xiang LB, Wang L: Involvement of FAKmediated BMP-2/Smad pathway in mediating osteoblast adhesion and differentiation on nano-HA/ chitosan composite coated titanium implant under diabetic conditions. Biomater Sci 2017;6:225-238.