

5-2004

# Aniline Sensor Based on Nanodimensional Reaction with Carbon Nanotubes: Helpful for Fighting Bioterrorism

I. Cawthray

*Rochester Institute of Technology*

M. Croston

*Rochester Institute of Technology*

KSV Santhanam

*Rochester Institute of Technology*

Follow this and additional works at: <http://scholarworks.rit.edu/other>

---

## Recommended Citation

Cawthray, I., Croston, M., Santhanam, KSV., (2004). Aniline sensor based on nanodimensional reaction with carbon nanotubes: Helpful for fighting bioterrorism [PowerPoint Slides]. Presented at the 205th Meeting of the Electrochemical Society (ECS), San Antonio, TX.

This Presentation is brought to you for free and open access by RIT Scholar Works. It has been accepted for inclusion in Presentations and other scholarship by an authorized administrator of RIT Scholar Works. For more information, please contact [ritscholarworks@rit.edu](mailto:ritscholarworks@rit.edu).

# **ANILINE SENSOR BASED ON NANODIMENSIONAL REACTION WITH CARBON NANOTUBES: HELPFUL FOR FIGHTING BIOTERRORISM**

I. Cawthray<sup>1</sup> , M. Croston<sup>1</sup> and K.S.V. Santhanam<sup>1,2</sup>

■ <sup>1</sup>Department of Chemistry and <sup>2</sup>Center For  
Materials Science and Engineering, Rochester  
Institute of Technology, Rochester, NY 14623

# Why is a chemical sensor necessary?

- The possibility of a bioterrorist attack using a poisonous organic chemical requires that precautions be taken
- Aniline and other aromatic amines are possible choices for this type of attack
- Early detection of these chemicals would allow for evacuation of people in an affected area
- The dye production industry also makes use of aniline and similar compounds, so inexpensive safety precautions would be helpful


# Aniline Poisoning

- Aniline poisoning results in asphyxiation due to attack on hemoglobin in red blood cells
- The EPA suggested toxic limit for aniline: not to exceed 50-500mg/kg
- The MSDS for aniline lists Oral – Rat LD50 as 250mg/kg
- Typical workplace detection methods for aniline involve Gas Chromatography



# Functionalized Carbon Nanotubes

- Produced via graphite placed in a 20V, 90A arc
- Functionalized by the addition of a Carboxylic Acid group
- Typical diameter of a MultiWalled FCNT is ~10nm, however there is some variance.



# Previous Work

- It has been shown that functionalized carbon nanotubes (FCNT) catalyze the conversion of aniline to azobenzene, and p-toluidine to azotoluene<sup>1</sup>.
- Study of this reaction had been successful to concentrations approaching 5mM

# Theorized Reaction Pathway inside of a FCNT






# NANODIMENSIONAL REACTION


## Aniline to Azobenzene Conversion

### Data

- Absorbance found at 344nm
- Solutions were held at room temperature
- Four replicates were used to find a standard deviation




# 5mM Aniline + 5mM H<sub>2</sub>O<sub>2</sub> Data





# Centrifuged 5mM Aniline+5mM H<sub>2</sub>O<sub>2</sub>




# NANODIMENSIONAL REACTION

## para-Toluidine to Azotoluene


### Conversion Data

- Absorbance found at 460nm
- Solutions were held at room temperature
- Four replicates were used to find a standard deviation




# 5mM p-Toluidine+5mM H<sub>2</sub>O<sub>2</sub>

**5mM Absorbance Data**



# Centrifuge

## 5mM p-Toluidine+5mM H<sub>2</sub>O<sub>2</sub>





# Chemical Sensor Application: Paper test strips

- FCNTs could be used to determine aniline vapor in low concentrations, specifically, on the order of 5mM in air
- FCNTs were doped onto paper strips
- The pores of the paper were filled with aggregations of the FCNTs




# Paper Sensor Preparation

- The FCNT doped strips were adhered to slides
- The strips were pretreated with 30%  $\text{H}_2\text{O}_2$




100X zoom of FCNT doped paper





50X zoomed view of FCNT doped  
paper





1x zoom of FCNT doped paper  
exposed to 93ppm aniline w/o H<sub>2</sub>O<sub>2</sub>



No visible difference, although acetonitrile workup reveals a slight absorbance relative to blank

# Reacted Test Strip at 1x at 93ppm Aniline Vapor





# Conclusions


- Centrifugation appears to accelerate the second order process of aniline or p-toluidine oxidation
- It is possible to have a paper sensor based on FCNTs to fight bioterrorism
- The dye industry could also benefit from an economical paper sensor approach

# Acknowledgements


- Dr. T.C. Morrill
- Dr. G.A. Takacs
- Brenda Mastrangelo
- Tom Allston

# Centrifuge

0.1mM p-Toluidine+0.1mM H<sub>2</sub>O<sub>2</sub>



# 0.01mM Aniline+0.01mM H<sub>2</sub>O<sub>2</sub>






# Future Work

- Finding a gel electrode sensor that will work
- Increasing the efficiency of the paper strip sensor so less time is necessary for detection
- Application of these methods to other functional groups and molecules



# 0.1mM Aniline+0.1mM H<sub>2</sub>O<sub>2</sub>




# Acceleration of reactions via centrifuge


- Solutions centrifuged at constant 1550 RPM
- Held at room temperature

# Centrifuge

0.01mM p-Toluidine+0.01mM H<sub>2</sub>O<sub>2</sub>




# 0.01mM p-Toluidine+0.01mM H<sub>2</sub>O<sub>2</sub>






# Centrifuge

1mM p-Toluidine+1mM H<sub>2</sub>O<sub>2</sub>




500X zoom of FCNT doped paper






# Centrifuged 1mM Aniline+1mM H<sub>2</sub>O<sub>2</sub>



# 1mM p-Toluidine+1mM H<sub>2</sub>O<sub>2</sub>






# Other Sensor Methods:

## Electrochemical

- Creating a FCNT doped gel to sit between two electrical leads
  - All preparation methods tested would not solidify as expected
- A FCNT bridge overtop of a “Krazy Glue” binder was placed between two electrical leads to measure resistance changes
  - Results could not be easily replicated
  - Practical issues with electrode preparation


# Centrifuged

## 0.1mM Aniline+0.1mM H<sub>2</sub>O<sub>2</sub>



# 0.1mM p-Toluidine+0.1mM H<sub>2</sub>O<sub>2</sub>


**0.1mM Absorbance Data**






# Centrifuge


0.001mM Aniline+0.001H<sub>2</sub>O<sub>2</sub>



# 0.001mM Aniline+0.001mM H<sub>2</sub>O<sub>2</sub>




# 1mM Aniline + 1mM H<sub>2</sub>O<sub>2</sub>





# Centrifuged

## 0.01mM Aniline+0.01mM H<sub>2</sub>O<sub>2</sub>



1X zoom of FCNT doped paper

