

Engineering Conferences International ECI Digital Archives

Electric Field Enhanced Processing of Advanced
Materials II: Complexities and Opportunities

Proceedings

3-11-2019

Field assisted sintering of larger scaled ceramic parts using adapted tool design and hybrid heating

Martin Bram

Forschungszentrum Jülich GmbH, Germany, m.bram@fz-juelich.de

Moritz Kindelmann

Forschungszentrum Jülich GmbH, Germany

Alexander M. Laptev

Forschungszentrum Jülich GmbH, Germany

Olivier Guillon

Forschungszentrum Jülich GmbH, Germany

Follow this and additional works at: http://dc.engconfintl.org/efe_advancedmaterials_ii



Part of the [Materials Science and Engineering Commons](#)

Recommended Citation

Martin Bram, Moritz Kindelmann, Alexander M. Laptev, and Olivier Guillon, "Field assisted sintering of larger scaled ceramic parts using adapted tool design and hybrid heating" in "Electric Field Enhanced Processing of Advanced Materials II: Complexities and Opportunities", Rishi Raj, University of Colorado, USA Olivier Guillon, Forschungszentrum Jülich, Germany Hidehiro Yoshida, National Institute for Materials Science, Japan Eds, ECI Symposium Series, (2019). http://dc.engconfintl.org/efe_advancedmaterials_ii/2

This Abstract and Presentation is brought to you for free and open access by the Proceedings at ECI Digital Archives. It has been accepted for inclusion in Electric Field Enhanced Processing of Advanced Materials II: Complexities and Opportunities by an authorized administrator of ECI Digital Archives. For more information, please contact franco@bepress.com.

Field assisted sintering of larger scaled ceramic parts using adapted tool design and hybrid heating

Field Enhanced Processing of Advanced Materials II: Complexities and Opportunities
10 - 15 March 2019, Tomar, Portugal

M. Bram, M. Kindelmann, A.M. Laptev, O. Guillon

Forschungszentrum Jülich GmbH
Institute of Energy and Climate Research
IEK-1: Materials Synthesis and Processing



Motivation of field assisted sintering technologies

Attractive due to:

- Direct heat transfer
- High heating rates
- Pressure assisted sintering

- Rapid densification
- New material concepts
- Efficiency



Challenges of scaling up:

- Thermal gradients
- Tool design and tool materials
- Taking advantage of new heating concepts (e.g. Hybrid heating, Flash)
- Net-shaping
- Strategies for automated production

Motivation of field assisted sintering technologies

Attractive due to:

- Direct heat transfer
- High heating rates
- Pressure assisted sintering

- Rapid densification
- New material concepts
- Efficiency



Challenges of scaling up:

- **Thermal gradients**
- **Tool design** and tool materials
- Taking advantage of new heating concepts (e.g. **Hybrid heating**, Flash)
- Net-shaping
- Strategies for automated production

FAST/SPS equipment at our institute

Lab-scale: HP-D 5



50 kN max. force
37 kW power source
Max. sample size \varnothing 30 mm
Atmosphere control

Scale up: H-HP-D25 SD/FL/MoSi



in operation
since 2018

Max. load 250 kN
Max. sample size \varnothing 100 mm
60 kW for FAST/SPS heating
80 kW for hybrid heating
1.000 V voltage source (AC/DC)

FAST/SPS equipment at our institute

Lab-scale: HP-D 5



Modes of operation:

- FAST/SPS

Scale up: H-HP-D25 SD/FL/MoSi




Modes of operation:

- FAST/SPS
- Hybrid FAST/SPS (+ induction coil)
- Flash (AC/DC source + induction coil)
- Hot press (+ MoSi₂ heater)


Concepts of reducing thermal gradients



Graphite tool
sample Ø100 mm



CFRC = Carbon fiber reinforced carbon




Well-balanced combination of all influence factors

Importance of thermal insulation (HP-D5, Tool for sample size $\varnothing 17$ mm)


A.M. Laptev et al. J. Mat. Proc. Techn. 262 (2018) 326 - 339.

Starting materials and FAST/SPS parameters

8YSZ powder




soft agglomerates



small primary particles

Precipitation, spray drying (TOSOH)
 Agglomerate size 10 - 50 μm
 Primary particle size < 100 nm (16 ± 3 m²/g)
 8YSZ = ZrO₂ doped with 8 mol.% Y₂O₃

Established for SOFC/SOEC electrolytes



FAST/SPS parameters:


Heating: 100 K/min, 50 K/min

T = 1375°C, t = 30 min

p = 50 MPa

Sintering density > 94%

Different set-ups of thermal insulation




Sample diameter: 17 mm
 Die wall thickness: 11.5 mm
 Graphite felt: 11.5 mm

Mitglied der Helmholtz-Gemeinschaft

Page 9



Modelling of temperature distribution




A.M. Laptev et al. J. Mat. Proc. Techn. 262 (2018) 326 - 339.

Page 10


Mitglied der Helmholtz-Gemeinschaft




Modelling of temperature distribution



Total energy consumption




Measurement of total energy consumption



Total energy consumption:

Reduced by factor 2 due to thermal insulation and CFRC spacer (set-up IV)



To consider:

Large contribution of cooling water system

Mitglied

Page 13

Scaling up of technology (H-HP-D25, Tool for sample size $\varnothing 100$ mm)

Preliminary results



PhD thesis M. Kindelmann

Mitglied der Helmholtz-Gemeinschaft


Page 14

Starting materials and FAST/SPS parameters

Y₂O₃ powder




primary
particle size
~ 60 nm



agglomerate
size

$d_{10} = 3.0 \mu\text{m}$
 $d_{50} = 5.2 \mu\text{m}$
 $d_{90} = 8.5 \mu\text{m}$



FAST/SPS parameters:

Heating rate: 25 K/min

T = 1400°C, t = 30 min

p = 30 MPa

Sintering density > 95%


Mitglied de

Commercial Y₂O₃ powder with
non-optimized powder morphology

Page 15




Different experimental set-ups




I

Graphite felt
no CFRC spacer




II

Graphite felt
1 set of CFRC spacer



III

Graphite felt
2 sets of CFRC spacers



IV

Graphite felt
2 sets of CFRC spacers
Induction coil
= Hybrid FAST/SPS


Sample diameter: 100 mm
Die wall thickness: 35 mm
Graphite felt: 11.5 mm

Mitglied der Helmholtz-Gemeinschaft




Page 16

Different experimental set-ups





Modelling of temperature distribution in progress...

Microstructure of Y_2O_3 samples



Set-up III: Graphite felt + 2 sets of CFRC spacer




Set-up IV: Hybrid FAST/SPS

Mitglied der Helmholtz-Gemeinschaft

Page 19



Grain size and porosity of Y_2O_3 samples




Set-up III: FAST/SPS + CFRC spacer

- Slightly increased grain size
- Slightly reduced porosity

Set-up IV: Hybrid FAST/SPS

- No clear advantage for $\varnothing 100$ mm samples and moderate heating rates (25 K/min)
- Required for higher heating rates
- Recommended for larger parts > 100 mm**

**J. Hennicke et al. cfi/Ber. DKG 95 (2018) E27 - E33.




Mitglied der Helmholtz-Gemeinschaft

* Measured by image analysis

Page 20





Summary and outlook

Scaling up of FAST/SPS technology:

- Thermal insulation highly recommended (Graphite felt + CFRC spacer)
- Hybrid FAST/SPS recommended for higher heating rates
- Large contribution of cooling water system on total energy consumption

Outlook:

- Experimental study to be continued...
- Modelling of temperature distribution
Understanding the role of CRFC spacer
- Flash sintering in our H-HP-D25 device

Set-up for flash sintering:

- Special graphite/BN tool setup
- Tool \varnothing 45 mm
- Pt electrodes
- AC/DC power source with $U_{\max} = 1000\text{V}$
- Heating by induction coil

Mitglied der Helmholtz-Gemeinschaft

Page 22

JÜLICH
Forschungszentrum

Thank you for your attention!

Our funding is highly acknowledged:



Helmholtz Energy Materials Foundry (HEMF)



GZ: BR 3418/1-1
„Feldunterstütztes Sintern von seltenerddotiertem Ceroxid“
im Rahmen des Schwerpunktprogramms SPP 1959

Mitglied der Helmholtz-Gemeinschaft

Page 23

