Lehigh Valley Health Network LVHN Scholarly Works

Department of Medicine

Trend Recognition for Unusual Pathogens in Clinical Specimens

Deborah Fry MT (ASCP), MBA, CIC Lehigh Valley Health Network, Deborah.Fry@lvhn.org

Terry Burger MBA, BSN, RN, NE-BC, CIC Lehigh Valley Health Network, Terry Lynn.Burger@lvhn.org

Alida Ammon Lehigh Valley Health Network, Alida V.Ammon@lvhn.org

Georgia G. Colasante Lehigh Valley Health Network, Georgia G.Colasante@lvhn.org

Follow this and additional works at: https://scholarlyworks.lvhn.org/medicine



Part of the Medical Sciences Commons

Published In/Presented At

Fry, D., Burger, T. L., Ammon, A., Colasante, G., (2015 June 26). Trend Recognition for Unusual Pathogens in Clinical Specimens. Poster Presented at: Association for Professionals in Infection Control and Epidemiology 2015 Annual Conference, Nashville, Tennessee.

This Poster is brought to you for free and open access by LVHN Scholarly Works. It has been accepted for inclusion in LVHN Scholarly Works by an authorized administrator. For more information, please contact LibraryServices@lvhn.org.

Trend Recognition for Unusual Pathogens in Clinical Specimens

Deborah Fry, MT(ASCP), MBA, CIC, Terry L. Burger, MBA, BSN, RN, NE-BC, CIC, Alida Ammon, MSN, CRNP, CIC, Georgia Colasante, MS, MT(ASCP), SM(NRM)


Lehigh Valley Health Network, Allentown, PA

Background:

- Raoultella is primarily an environmental bacterium and is rarely identified as a soft tissue pathogen in humans.
- Further investigation is warranted when an increase in isolates is identified in multiple tissue specimens over a short period of time.
- An increase in the number of tissue specimens identified with Raoultella species was observed during the months of July and August 2014.

Methods:

- A look-back of Raoultella isolated from all clinical specimens from January through August 2014 was completed.
- Patient demographic information was organized on a detailed line list including collection date, location, collection time, specimen source, physician and date of result.
- Operating room procedures for collecting tissue specimens were directly observed.
- The microbiology department performed direct observations for processing tissue specimens from receipt to isolate identification.
- A case control study was developed to compare patients with negative tissue results.



Sterile Saline Bottle Used by Laboratory



Raoultella Specimens				
LOCATION	COLLECT MONTH	TIME	SPECIMEN SOURCE	RESULT
Ward	January	02:12	Blood	RAOULTELLA SPP.
Outpatient	January	08:43	Urine	RAOULTELLA (KLEBSIELLA) ORNITHINOLYTICA
Outpatient	March	12:16	Urine	RAOULTELLA SPP.
ICU	March	08:52	Respiratory	RAOULTELLA SPP.
Ward	April	08:52	Tissue	RAOULTELLA SPP.
Ward	June	17:37	Urine	RAOULTELLA SPP.
MOR2	July	18:50	Abscess Fluid	RAOULTELLA SPP.
CCOR5	July	11:57	Wound	RAOULTELLA PLANTICOLA
CCOR3	July	13:27	Wound	RAOULTELLA SPP.
CCOR9	July	14:01	Tissue	RAOULTELLA SPP.
MOR3	August	14:17	Tissue	RAOULTELLA SPP.
MOR5	August	08:17	Tissue	RAOULTELLA SPP.
CCOR1	August	15:57	Tissue	RAOULTELLA PLANTICOLA
CCOR4	August	15:57	Tissue	RAOULTELLA PLANTICOLA

Results:

- The look-back of tissue specimens identified with Raoultella confirmed a dramatic increase in July and August.
- The line list also revealed the majority of specimens, collected in various network locations, were submitted to the laboratory during afternoon and evening hours.
- Tissue specimens submitted in the morning hours were negative.
- Direct observation of microbiology plating techniques detected first shift technicians used "single use" sterile thioglycolate broth to moisten tissue samples prior to morcellation.
- A one liter bottle of sterile saline dated 5/17/14 was used by the second shift technician for the same purpose. This practice was not consistent with protocol.
- Raoultella was isolated from the open saline bottle.
- Original tissue samples were re-cultured using sterile thioglycolate broth and were negative.

Conclusions:

The investigation identified a pseudo-outbreak of *Raoultella* from a contaminated bottle of saline used in the laboratory on second shift to moisten tissue samples prior to plate inoculation. Trend recognition is vital to identify pseudo-outbreaks that can result in the unnecessary administration of antibiotics.

© 2015 Lehigh Valley Health Network

A PASSION FOR BETTER MEDICINE.



610-402-CARE LVHN.org

