

Wright State University

CORE Scholar

---

Physics Seminars

Physics

---

11-13-2015

## Controlling Surface Chemistry of Liquid Metals to Enhance their Fluidic Properties

Nahid Ilyas

Follow this and additional works at: [https://corescholar.libraries.wright.edu/physics\\_seminars](https://corescholar.libraries.wright.edu/physics_seminars)



Part of the [Physics Commons](#)

---

### Repository Citation

Ilyas , N. (2015). *Controlling Surface Chemistry of Liquid Metals to Enhance their Fluidic Properties*. .

This Presentation is brought to you for free and open access by the Physics at CORE Scholar. It has been accepted for inclusion in Physics Seminars by an authorized administrator of CORE Scholar. For more information, please contact [library-corescholar@wright.edu](mailto:library-corescholar@wright.edu).



# Controlling Surface Chemistry of Liquid Metals to Enhance their Fluidic Properties

November 13, 2015

Nahid Ilyas



Air Force Research Laboratory  
UES, Inc.

***Integrity ★ Service ★ Excellence***








# Room Temperature Liquid Metals



## Liquid Conductors



Proc. of SPIE  
Vol. 9467  
946707-1



Ga in Carbon Nanotubes

PRL, 93,  
2004, 95504



# Reconfigurable Circuits

## Possible Only with Liquid Conductors



Reconfigurability achieved by



**Mercury**

Pneumatic Actuation

**Toxic**







Brad Cumby, AFRL



B. Cumby et al, *Appl. Phys. Lett.* **101** (2012) 174102

Electrochemistry

Nontoxic Liquid Metal  
(Gallium alloys)



M. R. Khan et al., *Adv. Funct. Mater.* (2014) available online






# Non-Toxic Room Temperature Liquid Metals Gallium Liquid Metal Alloys (GaLMA)



The Oxide Skin is Solid



**Lowers the surface tension**  
of liquid metal and allows it  
to conform into various 3D  
structure





C. Ladd et al. *Adv. Mater.* **2013** 25 5081-5085

**3D Printing of  
Liquids !!!**

**Non-Toxic  
Alternative to Hg**






Printed by  
**Alex Cook, RXAS**  
(Flex Group)





# Reversibly Deformable Dipole Antenna Gallium Liquid Metal Alloys (GaLMA)




**No hysteresis** in the spectral properties of the antenna

Antenna **self-heals** in response to sharp cuts

J.-H. So et al., *Adv. Funct. Mater.* **19** (2009) 3632-3637

EGaIn embedded in microfluidic channels composed of PDMS and Ecoflex.



M. Kubo et al, *Adv. Mater.* **22** (2010) 2749-2752




## Non-Toxic Material for Flexible Electronics

### Melting Points

- Ga : 29.77 °C (85.59 °F)
- **EGaIn**: 15.7 °C (60.6 °F)
- GaInSn : -19 °C (-2 °F)

### Soft Electronics for Soft Robotics



Proc. of SPIE Vol. 9467 946707-1

### Gallium Alloy Properties


Viscosity  $\approx$  Water

Vapor pressure  $\approx$  0

### Liquid Metal encapsulated in Elastomer



### Microstrip Patch Antenna



IEEE TRANSACTIONS ON ANTENNAS AND PROPAGATION, 60(5), 2012, 2151-2156




# CHALLENGES

## Reconfigurability in Microfluidic Systems









**Surface Oxide  
Permanently Adheres  
to Most Surfaces**



Advancing

Receding




K. Doudrick *et al.*, *Langmuir* **30** (2014)  
6867–6877





# Liquid Metal with a Thin Solid Skin



## Thin solid layer on the surface:


- ✓ Native Oxide – instantaneously forms
- ✓ As thick as 20 nm: XRD<sup>[1]</sup> and XPS
- ✓ Amorphous: XRD<sup>[1]</sup>
- ✓ Stabilizes – allows 3D printing

[1] Phys. Rev. B, 55, **1997**, 786-790.

[2] Surf. Sci., 24, **1983**, 407-422.

[3] Phys. Rev. B., 46, **1992**, 11346-11357.

After 40 min of exposure to  $\text{O}_2$  at partial pressure of  $5.0 \times 10^{-7}$  Torr



SIMS  
Imaging  
in UHV <sup>[3]</sup>



# Methods Proposed in Literature to Alleviate these Problems in Device Fabrication & Operation




Coplanar microfluidic channels


Filling the channels with HCl solution  
**NOT PRACTICAL !!!**

Frequency reconfigurable patch antenna

Use of HCl solutions of high concentration  
**NOT PRACTICAL !!!**



Li, G., et al. *Lab Chip*, **14** (2014) 200



M. Kelley, et al. *Elect. Lett.*, **49** (2013) 1370-1371

GaLMA exposed to HCl vapor




M. Dickey, NC State U.



**Need an Alternative Method to Replace HCl**



# An Interface Modification Layer To Protect the Surface Oxide of GaLMA







## Alkyl Phosphonic Acids






# Contact Angle of H<sub>2</sub>O - Modification of Surface Wettability of EGaIn (Eutectic GaIn)



Doctor-bladed: tilted to remove excess EGaIn.





Contact angle of H<sub>2</sub>O measured on smooth areas of the surface.









# Decyl Phosphonic Acids Make the EGaIn Surface Hydrophobic



1 mM, 10 sec





ATR-FTIR: all background subtracted

88ABW-2015-5371









# Decyl Phosphonic Acids Make the EGaIn Surface Hydrophobic









1 mM, 10 sec



1 mM, 5 min



ATR-FTIR: all background subtracted







88ABW-2015-5371









# Decyl Phosphonic Acids Make the EGaIn Surface Hydrophobic



- EGaIn / Decyl PA
1. 1 mM Decyl PA, 5 min
  2. Ethanol, 17 hours




- EGaIn  
(No prior treatment with Decyl PA)
1. Ethanol, 23 hours



# GaLMA Sticks to Glass During Injection and Flow




Glass tube prefilled with **ethanol**



Withdrew, syringe flow rate: 0.5 mL/min, flow volume: 500  $\mu$ L

Glass tube prefilled with **dodecane**




Infused, syringe rate: 0.5 mL/min, flow volume: 500  $\mu$ L



# Reversible Flow of GaLMA Achieved in Decyl Phosphonic Acid Solution



Glass tube prefilled with **1 mM Decyl PA in Ethanol**




Infused, syringe rate: 2 mL/min, flow volume: 50  $\mu$ L








# Reversible Flow of GaLMA Achieved in Decyl Phosphonic Acid Solution



Glass tube prefilled with **1 mM Decyl PA in Ethanol**



Infused, syringe rate: 2 mL/min, flow volume: 50  $\mu$ L








# Functionalization of the Glass Tube Inner Walls vs the Surface of EGaIn




## Glass Tube **Pre-Treated** with Decyl PA


**Ethanol/EGaIn** in Glass




LM (EGaIn) In




LM (EGaIn) Out



0.001 M Decyl PA – Injected LM  
(EGaIn)




0.001 M Decyl PA – LM (EGaIn)  
Evacuated



## Glass Tube **Filled** with Decyl PA

**Decyl PA/Ethanol/EGaIn** in Glass



Infused, syringe rate: 3 mL/min, flow volume: 50  $\mu$ L



# Surface Characterization Vibrational Spectroscopy




## ATR-FTIR

Attenuated Total Reflection

Analysis of nanoscale thin films

Total internal reflection at the interface when  $\theta > \theta_c$

Sample in contact with  
evanescent wave



IR Beam

ATR Crystal


To Detector

$$\theta_c = \sin^{-1} \left( \frac{n_2}{n_1} \right)$$

$$n_1 > n_2$$

$$E = E_0 e^{-\left(\frac{z}{d_p}\right)}$$

$$d_p = \frac{\lambda}{2\pi \sqrt{n_1^2 \sin^2 \theta - n_2^2}}$$



Single Reflection  
ATR Crystal (**Diamond**)



**Evanescent wave:** standing wave due to the superposition of incident and reflected waves

$E$ : Amplitude of standing electric wave

$E_0$ : Amplitude at the interface ( $z=0$ )

$z$ : Distance from the interface

$d_p$ : Penetration depth

$\theta$ : Incidence angle

$n_1, n_2$ : Refractive Indices

$\lambda$ : Wavelength of the radiation

Image taken from  
Bruker Catalog




# Surface Characterization

## Vibrational Spectroscopy



### ATR-FTIR

- Sensitive to thin films
- Our setup is not sensitive for monolayer films (need sensitive detectors/reflection methods)
- **Sufficient to study thin film formation dynamics**






# Surface Characterization

## Photoelectron Spectroscopy




### Photoelectron Spectrometer



**XPS**


[http://www.chem.qmul.ac.uk/surfaces/scc/scat5\\_3.htm](http://www.chem.qmul.ac.uk/surfaces/scc/scat5_3.htm)



Binding energy (BE) depends on:

1. Formal oxidation state of the atom
2. Local chemical environment

Chemical/elemental analysis of alkyl phosphonic acids on **EGaIn**









# Surface Characterization

## Photoelectron Spectroscopy



### XPS

- X-Ray Photoelectron Spectroscopy
- Sensitive to submonolayers (parts per thousand)
- Our setup: sampling depth of ~2-6 nm
- **Quantitative/chemical information for elemental analysis**







# Surface Characterization

## Atomic Force Microscopy



### AFM

- ❑ Excellent vertical resolution up to 1 Å
- ❑ Lateral resolution generally not as good



Contact Mode | Non-Contact Mode | Tapping Mode

**deflection**      **attractive vdW**      **oscillation amplitude**


<http://www.nanoscience.gatech.edu/zlwang/research/afm.html>

<http://www.physik.uni-greifswald.de/scientific-groups/helm/methods/afm-atomic-force-microscope.html?L=1>




# Surface Coverage is a Dynamic Process


## Surface Film Coverage Increases with Adsorption Time




LM injected into  
the PA solution  
& suspended



ATR-FTIR – gently  
placed the suspended  
droplet onto ATR crystal



EGain  
background  
subtracted






# Surface Coverage is a Dynamic Process


## ATR-FTIR/AFM - Growth mode: 3D islands




5 min exposure



30 s exposure




10 s exposure




Height

10.0 nm




Height

10.0 nm




Height

10.0 nm



The onset of  
Island formation












# Surface Coverage is a Dynamic Process

## ATR-FTIR/XPS - Growth mode: 3D islands



### Atomic Composition

Ga/P = 5.5  
Ga/O = 0.8  
C/P = 7.9 (10)  
O/P = 7.0 (3)



### Atomic Composition




Ga/P = 5.4  
Ga/O = 0.8  
C/P = 6.7 (10)  
O/P = 6.8 (3)

Our XPS setup: sampling depth of ~2-6 nm





# Surface Coverage is a Dynamic Process

## Surface Film Coverage Increases with Adsorption Time



### Atomic Composition

Ga/P = 5.5  
Ga/O = 0.8  
**C/P = 7.9** (10)  
O/P = 7.0 (3)



### Atomic Composition

Ga/P = 5.4  
Ga/O = 0.8  
**C/P = 6.7** (10)  
O/P = 6.8 (3)


Our XPS setup: sampling depth of ~2-6 nm




# Film Growth- Adsorption Rate of Decyl PA Increases with Solution Concentration




ATR-FTIR



5 min treatment






LM injected into  
the PA solution &  
suspended: 5 min



Decyl PA  
(in ethanol)

Our XPS setup: sampling depth of ~2-6 nm

XPS







# Film Growth- Adsorption Rate of Decyl PA Increases with Solution Concentration




ATR-FTIR



5 min treatment




LM injected into  
the PA solution &  
suspended: 5 min





Decyl PA  
(in ethanol)

Adsorption Rate ↑  
as Concentration ↑

XPS



C ↑  
P ↑



Our XPS setup: sampling depth of ~2-6 nm




# Thin Film Structure

## Bulk Crystalline vs Thin Film




ATR-FTIR


Decyl PA  
Powder



EGain in  
Saturated  
Decyl PA (5 min)






EGain in  
Saturated  
Decyl PA (5 min)  
Ethanol (5 s)






Wavenumber (cm<sup>-1</sup>)

Bulk Crystal



Wavenumber (cm<sup>-1</sup>)









# PA-Functionalized EGaIn

## Film Coverage Decreases upon Rinsing with Ethanol

ATR-FTIR



5 min in 1 mM Decyl PA



1 mM Decyl PA  
(in ethanol)

5 min in 1 mM Decyl PA + 30 s Ethanol

5 min in 1 mM Decyl PA  
and 30 s in Ethanol



Ethanol




# PA-Functionalized EGaIn

## Film Coverage Decreases upon Rinsing with Ethanol




ATR-FTIR

5 min in 1 mM Decyl PA



Below detection limit of the given ATR-FTIR setup

5 min in 1 mM Decyl PA + 30 s Ethanol



1 mM Decyl PA (in ethanol)



Ethanol



# PA-Functionalized EGaIn



## Film Coverage Decreases upon Rinsing with Ethanol

XPS

5 min in 1 mM Decyl PA

**Atomic Composition**


Ga/P = 5.4 Ga/O = 0.8 C/P = 6.7 (10) O/P = 6.8 (3)



5 min in 1 mM Decyl PA + 30 s Ethanol

**Atomic Composition**

Ga/P = 5.9 Ga/O = 1.1 C/P = 6.9 (10) O/P = 5.6 (3)



Our XPS setup: sampling depth of ~2-6 nm



# PA-Functionalized EGaIn



## Film Coverage Decreases upon Rinsing with Ethanol

XPS

5 min in 1 mM Decyl PA

**Atomic Composition**


Ga/P = 5.4 Ga/O = 0.8 C/P = 6.7 (10) O/P = 6.8 (3)



5 min in 1 mM Decyl PA + 30 s Ethanol

**Atomic Composition**

Ga/P = 5.9 Ga/O = 1.1 C/P = 6.9 (10) O/P = 5.6 (3)



Our XPS setup: sampling depth of ~2-6 nm




# Effects of Alkyl Chain Length




## Decyl (10 carbons) PA vs Octadecyl (18 carbons) PA

~ 1.72 nm



~ 2.79 nm






### Atomic Composition

Decyl PA	Ga/P = 5.5	Ga/O = 0.8	C/P = 8.0	(10)	O/P = 7.0	(3)
Octadecyl PA	Ga/P = 0.8	Ga/O = 0.1	C/P = 22.2	(10)	O/P = 5.1	(3)

XPS

Our XPS setup: sampling depth of ~2-6 nm








# Effects of Alkyl Chain Length



## Decyl (10 carbons) PA vs Octadecyl (18 carbons) PA

~ 1.72 nm



### Atomic Composition

Decyl PA

Ga/P = 5.5

Ga/O = 0.8

C/P = 8.0

(10)

O/P = 7.0

(3)

Octadecyl PA

Ga/P = 0.8

Ga/O = 0.1


C/P = 22.2

(10)


O/P = 5.1

(3)

~ 2.79 nm




Our XPS setup: sampling depth of ~2-6 nm





# Decyl Phosphonic Acid – Film Structure

## Effects of the Surface Oxide on Film Formation








# Decyl Phosphonic Acid – Film Structure





## Effects of the Surface Oxide on Film Formation



Directly exposed to PA




1 min Air then exposed to PA





# SUMMARY - Protecting the Oxide Layer Prevents Sticking to Channel Inner Walls





Glass Capillary filled with

Ethanol / EGaIn




PA+Ethanol / EGaIn






**PA:** phosphonic Acids






# SUMMARY – Decyl Phosphonic Acids Strongly Bind to Ga-Oxide/EGaIn




1 mM Decyl PA, 5 min



1 mM Decyl PA, 5 min  
**Ethanol, 17 hours**



XPS







# Acknowledgment



## AFRL Team:

Chris Tabor, Brad Cumby,  
Alex Cook, Michael Durstock



Chris Tabor



Brad Cumby



Alex Cook

## Collaborators:

Michael Dickey - North Carolina State Univ.  
Jason Heikenfeld - University of Cincinnati