

Novel β -cyclodextrin Polymer Adsorbents for Removal of PFAS from Diverse Water Matrices

Yuhan Ling, Ph.D.

Director, Environmental Engineering

yling@cyclopure.com




CYCLOPURE.COM

INFO@CYLOPURE@GMAIL.COM



PFAS – Forever Chemicals in Water

- PFAS: Per- and polyfluorinated alkyl substances
- Widely-used: firefighting and household products
- Pervasive – GW, SW, WW, Leachate
- Persistent, Bio-accumulative, and Toxic




- Over 6,000 different PFAS structures

Challenges: PFAS are difficult to remove:

- (1) diverse chemical structures;
- (2) low concentrations (ng/L to $\mu\text{g/L}$);
- (3) present in complex water matrices.




Point source and Nonpoint source Contamination:
PFAS's surfactant nature and high stability = Persistence



PFAS – Treatment Technology


Activated Carbon



Ion Exchange Resin




Cyclodextrin Polymers



Reverse Osmosis






Shellfish Allergy



Proprietary Technology: DEXSORB®

One-Step Synthesis: 1 gram of DEXSORB = 3×10^{20} cyclodextrin cups



DEXSORB




micropollutants:
i.e. pharmaceuticals,
pesticides

DEXSORB+



PFAS:
i.e. GenX,
PFOA, PFOS



Features:

1. **High Selectivity** for micropollutants like PFAS.
2. **Rapid Kinetics** in both powder and granular forms.
3. **High Capacity** for micropollutant uptake.
4. **Resistance to fouling** of TOC and TDS (size exclusion).
5. **Easy regeneration** for multi-cycle reuse.



OFFICIAL LISTING

NSF certifies that the products appearing on this Listing conform to the requirements of NSF/ANSI/CAN 61 - Drinking Water System Components - Health Effects

This is the Official Listing recorded on February 3, 2021.


Facility: Skokie, IL

Trade Designation	Process Media	Size	Water	
			Contact Temp	Contact Material
Adsorption Media DEXSORB+ [1]		12 x 40 mesh	CLD 23	SYN


[1] This product is Certified for a maximum use level of 150 g/L.

Unique Feature: Size Exclusion & Size Inclusion




Host-Guest Complexation



- Size inclusion for PFAS



- Size exclusion for NOM, inorganic ions, etc.




Performance: Consistent PFAS Removal in Complex Matrices

Removal in Different Matrices

DEXSORB+ Dose: **20 mg/L**



DOM Concentration: **5.4 mg/L (WW)**; **2.5 mg/L (SW)**; **<1 mg/L (GW)**



Removal at High Contamination

DEXSORB+ Dose: **50 mg/L**

Total PFAS level: **2650 ppt** DOM Concentration: **>5 mg/L**



Resistant to Matrix Effects:


- Consistent performance across different water quality conditions (e.g., DOM)
- Allows application in diverse water matrices

Efficiency at High PFAS Contamination:

- Rapid and efficient removal across different PFAS chain lengths and contamination levels

Drinking water PBF treatment at Town X, MA

Town X, MA




RSSCT Conditions:

- Run for **10** days
- Simulated EBCT: **5** min
- Throughput: **5** gallons
- Loading: **0.08** g.



Performance:

- **1** kg for the treatment of more than **150,000** L;
- Equally effective against **short- & long-chain** PFAS






Industrial Groundwater Remediation in Michigan


RSSCT results, superior PFAS removal:



On-site pilot test, CP compact vessel system:




Landfill Leachate Pre-treatment in New York



Third-party leachate treatment study:

DEXSORB+ Dose: **5 g/L**; Contact time: 30 minutes


TOC: **> 1000 mg/L**; TDS: **> 5000 mg/L**




Important Observations:

- **Rapid kinetics and high capacity are maintained in the most challenging matrix**
- **Both short- and long-chain can be effectively removed**


DEXSORB®: From Separation to Mineralization for PFAS



Multi-cycle regeneration for Reuse



EPA funded Proprietary Process




DEXSORB®: Effective Uptake of Emerging PFAS

ES&T – 9.14.2020

“β-Cyclodextrin Polymers with Different Cross-Linkers and Ion-Exchange Resins Exhibit Variable Adsorption of Anionic, Zwitterionic, and Nonionic PFASs.” Environ. Sci. Technol. 2020, 54, 19, 12693–12702.


DEXSORB® exhibits efficient removal of zwitterionic, anionic, and non-ionic PFAS.



ES&T Letters – 10.15.2020

“Evaluating the Removal of Per- and Polyfluoroalkyl Substances from Contaminated Groundwater with Different Adsorbents Using a Suspect Screening Approach.” Environ. Sci. Technol. 2020, DOI: 10.1021/acs.estlett.0c00736.

DEXSORB® show broad efficacy against all 68 identified PFAS in short contact time.



Thanks for your attention!

Yuhan Ling, Ph.D.

Director, Environmental Engineering

yling@cyclopure.com



RESEARCH + TECH CENTER

8045 Lamon Avenue, Suite 140
Skokie IL 60077

CORPORATE OFFICE

171 Saxony Road, Suite 208
Encinitas CA 92024

INQUIRIES

312.639.5009

info@cyclopure.com

cyclopure.com