
Thinking Matters Symposium

2021 Thinking Matters Symposium

Apr 30th, 12:00 AM

Design of a Constant Volume Combustion Chamber

John Bono

University of Southern Maine, john.bono@maine.edu

Collin Gould

University of Southern Maine, collin.gould@maine.edu

Scott Eaton

University of Southern Maine, scott.eaton@maine.edu

Follow this and additional works at: <https://digitalcommons.usm.maine.edu/thinking-matters-symposium>

 Part of the [Engineering Commons](#)

Bono, John; Gould, Collin; and Eaton, Scott, "Design of a Constant Volume Combustion Chamber" (2021).
Thinking Matters Symposium. 4.

<https://digitalcommons.usm.maine.edu/thinking-matters-symposium/2021/poster-sessions/4>

This Poster Session is brought to you for free and open access by the Student Scholarship at USM Digital Commons. It has been accepted for inclusion in Thinking Matters Symposium by an authorized administrator of USM Digital Commons. For more information, please contact jessica.c.hovey@maine.edu.

DESIGN OF A CONSTANT VOLUME COMBUSTION CHAMBER FOR FUEL INJECTION ANALYSIS



Authors: John Bono and Collin Gould
Advisor: Dr. Scott Eaton, Engineering Department



Abstract:

- Fuel injection is studied because the performance, low level of emissions, and noise of a diesel engine is directly influenced by the fuel injection system
- The constant volume combustion chamber (CVCC) provides the optimal controlled environment for injection spray analysis
- The CVCC is required to meet all guidelines defined by the state of Maine for pressure vessel certification


Project Goals:

- Create a CVCC with optical access to analyze fuel injection
- Record slow-motion video of a fuel injection event
- Use telemetry data and motion analysis software to deduce scientific data
- Acquire the following data: fuel injection speed, spray cone angle, droplet size as a function of spray penetration, mean droplet size, spray density mapping, flame front of combustion

Constant Volume Combustion Chamber Stress Analysis

Key Chamber Safety Features

- All chamber components designed to ASME B16.5 standard
- Typical factor of safety for a pressure vessel is between 3 and 6
- Optimal depth of thread engagement for bolted connections ensure a factor of safety greater than 5



Finite Element Analysis Conditions

Temperature	Pressure	Mesh Type
400 (K)	2000 (PSI)	Curvature Based Mesh

Design of Chamber


Injector Adapter

Required Instrumentation


- Single hole injector
- Spark plugs
- Thermocouple
- Hydrostatic port
- Pressure transducer

Key Features

- Injector Tip Placement
- Provides Proper Seal of the Injector
- Creates Chamber Adaptability



Injector Spray Calculations




$$\text{Spray Distance [mm]} = 3.07 * \left(\frac{\Delta P_{\text{Chamber}}}{\rho_{\text{Diesel}}} \right)^{0.25} * (\text{Time} * \text{Dia}_{\text{injector}})^{0.5} * \left(\frac{294}{\text{Temp}_{\text{Gas}}} \right)^{0.25}$$

Chamber Operating Conditions


Combustion Event 1 (H ₂ Pre-burn)	
Temperature Inside Chamber	Chamber Pressure
400 (K)	500 (PSI)
Combustion Event 2 (Injection Event)	
Temperature Inside Chamber	Chamber Pressure
1200 (K)	1500 (PSI)

Schlieren Results


iX-Camera Testing



Point Source



Extended Light Source



Point Source:

- 400 μm pinhole source
- 800 μm pinhole block
- Infinite focus
- Infinite sensitivity
- Zero measuring range
- Analytical data not measurable
- Not useful for this project

Extended Light Source:

- 1 x 5 mm rectangular slit
- Adjustable razorblade cut off
- Graduated measuring range
- Useful for analysis

Schlieren Optics Design

Schlieren photography is a method of visualizing the refractivity differences of a transparent inhomogeneous medium. The inhomogeneous media refracts light proportional to their gradients of refractive index in the x-y plane, producing angular ray deflection angles of ε.


$$\epsilon_x = \frac{1}{n} \int \frac{\partial n}{\partial x} dz, \quad \epsilon_y = \frac{1}{n} \int \frac{\partial n}{\partial y} dz$$

Key Features

- Designed to fit around CVCC
- Testing region over 2 times focal length
- Coma aberration eliminated
- Astigmatism aberration minimized

Schlieren Optical Setup

Z-type Herschelian Schlieren Setup



Final Setup Dimensions

θ ₁ (deg.)	θ ₂ (deg.)	f ₁ (in.)	f ₂ (in.)	Center Distance (in)
5.9	5.9	49	49	104

Future Work

Optics

- Planar-laser induced fluorescence (PLIF) integration
- Purchase an optical table/rail system
- Use manual positioning stages
- Use a focusing lens for the lighting system in conjunction with a diffuser

Constant Volume Combustion Chamber

- Purchase viewing flanges
- Seek quotes for chamber components
- Purchase stand for CVCC
- Design fuel delivery system

Acknowledgements

Thank you to the MIST lab of the University of Southern Maine for creating a 3D prototype and the University of Maine at Orono for providing funding of this project. Thank you to the companies that helped us design our system, Michael Quzor of iX-Cameras and Justin Parker of Rayotek Sight Windows.

Special thank you to Dr. Scott Eaton, our project supervisor, for mentoring us throughout the process.

References

- [1] iX-Cameras, "i-SPEED 513 Datasheet," DS-513-02.01.20
- [2] G. S. Settles, Schlieren and Shadowgraph Techniques. New York: Springer-Verlag Berlin Heidelberg, 2001.
- [3] Oil Burners. (2012, May. 25). stanadyne injectors [Online]. Available: <https://www.oilburners.net/threads/stanadyne-injectors.57134/>
- [4] J. B. Heywood, Internal Combustion Engine Fundamentals, McGraw-Hill Education, 1988