

1-1-2015

Ultraviolet Radiation Penetration Through Clothing

Jordan Ramage

Ultraviolet Radiation Penetration Through Clothing

Jordan Ramage, Department of Community and Environmental Health, College of Health Sciences

Introduction

- Exposure to ultraviolet radiation can result in significant health risks
- The primary organs affected are the eyes and the skin
- Eyes: Inflammation of the cornea and conjunctiva
- Skin: Erythema, sunburn, accelerated aging and cancer
- Protective eyewear and clothing can reduce injuries
- Effectiveness of clothing in reducing ultraviolet exposure was investigated





Background

- Workers exposed to intense outdoor sunlight conditions are at increased risk of UV related injuries
- Safety criteria have been established by the American Conference of Industrial Hygienists (ACGIH)
- To determine the protective clothing required, knowledge about UV penetration characteristics is needed
- Laboratory experiments were conducted to determine these characteristics

Methods

- Controlled laboratory experiments were performed to assess UV penetration through selected fabric materials
- 15cm² samples were exposed to 11.5 Watts/m² radiation intensity level
- Each sample was measured three times and the average calculated
- Samples were measured for dry, wet, and stretched conditions
- The equipment used for conducting the tests is illustrated in Figure 1

Analysis




Results

| Garment Sample | Ultraviolet Radiation Penetration (%) (Single layer) |
|-------------------|--|
| 100% Cotton | |
| ○ White | 8.1 |
| ○ Red | 3.7 |
| ○ Black | 3.1 |
| 100% Cotton | |
| ○ Dry | 8.1 |
| ○ Wet | 9.6 |
| 100% Cotton | |
| ○ Normal | 8.1 |
| ○ Stretched | 12.3 |
| Cotton | |
| ○ 100% | 8.1 |
| ○ 60% / Polyester | 12.4 |
| Polyester | |
| ○ 100% | 5.7 |
| ○ 40% / Cotton | 12.4 |
| Human Hair | |
| ○ Dry | 4.9 |
| ○ Wet | 4.8 |

Conclusions

- All fabric samples tested exhibited good UV penetration protection
- Light colored fabrics exhibited lower UV protection than dark fabrics
- Synthetic fabrics provided more protection than natural textiles



Equipment

Figure 1.
UV Measurement Equipment

