

Honeywell

CHARACTERIZATION OF LITHIUM STEARATE: PROCESSING AID FOR FILLED ELASTOMERS

Federal Manufacturing & Technologies

E. A. Eastwood
C. Densmore

KCP-613-8264

February 2007

Final Report

Approved for public release; distribution is unlimited.



Prepared under prime contract DE-ACO4-01AL66850 for the
United States Department of Energy

DISCLAIMER

This report was prepared as an account of work sponsored by an agency of the United States Government. Neither the United States Government nor any agency thereof, nor any of their employees, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. Reference herein to any specific commercial product, process or service by trade names, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation or favoring by the United States Government or any agency thereof. The views and opinions of authors expressed herein do not necessarily state or reflect those of the United States Government or any agency thereof.

All data prepared, analyzed and presented has been developed in a specific context of work and was prepared for internal evaluation and use pursuant to that work authorized under the reference contract. Reference herein to any specific commercial product, process or service by trade name, trademark, manufacturer, or otherwise, does not necessarily constitute or imply its endorsement, recommendation or favoring by the United States Government, any agency thereof or Honeywell Federal Manufacturing & Technologies, LLC.

Printed in the United States of America.

This report has been reproduced from the best available copy.

Available to DOE and DOE contractors from the Office of Scientific and Technical Information, P.O. Box 62, Oak Ridge, Tennessee 37831; prices available from (865) 576-8401, FTS 626-8401.

Available to the public from the National Technical Information Service, U.S. Department of Commerce, 5285 Port Royal, Rd., Springfield, Virginia 22161, (703) 487-4650.

KCP-613-8264
Distribution Category UC-36

Approved for public release; distribution is unlimited.

CHARACTERIZATION OF LITHIUM STEARATE: PROCESSING AID FOR FILLED ELASTOMERS

E. A. Eastwood
C. Densmore

February 2007

Final Report

Contents

<i>Section</i>	<i>Page</i>
Abstract	5
Summary	5
Discussion	7
Scope and Purpose	7
Activity	7
<u>Background</u>	7
<u>Potential Suppliers</u>	7
<u>Characterization</u>	8
NMR	8
FT-IR.....	9
Moisture	10
DSC.....	10
TGA	10
<u>Discussion</u>	13
Accomplishments.....	13
References.....	14

Illustrations

<i>Figure</i>	<i>Page</i>
1 Structure of lithium stearate.....	7
2 Transmission FT-IR spectra of lithium stearate samples prepared with KBr. Spectra collected at 2 cm ⁻¹ resolution with 16 scans	9
3 First heat DSC curves for three lots of lithium stearate	11
4 Cool down DSC curves for three lots of lithium stearate	11
5 Second heat (reheat) DSC curves for three lots of lithium stearate	12
6 TGA thermograms of the three lots of lithium stearate	13

Tables

<i>Table</i>	<i>Page</i>
1 Alfa Aesar supplied data.....	7
2 Initial characterization data from Chemtura	8
3 Solvents assessed for lithium stearate.....	8
4 FT-IR peak identification for lithium stearate	9
5 Moisture data in ppm and weight % for the three lithium stearates	10
6 Peak transitions from DSC data for three lithium stearates	12

Abstract

This topical report presents work completed to characterize lithium stearate so a replacement supplier could be identified. Lithium stearate from Alfa Aesar and Chemtura was obtained and characterized along with the current material from Witco. Multiple methods were used to characterize the materials including Karl Fischer, FT-IR, differential scanning calorimetry, and thermogravimetric analysis.

Summary

This report details characterization studies of lithium stearate. Lithium stearate is a lithium salt of stearic acid ($\text{LiC}_{18}\text{H}_{35}\text{O}_2$) and is used as a processing aid or lubricant during filled elastomer part production. Currently, lithium stearate from Witco is used in production; however, this material is no longer commercially available and an alternate, replacement supplier must be identified. Two replacement vendors that distribute technical grade lithium stearate were identified: Alfa Aesar and Chemtura (formerly Crompton Corporation). Several techniques were used to characterize the current material and material from the two replacement vendors. Solution NMR was attempted with numerous solvents; however, the analysis could not be completed due to the limited solubility of lithium stearate. The structure of the lithium stearate was confirmed with transmission FT-IR. The FT-IR spectra for two lots of the lithium stearate showed characteristic peaks associated with carboxylate and aliphatic C-H deformations. All three lots of lithium stearate were evaluated for moisture by Karl Fischer techniques and were found to have a very low amount of residual water. In addition, all three lots have very similar moisture values. The thermal properties were characterized using differential scanning calorimetry and thermogravimetric analysis for the lithium stearates. Again, all three lots of lithium stearates revealed similar thermal behavior. Alfa Aesar lithium stearate was chosen as the replacement material based on the container sizes available commercially.

This Page is Intentionally Left Blank

Discussion

Scope and Purpose

This study is a part of a project to characterize the starting materials used in filled elastomer part production. While other reports¹⁻⁷ have detailed characterization of the other materials used for filled elastomer part production (ethylene/vinyl acetate/vinyl alcohol terpolymer called VCE and curing agent called Hylene MP), this report details work to characterize lithium stearate. Currently, lithium stearate from Witco is used during production; however, this material is no longer commercially available and an alternate, replacement supplier must be identified. Once the lithium stearates have been well characterized, a replacement lithium stearate can be chosen to replace the current material being used.

Activity

Background

Lithium stearate is a processing aid or lubricant used during filled elastomer part production.⁸ Lithium stearate is the lithium salt of stearic acid ($\text{LiC}_{18}\text{H}_{35}\text{O}_2$) and shown in Figure 1. The CAS number for lithium stearate is 4485-12-5.




Figure 1: Structure of lithium stearate.

Potential Suppliers

Two replacement vendors that distribute technical grade lithium stearate were identified: Alfa Aesar and Chemtura (formerly Crompton Corporation). Item #39335 (lot number G31M14) was purchased from Alfa Aesar and the following vendor data was supplied with the material.

Table 1: Alfa Aesar supplied data.

Total Ash	5.28%
Moisture	0.13%
Free fatty acid	0.36%
Softening Point	215°C
Fineness through 325 mesh	100%

Chemtura supplies a number of different grades of lithium stearates: 90A, 90B, 304, and 306. Due to availability, lithium stearate 306 with batch # ME5K14M001 was obtained for evaluation. The data provided in Table 2 was supplied from Chemtura with the material:

Table 2: Initial characterization data from Chemtura.

Alkalinity	0.02%
Moisture	1.00%
Free fatty acid	0.00%
Lithium Content	2.50
Fineness through 200 mesh	99.6%
Fineness through 40 mesh	100%

Characterization

NMR. An attempt was made to analyze and compare two samples of lithium stearate by ^1H NMR; one sample was the lithium stearate currently used in production (from Witco with lot number B3613190010001), and the other sample was the lot G31M14 from Alfa Aesar. However, the extremely limited solubility of lithium stearate prevented analysis by solution NMR. The solubility of lithium stearate was assessed using the solvents listed in Table 3. At best, lithium stearate was slightly soluble in any of these solvents.

Table 3: Solvents assessed for lithium stearate.

Solvent:
Chloroform - CHCl_3
Methylene Chloride - CH_2Cl_2
Carbon Tetrachloride - CCl_4
Acetone
Water
Dimethylsulfoxide - DMSO
n, n- Dimethylformamide - DMF
Methanol - CH_3OH
Ethanol – $\text{CH}_3\text{CH}_2\text{OH}$
Acetonitrile – CH_3CN
Tetrahydrofuran - THF
Toluene
Benzene
n-Hexane

FT-IR. Because we could not find a solvent system suitable for lithium stearate, transmission FT-IR spectra of the two samples were collected. A potassium bromide (KBr) pellet was prepared for each sample. A Mattson 5000 FT-IR spectrometer was used for the analysis. Before spectra were collected, a background spectrum was collected and stored. All spectra were collected from 4000 cm^{-1} to 400 cm^{-1} with a resolution of 2 cm^{-1} and 16 scans (see Figure 2).

The transmission FT-IR spectra of the lithium stearate samples are very similar and both show characteristic peaks associated with carboxylate and aliphatic C-H deformations, as shown in Table 4.

Table 4: FT-IR peak identification for lithium stearate.

Wavenumber (cm^{-1})	Functional Group:
3000-2840	Aliphatic C-H stretching from CH_3 and CH_2 groups
1600-1550	Asymmetric $(\text{COO})^-$ stretching from carboxylate group
1500-1400	Multiple peaks arising from symmetric $(\text{COO})^-$ stretching from carboxylate group and asymmetric C-H stretching from CH_3 and CH_2 groups
*750-700	CH_2 deformation

*Other deformations associated with $(\text{COO})^-$ can also occur below 800cm^{-1} .




Figure 2. Transmission FT-IR spectra of lithium stearate samples prepared with KBr. Spectra collected at 2 cm^{-1} resolution with 16 scans.

Moisture. Moisture data were available for three lots (from Witco, Alfa Aesar, and Chemtura); however, it is unclear if the same methods were used for the data available. Therefore, all three lots of lithium stearate were re-tested for moisture using a Karl Fischer oven at 180°C. The moisture data for the three lots tested are given below in Table 5. The Chemtura lithium stearate had a much lower value than reported from the manufacturer (0.019% vs. 1%). Generally, all of lithium stearates had comparable moisture contents ranging from 0.019 to 0.029%.

Table 5: Moisture data in ppm and weight % for the three lithium stearates.

Vendor	Lot #	Water Content (ppm)	Water Content (%)
Witco	B3613190010001	293	.029%
Alfa Aesar	G31M14	241	.024%
Chemtura	ME5K14M001	188	.019%

DSC. Alkali metal stearates such as lithium stearate are reported in the literature to exhibit liquid crystalline behavior and have multiple phase transitions.⁹⁻¹⁵ Solid state crystalline transition from orthorhombic to hexagonal packing transition is reportedly expected to occur from 102 °C to 104 °C. From 193 °C to 194 °C, a transition from crystalline to rotational or crystalline state occurs. Finally, from 225 °C to 228 °C a melting transition is found. The three lots of lithium stearate from Witco, Alfa Aesar, and Chemtura, respectively, were analyzed using a TA Instruments Q1000 differential scanning calorimeter (DSC). Approximately 10-mg samples were placed in aluminum pans and heated from 25 °C to 250 °C at 10 °C/min under a helium atmosphere, followed by cooling at the same rate to 0 °C. The samples were then reheated a second time to 250 °C. The DSC profiles of these metal stearates are very dependent on the atmosphere under which it is heated.⁹ Under an inert atmosphere such as under nitrogen, helium, or argon, all three transitions are endothermic. However, if the sample is heating in air or oxygen, the two higher temperature transitions (at approximately 193 °C and 225 °C) become exothermic. The DSC profiles of all three lithium stearate samples obtained under helium are shown in Figures 3 through 5; the peak positions of the thermal transitions are listed in Table 6. All of the lithium stearates have very similar thermal behavior and peak positions were nearly identical.

TGA. Thermogravimetric analysis (TGA) was completed on the lithium stearates using a TA Instruments Q500 TGA. Approximately 10 mg of each sample was heated from room temperature up to 600 °C at 10 °C/min and the corresponding change in weight percents are plotted as a function of temperature in Figure 6. These thermograms are quite similar to those reported in the literature under similar conditions. Under inert atmosphere the first degradation begins around 200 °C, followed by an accelerated degradation above 400 °C. The weight loss continues until approximately 530 °C where approximately 10% weight/ash remains. According to the literature, lithium stearate first decomposes to lithium oxalate and then to carbonate at 550 °C.⁹ Regardless, there are not many differences between the TGA thermograms and decomposition profiles for the three lots of lithium stearates.




Figure 3. First heat DSC curves for three lots of lithium stearate.




Figure 4. Cool down DSC curves for three lots of lithium stearate.




Figure 5. Second heat (reheat) DSC curves for three lots of lithium stearate.

Table 6: Peak transitions from DSC data for three lithium stearates.

Vendor	Step	1st transition	2nd transition	3rd transition	4th transition
Alfa Aesar	1st heat	103.2°C	192.0°C	227.6°C	NA
	cool down	93.6°C	134.4°C	205.7°C	218.7°C
	2nd heat	98.6°C	190.0°C	227.4°C	NA
Chemtura	1st heat	101.8°C	191.9°C	228.2°C	NA
	cool down	92.3°C	128.8°C	207.9°C	219.4°C
	2nd heat	97.5°C	190.8°C	227.8°C	NA
Witco	1st heat	102.6°C	192.4°C	224.9°C	NA
	cool down	87.1°C	131.9°C	200.5°C	214.4°C
	2nd heat	93.4°C	190.6°C	224.9°C	NA




Figure 6. TGA thermograms of the three lots of lithium stearate.

Discussion

The characterization data for all three lots of lithium stearates are comparable and have very little differences between them. The lithium stearates from Alfa Aesar and Chemtura (306) are both suitable replacements for the Witco lithium stearate. Lithium stearate from Alfa Aesar is available in 250-gram and 1-kilogram containers, while lithium stearate 306 from Chemtura is packaged in 25-pound bags. The smaller containers from Alfa Aesar are much more suitable for our production quantities and thus were chosen as the replacement lithium stearate.

Accomplishments

Several techniques were used to characterize the lithium stearates. Solution NMR was attempted with numerous solvents; however, the analysis could not be completed due to the limited solubility of lithium stearate. The structure of the lithium stearate was confirmed with transmission FT-IR. The FT-IR spectra for two lots of the lithium stearate showed characteristic peaks associated with carboxylate and aliphatic C-H deformations. All three lots of lithium stearate were evaluated for moisture by Karl Fischer techniques and were found to have a very low amount of water remaining. In addition, all three lots have very similar moisture values. The thermal properties were characterized using differential scanning calorimetry and thermogravimetric analysis for the lithium stearates. Again, all three lots of lithium stearates revealed similar thermal behavior. Alfa Aesar lithium stearate was chosen as the replacement material based on the container sizes available commercially.

References

1. E. A. Eastwood, *VCE Replacement Development: Characterization of EVA Materials* (Topical Report). UNCLASSIFIED. Federal Manufacturing & Technologies: KCP-613-6929, December 2004.
2. E. A. Eastwood, *VCE Replacement: Curing Studies* (Topical Report). UNCLASSIFIED. Federal Manufacturing & Technologies: KCP-613-8161, July 2006.
3. Densmore, C.; Labouriau, A.; Wingo, B.; Robison, T. "Thermal Stability Studies of VCE and TW Using a Range of Experimental Techniques," December 2004 (LA-UR-04-8442).
4. Labouriau, A., Densmore, C., Meadows, K., Cordova, B., and Lewis, R., *Characterization of VCE and Starting Materials: Part 1*. LA-UR-06-5294. Los Alamos National Laboratory.
5. E. A. Eastwood, *Characterization of Hylene MP: Curing Agent for Filled Elastomers* (Topical Report). UNCLASSIFIED. Federal Manufacturing & Technologies: KCP-613-8192, September 2006.
6. E. A. Eastwood, *VCE Replacement: Synthesis of VCEs with New Formulations* (Topical Report). UNCLASSIFIED. Federal Manufacturing & Technologies: KCP-613-8202, September 2006.
7. Densmore, C., Eastwood, E., *Characterization of VCE and Starting Materials: Part 2*. LA-UR-06-6812. Los Alamos National Laboratory.
8. P. M. Wilson, *Filled VCE (Ethylene Vinyl Acetate/Vinyl Alcohol Terpolymer) Materials and Processing Handbook* (Topical Report). UNCLASSIFIED. Federal Manufacturing & Technologies: KCP-613-6051, February 1998.
9. Barbooti, M. M.; Al-Sammerrai, D. A. *Journal of Thermal Analysis* 1985, 30, 587-595.
10. Cronin, T.; Berry, D. *Advances in Powder Metallurgy* 1990, 1, 295-305.
11. Thomas, Y.; Cole, K. C.; Pelletier, S.; St-Laurent, S. *Advances in Powder Metallurgy and Particulate Materials* 1997, 1, 4/23-4/34.
12. Skoulios, A.; Luzzati, V. *Nature* 1959, 183, 1310-1312.
13. Gavrilko, T.; Drozd, M.; Puchkovskaya, G.; Naumovets, A.; Tkachenko, Z.; Viduta, L.; Baran, J.; Ratajczak, H. *Journal of Molecular Structure* 1998, 450, 135-139.
14. Ishchuk, Y. L.; Podlennykh, L. V.; Godun, B. A. *Chemistry and Technology of Fuels and Oils* 1989, 25, 53-55.
15. Ripmeester, J. A.; Dunell, B. A. *Canadian Journal of Chemistry* 1971, 49, 2906-2909.

Distribution

Internal

Technical Information Center	A56	2C44	1
E. A. Eastwood	D/834	2C43	2-5
M. B. Pennington	D/200	2B38	6
E. W. Grotheer	D/834	2C43	7
T. J. Reno	D/800	MG39	8
P. J. Scheuer	D/843	FJ39	9
M. W. Trimmer	D/843	FJ39	10

External

Daniel Mendoza, LANL ORG: W-2 Mail Stop C921	11
Crystal Densmore, LANL Mail Stop J569	12
Tom Robison, LANL Mail Stop J569	13
Douglas Strack, NNSA	14
Kent Davis, KCSO	15