

LA-UR-02-6953

Approved for public release;
distribution is unlimited.

Title: CHARACTERIZATION OF Si(100) HOMOEPITAXY
GROWN IN THE STM AT LOW TEMPERATURES

Author(s): Holger NMI Grube, MST-8, 181202
Geoffrey W. Brown, MST-8, 118813
Joshua M. Pomeroy, MST-8, 188125
Marilyn E. Hawley, MST-8, 105351

Submitted to: AMERICAN VACUUM SOCIETY
49TH INTERNATIONAL SYMPOSIUM





Los Alamos National Laboratory, an affirmative action/equal opportunity employer, is operated by the University of California for the U.S. Department of Energy under contract W-7405-ENG-36. By acceptance of this article, the publisher recognizes that the U.S. Government retains a nonexclusive, royalty-free license to publish or reproduce the published form of this contribution, or to allow others to do so, for U.S. Government purposes. Los Alamos National Laboratory requests that the publisher identify this article as work performed under the auspices of the U.S. Department of Energy. Los Alamos National Laboratory strongly supports academic freedom and a researcher's right to publish; as an institution, however, the Laboratory does not endorse the viewpoint of a publication or guarantee its technical correctness.

**H. Grube, G. W. Brown, J. M. Pomeroy and
M.E. Hawley**

*Materials Science & Technology Division, MST-8, Structure Property Relations
Los Alamos National Laboratory, Los Alamos, NM 87545, USA*

**L. Oberbeck, S. R. Schofield, N. J. Curson, M. Y. Simmons, and
R. G. Clark**

*Centre for Quantum Computer Technology, School of Physics,
University of New South Wales, Sydney, NSW 2052, Australia*



We explore the growth of low-temperature bulk-like Si(100) homoepitaxy with regard to microscopic surface roughness and defects. We characterize films grown at different temperatures up to 500K in-situ by means of an effusion cell added to our UHV-STM. The development of novel architectures for future generation computers calls for high-quality homoepitaxial Si(100) grown at low temperature.¹ Even though Si(100) can be grown crystalline up to a limited thickness,² the microstructure reveals significant small-scale surface roughness³ and defects specific to low-temperature growth.⁴ Both can be detrimental to fabrication and operation of small-scale electronic devices.

¹ B. Kane, *Nature* 393, 133 (1998)

² DJ Eaglesham, *J. Appl. Phys.*, 77, 3597 (1995)



³ RJ Hamers et al., *J. Vac. Sci. Technol. A* 8, 195 (1990)

⁴ MJ Bronikowski et al., *Phys. Rev. B*, 48, 12 361 (1993)






Silicon Based Quantum Computer

- Arrays of Spin Centers in Silicon Matrix
B. Kane, *Nature* 393, 133 (1998)
- High Quality Epitaxial Layer
 - Isolate Spins from Environment
- Low Temperature Silicon Epitaxy
 - Preserve Atomic Arrangement
- Manufacture in the STM
 - Facilitate Positioning between Process Steps







40 nm x 40 nm. Filled States $V_{\text{sample}} = -3$ V

Reconstructed

Unit Cell
3.85 Å x 7.70 Å



- Crystalline Growth up to a Temperature Dependent Thickness
- Surface Roughness Increases with Epitaxy Thickness

DJ Eaglesham, J. Appl. Phys., 77, 3597 (1995).


- Surface Roughness Increases with Background Hydrogen

JE Vasek et al., Phys. Rev. B, 51, 17 207 (1995).

- Preferred Nucleation at Antiphase Domain Boundaries

P Bedrossian et al., Phys. Rev Lett., 70, 2589 (1993).
 MJ Bronikowski et al., Phys. Rev. B, 48, 12 361 (1993).

Los Alamos NATIONAL LABORATORY UNSW







100nm x 100nm STM scans -1.5V sample bias, 150pA. Epitaxy grown at 100°C


0.66 ML, 3.6% 2nd layer 0.81 ML, 10% 2nd layer 1.05 ML, 22% 2nd layer

Early Onset of Second Layer Nucleation at submonolayer coverages


Los Alamos NATIONAL LABORATORY UNSW



100nm x 100nm STM scans -1.5V sample bias, 150pA. Epitaxy grown at 200°C



0.18 ML, 1.8% 2nd layer




0.64 ML, 3.1% 2nd layer

Reduced Second Layer Nucleation at submonolayer coverages

Smoother Epitaxy than Grown at 100°C or 150°C


Second Layer Fraction of Coverage




Higher Growth Temperatures Lead to Smoother Epitaxy

High Quality Thin Homoepitaxy on Silicon (100)

- Considerable Small Scale Surface Roughness
- Postanneal at Moderate Temperatures Ineffective
- Smoother Epitaxy at Higher Temperatures
- In Situ STM Study



AP1



AP2