

California State University, San Bernardino CSUSB ScholarWorks

Electronic Theses, Projects, and Dissertations

Office of Graduate Studies

9-2017

COMPARING AND IMPROVING FACIAL RECOGNITION METHOD

Brandon Luis Sierra California State University – San Bernardino, bsierra@csusb.edu

Follow this and additional works at: https://scholarworks.lib.csusb.edu/etd

Part of the Artificial Intelligence and Robotics Commons, Computer Engineering Commons, and the Other Computer Sciences Commons

Recommended Citation

Sierra, Brandon Luis, "COMPARING AND IMPROVING FACIAL RECOGNITION METHOD" (2017). *Electronic Theses, Projects, and Dissertations*. 575. https://scholarworks.lib.csusb.edu/etd/575

This Project is brought to you for free and open access by the Office of Graduate Studies at CSUSB ScholarWorks. It has been accepted for inclusion in Electronic Theses, Projects, and Dissertations by an authorized administrator of CSUSB ScholarWorks. For more information, please contact scholarworks@csusb.edu.

COMPARING AND IMPROVING FACIAL RECOGNITION METHOD

A Project

Presented to the

Faculty of

California State University,

San Bernardino

In Partial Fulfillment

of the Requirements for the Degree

Master of Science

in

Computer Science

by

Brandon Luis Sierra

September 2017

COMPARING AND IMPROVING FACIAL RECOGNITION METHOD

A Project

Presented to the

Faculty of

California State University,

San Bernardino

by

Brandon Luis Sierra

September 2017

Approved by:

Dr. Haiyan Qiao, Adviser, Computer Science

Dr. Ernesto Gomez, Committee Member

Dr. David Turner, Committee Member

© 2017 Brandon Luis Sierra

ABSTRACT

Facial recognition is the process in which a sample face can be correctly identified by a machine amongst a group of different faces. With the neverending need for improvement in the fields of security, surveillance, and identification, facial recognition is becoming increasingly important. Considering this importance, it is imperative that the correct faces are recognized and the error rate is as minimal as possible. Despite the wide variety of current methods for facial recognition, there is no clear cut best method. This project reviews and examines three different methods for facial recognition: Eigenfaces, Fisherfaces, and Local Binary Patterns to determine which method has the highest accuracy of prediction rate. The three methods are reviewed and then compared via experiments. OpenCV, CMake, and Visual Studios were used as tools to conduct experiments. Analysis were conducted to identify which method has the highest accuracy of prediction rate with various experimental factors. By feeding a number of sample images of different people which serve as experimental subjects. The machine is first trained to generate features for each person among the testing subjects. Then, a new image was tested against the "learned" data and be labeled as one of the subjects. With experimental data analysis, the Eigenfaces method was determined to have the highest prediction rate of the three algorithms tested. The Local Binary Pattern Histogram (LBP) was found to have the lowest prediction rate. Finally, LBP was selected for the algorithm improvement. In this project, LBP was improved by identifying the most

iii

significant regions of the histograms for each person in training time. The weights of each region are assigned depending on the gray scale contrast. At recognition time, given a new face, different weights are assigned to different regions to increase prediction rate and also speed up the real time recognition. The experimental results confirmed the performance improvement.

ACKNOWLEDGEMENTS

I would like to thank the biggest inspirations in my life, my wife Angela and my son Nicholas. They are the reason that I try to do better every day. I would also like to thank my parents, the rest of my family for pushing me to always try my hardest in school, and my uncle who was not able to see me get this degree. Lastly, I would like to thank my adviser, Dr. Qiao for spending numerous hours with me brainstorming ideas and guiding me.

TABLE OF CONTENTS

ABSTRACTiii
ACKNOWLEDGEMENTSv
LIST OF TABLES viii
LIST OF FIGURESix
CHAPTER ONE: INTRODUCTION 1
CHAPTER TWO: BACKGROUND REVIEW
Overview of Machine Learning and Object Recognition2
Overview of Facial Recognition2
Challenges in Object Recognition5
Current Work Review7
CHAPTER THREE: METHODOLOGY
Eigenfaces11
Fisherfaces12
Local Binary Patterns Histograms14
Original Local Binary Patterns Histogram16
Extended Local Binary Patterns Histogram17
Pros and Cons of Algorithms20
Local Binary Patterns Histogram Flowchart21

CHAPTER FOUR: IMPLEMENTATION AND EXPERIMENTAL RESULTS

Downloading OpenCV, CMake, and Visual Studios
Compiling, Executing, and Testing the Samples
Method Comparison Results 40
1:1 Facial Verification42
1:N Facial Identification49
Implementation of Local Binary Pattern Histogram58
CHAPTER FIVE: CONCLUSION AND FUTURE RESEARCH
APPENDIX A 1:N EIGENFACES RESULTS65
APPENDIX B 1:N FISHERFACES RESULTS70
APPENDIX C 1:N LOCAL BINARY PATTERN (ORIGINAL) RESULTS
APPENDIX D 1:N LOCAL BINARY PATTERN (MODIFIED) RESULTS
APPENDIX E 1:1 EIGENFACES RESULTS 85
APPENDIX F 1:1 LOCAL BINARY PATTERN (ORIGINAL) RESULTS 89
APPENDIX G 1:1 LOCAL BINARY PATTERN (MODIFIED) RESULTS
REFERENCES

LIST OF TABLES

Table 1. Algorithm Pros and Cons	. 20
Table 2. Subject Labels	. 41
Table 3. 1:1 Eigenfaces vs Local Binary Pattern	. 43
Table 4. 1:1 Local Binary Pattern Original vs Local Binary Pattern Modified	. 46
Table 5. 1:N Eigenfaces vs Fisherfaces vs Local Binary Pattern	. 49
Table 6. 1:N Local Binary Pattern Original vs Local Binary Pattern Modified	. 54

LIST OF FIGURES

Figure 1. Facial Recognition Algorithms9
Figure 2. Training Set Databases 10
Figure 3. Principal Component Analysis Dimensionality Reduction12
Figure 4. Principle Component Analysis and Fisher Linear Discriminant 14
Figure 5. Spatial Histograms15
Figure 6. Binary Values from Neighbors Comparison16
Figure 7. Original Local Binary Pattern Source Code
Figure 8. Extended Local Binary Pattern Neighbors Calculation 17
Figure 9. X and Y Coordinates of Extended Local Binary Pattern
Figure 10. Extended Local Binary Pattern Source Code
Figure 11. Facial Recognition Flow Chart24
Figure 12. Local Binary Pattern Train Flow Chart25
Figure 13. Extended Local Binary Pattern Flow Chart
Figure 14. Local Binary Pattern Spatial Histogram (Original) Flow Chart 27
Figure 15. Local Binary Pattern Predict Flow Chart
Figure 16. CMake Settings 1 32
Figure 17. CMake Settings 2
Figure 18. CMake Settings 3
Figure 19. CMake Settings 4 34
Figure 20. Visual Studios Settings 135
Figure 21. Visual Studios Settings 2

Figure 22. Visual Studios Settings 3	.37
Figure 23. Prediction Image	.39
Figure 24. Facerec_video	. 39
Figure 25. Local Binary Pattern Spatial Histogram (Modified) Flow Chart	60
Figure 26. Local Binary Pattern Standard Deviation Flow Chart	61
Figure 27. Local Binary Pattern Modified Source Code 1	.62
Figure 28. Local Binary Pattern Modified Source Code 2	. 63

CHAPTER ONE

The purpose of this project is to review, compare, and improve face recognition algorithms. Facial recognition is different than facial detection, and in certain situations, can be much more important than facial detection. Facial detection is the ability for a machine to detect whether a face exists in a live test. It answers the yes/no question "is this a face" or "is there a face in the image". Facial recognition is the ability for a machine to correctly label a face among a group different faces. It answers the question "whose face". Face recognition is important with regard to biometrics authentication. For security purposes, it is very important to correctly identify a person when attempting to authenticate. This can be necessary for door/area access, airport security and home security. In these situations, it can be imperative that the user presented is correctly identified and either granted access correctly or incorrectly. There are currently multiple applications available on both Android and iPhone that use facial recognition for both phone and application access as a means of additional security in the event that someone that is not authorized has access to another individual's phone.

CHAPTER TWO BACKGROUND REVIEW

Overview of Machine Learning and Object Recognition

"Machine learning refers to the study of algorithms that analyze data in order to help computer systems become more accurate over time when completing a task." [1]. The goal of machine learning is for computer systems to continually improve on the required task, or "learn" how to better complete a required task. This task is done by creating algorithms that the machines use to learn automatically. One example of machine learning could be spam filtering, where the software continually learns what the user considers spam and what is not. Machine learning is used in object recognition to help computer systems to better identify and recognize objects. Object recognition is the computer system's ability to not only detect that an object exists in an image, but also to identify what the object is. One example of object recognition is facial recognition.

Overview of Facial Recognition

Facial recognition is a technique that is quickly becoming a major goal of machine learning. Recently, with the aid of new algorithms, the ever increasing hardware capabilities, and the constant decrease in price for these advancements, facial recognition is becoming a more heavily researched field.

One of the main reasons for the current expansion of research in this field is that facial recognition aids in security and surveillance. Other applications of facial recognition include: general identity verification, criminal justice systems, image database investigations, "Smart Card" applications, multi-media environments with adaptive human-computer interfaces, video indexing, and witness face reconstruction. These are listed in details below according to [2]:

- Security (access control to buildings, airports/seaports, ATM machines and border checkpoints; computer/ network security; email authentication on multimedia workstations).
- Surveillance (a large number of CCTVs can be monitored to look for known criminals, drug offenders, etc. and authorities can be notified when one is located; for example, this procedure was used at the Super Bowl 2001 game at Tampa, Florida; in another instance, according to a CNN report, two cameras linked to state and national databases of sex offenders, missing children and alleged abductors have been installed recently at Royal Palm Middle School in Phoenix, Arizona).
- General identity verification (electoral registration, banking, electronic commerce, identifying newborns, national IDs, passports, drivers' licenses, employee IDs).
- Criminal justice systems (mug-shot/booking systems, post-event analysis, forensics).

3

- Image database investigations (searching image databases of licensed drivers, benefit recipients, missing children, immigrants and police bookings).
- "Smart Card" applications (in lieu of maintaining a database of facial images, the face-print can be stored in a smart card, bar code or magnetic stripe, authentication of which is performed by matching the live image and the stored template).
- Multi-media environments with adaptive human computer interfaces (part of ubiquitous or contextaware systems, behavior monitoring at childcare or old people's centers, recognizing a customer and assessing his needs).
- Video indexing (labeling faces in video).
- Witness face reconstruction.

There are also two main categories involved in facial recognition and identification. These are face verification and face identification. Although they seem similar, there is a difference between the two. According to [3], "Face verification is a 1:1 match that compares a face image against a template face images, whose identity is being claimed. On the contrary, face identification is a 1:N problem that compares a query face image against all image templates in a face database to determine the identity of the query face." Currently, there are applications on the market for facial recognition. Most of these applications would use facial recognition as a means for facial verification. When facial

verification is used for device security, there needs to be a 1:1 match. A device will only grant access if there is match between who should be allowed, and who is being recognized. An example of such an application is Windows Hello, which is included in Windows 10. One of the key points to consider before any face can be recognized is a good object classifier must first be developed. To develop a strong object classifier, a number of sample data must be preloaded into the machine in order for the machine to learn what the face should look like. The machine takes this sample data and, depending on the algorithm, develops discriminative features to look for in objects presented to it.

Challenges in Object Recognition

A robot can be any computer that is capable of machine learning. There are a number of challenges that arise when a robot tries to learn new information. One such issue is developing a strong classifier. A weak classifier occurs when the robot has an error rate that is greater than 50% over any distribution. In order to develop a strong classifier, there must be a large enough training set of labeled sample images for the robot to develop what discriminative features to look for. If the training data is not large enough, the machine may develop false positives. False positives are objects that are detected by the robot that should not be. For example, given a robot that has been designed to detect a human face and given an image of trees, the machine will falsely detect a human face in

5

the image of trees. However, the training data must not be too large, so as to avoid a low detection rate. A dataset range is determined through trial and error, depending on the number of features in an image. If the robot has been taught to detect too many discriminative features, it might not be able to detect an image with some, but not most of, these features. For example, given a robot that has been designed to detect a human face and was given more images to learn from containing faces having either short hair, no glasses, or earrings, the robot might not be able to detect the same face having long hair, glasses, or no earrings. These factors are especially important in facial identification. Another issue that can lead to false detections, especially in facial identification, is using training data of subjects who look too similar. For example, if training data consists of multiple family members who share similar facial features, the robot may have a difficult time correctly identifying one subject over the other. This could mean a low identification rate between parent/child, siblings, or even cousins whose facial features are similar enough. Other factors also exist that can pose challenges to recognizing a face. According to [3] five factors that can play an important role in face recognition are:

 Illumination variations due to skin reflectance properties and due to the internal camera control. Several 2D methods do well in recognition tasks only under moderate illumination variation, while performances noticeably drop when both illumination and pose changes occur.

6

- Pose changes affect the authentication process, because they introduce projective deformations and self-occlusion. Even if methods dealing with up to 32 head rotation exists, they do not solve the problem considering that security cameras can create viewing angles that are outside of this range when positioned. On the contrary, with exception of extreme expressions such as scream, the algorithms are relatively robust to *facial expression*.
- Another important factor is the *time delay*, because the face changes over time, in a nonlinear way over long periods. In general, this problem is harder to solve with respect to the others and not much has been done especially for age variations.
- At last, occlusions can dramatically affect face recognition performances, in particular if they located on the upper-side of the face, as documented in literature.

Current Work Review

Currently, facial recognition is a heavily researched field, with researchers studying numerous different algorithms. Figure 1 shows some of the different methods that are being tested [3]. Some popular methods are: Eigenfaces, Fisherfaces, and Local Binary Pattern Histogram. Many of the listed methods can use sample training data that has been compiled into databases by large research organizations (see Figure 2) [3]. One project, OpenCV, currently uses the Eigenfaces, Fisherfaces, and Local Binary Pattern Histogram algorithms to do facial recognition. These same algorithms codes were used to test, compare, and improve on the Local Binary Pattern Histogram in this project.

Method		Databases	Image	Max G-Max P	Time	Recog.	Expr.	Ш.	Pose	Occl.	Age
Authors	Name		size		lapse	rate (%)					
Martinez and Kak (2001)	PCA	AR-Faces	85 × 60	100-250	No	70		No	No	No	No
Martinez and Kak (2001)	LDA	AR-Faces	85 × 60	100-250	No	88		No	No	No	No
Belhumeur et al. (1997) Yu and Yang (2001)	Fisherfaces Direct LDA	VALE ORL	112×92	144-16 200-200	No No	99.6 90.8	Yes Yes	Yes Yes	No Yes	No No	No No
Lu et al. (2003)	DF-LDA	ORL UMIST	112×92 112×92	200-200 160-415	Yes No	96 98		Yes No	No No	No No	No No
Cevikalp et al. (2005)	DCV	Yale AR-Faces	126 × 152 229 × 299	15-150 350-350	No Yes	97.33 99.35		Yes	No	No	No
Bartlett Marian et al. (2002)	ICA	FERET	60 × 50	425-421	Yes	89	Yes	No	No	No	No
Lin et al. (1997)	PDBNN	SCR FERET ORL	80 × 20	320-1280 200-200	No No No	100 99 96	Yes Yes	Yes Yes Yes	Yes No Yes	No No No	No No No
Joo Er et al. Meng et al. (2002)	RBF	? ORL PropertyDB	160 × 120	300-300		98.1 100	Yes		Yes	No	No
Perronnin and Dugelay (2003)	HMM	FERET	128×128	500-500	No	97	Yes	No	No	No	No
Lades et al. (1993)	DLA	PropertyDB	128×128	88-88	No	90.3	Yes		Yes	No	No
Liu (2004)	Gabor EFM	FERET ORL	128 × 128 128 × 128	200-100 200-200	No No	99 100	Yes Yes	No No	No Yes	No No	No No
Wiskott et al. (1997)	EGM	FERET PropertyDB	256 x 384	250-250 108-//	No	80 90	Yes Yes		Yes Yes	No No	No No
Garcia et al. (2000)	WPA	MIT FERET	480 x 640 256 x 384	155-155 200-400		80.5 89	Yes	Yes		No	no
Kouzani et al. (1997) Tan and Tan (1999) Ebrahimpour-Komleh et al. (2001)	IFS IFS IFS	PropertyDB ORL MIT	64 × 64 92 × 112 480 × 640	100–100 200–// 90–90	No	100 95 90		No	No Yes	No No No	No No No
Chen et al. (2003) Socolinsky and	Th-Infrared Thermal	PropertyDB PropertyDB	99 × 132	166-166 770-2310	No Yes	98 93	Yes Yes	Yes Yes	No No	No No	No No
Selinger (2004b) Buddharaju et al. (2004)	Th-Spectrum	Equinox		225-2500		86.8	Yes		Yes	No	No
Pan et al. (2003)	Hyperspectral	PropertyDB		200-1200	Yes	92	No	Yes	No	No	No
Open question methods Gao and Leung (2002)	LEM	Bern AR-Faces Yale		40-160 112-336 15-150	No	72.09 86.03 85.45	Yes	Yes Yes	Yes No No	No No No	No No No
Kim et al. (2003)	ICA	Subset of AR Faces, Yale, ORL, Bern and FERET	46 x 56	1685-1490		98		Yes	Yes	No	No
Li et al. (2004)	LDA/GSVD LDA/QR	CMU_PIE/Pose27		68-1360	No	100 99,53	No	Yes	No	No	No
		YaleB/Pose00		80-432	No	99 98.03		Yes	No	No	No
Georghiades et al. (2001)	Cones Gen.	Yale B	36 × 42	450-4050	No	97	No	Yes	Yes	No	No
Okada and von der Malsburg (2002)	Linear Subspaces	ATR-Database		2821-804	No	98.7	n	No	Yes	No	No
Gross et al. (2002)	Eigen Lights	CMU-PIE		5304-5304	No	36	No	Yes	Yes	No	No

Figure 1. Facial Recognition Algorithms [3]

Name	RGB/ gray	Image size	Number of people	Pictures/ person	Number of conditions	Available	Web address
AR Face Database*	RGB	576 × 768	126 70 Male 56 Female	26	i, e, o, t	Yes	http://rvl1.ecn.purdue.edu/~aleix/ aleix_face_DB.html
Richard's MIT database	RGB	480 × 640	154 82 Male 74 Female	6	p, o	Yes	
CVL Database	RGB	640×480	114 108 Male 6 Female	7	p, e	Yes	http://www.lrv.fri.uni-lj.si/ facedb.html
The Yale Face Database B*	Gray Scale	640×480	10	576	p, i	Yes	http://cvc.yale.edu/projects/ yalefacesB/yalefacesB.html
The Yale Face Database*	Gray Scale	320 × 243	15 14 Male 1 Female	11	i, e	Yes	http://cvc.yale.edu/projects/ yalefaces/yalefaces.html
PIE Database*	RGB	640 imes 486	68	~608	p, i, e	Yes	http://www.ri.cmu.edu/projects/ project_418.html
The UMIST Face Database	Gray	220×220	20	19-36	р	Yes	http://images.ee.umist.ac.uk/danny/ database.html
Olivetti Att – ORL*	Gray	92×112	40	10		Yes	http://www.uk.research.att.com/ facedatabase.html
(JAFFE) Database	Gray	256×256	10	7	e	Yes	http://www.mis.atr.co.jp/~mlyons/ jaffe.html
The Human Scan Database	Gray	384×286	23	~66		Yes	http://www.humanscan.de/support/ downloads/facedb.php
The University of Oulu Physics- Based Face Database	Gray	428 × 569	125	16	i	Cost \$50	http://www.ee.oulu.fi/research/imag color/pbfd.html
XM2VTSDB	RGB	576 × 720	295		р	Frontal \$153 Side \$229.5	http://www.ee.surrey.ac.uk/ Research/VSSP/xm2vtsdb/
FERET*	Gray RGB	256 × 384	30.000		p, i, e, i/o, t	Yes	http://www.itl.nist.gov/iad/humanic feret/

The "* points out most used databases. Image variations are indicated by (i) illumination, (p) pose, (e) expression, (o) occlusion, (i/o) indoor/outdoor conditions and (t) time delay.

Figure 2. Training Set Databases [3]

CHAPTER THREE METHODOLOGY

The three methods that were used and compared in this project were: Eigenfaces, Fisherfaces, and Local Binary Patterns Histograms. The three methods were compared by using the OpenCV project, collecting a number of photos (in the range of 20-50 per training person,) uploading images to the program for training, and then comparing the accuracy of each method to see if it could correctly identify a live video of some of the trained subjects.

Eigenfaces

To generate a set of Eigenfaces, principal component analysis (PCA) must be applied on a set of images of different human faces. This is done to "identify vectors which best account for the distribution of face images within" the image space [4]. First, a sample set of facial images must be gathered. It is ideal to use sample data with similar lighting and have the faces in similar poses with the eyes and mouths aligned across the images. The next step is to compute and subtract the mean. Following this step, the covariance matrix is calculated. Next, the eigenvectors and eigenvalues will be calculated from the covariance matrix. The eigenvectors all have the same dimensionality as the original images and are therefore also considered an image. Thus these are

11

called Eigenfaces. The eigenvectors are then ordered in descending order by their eigenvalues. The Eigenfaces with the largest eigenvalue are kept.




Figure 3. Principal Component Analysis Dimensionality Reduction https://onlinecourses.science.psu.edu/stat857/node/35

Fisherfaces

The Fisherface method is similar the Eigenface method, but instead uses a technique called Fisher's linear discriminant (FLD) analysis along with PCA.

PCA is used to reduce the dimensionality from N - c, and then FLD to further

reduce the dimensionality to c - 1, where N is the number of images in the training data and c is the number of classes. Because the Eigenface method does not take into consideration classes, some discriminative data could possibly be lost when discarding data during the reduction. The advantage to Fisherfaces is that it is less sensitive to differences in lighting and the positions of the faces in the sample data compared to Eigenfaces method. After sample data is gathered, the scatter matrices are calculated. This method maximizes the ratio of between-class scatter and within-class scatter. Figure 5 shows the difference in dimensionality reduction using both PCA and FLD with two classes. Note that using PCA, both class 1 and class 2 are not kept separate, as is the case when using FLD. This demonstrates the maximization of the ratio of class scatter.




Figure 4. Principle Component Analysis and Fisher Linear Discriminant https://onlinecourses.science.psu.edu/stat857/node/35

Local Binary Patterns Histograms

The Local Binary Patterns (LBPH) method compares the histogram of a displayed image and compares it to the original sample input images. This particular method examines a provided image by dividing the image into smaller regions to generate binary patterns for each pixel. It then graphs the binary patterns to a single feature histogram by comparing the neighbors of each pixel. A gray value is assigned to the center pixel as well as to each neighbor pixel. If the gray scale value of each neighbor is greater than or equal the center pixel's

gray scale value, then a '1' value is assigned to the neighbor pixel. If the value is less, a '0' value is assigned. The binary pattern is generated by starting with the top left pixel's binary value, and appending each additional binary value of each pixel by moving in a clockwise pattern. This binary value is then converted to a decimal value. This is repeated for every pixel and a histogram is eventually generated for this region. This process is done for every region, and then the histograms for each region are concatenated into one large histogram.




Figure 5. Spatial Histograms http://bytefish.de/blog/local_binary_patterns/

When an image is presented to predict if the image is known to the machine, it uses the same technique and compares the distances of the two histograms to see if the images are similar. The advantage to this method, as written by, is that several studies have demonstrated that using this method provides consistently accurate results for face recognition, both in terms of speed

and discrimination performance [5]. This method also seems to be strong for facial images with varying facial expressions, lighting conditions, image rotation and aging persons. The Local Binary Pattern Histogram has evolved to now contain two different methods, an "original" and an "extended."

Original Local Binary Patterns Histogram

The Original Local Binary Pattern (olbp) Histogram uses eight neighbors and uses a radius of one. That means that every pixel is compared with each of the eight neighbor pixels that touch it. The one disadvantage to this method is that its computational time can be large, depending on the number of pixels in an image. For example, an image with a size of 200 x 200 pixels will have 40,000 pixels that will need to be compared with eight neighbors.




Figure 6. Binary Values from Neighbors Comparison [5]

Below is the OpenCV code for calculating the binary values of eight neighbors depending on the gray scale value.

```
for(int i=1;i<src.rows-1;i++) {
    for(int j=1;j<src.cols-1;j++) {
        __Tp center = src.at<_Tp>(i,j);
        unsigned char code = 0;
        code |= (src.at<_Tp>(i-1,j-1) >= center) << 7;
        code |= (src.at<_Tp>(i-1,j) >= center) << 6;
        code |= (src.at<_Tp>(i-1,j+1) >= center) << 5;
        code |= (src.at<_Tp>(i,j+1) >= center) << 3;
        code |= (src.at<_Tp>(i+1,j+1) >= center) << 3;
        code |= (src.at<_Tp>(i+1,j+1) >= center) << 2;
        code |= (src.at<_Tp>(i+1,j) >= center) << 2;
        code |= (src.at<_Tp>(i+1,j-1) >= center) << 1;
        code |= (src.at<_Tp>(i+1,j-1) >= center) << 0;
        dst.at<unsigned char>(i-1,j-1) = code;
    }
}
```

Figure 7. Original Local Binary Pattern Source Code

Extended Local Binary Patterns Histogram

The Extended Local Binary Pattern (elbp) Histogram is a bit different than the original, in that it allows a user to specify the number of neighbors to use as well as the radius.




Figure 8. Extended Local Binary Pattern Neighbors Calculation [5]

When the default neighbor count and radius change, a new formula needs to be used to calculate the x and y coordinate of the neighboring pixels. Bilinear interpolation will need to be done in the event that the x and y coordinate of the neighbor's pixels are not in the center of the pixel.




Figure 9. X and Y Coordinates of Extended Local Binary Pattern http://www.sciencedirect.com/science/article/pii/S0262885612000066

The formula is as follows:

Equation 1. Formula for X and Y Coordinates

$$\left(-r\sin\left(\frac{2\pi n}{p}\right), r\cos\left(\frac{2\pi n}{p}\right)\right) \tag{1}$$

where *r* is radius and *p* is the number of neighbors.

Below is the OpenCV code for calculating the binary values of a given set of

neighbors.

```
for(int n=0; n<neighbors; n++) {</pre>
        // sample points
        float x = static cast<float>(-radius *
sin(2.0*CV_PI*n/static_cast<float>(neighbors)));
        float y = static_cast<float>(radius *
cos(2.0*CV_PI*n/static_cast<float>(neighbors)));
        // relative indices
        int fx = static_cast<int>(floor(x));
        int fy = static_cast<int>(floor(y));
        int cx = static_cast<int>(ceil(x));
        int cy = static_cast<int>(ceil(y));
        // fractional part
        float ty = y - fy;
        float tx = x - fx;
        // set interpolation weights
        float w1 = (1 - tx) * (1 - ty);
        float w^2 = tx * (1 - ty);
        float w3 = (1 - tx) *
                                   ty;
        float w4 = tx *
                                   ty;
        // iterate through your data
        for(int i=radius; i < src.rows-radius;i++) {</pre>
            for(int j=radius;j < src.cols-radius;j++) {</pre>
                // calculate interpolated value
                float t = static_cast<float>(w1*src.at<_Tp>(i+fy,j+fx) +
w2*src.at<_Tp>(i+fy,j+cx) + w3*src.at<_Tp>(i+cy,j+fx) + w4*src.at<_Tp>(i+cy,j+cx));
                // floating point precision, so check some machine-dependent epsilon
                dst.at<int>(i-radius,j-radius) += ((t > src.at<_Tp>(i,j)) || (std::abs(t-
src.at<_Tp>(i,j)) < std::numeric_limits<float>::epsilon())) << n;</pre>
            }
        }
```

Figure 10. Extended Local Binary Pattern Source Code

Pros and Cons of Algorithms

Each of the three algorithms mentioned has its own advantages and disadvantages. There are many different algorithms for facial recognition due to no single method being the most optimal in one area, without sacrificing an advantage in another area. Table 1 lists the different pros and cons of the three tested algorithms.

Table 1. Algorithm Pros and Cons

Algorithm	Pros	Cons
Eigenfaces	-Agnostic to object even being a face -Adequately reduces statistical redundancy in a face image representation	-Sensitive to light -Sensitive to pose and facial expressions -Sensitive to pixel misalignment
Fisherfaces	-Achieves greater between-class scatter, thus making classification easier compared to Eigenfaces -Insensitive to light	-If between-class scatter is large, then within-class scatter could be large
Local Binary Patterns	-Resistance to lighting changes -Low computational complexity -Ability to code fine details	-Produce long histograms, which can slow down recognition speed, especially on large training database -Can miss local structure as doesn't

-One of the best performing texture descriptures	consider effect of center pixel -Small spatial support, in its basic form cannot properly detect large scale textual structures (olb)
--	--

Local Binary Patterns Histogram Flowchart

The steps for a generic facial recognition flowchart is described in Figure 10. Every facial recognition algorithm needs a training method to calculate a comparison reference. The training method for the Local Binary Pattern Histogram is described in Figure 11. In the training method for the Local Binary Pattern Histogram algorithm, the two methods that compute the most calculations are the extended local binary pattern (elbp) and spatial_histogram methods. The elbp method calculates the X and Y coordinates of the eight neighbors for each center pixel that will be used to calculate the binary pattern. The binary pattern is then calculated by comparing the gray scale values of the eight neighbors to the center pixel. The binary value is then converted into a decimal number (see Figure 12). The spatial histogram function calculates a histogram for each image. The function first calculates how many regions will be used for the training image. This is determined before run time by manually entering a static value into the code by for a width and height to be used. The size of the region is calculated by dividing the number of pixels of the image by

both the width and height. After the size of each region is calculated, the range of each region must then be determined and the decimal values that were calculated for each pixel in the elbp method are stored in a matrix ordered by region. A histogram for each region is then calculated using the normalized decimal values. All of the regional histograms are then concatenated into one large histogram. These are then stored in a separate matrix (see Figure 13). This is done for each image in the training set and added to a vector that stores the matrix of each image. This completes the training function. The prediction function performs both the elbp and spatial_histogram functions, similar to the training function. The difference is that the information is only calculated on the live video image, rather than on the whole training set. The histogram of the live image is then compared to the histogram of every image of the training set that is stored in the vector. The histograms are compared using the Chi Square Distance method, which can be defined in Equation 2.

Equation 2. Chi Square Distance Formula

$$x_{\omega}^{2}(x,\varepsilon) = \sum_{j,i} \omega_{j} \frac{(x_{i,j}-\varepsilon_{i,j})^{2}}{x_{i,j}+\varepsilon_{i,j}}$$
⁽²⁾

The distance between the two histograms is stored as variable *dist*. Each distance is compared with the lowest distance (the initial comparison automatically defaults to the least distance). If the new distance is less than the

least distance, the new distance becomes the least distance. If the new distance is greater, no values change and the next image is compared to the live image. After each image in the training set has been compared to the live image, whichever image has the lowest distance is determined to be the prediction result (see Figure 14).




Figure 11. Facial Recognition Flow Chart




Figure 12. Local Binary Pattern Train Flow Chart






Figure 13. Extended Local Binary Pattern Flow Chart



LBPH Spatial Histogram (Original) Flow Chart

Figure 14. Local Binary Pattern Spatial Histogram (Original) Flow Chart






Figure 15. Local Binary Pattern Predict Flow Chart

CHAPTER FOUR

IMPLEMENTATION AND EXPERIMENTAL RESULTS

Downloading OpenCV, CMake, and Visual Studios

Below are the steps to setup the OpenCV projects in Visual Studios:

 Install a preferred version of Visual Studios to build and compile the project. Note that depending on the version of Visual Studios installed, there may be some necessary changes to building the project with CMake; the reason being that the different versions of Visual Studios (i.e.: 2010, 2012, 2015, etc.) can occasionally use different libraries. The latest trial version can be downloaded from

https://www.visualstudio.com/downloads/.

- Obtain the necessary project files by downloading the project from OpenCV which can be found at <u>http://opencv.org/releases.html</u>.
- Download and install CMake to extract and build the OpenCV project.
 This can be downloaded from the website at <u>https://cmake.org/download/</u>.
- 4. Run CMake to build the OpenCV project. One thing to note is that the facerec_eigenfaces.cpp, facerec_fisherfaces.cpp, facerec_lbph.cpp, facerec_save_load.cpp, and facerec_video.cpp were not originally in the samples folder for the OpenCV project. If these files are not in the proper location when building the project, the executables will not be generated and will be unable to run. These five files have to copied from

C:\opencv\sources\modules\contrib\doc\facerec\src to

C:\opencv\sources\samples\cpp.

5. Now that these files have been copied to the appropriate location, CMake can be used to generate the project. Below are some screenshots of the different settings that were determined to work best to generate the project. The first step is to open CMake and choose the location of the OpenCV source files and also where the binaries may be saved. Next, click on the "Configure" button. Figures 16-19 shows the settings that were used in this project. Click the "Generate" button. Because Visual Studios 2010 was used in this project, the native environment for VS10 was chosen. This will vary depending on the version of Visual Studios that is installed.

CMake 3.0.0 - C:/OpenCVbinary					— D <mark>—</mark> X
File Tools Options Help					
Where is the source code: C:/opencv/source	es				Browse Source
Where to build the binaries: C:/OpenCVbinary	у				Browse Build
Search:				Grouped 🔲 Advanced 📫 Add Entr	ry 🔀 Remove Entry
Name	Value				
ANT EXECUTABLE	ANT EXECUTABLE-NOTFOUND				
BUILD DOCS					
BUILD EXAMPLES					
BUILD_JASPER					2
BUILD_JPEG					
BUILD OPENEXR					
BUILD PACKAGE					
BUILD PERF TESTS	V				
BUILD PNG					
BUILD_SHARED_LIBS					
BUILD_TBB					
BUILD_TESTS					
BUILD TIFF					
BUILD_WITH_DEBUG_INFO					
BUILD_WITH_STATIC_CRT					
BUILD_ZLIB					
BUILD_opencv_apps					
BUILD_opencv_calib3d					
BUILD_opency_contrib					
BUILD_opencv_core	V				
BUILD_opencv_core BUILD_opencv_features2d					
BUILD_opencv_flann					
BUILD_opencv_tiann BUILD_opencv_gpu					
BUILD_opencv_highgui BUILD_opencv_imgproc					
BUILD_opency_legacy					
BUILD_opencv_ml BUILD_opencv_nonfree					
BUILD_opency_nonfree					
	Press Conf	figure to update and display new values in red,	then press Generate to generate selected build files	3.	
Configure Generate Current Gene	erator: Visual Studio 10 2010				
command to set the policy and	suppress this warning.	_			(
Target "opency haartraining en	ngine" links to itself				
	aloners lies -Wno-dev to summass				
4					4
වු 🔽 🧿	📋 🐺 🔺 ≤	0		► ∞ 🛱 .	.al

Figure 16. CMake Settings 1




Figure 17. CMake Settings 2

	Make 3.0.0 - C:/OpenC\ Tools Options H				
ard: advanced Advance	ere is the source code:	C:/opencv/sources			Browse Sour
ard: advanced Advance	re to build the binaries:	C:/OpenCVbipary			Browse Built
ame Value AABLE PRECOMPUTED HEADORS AABLE SNE VALUE V		ci/openeronary			
VAREL ROKY WARNINGS Image RefCOMPUTED HEADRES VAREL SOLUTION FOLDERS Image Solution Folders VAREL WINT MODE Image Solution Folders VAREL SOLUTION FOLDERS Image Solution Folders GGAP (INCLUDE PATH C/OpenCVbinary/bin GGAP (INSLUE PATH GGEAP(INCLUDE PATH-NOTFOUND GGAP (INSLUE FOR	rch:			Grouped Advanced	3d Entry Remove E
MalE SPRICOMPLED, HEADERS VALES, SOUTON-FOLDERS VALES, SOUTON-FOLD	me		Value		
ABLE SOLUTION FOLDERS ABLE SSE					
MARE SS2 MARE WINT, MODE NATIVE ARE WINT, MODE NATIVE ARE WINT, MODE NATIVE ARE WINT, MODE NATIVE GRAP, MULUDE PATH A GRAP, MULUDE PATH A GRAP, MULUDE PATH FOR COMPARIANCE	ABLE_PRECOMPILED_H	IEADERS			
ABLE_SS2 ABLE_WINKT_MODE_MATIVE ABLE_WINKT_MODE_MATIVE ABLE_WINKT_MODE_MATIVE ABLE_WINKT_MODE_MATIVE ABLE_WINKT_MODE_MATIVE ABLE_WINKT_MODE_MATIVE ABLE_MODE_MATIVE ABLE_MODE_MODE_MATIVE ABLE_MODE_MODE_MODE_MODE_ABLE_MODE_ABLE_MODE_ABLE_MODE_ABLE_MODE_ABLE_MODE_ABLE_MODE_ABLE_MODE_ABLE_MODE_ABLE_MODE_ABLE_MODE_MODE_MODE_MODE_MODE_MODE_MODE_MOD		ERS			
ABLE_SS2 ABLE_WINKT_MODE_MATIVE ABLE_WINKT_MODE_MATIVE ABLE_WINKT_MODE_MATIVE ABLE_WINKT_MODE_MATIVE ABLE_WINKT_MODE_MATIVE GIGAPUNCLUDE_PATH ACTOONND SAPU_INCLUDE_PATH GIGAPUNCLUDE_PATH GIGAPUNCLUDE_PATH GIGAPUNCLUDE_PATH GIGAPUNCLUDE_PATH GIGAPUNCLUDE_PATH FUNCTURANPUNCS GIGAPUNCUDE_PATH FUNCTURANPUNCS GIGAPUNCUDE_FUNCTURANPUNCUD FUNCTURANPUNCS GIGAPUNCUDE_FUNCTURANPUNCUD FUNCTURANPUNCS GIGAPUNCUDE_FUNCTURANPUNCUD FUNCTURANPUNCUDE_FUNCTURANPUNCUD FUNCTURANPUNCUD FUNCTU					
ABLE_WINT_MODE_NATIVE ABLE_WINT_MODE_NATIVE GIGGAPU_INCLUDE_PATH CC/OpenCVbinary/bin GIGGAPU_INCLUDE_PATH ACTFOUND SAPU_INCLUDE_PATH GIGGAPU_INCLUDE_PATH-NOTFOUND TAIL_CRAIPLES GIGGAPU_INCLUDE_PATH GIGGAPU_INCLUDE_PATHADTFOUND TAIL_CRAIPLES GIGGAPU_INCLUDE_PATHADTFOUND FINDUE_DATHADTFOUND FINDUE_DATHADTFO					
ABLE_UNINET_MODE_NATIVE ABLE_UNINET_MODE_NATIVE ABLE_UNINET_MODE_NATIVE SAPU_INCLUDE_PATH CC/OpenCVbinary/bin SAPU_INCLUDE_PATH CC/OpenCVbinary/bin SAPU_INCLUDE_PATH ANDTFOUND TALL_CPLANPELS TALL_PITHON_EXAMPLES CV_DETAM_NOUSES_PATH CV_DETAM_CV_DETAM_NOUSES_PATH CV_DETAM_NOUSES_PATH CV_DETAM_CV_DETAM_NOUSES_PATH CV_DETAM_CV_DE	ABLE_WINRT_MODE				
GAPLINCLUDE PATH GIGEAPLINCLUDE PATH-NOTFOUND GAPLINEARS GIGEAPLINEARES-NOTFOUND STALL CPATE DISTING STALL CPAT					
GEAP_INCLUDE_PATH GIGEAP_INCLUDE_PATH-NOTFOUND GEAP_INCLUDE_PATH-NOTFOUND STALL_CEARTE_DISTRB GIGAP_INCLUDE_PATH-NOTFOUND STALL_FIST GIGAP_INCLUDE_PATH-NOTFOUND STALL_FIST FIST FIST FIST FIST FIST FIST FIST	ECUTABLE_OUTPUT_PA	TH			
GEAP LIBRARIES GIGEAP LIBRARIES NOTFOUND GEAP LIBRARIES NOTFOUND STALL CEAPA DISTRIB GIGEAP LIBRARIES NOTFOUND STALL CEAPA DISTRIB GIGAP LIBRARIES GIGAP LIBRA	SEAPI_INCLUDE_PATH				
STALL C EXAMPLES STALL C EXAMPLES STALL C EXAMPLES STALL TESTS ST	SEAPI LIBRARIES		GIGEAPI LIBRARIES-NOTFOUND		
STALL C EXAMPLES STALL C EXAMPLES STALL C EXAMPLES STALL TESTS ST	STALL CREATE DISTRIB				
STALL PTHON EXAMPLES STALL TSTS STALL PTHON EXAMPLES STALL TSTS ST	TALL_C_EXAMPLES		V		
STALL TESTS	STALL PYTHON EXAMP	PLES			
>H PATH IPP_HPATH-MOTFOUND ERKV_CONFS_FLE_NCULDE_DER C/Oper/Chinary ERKV_CONFS_FLE_NCULDE_DER IPP ERKV_CONFS_FLE_NCULDE_DER IPP ERKV_CONFS_FLE_NCULDE_DER IPP APL_NCULDE_PATH IPP APL_NCULDE_PATH Cregistry APL_NCUDE_FATH IPP APL_NCUDE_PATH Cregistry MCONSOC_PATH /registry MCON					
PENCY ETRA, MODULES, PATH PENCY ETRA, MODULES, PATH MOVINGS, REFERRORS APLINCIUDE, PATH PVAPILINCLUDE, PATH Cregistry NDOVIS, SDC, PATH Cregistry TH, CUBLAS O Include IEEE1394 support TH, CUBLAS O Include IEEE1394 support TH, CUPAT O Inth, DSHOW Origone Creeneda Configure to update and display new values in red, then press Generate to generate selected build fles. Configure Configure 1 Configure 2 Configure 3 Configure 3 Configure 3 Configure 4 Configure 4 Configure 5 Conf			IPP H PATH-NOTFOUND		
PENCY ETRA, MODULES, PATH PENCY ETRA, MODULES, PATH MOVINGS, REFERRORS APLINCIUDE, PATH PVAPILINCLUDE, PATH Cregistry NDOVIS, SDC, PATH Cregistry TH, CUBLAS O Include IEEE1394 support TH, CUBLAS O Include IEEE1394 support TH, CUPAT O Inth, DSHOW Origone Creeneda Configure to update and display new values in red, then press Generate to generate selected build fles. Configure Configure 1 Configure 2 Configure 3 Configure 3 Configure 3 Configure 4 Configure 4 Configure 5 Conf	ENCV CONFIG FILE IN	CLUDE DIR	C:/OpenCVbinary		
ENCV_WARNINGS_ARE_ERRORS Image: Configure to update and display new values in red, then press Generate to generate selected build files.	ENCV EXTRA MODULE	S PATH			
APLINCLUDE_PATH PUAP_INCLUDE_PATH-NOTFOUND APLINCLUDE_PATH-NOTFOUND MOUND_SDX_ATH Cregistry NDOWS_SDX_PATH Cregistry Int_SINPES V Int_SINPE V Int_SINPE V Int_SINPE V Int_SINP					
SUAL_STUDIO_PATH C/registry TH_I384 TH_USALSAFI TH_I384 TH_USALSAFI TH_USALSAF					
NDOWS SDC/RATH /registry TH 258 // Include IEEE1394 support TH 259 // Include IEEE1394 support TH 2004 // Include IEEE1					
THL 134 0 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1 1					
THL CSTRIPS I Include IEEE1394 support THL CUBA I Include IEEE1394 support Include IEEE1					
TH: CUBLAS Include IEEE1394 support TH: CUDA TH: CUDA TH: CUDFT TH: CUDFT FILEGEN Frees Configure to update and display new values in red, then press Generate to generate selected build fles. Frees Configure to update and display new values in red, then press Generate to generate selected build fles. Frees Configure to update and display new values in red, then press Generate to generate selected build fles. Frees Configure to update and display new values in red, then press Generate to generate selected build fles. Frees Configure to update and display new values in red, then press Generate to generate selected build fles. Frees Configure to update and display new values in red, then press Generate to generate selected build fles. Frees Configure to update and display new values in red, then press Generate to generate selected build fles. Frees Configure to update and display new values in red, then press Generate to generate selected build fles. Frees Configure to update and display new values in red, then press Generate to generate selected build fles. Frees Configure to update and display new values in red, then press Generate to generate selected build fles. Frees Configure to update and display new values in red, then press Generate to generate selected build fles. Frees Configure to update and display new values in red, then press Generate to generate selected build fles. Frees Configure to update and display new values in red, then press Generate to					
TH CUDA C C C C C C C C C C C C C C C C C C C				Include IEEE1394 support	
TH, DSHOW V TH, EGEN V Press Configure to update and display new values in red, then press Generate to generate selected build files. Infigure Generate Current Generator: Visual Studio 10 2010 Command to set the policy and suppress this varning. Target Vestor basetratining_engine® links to itself.					
TH, DSHOW					
TH-EIGEN Press Configure to update and display new values in red, then press Generate to generate selected build fles. Configure Generate Ourrent Generator: Visual Studio 10 2010 Constand to set the policy and suppress this varning. Target "update" and the set the policy and suppress this varning. Target To update and Management Lines to install.					
Press Configure to update and display new values in red, then press Generate to generate selected build files. Configure Configure Courter Generator: Visual Studio 10 2010 Command to set the policy and suppress this warning. Target "openor_heartraining, engine" links to itself.					
Configure Generate Current Generator: Woud Studo 10 2010 command to set the policy and suppress this warning. Target "openor_heartraining_engine" links to issail.					
Command to set the policy and suppress this warning. Target "uppercy heartraining engine" links to isself. Is warning is for another despingers. Isse albender to annouse 't		_	Press Configure to update and display new values in re-	J, then press Generate to generate selected build files.	
Target "opency haartraining engine" links to itself.	Configure Generate	Current Generator: Vi	ual Studio 10 2010		
is verning is for project developers. Use -Who-dev to suppress it	command to set the	e policy and suppre	ss this warning.		
is warning is for project developers. Use -Wno-dev to suppress it	Target "opency has	artraining engine"	links to itself.		
m			Hee -Who-dev to sumpress it		

Figure 18. CMake Settings 3

CMake 3.0.0 - C:/OpenC	Vbinary			
File Tools Options H				
Where is the source code:	C:/opencv/sources			Browse Source
Where to build the binaries:	C:/OpenCVbinary			Browse Build
Search:			🔲 Grouped 📃 Advanced 🛛 🗳 Add B	Entry 🛛 🗱 Remove Entry
Name	Value			
WITH CUDA				
WITH CUFFT				
WITH_DSHOW				
WITH_EIGEN				
WITH FFMPEG				
WITH_GIGEAPI				
WITH INTELPERC	V			
WITH_IPP	\checkmark			
WITH JASPER				
WITH_JPEG	\checkmark			
WITH_MSMF				
WITH_NVCUVID				
WITH_OPENCL				
WITH_OPENCLAMDBLAS	\checkmark			
WITH_OPENCLAMDFFT				
WITH_OPENEXR	\checkmark			
WITH_OPENGL				
WITH_OPENMP				
WITH_OPENNI	\checkmark			
WITH_PNG				
WITH_PVAPI				
WITH_QT				
WITH_TBB				
WITH_TIFF	\checkmark			
WITH_VFW				
WITH_VTK	(m)			
WITH_WIN32UI	V			
WITH_XIMEA				
	Pr	ress Configure to update and display new values in red, then press Generate to generate selected build files.		
Configure Generate	Current Generator: Visual Studio 10 2010			
command to set the	e policy and suppress this warning.	_		
				• •
	artraining_engine" links to itself.			-
This varning is for	project developers. Hes -Wno-dev to ev	Innress it		E F
🚱 🔽 🔇	🕘 📋 🐺 📐	🐼 💘	- Ē	

Figure 19. CMake Settings 4

Compiling, Executing, and Testing the Samples

1. Studios. By changing "Treat Warnings As Errors" to "No", the project

was then able to compile easier (see Figures 20-22).

tion Explorer	▼ 🕂 × facere	c_video.cpp ×			
2		lobal Scope)		✓ ➡ main(int argc, const char * argv[])	
Solution 'OpenCV' (270 projects)			->predict(face_resized);		
🚞 3rdparty	= 7		11 we've found out to the orig		
ImImf			green rectangle around the de ce_i, CV_RGB(0, 255,0), 1);	etected face:	
b 🛐 libjasper			will annotate the box with:		
Iibjpeg			at("Prediction = %d", predict:	ion):	
Iibpng			ion for annotated text (make :		
Iibtiff		<pre>// put illegal values i</pre>			
III zlib		<pre>int pos_x = std::max(fa</pre>			
applications		<pre>int pos_y = std::max(fa</pre>			
opencv_createsamples		// And now put it into			
opencv_haartraining		putlext(original, box_1	text, Point(pos_x, pos_y), Poi	IT_HERSHEY_PLAIN, 1.0, CV_RGB(0,255,0), 2.0);	
opencv_haartraining_engin	e	// Show the result:			
opencv_performance		imshow("face_recognizer", o	original);		
> 3 opencv_traincascade		// And display it:			
CMakeTargets		char key = (char) waitKey(2			
INSTALL		<pre>// Exit this loop on escape</pre>	e:		
PACKAGE Ininstall		if(key == 27) break;			
 Image: Image: Ima		break;			
		return 0;			
🔆 extra	100 %	▼ 4			+
opency_modules Image: Second control opency perf tests	Output				- ↓
opencv_pen_tests					* *
modules		output from: Build chake does not need to re-run pect	- 🖓 🖓		
modules opency_calib3d		Chake does not need to re-run bec.	ause c: (opencybinary(modules)	video\chakeriies\generate.stamp is up-to-date.	
opency_contrib		1Compile:			
opency_contrib		opencv_test_video_pch.cpp			
opency_core		opencv_test_objdetect_pch.cpp			
anoncy flann	T 265	ICompile: opency test imgproc pch.cpp			
III Prope	rty Manager	opencv_test_imgproc_pch.cpp			
Solut ᄰ Class 🔚 Prop 📷					

Figure 20. Visual Studios Settings 1

Click on Property Manager tab.




Figure 21. Visual Studios Settings 2

Click on Properties.




Figure 22. Visual Studios Settings 3

On new window, highlight file **(Example) facerec_video**. Click Configuration Properties->C/C++->General. Change **"Treat Warnings As Errors"** to **"No"**. Next change back to Solutions tab. Now build the solution.

2. The next step is to put together a collection of images for training. Some sample images of celebrities were taken from offline and used. Additional photos were taken of other test subjects to use as training data. The images were edited by cropping out each image background other than the face. A program called IrfanView, which can be downloaded from many different repositories at http://www.irfanview.com/main_download_engl.htm, was used to edit the size of the images and make them square at 200x200 pixels.

3. After the images have been edited, a text (.txt) file needs to be created with the image location along with a label for the image. This is an example of what used for each line in the text file for this project: **C**:\

Pictures\Project2\Brad_Pitt_01.jpg;0. For better training results, a large enough number of images per person needs to be used in order to accurately recognize an individual. This can be determined through trial and error. For this project, 50 images per subject were used.

4. At this point, the facial recognition application is able to tested out. A command prompt needs to be opened and the following commands need to be entered and run C:\OpenCVbinary5\bin\Debug\cpp-example-

facerec_video.exe

C:\opencv\sources\data\haarcascades\haarcascade_frontalface_default. xml C:\celebrities2.txt 1. This command will vary depending on what name was chosen for location to build the binaries in CMake, where the location of the haarcascade_frontalface_default.xml is, where the training images are stored, and the device number of the webcam.

5. To simplify the run process, the commands can be entered into a script file and the script file can be run rather, than having to run the commands each time. By default, the Fisherfaces method will be the one that is used for facial recognition.

38



Figure 23. Prediction Image

The method used is changed in the **facerec_video.cpp** file. All of the code files were modified using Visual Studios. Below are the lines that need to be modified. Only one can be uncommented at a time.

// Create a FaceRecognizer and train it on the given images: Ptr<FaceRecognizer> model = createFisherFaceRecognizer(); //Ptr<FaceRecognizer> model = createEigenFaceRecognizer(); //Ptr<FaceRecognizer> model = createLBPHFaceRecognizer();

Figure 24. Facerec_video

A walkthrough can be found at

http://docs.opencv.org/2.4/modules/contrib/doc/facerec/facerec_tutorial.html#intr oduction.

Method Comparison Results

The process that was used to test the accuracy of the three different methods began with using three trials per method, per user. The testing was done at three different distances: 1.5 ft, 2.5 ft, and 3.5 ft. Facial position was another factor that was tested: straight, left side, right side. Each subject was tested for ten seconds in a still position. The prediction false positive rates were determined by the amount of time (in seconds) that the program displayed the false positives. This was presented as a percentage of the ten second trial (i.e., 8 seconds = 80%). The goal was to have the actual prediction results match the expected prediction results. The prediction results are integers that are labels and represent a person in the training data. Table 2 shows a list of the prediction results that of the subjects names associated with each integer label.

Table 2. Subject Labels

Integer Label	Person Name
0	Brad Pitt (Celebrity)
1	Reilly Flynn (Author's cousin)
2	Brandon Sierra (Author)
3	Angelina Jolie (Celebrity)
4	Jesse Pangelinan (Author's
	coworker)
5	Matt Marra (Author's coworker)

Definitions for table headers:

Expected Prediction Results – The integer label of the person being tested.

Actual Prediction Results – The integer label of the subject that the application was predicting the testing person was.

Prediction Rate (%) – The percentage rate at which the actual prediction results was correct.

False Positives Rate (%) – The percentage rate that the application falsely identified or recognized a face where a face was not present. (i.e., on a shirt, on a wall, etc.)

Note: A (-) in the results table means that no prediction could be determined at that time.

1:1 Facial Verification

The process of facial verification included Subject A in the training set and was tested against three different subjects. The first test was to determine if Subject A could be correctly identified in the *actual prediction* results by being verified for the maximum length of time during the testing period of 10 seconds. A longer verification time determined a higher prediction rate. When testing the other two subjects, verification should not occur, as their data was not included in the training set. The goal is to have the verification time of the other two subjects be as low as possible during the testing period. In this case, a shorter verification time determines a higher prediction rate. With the training set only containing one user, the Fisherfaces method was unable to be tested as it requires a minimum of two users. The comparison results of the testing can be seen in Table 3.

42

		Eigenfaces vs Local B	inary Pattern	Histogr	am	
			Prediction (%)	Rate	False Positiv (%)	e Rate
Person 1:	Trial 1:	Position	Eigenfaces	LBPH	Eigenfaces	LBPH
		1.5 ft. Straight	100	100	20	5
		1.5 ft. Right Side	100	100	60	0
		1.5 ft. Left Side	40	100	30	0
		2.5 ft. Straight	100	100	70	100
		2.5 ft. Right Side	70	100	100	100
		2.5 ft. Left Side	10	100	80	70
		3.5 ft. Straight	100	100	20	80
		3.5 ft. Right Side	100	100	10	20
		3.5 ft. Left Side	10	100	70	80
	Trial					
	2:	1.5 ft. Straight	100	100	80	20
		1.5 ft. Right Side	95	100	10	5
		1.5 ft. Left Side	10	20	50	90
		2.5 ft. Straight	100	100	40	20
		2.5 ft. Right Side	100	100	60	80
		2.5 ft. Left Side	30	100	40	10
		3.5 ft. Straight	100	100	100	100
		3.5 ft. Right Side	90	100	10	20
		3.5 ft. Left Side	95	100	10	100
	Trial					
	3:	1.5 ft. Straight	100	100	100	0
		1.5 ft. Right Side	100	100	20	10
		1.5 ft. Left Side	0	80	10	80
		2.5 ft. Straight	100	100	100	70
		2.5 ft. Right Side	95	100	100	80
		2.5 ft. Left Side	0	100	100	10
		3.5 ft. Straight	100	100	10	30
		3.5 ft. Right Side	100	100	10	70
		3.5 ft. Left Side	80	100	20	50
Person	Trial					
2:	1:	Position	Eigenfaces	LBPH	Eigenfaces	LBPH

Table 3. 1:1 Eigenfaces vs Local Binary Pattern

		1.5 ft. Straight	0	0	0	100
		1.5 ft. Right Side	0	0	0	5
		1.5 ft. Left Side	100	0	0	20
		2.5 ft. Straight	0	0	0	0
		2.5 ft. Right Side	0	0	0	20
		2.5 ft. Left Side	0	0	0	0
		3.5 ft. Straight	0	0	0	0
		3.5 ft. Right Side	0	0	100	0
		3.5 ft. Left Side	0	0	0	0
				0		
	Trial					
	2:	1.5 ft. Straight	0	0	0	0
		1.5 ft. Right Side	0	0	20	0
		1.5 ft. Left Side	0	10	50	20
		2.5 ft. Straight	0	0	10	0
		2.5 ft. Right Side	0	0	10	0
		2.5 ft. Left Side	0	0	0	0
		3.5 ft. Straight	0	0	20	0
		3.5 ft. Right Side	0	0	20	0
		3.5 ft. Left Side	20	0	10	10
	Trial 3:	1.5 ft. Straight	0	0	10	0
	э.	1.5 ft. Right Side	0	0	10	0
		1.5 ft. Left Side	0	0	10	0
		2.5 ft. Straight	0	0	10	0
		2.5 ft. Right Side	0	0	0	0
		2.5 ft. Left Side	50	0	0	0
			100	0	10	0
		3.5 ft. Straight	0	0	0	0
		3.5 ft. Right Side 3.5 ft. Left Side	0	0	20	0
		5.5 IL. LEIL SIDE	0	30	10	0
Person	Trial					
3:	1:	Position	Eigenfaces	LBPH	Eigenfaces	LBPH
-		1.5 ft. Straight	0	0	10	0
		1.5 ft. Right Side	100	100	0	25
		1.5 ft. Left Side	50	50	80	50
		2.5 ft. Straight	0	0	0	20
		2.5 ft. Right Side	100	100	0	25
		2.5 ft. Left Side	100	50	20	20
		3.5 ft. Straight	0	0	0	0
				U	0	0

		1			
	3.5 ft. Right Side	100	0	20	0
	3.5 ft. Left Side	100	0	100	0
Trial					
2:	1.5 ft. Straight	0	0	20	10
	1.5 ft. Right Side	100	100	20	0
	1.5 ft. Left Side	100	100	30	80
	2.5 ft. Straight	0	0	0	0
	2.5 ft. Right Side	100	20	0	10
	2.5 ft. Left Side	0	0	25	0
	3.5 ft. Straight	0	0	10	0
	3.5 ft. Right Side	0	50	10	0
	3.5 ft. Left Side	75	50	20	20
Trial					
3:	1.5 ft. Straight	0	0	0	0
	1.5 ft. Right Side	100	100	10	100
	1.5 ft. Left Side	25	100	20	100
	2.5 ft. Straight	0	0	0	0
	2.5 ft. Right Side	100	100	0	10
	2.5 ft. Left Side	50	100	80	100
	3.5 ft. Straight	0	0	0	0
	3.5 ft. Right Side	100	100	0	0
	3.5 ft. Left Side	100	100	80	100

In these results, it shows that the Eigenfaces and Local Binary Pattern Histogram original performed similarly in regard to both the detection rate and false positive rate. When testing the Local Binary Pattern Histogram modified compared to the original, the prediction rates were similar; however, the false positive rates decreased for the modified method (see Table 4).

	Local	Binary Pattern Hi	stogram Origir	al vs Local Bina	ry Pattern Mod	fied
Person 1:	Trial 1:	Position	Predictio LBPH Original	on Rate (%) LBPH Modified	False Posi LBPH Original	tive Rate (%) LBPH Modified
		1.5 ft. Straight 1.5 ft. Right	100	100	5	5
		Side	100	100	0	0
		1.5 ft. Left Side	100	100	0	0
		2.5 ft. Straight 2.5 ft. Right	100	100	100	0
		Side	100	100	100	80
		2.5 ft. Left Side	100	100	70	20
		3.5 ft. Straight 3.5 ft. Right	100	100	80	20
		Side	100	100	20	20
		3.5 ft. Left Side	100	60	80	30
	Trial					
	2:	1.5 ft. Straight 1.5 ft. Right	100	100	20	100
		Side	100	10	5	60
		1.5 ft. Left Side	20	100	90	60
		2.5 ft. Straight 2.5 ft. Right	100	100	20	95
		Side	100	100	80	20
		2.5 ft. Left Side	100	100	10	90
		3.5 ft. Straight 3.5 ft. Right	100	100	100	90
		Side	100	80	20	80
		3.5 ft. Left Side	100	95	100	10
	Trial					
	3:	1.5 ft. Straight 1.5 ft. Right	100	100	0	100
		Side	100	100	10	100
		1.5 ft. Left Side	80	95	80	70
		2.5 ft. Straight 2.5 ft. Right	100	100	70	95
		Side	100	100	80	100
		2.5 ft. Left Side	100	70	10	90
		3.5 ft. Straight	100	100	30	5

Table 4. 1:1 Local Binary Pattern Original vs Local Binary Pattern Modified

		3.5 ft. Right	l			
		Side	100	100	70	70
		3.5 ft. Left Side	100	100	50	95
Person	Trial		LBPH	LBPH	LBPH	LBPH
2:	1:	Position	Original	Modified	Original	Modified
		1.5 ft. Straight 1.5 ft. Right Side	0	0	10	0
			0	0	0	20
		1.5 ft. Left Side	0	20	10	50
		2.5 ft. Straight 2.5 ft. Right Side	0	0 20	10 30	0
		2.5 ft. Left Side	0		20	
			0	0		0
		3.5 ft. Straight 3.5 ft. Right	0	0	0	0
		Side	0	0	0	0
		3.5 ft. Left Side	0	0	50	0
	Trial		0			
	2:	1.5 ft. Straight 1.5 ft. Right	0	0	0	0
		Side	0	0	0	0
		1.5 ft. Left Side	10	0	0	0
		2.5 ft. Straight 2.5 ft. Right	0	0	20	0
		Side	0	0	0	10
		2.5 ft. Left Side	0	0	0	10
		3.5 ft. Straight 3.5 ft. Right	0	0	20	10
		Side	0	0	10	0
		3.5 ft. Left Side	0	0	20	0
	Trial					
	3:	1.5 ft. Straight 1.5 ft. Right	0	0	20	0
		Side	0	0	10	0
		1.5 ft. Left Side	0	0	20	0
		2.5 ft. Straight 2.5 ft. Right	0	0	30	0
		Side	0	0	20	0
		2.5 ft. Left Side	0	0	10	0
		3.5 ft. Straight 3.5 ft. Right	0	0	0	0
		Side	0	0	90	5

		3.5 ft. Left Side	20	0	0	0
		5.5 It. Left Side	30	0		0
Person	Trial		LBPH	LBPH	LBPH	LBPH
3:	1:	Position	Original	Modified	Original	Modified
		1.5 ft. Straight 1.5 ft. Right	0	0	20	0
		Side	100	100	10	20
		1.5 ft. Left Side	50	25	30	100
		2.5 ft. Straight 2.5 ft. Right	0	0	10	0
		Side	100	100	20	30
		2.5 ft. Left Side	50	25	20	85
		3.5 ft. Straight 3.5 ft. Right	0	0	10	0
		Side	0	100	50	0
		3.5 ft. Left Side	0	50	20	0
	Trial					
	2:	1.5 ft. Straight 1.5 ft. Right	0	0	20	0
		Side	100	75	15	20
		1.5 ft. Left Side	100	0	60	80
		2.5 ft. Straight 2.5 ft. Right	0	0	10	0
		Side	20	100	10	50
		2.5 ft. Left Side	0	0	5	20
		3.5 ft. Straight 3.5 ft. Right	0	0		10
		Side	50	100	20	20
		3.5 ft. Left Side	50	0	5	80
	Trial 3:	1.5 ft. Straight	0	0	30	10
		1.5 ft. Right Side	100	25	20	0
		1.5 ft. Left Side	100	10	100	10
		2.5 ft. Straight 2.5 ft. Right	0	0	0	0
		Side	100	75	40	10
		2.5 ft. Left Side	100	0	0	0
		3.5 ft. Straight 3.5 ft. Right	0	0	0	10
		Side	100	100	0	10
		3.5 ft. Left Side	100	0	0	0

1:N Facial Identification

The process of facial identification included seven subjects in the training set and was tested against four subjects. The testing included verifying if each subject could be correctly identified in the actual prediction results by being correctly identified for as long as possible during the ten seconds tested. This would result in a higher prediction rate. The comparison results of the testing can be seen in Table 5.

Eigenfaces vs Fisherfaces vs Local Binary Pattern Histogram									
		Prediction Rate (%) False Positive Rate (%							
Person	Trial		Eigenface	Fisherface	LBP	Eigenface	Fisherface	LBP	
1:	1:	Position	S	S	н	S	S	н	
		1.5 ft. Straight 1.5 ft. Right	100	30	0	10	20	0	
		Side 1.5 ft. Left	0	-	-	90	20	10	
		Side	80	-	0	30	10	10	
		2.5 ft. Straight 2.5 ft. Right	90	20	0	20	50	0	
		Side 2.5 ft. Left	0	60	-	70	10	30	
		Side	100	-	-	30	5	0	
		3.5 ft. Straight 3.5 ft. Right	100	80	30	90	100	10	
		Side 3.5 ft. Left	95	0	-	40	95	20	
		Side	10	95	100	20	10	10	
	Trial								
	2:	1.5 ft. Straight 1.5 ft. Right	95	0	30	10	10	5	
		Side 1.5 ft. Left	100	-	-	90	10	10	
		Side	90	-	0	60	10	10	
		2.5 ft. Straight	100	50	20	70	5	30	

Table 5. 1:N Eigenfaces vs Fisherfaces vs Local Binary Pattern

		2.5 ft. Right						
		Side 2.5 ft. Left	70	60	-	30	80	60
		Side	20	-	20	40	20	10
		3.5 ft. Straight 3.5 ft. Right	95	50	0	20	30	10
		Side 3.5 ft. Left	100	30	0	10	90	10
		Side	10	100	50	10	20	0
	Trial							
	3:	1.5 ft. Straight 1.5 ft. Right	100	0	30	20	5	0
		Side 1.5 ft. Left	50	-	-	10	10	10
		Side	100	-	-	20	5	20
		2.5 ft. Straight 2.5 ft. Right	100	60	5	30	20	30
		Side 2.5 ft. Left	100	10	-	20	40	60
		Side	100	40	40	20	10	20
		3.5 ft. Straight 3.5 ft. Right	00	50	0	20	100	20
		Side	00	0	-	30	100	80
		3.5 ft. Left						
		3.5 ft. Left Side	100	100	5	30	20	40
Person 2:	Trial 1:	Side	Eigenface	Fisherface	LBP	Eigenface	Fisherface	LBP
Person 2:	Trial 1:	Side Position	Eigenface S	Fisherface s	LBP H	Eigenface s	Fisherface S	LBP H
		Side	Eigenface	Fisherface	LBP	Eigenface	Fisherface	LBP
		Side Position 1.5 ft. Straight	Eigenface S	Fisherface s	LBP H	Eigenface s	Fisherface S	LBP H
		Side Position 1.5 ft. Straight 1.5 ft. Right Side	Eigenface s	Fisherface s	LBР Н	Eigenface s 10	Fisherface s	LBР Н 10
		Side Position 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left	Eigenface s 0 0	Fisherface s	LBP H 0	Eigenface s 10 60	Fisherface s 0 5	LBP H 10 0
		Side Position 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight	Eigenface s 0 0 0	Fisherface s 0 0	LBP H 0 -	Eigenface s 10 60 10	Fisherface s 0 5 20	LBP H 10 0 10
		Side Position 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side	Eigenface s 0 0 0 0 0 0 0	Fisherface s 0 - 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	LBP H 0 - 0 0 0 0	Eigenface s 10 60 10 5 60 0	Fisherface s 0 5 20 20 15 5	LBP H 10 0 10 10 30 20
		Side Position 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Straight 3.5 ft. Right	Eigenface s 0 0 0 0 0 0 0 0 0	Fisherface s 0 - 0 - 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	LBP H 0 - 0 0 0 0 0 0	Eigenface s 10 60 10 5 60 0 10	Fisherface s 0 5 20 20 15 5 5 5 5	LBP H 10 0 10 10 10 30 20 0
		Side Position 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Right Side 3.5 ft. Left	Eigenface s 0 0 0 0 0 0 0 0 0 0	Fisherface s 0 - 0	LBP H 0 - 0 0 0 0 0 0 0	Eigenface s 10 60 10 5 60 0 10 10 0	Fisherface s 0 5 20 20 15 5 20	LBP H 10 0 10 10 10 30 20 0 0
		Side Position 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 3.5 ft. Straight 3.5 ft. Straight 3.5 ft. Right Side	Eigenface s 0 0 0 0 0 0 0 0 0	Fisherface s 0 - 0 - 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	LBP H 0 - 0 0 0 0 0 0	Eigenface s 10 60 10 5 60 0 10	Fisherface s 0 5 20 20 15 5 5 5 5	LBP H 10 0 10 10 10 30 20 0
		Side Position 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Right Side 3.5 ft. Left	Eigenface s 0 0 0 0 0 0 0 0 0 0	Fisherface s 0 - 0	LBP H 0 - 0 0 0 0 0 0 0	Eigenface s 10 60 10 5 60 0 10 10 0	Fisherface s 0 5 20 20 15 5 20	LBP H 10 0 10 10 10 30 20 0 0

		1.5 ft. Right	1			1		
		Side	0	-	0	5	5	0
		1.5 ft. Left	-		-	-	-	-
		Side	0	0	0	60	20	0
		2.5 ft. Straight 2.5 ft. Right	0	0	0	0	20	20
		Side 2.5 ft. Left	-	0	0	50	50	0
		Side	0	0	-	10	5	0
		3.5 ft. Straight 3.5 ft. Right	0	0	0	40	0	20
		Side 3.5 ft. Left	0	0	0	50	15	10
		Side	0	0	0	20	10	20
	Trial							
	3:	1.5 ft. Straight 1.5 ft. Right	0	0	0	0	30	20
		Side 1.5 ft. Left	0	0	0	0	0	10
		Side	0	0	0	10	20	20
		2.5 ft. Straight 2.5 ft. Right	0	0	0	5	0	30
		Side 2.5 ft. Left	0	0	0	5	0	20
		Side	0	0	0	15	0	10
		3.5 ft. Straight 3.5 ft. Right	0	0	0	0	20	0
		Side 3.5 ft. Left	0	0	0	100	0	90
		Side	0	0	0	100	20	0
-								
Person	Trial	Position	Eigenface	Fisherface	LBP	Eigenface	Fisherface	LBP
3:	1:		s	s	<u>H</u>	S	S	Н
		1.5 ft. Straight 1.5 ft. Right	0	0	30	10	20	20
		Side 1.5 ft. Left	-	0	-	60	20	10
		Side	0	0	-	10	40	30
		2.5 ft. Straight 2.5 ft. Right	25	0	0	20	40	10
		Side 2.5 ft. Left	0	50	-	15	10	20
		Side	0	0	-	60	0	20
		3.5 ft. Straight 3.5 ft. Right	30	0	0	40	20	10
		Side	100	25	0	0	10	50

		3.5 ft. Left						
		Side	0	-	-	0	0	20
	Trial 2:	1.5 ft. Straight 1.5 ft. Right	0	0	30	0	30	20
		Side 1.5 ft. Left	0	0	-	60	0	15
		Side	0	0	-	100	20	60
		2.5 ft. Straight 2.5 ft. Right	60	0	50	60	100	10
		Side 2.5 ft. Left	0	75	-	10	0	10
		Side	0	0	-	100	60	5
		3.5 ft. Straight 3.5 ft. Right	75	0	30	80	70	
		Side 3.5 ft. Left	100	50	0	50	0	20
		Side	90	-	-	60	20	5
	Tuial							
	Trial 3:	1.5 ft. Straight 1.5 ft. Right	0	0	20	0	60	30
		Side 1.5 ft. Left	0	0	0	0	0	20
		Side	0	0	0	50	50	100
		2.5 ft. Straight 2.5 ft. Right	25	0	10	10	0	0
		Side 2.5 ft. Left	100	50	0	60	0	40
		Side	0	-	-	10	0	0
		3.5 ft. Straight 3.5 ft. Right	75	0	0	10	60	0
		Side 3.5 ft. Left	-	100	0	20	0	0
		Side	100	0	-	10	10	0
Derson	Tulal		Figerfron	Fisherford	100	Figerford	Fish a fees	
Person 4:	Trial 1:	Position	Eigenface s	Fisherface s	LBP H	Eigenface s	Fisherface s	LBP H
L		1.5 ft. Straight	100	90	100	60	10	100
		1.5 ft. Right Side	100	100	90	0	90	0
		1.5 ft. Left Side	0	0	100	60	90	30
		2.5 ft. Straight 2.5 ft. Right	100	0	100	0	100	5
		Side	100	50	100	0	10	0

	2.5 ft. Left					20	
	Side	-	75	-	50	30	0
	3.5 ft. Straight 3.5 ft. Right	100	0	100	50	30	0
	Side 3.5 ft. Left	75	75	-	20	100	70
	Side	-	100	-	50	100	5
Trial							
2:	1.5 ft. Straight 1.5 ft. Right	100	100	100	5	0	90
	Side 1.5 ft. Left	70	100	100	60	60	40
	Side	-	50	50	20	50	0
	2.5 ft. Straight 2.5 ft. Right	100	60	100	50	25	60
	Side 2.5 ft. Left	0	100	100	60	70	20
	Side	-	60	100	0	60	50
	3.5 ft. Straight 3.5 ft. Right	100	0	100	0	90	0
	Side 3.5 ft. Left	0	90	100	10	20	70
	Side	-	100	-	50	20	20
Trial							
3:	1.5 ft. Straight 1.5 ft. Right	100	75	100	20	10	100
	Side 1.5 ft. Left	0	75	100	20	50	50
	Side	-	0	100	10	75	40
	2.5 ft. Straight 2.5 ft. Right	100	0	100	100	5	100
	Side 2.5 ft. Left	100	50	100	0	50	0
	Side	-	90	100	0	10	50
	3.5 ft. Straight 3.5 ft. Right	100	0	100	0	0	10
	Side 3.5 ft. Left	0	100	100	10	50	90
	Side	-	-	100	0	50	20

In these results, it shows that the Eigenfaces method performed the best between Eigenfaces, Fisherfaces, and Local Binary Pattern Histogram original in regard to the detection rate. However, the Eigenfaces method also had the largest false positive rate. The Local Binary Pattern Histogram original had the lowest prediction rate, while also having the lowest false positive rate. For this reason, the Local Binary Pattern Histogram was determined to be the best method to test an improvement on the algorithm. After the improvements, the Local Binary Pattern Histogram had both a higher prediction rate and a higher false positive rate. The prediction rate percentage increased for three of the four users tested. There were also fewer occurrences where the prediction rate was 0% correct (see Table 6).

	Local	Binary Pattern Hi	stogram Origii	nal vs Local Binar	y Pattern Mod	ified
			Predicti	on Rate (%)	False Positive Rate (%)	
Person	Trial		LBPH	LBPH	LBPH	LBPH
1:	1:	Position	Original	Modified	Original	Modified
		1.5 ft. Straight	0	40	0	20
		1.5 ft. Right				
		Side	-	20	10	40
		1.5 ft. Left Side	0	0	10	80
		2.5 ft. Straight	0	50	0	30
		2.5 ft. Right				
		Side	-	40	30	10
		2.5 ft. Left Side	-	0	0	40
		3.5 ft. Straight	30	0	10	20
		3.5 ft. Right				
		Side	-	0	20	10
		3.5 ft. Left Side	100	5	10	30

Table 6. 1:N Local Binary Pattern Original vs Local Binary Pattern Modified

			I		I	
	Trial					
	2:	1.5 ft. Straight 1.5 ft. Right	30	10	5	60
		Side	-	0	10	40
		1.5 ft. Left Side	0	30	10	20
		2.5 ft. Straight 2.5 ft. Right	20	10	30	40
		Side	-	20	60	30
		2.5 ft. Left Side	20	0	10	20
		3.5 ft. Straight 3.5 ft. Right	0	30	10	80
		Side	0	0	10	20
		3.5 ft. Left Side	50	30	0	10
						
	Trial 3:	1.5 ft. Straight 1.5 ft. Right	30	40	0	60
		Side	-	20	10	60
		1.5 ft. Left Side	-	0	20	70
		2.5 ft. Straight 2.5 ft. Right	5	0	30	30
		Side	-	40	60	20
		2.5 ft. Left Side	40	0	20	40
		3.5 ft. Straight 3.5 ft. Right	0	10	20	80
		Side	-	30	80	20
		3.5 ft. Left Side	5	0	40	70
-						
Person 2:	Trial 1:	Position	LBPH Original	LBPH Modified	LBPH Original	LBPH Modified
		1.5 ft. Straight 1.5 ft. Right	0	30	10	0
		Side	-	0	0	5
		1.5 ft. Left Side	0	-	10	20
		2.5 ft. Straight 2.5 ft. Right	0	0	10	10
		Side	0	0	30	5
		2.5 ft. Left Side	0	-	20	100
		3.5 ft. Straight 3.5 ft. Right	0	0	0	0
		Side	0	25	0	20
		3.5 ft. Left Side	0	20	50	10

	Trial		I		I	
	2:	1.5 ft. Straight	0	10	0	0
		1.5 ft. Right	-		-	-
		Side	0	0	0	0
		1.5 ft. Left Side	0	10	0	10
		2.5 ft. Straight 2.5 ft. Right	0	0	20	0
		Side	0	0	0	10
		2.5 ft. Left Side	-	50	0	0
		3.5 ft. Straight 3.5 ft. Right	0	0	20	0
		Side	0	10	10	0
		3.5 ft. Left Side	0	50	20	10
	Trial					
	3:	1.5 ft. Straight 1.5 ft. Right	0	0	20	10
		Side	0	40	10	0
		1.5 ft. Left Side	0	50	20	20
		2.5 ft. Straight 2.5 ft. Right	0	0	30	0
		Side	0	50	20	10
		2.5 ft. Left Side	0	15	10	20
		3.5 ft. Straight 3.5 ft. Right	0	25	0	10
		Side	0	20	90	5
		3.5 ft. Left Side	0	50	0	10
-						
Person	Trial	.	LBPH	LBPH	LBPH	LBPH
3:	1:	Position	Original	Modified	Original	Modified
		1.5 ft. Straight 1.5 ft. Right	30	30	20	20
		Side	-	50	10	0
		1.5 ft. Left Side	-	0	30	60
		2.5 ft. Straight 2.5 ft. Right	0	0	10	20
		Side	-	60	20	10
		2.5 ft. Left Side	-	25	20	0
		3.5 ft. Straight 3.5 ft. Right	0	0	10	0
		Side	0	0	50	0
		3.5 ft. Left Side	-	0	20	0
	Trial					


		1.5 ft. Right	I		I	
		Side	-	30	15	10
		1.5 ft. Left Side	-	0	60	100
		2.5 ft. Straight 2.5 ft. Right	50	0	10	10
		Side	-	30	10	5
		2.5 ft. Left Side	-	0	5	0
		3.5 ft. Straight 3.5 ft. Right	30	75		10
		Side	0	25	20	5
		3.5 ft. Left Side	-	20	5	5
	Trial					
	3:	1.5 ft. Straight 1.5 ft. Right	20	0	30	30
		Side	0	0	20	20
		1.5 ft. Left Side	0	0	100	80
		2.5 ft. Straight 2.5 ft. Right	10	0	0	20
		Side	0	50	40	10
		2.5 ft. Left Side	-	0	0	0
		3.5 ft. Straight	0	50	0	5
		3.5 ft. Right				
		Side	0	75	0	5
		-	0	75 0	0	5 10
Demonst	Trial	Side	-	0	0	10
Person 4:	Trial 1:	Side 3.5 ft. Left Side	- LBPH	0 LBPH	0 LBPH	10 LBPH
Person 4:	Trial 1:	Side 3.5 ft. Left Side Position	- LBPH Original	0 LBPH Modified	0 LBPH Original	10 LBPH Modified
		Side 3.5 ft. Left Side Position 1.5 ft. Straight 1.5 ft. Right	- LBPH Original 100	0 LBPH Modified 25	0 LBPH Original 100	10 LBPH Modified
		Side 3.5 ft. Left Side Position 1.5 ft. Straight 1.5 ft. Right Side	- LBPH Original 100 90	0 LBPH Modified 25 0	0 LBPH Original 100 0	10 LBPH Modified 0 0
		Side 3.5 ft. Left Side Position 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight	- LBPH Original 100	0 LBPH Modified 25	0 LBPH Original 100	10 LBPH Modified
		Side 3.5 ft. Left Side Position 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side	- LBPH Original 100 90 100	0 LBPH Modified 25 0 50	0 LBPH Original 100 0 30	10 LBPH Modified 0 0 0 0 0
		Side 3.5 ft. Left Side Position 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right	- LBPH Original 100 90 100 100	0 LBPH Modified 25 0 50 50	0 LBPH Original 100 0 30 5	LBPH Modified 0 0 0 10
		Side 3.5 ft. Left Side Position 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 3.5 ft. Left Side 3.5 ft. Straight	- LBPH Original 100 90 100 100 100	0 LBPH Modified 25 0 50 50 0	0 LBPH Original 100 0 30 5 0	10 LBPH Modified 0 0 0 10 0
		Side 3.5 ft. Left Side Position 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side	- LBPH Original 100 90 100 100 100 -	0 LBPH Modified 25 0 50 50 0 50	0 LBPH Original 100 0 30 5 0 0 0	LBPH Modified 0 0 10 0 10 10 0 100
		Side 3.5 ft. Left Side Position 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Straight 3.5 ft. Right	- LBPH Original 100 90 100 100 100 - 100	0 LBPH Modified 25 0 50 50 0 50 20	0 LBPH Original 100 0 30 5 0 0 0 0 0	LBPH Modified 0 0 10 0 10 0 100 0
		Side 3.5 ft. Left Side Position 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Straight 3.5 ft. Straight 3.5 ft. Right Side	- LBPH Original 100 90 100 100 - 100 - 100 -	0 LBPH Modified 25 0 50 50 0 50 20 15	0 LBPH Original 100 0 30 5 0 0 0 0 70	10 LBPH Modified 0 0 0 10 10 0 100 0 5
	1:	Side 3.5 ft. Left Side Position 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Straight 3.5 ft. Straight 3.5 ft. Right Side	- LBPH Original 100 90 100 100 - 100 - 100 -	0 LBPH Modified 25 0 50 50 0 50 20 15	0 LBPH Original 100 0 30 5 0 0 0 0 70	10 LBPH Modified 0 0 0 10 10 0 100 0 5

		1		1	
	1.5 ft. Left Side	50	0	0	100
	2.5 ft. Straight	100	50	60	0
	2.5 ft. Right				
	Side	100	0	20	10
	2.5 ft. Left Side	100	0	50	50
	3.5 ft. Straight 3.5 ft. Right	100	50	0	0
	Side	100	0	70	0
	3.5 ft. Left Side	-	75	20	0
Trial					
3:	1.5 ft. Straight	100	15	100	10
	1.5 ft. Right				
	Side	100	60	50	20
	1.5 ft. Left Side	100	50	40	80
	2.5 ft. Straight	100	0	100	5
	2.5 ft. Right				
	Side	100	0	0	20
	2.5 ft. Left Side	100	60	50	100
	3.5 ft. Straight	100	0	10	0
	3.5 ft. Right				
	Side	100	30	90	0
	3.5 ft. Left Side	100	0	20	30

Implementation of Local Binary Pattern Histogram

On a human face, not all facial characteristics are equally identifiable by themselves. For example, if person A was shown only the forehead of person B, it is not very likely that person A would be able to easily distinguish person B from a group of people using the forehead alone to identify. The same can be said for other facial features, such as the cheeks. However, there are some facial features that play a greater role in being able to identify a person. These features could include eyes, nose, mouth, etc. Considering this nuance, one way that the Local Binary Pattern Histogram could be improved upon is by adding weights to specific regions on a face. Each weight would be differentiated and determined by the contrast of gray scale values for each pixel and its neighbors. The weights would be calculated using the standard deviation method (see Figure 25). The weights would be calculated, and the weight of each region would be multiplied to the region matrix using the scalar multiplication method. Then, the region histograms would be concatenated into one large histogram where they can be rearranged to have the regions with the highest weights being pushed onto the matrix first. The region with the second highest regions would be pushed next, then the third, and so on. This process would continue until the lowest weight region was pushed onto the matrix last (see Figure 24). This would make the recognition process more accurate by forcing the regions with the higher weights to play a greater part in the identification process. The functions in Figures 26-27 were added and modified for this project. There will be comments that start with **// New:** followed by a description of what the code following does for the code that were added/modified.

59



LBPH Spatial Histogram (Modified) Flow Chart

Figure 25. Local Binary Pattern Spatial Histogram (Modified) Flow Chart




Figure 26. Local Binary Pattern Standard Deviation Flow Chart

```
*NEW FUNCTION
                                                             *
*Calculates the standard deviation for each region matrix and
*assigns the value as a weight.
                            **
          **********************
static float standard deviation(Mat input)
{
       float total;
       float totalDev;
       float mean;
       int i;
       float stdDev;
       for(i = 0; i < input.cols; i++)</pre>
       {
              total = input.at<float>(i);
       }
       mean = total / i;
       for(i = 0; i < input.cols; i++)</pre>
       {
              totalDev = (input.at<float>(i) - mean) * (input.at<float>(i) - mean);
       }
       stdDev = totalDev / i;
       return stdDev;
}
static Mat spatial_histogram(InputArray _src, int numPatterns,
                           int grid_x, int grid_y, bool /*normed*/)
{
   Mat src = _src.getMat();
                                                   //new
       Mat result_row;
       Mat cell_hist;
                                                           //new
       float weight;
                                                           //new
       vector<float> vecWeight;
                                                           //new
   // calculate LBP patch size
   int width = src.cols/grid_x;
   int height = src.rows/grid_y;
   // allocate memory for the spatial histogram
   Mat result = Mat::zeros(grid_x * grid_y, numPatterns, CV_32FC1);
   // return matrix with zeros if no data was given
   if(src.empty())
       return result.reshape(1,1);
   // initial result_row
   int resultRowIdx = 0;
   // iterate through grid
   for(int i = 0; i < grid_y; i++) {</pre>
       for(int j = 0; j < grid_x; j++) {</pre>
           Mat src_cell = Mat(src, Range(i*height,(i+1)*height), Range(j*width,(j+1)*width));
              cell_hist = histc(src_cell, 0, (numPatterns-1), true);
```

Figure 27. Local Binary Pattern Modified Source Code 1

```
// New: Calls the fuction to caculate each regions weight using standard deviation
               weight = standard_deviation(cell_hist);
               // New: The weight is added to a vector to keep track of the weight for all of the
regions in an image
               vecWeight.push_back(weight);
               // New: Uses scalar multiplication to multiply the regions weight to the region
matrix
               for(int i = 0; i < cell_hist.cols; i++)</pre>
               {
                       cell hist.at<float>(i) = cell hist.at<float>(i) * weight;
               }
            // copy to the result matrix
               result row = result.row(resultRowIdx);
               cell_hist.reshape(1,1).convertTo(result_row, CV_32FC1);
            // increase row count in result matrix
               resultRowIdx++;
        }
    }
        // New: Calculates the maximum weight in the vecWeight vector
        float it = *max_element(vecWeight.begin(), vecWeight.end());
       vector<int> weightOrder;
       // New: Calculates the position of the heaviest weights, and then places this order in a
vector.
        // After the heaviest weight is used, it is assigned a -1 so that it is not used again.
       while(it != -1)
        {
               for(int i = 0; i < vecWeight.size(); i++)</pre>
               {
                       if(vecWeight[i] == it)
                       {
                               weightOrder.push_back(i);
                               vecWeight[i] = -1;
                       }
               it = *max element(vecWeight.begin(), vecWeight.end());
       }
       // New: Places the regions in the result matrix based on the weight of the region
       for(int i = 0; i < result.rows; i++)</pre>
        {
                       //copy to the result matrix
                       resultRowIdx = weightOrder[i];
                       result_row = result.row(resultRowIdx);
                       cell_hist.reshape(1,1).convertTo(result_row, CV_32FC1);
       }
    //return result as reshaped feature vector
    return result.reshape(1,1);
```

Figure 28. Local Binary Pattern Modified Source Code 2

CHAPTER FIVE CONCLUSION AND FUTURE RESEARCH

The improvement to the Local Binary Pattern Histogram method for facial recognition is important due to the fact that each method has its advantages and disadvantages. It is extremely important that new methods are created and previous methods are continuously improved upon to make certain that facial recognition predictions are as accurate as possible. This is especially true with facial recognition being a form of biometric authentication that is increasing in popularity for facial verification and identification. If an optimal method could potentially be found, there could be possibly be an exponential increase in the popularity of facial recognition, along with increases in security, safety, and identification.

Another potential improvement to the Local Binary Pattern Histogram method in this project could be the option to disregard regions with a weight below a set threshold. During the process of building the image histogram by concatenating the regional histograms ordered by weights, it could be possible to not include histograms whose weights are below a specific threshold. This could increase the processing time it takes during the training portion. The concern would be if this would have any effect on the accuracy of the prediction rate as the training time is decreased.

64

APPENDIX A

1:N EIGENFACES RESULTS

			Eigenfa	ce		
Person 1:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	False Positives Rate (%)
		1.5 ft. Straight	2	2	100	10
		1.5 ft. Right Side	2	5	0	90
		1.5 ft. Left Side	2	2	80	30
		2.5 ft. Straight	2	2/4	90	20
		2.5 ft. Right Side	2	0/5	0	70
		2.5 ft. Left Side	2	2	100	30
		3.5 ft. Straight	2	2	100	90
		3.5 ft. Right				
		Side	2	0/2	95	40
		3.5 ft. Left Side	2	1/2/5	10	20
	Trial 2:	1.5 ft. Straight	2	2/4	95	10
		1.5 ft. Right Side	2	2	100	90
		1.5 ft. Left Side	2	2	90	90 60
		2.5 ft. Straight 2.5 ft. Right	2	2	100	70
		Side	2	2/5	70	30
		2.5 ft. Left Side	2	1/2/5	20	40
		3.5 ft. Straight 3.5 ft. Right	2	2/5	95	20
		Side 3.5 ft. Left Side	2	2 2/5	100 10	10 10
		3.5 It. Left Side	2	2/5	10	10
	Trial 3:	1.5 ft. Straight	2	2	100	20
		1.5 ft. Right Side	2	0/2/5	50	10
		1.5 ft. Left Side	2	2	100	20
		2.5 ft. Straight 2.5 ft. Right	2	2	100	30
		Side	2	2	100	20
		2.5 ft. Left Side	2	2	100	20
		3.5 ft. Straight 3.5 ft. Right	2	2	00	20
		Side 3.5 ft. Left Side	2	2 2	00 100	30 30
		<u>5.5 II. Left Side</u>		2	100	50
Person 2:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	False Positives Rate (%)
		1.5 ft. Straight	1	2	0	10
		1.5 ft. Right Side	1	4	0	60
		1.5 ft. Left Side	1	2	0	10
		2.5 ft. Straight 2.5 ft. Right	1	2	0	5
		Side	1	2	0	60

5
5
5
60
0
50
10
40
50
20
0
0
0
10
10
10 5
10 5 5
10 5 5 15
10 5 5 15 0
10 5 5 15 0 100 100
10 5 5 15 0 100
10 5 5 15 0 100 100 False
10 5 5 15 0 100 100 100 False Positives
10 5 5 15 0 100 100 100 False Positives Rate (%)
10 5 5 15 0 100 100 100 False Positives Rate (%) 10
10 5 5 15 0 100 100 100 False Positives Rate (%) 10 60
10 5 5 15 0 100 100 100 False Positives Rate (%) 10 60 10 20
10 5 5 15 0 100 100 100 False Positives Rate (%) 10 60 10 20 15
10 5 5 15 0 100 100 100 False Positives Rate (%) 10 60 10 20
10 5 5 15 0 100 100 100 False Positives Rate (%) 10 60 10 20 15 60 40
10 5 5 15 0 100 100 100 False Positives Rate (%) 10 60 10 20 15 60 40 0
10 5 5 15 0 100 100 100 False Positives Rate (%) 10 60 10 20 15 60 40
10 5 5 15 0 100 100 100 False Positives Rate (%) 10 60 10 20 15 60 40 0 0
10 5 5 15 0 100 100 100 False Positives Rate (%) 10 60 10 20 15 60 40 0
10 5 5 15 0 100 100 100 False Positives Rate (%) 10 60 10 20 15 60 40 0 0
10 5 5 15 0 100 100 100 False Positives Rate (%) 10 60 10 20 15 60 40 0 0
60 0 50 10 40 50

	Trial 3:	2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right	8 8 8 8 8	0 2 4/5 5 2/5 7	0 0 75 100 90	10 100 80 50 60 0
		Side	8	2	0	0
		1.5 ft. Left Side	8	2	0 25	50
		2.5 ft. Straight 2.5 ft. Right	8	2/4/5	25	10
		Side	8	5	100	60
		2.5 ft. Left Side	8	2	0	10
		3.5 ft. Straight 3.5 ft. Right	8	4/5	75	10
		Side	8	-	-	20
		3.5 ft. Left Side	8	8	100	10
						E de a
Person 4:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	False Positives Rate (%)
		1.5 ft. Straight	0	0	100	60
		1.5 ft. Right Side	0	0	100	0
		1.5 ft. Left Side	0	2	0	60
		2.5 ft. Straight	0	0	100	0
		2.5 ft. Right Side	0	0	100	0
		2.5 ft. Left Side	0	-	-	50
		3.5 ft. Straight 3.5 ft. Right	0	0	100	50
		Side	0	0/5	75	20
		3.5 ft. Left Side	0	-	-	50
	Trial				100	-
	2:	1.5 ft. Straight 1.5 ft. Right	0	0	100	5
		Side	0	0/5	70	60
		1.5 ft. Left Side	0	-	-	20
		2.5 ft. Straight 2.5 ft. Right	0	0	100	50
		Side	0	2	0	60 0
		2.5 ft. Left Side 3.5 ft. Straight	0	- 0	- 100	0
		3.5 ft. Right Side	0	2/5	0	10
		3.5 ft. Left Side	0	-	-	50
	Trial 3:	1.5 ft. Straight	0	0	100	20
	э.	1.5 ft. Right				20
		Side	0	2/5	0	20

1.5 ft. Left Side	0	-	-	10
2.5 ft. Straight 2.5 ft. Right	0	0	100	100
Side	0	0	100	0
2.5 ft. Left Side	0	-	-	0
3.5 ft. Straight 3.5 ft. Right	0	0	100	0
Side	0	2/5	0	10
3.5 ft. Left Side	0	-	-	0

APPENDIX B

1:N FISHERFACES RESULTS

	Fisherfaces					
Person 1:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	False Positives Rate (%)
		1.5 ft. Straight	2	2/4	30	20
		1.5 ft. Right Side	2	-	-	20
		1.5 ft. Left Side	2	-	-	10
		2.5 ft. Straight	2	1/2/4	20	50
		2.5 ft. Right Side	2	0/2	60	10
		2.5 ft. Left Side	2	-	-	5
		3.5 ft. Straight 3.5 ft. Right	2	2/4	80	100
		Side	2	0/4	0	95
		3.5 ft. Left Side	2	2/5	95	10
	Trial				0	10
	2:	1.5 ft. Straight 1.5 ft. Right	2	4	0	10
		Side	2	-	-	10
		1.5 ft. Left Side	2	-	-	10
		2.5 ft. Straight 2.5 ft. Right	2	2/4	50	5
		Side	2	2/4	60	80
		2.5 ft. Left Side	2	-	-	20
		3.5 ft. Straight 3.5 ft. Right	2	2/4	50	30
		Side	2	2/4	30	90
		3.5 ft. Left Side	2	2	100	20
	Trial					
	3:	1.5 ft. Straight 1.5 ft. Right	2	4	0	5
		Side	2	-	-	10
		1.5 ft. Left Side	2	-	-	5
		2.5 ft. Straight 2.5 ft. Right	2	2/4	60	20
		Side	2	0/2/4	10	40
		2.5 ft. Left Side	2	2/4	40	10
		3.5 ft. Straight 3.5 ft. Right	2	2/5	50	100
		Side	2	0/5	0	100
		3.5 ft. Left Side	2	2	100	20
						False
Person 2:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	Positives Rate (%)
		1.5 ft. Straight	1	2	0	0
		1.5 ft. Right Side	1	0/2	0	5
		1.5 ft. Left Side	1	-	-	20
		2.5 ft. Straight	1	2/4	0	20
		2.5 ft. Right Side	1	0/4/5	0	15

			I			
		2.5 ft. Left Side	1	2/4/5	0	5
		3.5 ft. Straight 3.5 ft. Right	1	2	0	5
		Side	1	0/5	0	20
		3.5 ft. Left Side	1	2	0	0
	Trial					
	2:	1.5 ft. Straight 1.5 ft. Right	1	2	0	0
		Side	1	-	-	5
		1.5 ft. Left Side	1	2	0	20
		2.5 ft. Straight 2.5 ft. Right	1	0/4	0	20
		Side	1	0	0	50
		2.5 ft. Left Side	1	2	0	5
		3.5 ft. Straight 3.5 ft. Right	1	0/2/5	0	0
		Side	1	0/5	0	15
		3.5 ft. Left Side	1	2/4	0	10
	Trial					
	3:	1.5 ft. Straight 1.5 ft. Right	1	2/4	0	30
		Side	1	0/5	0	0
		1.5 ft. Left Side	1	2/5	0	20
		2.5 ft. Straight 2.5 ft. Right	1	4	0	0
		Side	1	5	0	0
		2.5 ft. Left Side	1	0/2	0	0
		3.5 ft. Straight 3.5 ft. Right	1	0/2/4	0	20
		Side	1	0/5	0	0
		3.5 ft. Left Side	1	2	0	20
						False
Person	Trial				Prediction Rate	Positives
3:	1:	Position	Expected Prediction Results	Actual Prediction Results	(%)	Rate (%)
		1.5 ft. Straight 1.5 ft. Right	8	2/4	0	20
		Side	8	3/4	0	20
		1.5 ft. Left Side	8	3/4	0	40
		2.5 ft. Straight	8	2	0	40
		2.5 ft. Right				
		Side	8	0/5	50	10
		2.5 ft. Left Side	8	3/4	0	0
		3.5 ft. Straight 3.5 ft. Right	8	2	0	20
		Side	8	0/3/4/5	25	10
		3.5 ft. Left Side	8	-	-	0
	Trial					
	Trial 2:	1.5 ft. Straight 1.5 ft. Right	8	0/2/4	0	30
		1.5 ft. Straight	8	3	0	30 0
		1.5 ft. Straight 1.5 ft. Right				

			l l			
		2.5 ft. Right Side	8	0/4/5	75	0
		2.5 ft. Left Side	8	7	75 0	
			8			60
		3.5 ft. Straight 3.5 ft. Right	8	2	0	70
		Side	8	0/3/4/5	50	0
		3.5 ft. Left Side	8	-	-	20
	Trial					
	3:	1.5 ft. Straight	8	2	0	60
		1.5 ft. Right	0	0/4	0	0
		Side	8	0/4	0	0
		1.5 ft. Left Side	8	3/4	0	50
		2.5 ft. Straight 2.5 ft. Right	8	2/4	0	0
		Side	8	0/5	50	0
		2.5 ft. Left Side	8	-	-	0
		3.5 ft. Straight	8	0/2	0	60
		3.5 ft. Right	0	0/ =	0	
		Side	8	5	100	0
		3.5 ft. Left Side	8	2/3/4	0	10
_						
						False
Person	Trial	Position	From a stand Duradiation Describe	Actual Prediction Results	Prediction Rate	Positives
4:	1:		Expected Prediction Results		(%)	Rate (%)
		1.5 ft. Straight 1.5 ft. Right	0	0/5	90	10
		Side	0	0	100	90
		1.5 ft. Left Side	0	2	0	90
		2.5 ft. Straight	0	4	0	100
		2.5 ft. Right				
		Side	0	0/5	50	10
			0	0/2/5	75	20
		2.5 ft. Left Side	0	0/2/3		30
		3.5 ft. Straight	0	4	0	30
		3.5 ft. Straight 3.5 ft. Right	0	4	0	30
		3.5 ft. Straight 3.5 ft. Right Side	0 0	4 0/5	0 75	30 100
		3.5 ft. Straight 3.5 ft. Right	0	4	0	30
	Trial	3.5 ft. Straight 3.5 ft. Right Side	0 0	4 0/5	0 75	30 100
	Trial 2:	3.5 ft. Straight 3.5 ft. Right Side	0 0	4 0/5	0 75	30 100
		 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right 	0 0 0	4 0/5 0	0 75 100 100	30 100 100 0
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side	0 0 0 0	4 0/5 0 0	0 75 100 100 100	30 100 100 0 60
		 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right 	0 0 0	4 0/5 0 0 0 0/2/5	0 75 100 100 100 50	30 100 100 0 60 50
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight	0 0 0 0	4 0/5 0 0	0 75 100 100 100	30 100 100 0 60
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right	0 0 0 0 0 0 0	4 0/5 0 0 0 0 0/2/5 0/4	0 75 100 100 100 50 60	30 100 100 0 60 50 25
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 2.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side	0 0 0 0 0 0 0 0	4 0/5 0 0 0 0/2/5 0/4 0	0 75 100 100 50 60 100	30 100 100 0 60 50 25 70
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side	0 0 0 0 0 0 0 0 0	4 0/5 0 0 0 0/2/5 0/4 0 0/2/5	0 75 100 100 50 60 100 60	30 100 100 0 60 50 25 70 60
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight	0 0 0 0 0 0 0 0	4 0/5 0 0 0 0/2/5 0/4 0	0 75 100 100 50 60 100	30 100 100 0 60 50 25 70
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side	0 0 0 0 0 0 0 0 0	4 0/5 0 0 0 0/2/5 0/4 0 0/2/5	0 75 100 100 50 60 100 60	30 100 100 0 60 50 25 70 60
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Left Side 2.5 ft. Right Side 2.5 ft. Straight 3.5 ft. Straight 3.5 ft. Right	0 0 0 0 0 0 0 0 0 0	4 0/5 0 0 0 0/2/5 0/4 0 0/2/5 4	0 75 100 100 50 60 100 60 0	30 100 100 0 60 50 25 70 60 90
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 3.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side	0 0 0 0 0 0 0 0 0 0 0 0 0	4 0/5 0 0 0 0/2/5 0/4 0 0/2/5 4 0/5	0 75 100 100 50 60 100 60 0 90	30 100 100 0 60 50 25 70 60 90 20
	2: Trial	3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 3.5 ft. Left Side 3.5 ft. Right Side 3.5 ft. Left Side	0 0 0 0 0 0 0 0 0 0 0 0 0 0	4 0/5 0 0 0 0/2/5 0/4 0 0/2/5 4 0/5 0	0 75 100 100 50 60 100 60 0 90 100	30 100 100 0 60 50 25 70 60 90 20 20 20
	2:	3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 3.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Left Side 3.5 ft. Left Side 1.5 ft. Straight	0 0 0 0 0 0 0 0 0 0 0 0 0	4 0/5 0 0 0 0/2/5 0/4 0 0/2/5 4 0/5	0 75 100 100 50 60 100 60 0 90	30 100 100 0 60 50 25 70 60 90 20
	2: Trial	3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 3.5 ft. Left Side 3.5 ft. Right Side 3.5 ft. Left Side	0 0 0 0 0 0 0 0 0 0 0 0 0 0	4 0/5 0 0 0 0/2/5 0/4 0 0/2/5 4 0/5 0	0 75 100 100 50 60 100 60 0 90 100	30 100 100 0 60 50 25 70 60 90 20 20 20

1.5 ft. Left Side	0	5	0	75
2.5 ft. Straight 2.5 ft. Right	0	4	0	5
Side	0	0/5	50	50
2.5 ft. Left Side	0	0/2	90	10
3.5 ft. Straight 3.5 ft. Right	0	4	0	0
Side	0	0	100	50
3.5 ft. Left Side	0	-	-	50

APPENDIX C

1:N LOCAL BINARY PATTERN (ORIGINAL) RESULTS

	Local Binary Pattern Histogram (Original)					
Person 1:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	False Positives Rate (%)
		1.5 ft. Straight	2	4/5	0	0
		1.5 ft. Right	2			10
		Side	2	- 4	-	10
		1.5 ft. Left Side 2.5 ft. Straight	2	4/5	0	10 0
		2.5 ft. Right	2	4/5	0	0
		Side	2	-	-	30
		2.5 ft. Left Side	2	4/5	-	0
		3.5 ft. Straight	2	0/2/5	30	10
		3.5 ft. Right Side	2	-	_	20
		3.5 ft. Left Side	2	2	100	10
		<u>5.5 II. Left Side</u>	2	2	100	10
	Trial					
	2:	1.5 ft. Straight	2	2/4/5	30	5
		1.5 ft. Right Side	2	_	_	10
		1.5 ft. Left Side	2	- 4/5	0	10
		2.5 ft. Straight	2	0/2/5	20	30
		2.5 ft. Right	-	0/2/0	20	50
		Side	2	-	-	60
		2.5 ft. Left Side	2	2/4/5	20	10
		3.5 ft. Straight 3.5 ft. Right	2	0/5	0	10
		Side	2	4	0	10
		3.5 ft. Left Side	2	2/4/5	50	0
	T 2 1					
	Trial 3:	1.5 ft. Straight	2	0/4/5	30	0
	0.	1.5 ft. Right	-		50	U
		Side	2	-	-	10
		1.5 ft. Left Side	2	-	-	20
		2.5 ft. Straight	2	42771	5	30
		2.5 ft. Right Side	2	-	-	60
		2.5 ft. Left Side	2	38387	40	20
		3.5 ft. Straight	2	0/5	0	20
		3.5 ft. Right	-	0,0	c .	20
		Side	2	-	-	80
		3.5 ft. Left Side	2	38387	5	40
Person	Trial				Prediction Rate	False Positives
2:	1:	Position	Expected Prediction Results	Actual Prediction Results	(%)	Rate (%)
		1.5 ft. Straight	1	3/8	0	10
		1.5 ft. Right				0
		Side	1	-	-	0
		1.5 ft. Left Side	1	0/4/5	0	10
		2.5 ft. Straight 2.5 ft. Right	1	5	0	10
		Side	1	5	0	30

			l			
		2.5 ft. Left Side	1	0/4	0	20
		3.5 ft. Straight 3.5 ft. Right	1	0/5	0	0
		Side	1	0/4	0	0
		3.5 ft. Left Side	1	2/4/5	0	50
	Trial					
	2:	1.5 ft. Straight 1.5 ft. Right	1	2/4/5	0	0
		Side	1	-	0	0
		1.5 ft. Left Side	1	4	0	0
		2.5 ft. Straight 2.5 ft. Right	1	2/4/5	0	20
		Side	1	5	0	0
		2.5 ft. Left Side	1	-	-	0
		3.5 ft. Straight 3.5 ft. Right	1	0	0	20
		Side	1	4/5	0	10
		3.5 ft. Left Side	1	4	0	20
	Trial					
	3:	1.5 ft. Straight 1.5 ft. Right	1	5	0	20
		Side	1	-	0	10
		1.5 ft. Left Side	1	-	0	20
		2.5 ft. Straight 2.5 ft. Right	1	0/3/5	0	30
		Side	1	4	0	20
		2.5 ft. Left Side	1	4	0	10
		3.5 ft. Straight 3.5 ft. Right	1	0/3/4/5	0	0
		Side	1	0/4	0	90
		3.5 ft. Left Side	1	4	0	0
Person	Trial				Prediction Rate	False Positives
3:	1:	Position	Expected Prediction Results	Actual Prediction Results	(%)	Rate (%)
				Actual Frediction Results	(/0)	
		1.5 ft. Straight	5		30	20
		1.5 ft. Straight 1.5 ft. Right	5	0/4/5		
		1.5 ft. Right Side	5			20 10
		1.5 ft. Right Side 1.5 ft. Left Side	5 5 5	0/4/5 - -	30 - -	20 10 30
		 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right 	5 5 5 5			20 10 30 10
		1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side	5 5 5 5 5	0/4/5 - -	30 - -	20 10 30 10 20
		1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side	5 5 5 5 5 5	0/4/5 - - 0/4 -	30 - - 0 -	20 10 30 10 20 20
		1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right	5 5 5 5 5 5 5	0/4/5 - - 0/4 - - 0	30 - - 0 - - 0	20 10 30 10 20 20 10
		1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side	5 5 5 5 5 5 5 5	0/4/5 - - 0/4 -	30 - - 0 -	20 10 30 20 20 10 50
		1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right	5 5 5 5 5 5 5	0/4/5 - - 0/4 - - 0	30 - - 0 - - 0	20 10 30 10 20 20 10
		1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side	5 5 5 5 5 5 5 5	0/4/5 - - 0/4 - - 0	30 - - 0 - - 0	20 10 30 20 20 10 50
	Trial 2:	1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight	5 5 5 5 5 5 5 5	0/4/5 - - 0/4 - - 0	30 - - 0 - - 0	20 10 30 20 20 10 50
		1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right	5 5 5 5 5 5 5 5 5 5	0/4/5 - - 0/4 - - 0 0 0 -	30 - - 0 - 0 0 0 -	20 10 30 20 20 10 50 20 20 20 20
		1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 1.5 ft. Straight 1.5 ft. Right Side	5 5 5 5 5 5 5 5 5 5 5 5	0/4/5 - - 0/4 - - 0 0 0 -	30 - - 0 - 0 0 0 -	20 10 30 20 20 10 50 20 20 20 15
		1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right	5 5 5 5 5 5 5 5 5 5	0/4/5 - - 0/4 - - 0 0 0 -	30 - - 0 - 0 0 0 -	20 10 30 20 20 10 50 20 20 20 20

		2.5 ft. Right				
		Side	5	-	-	10
		2.5 ft. Left Side	5	-	-	5
		3.5 ft. Straight	5	0/5	30	
		3.5 ft. Right				
		Side	5	4	0	20
		3.5 ft. Left Side	5	-	-	5
	Trial					
	3:	1.5 ft. Straight	5	0/4/5	20	30
		1.5 ft. Right				
		Side	5	0	0	20
		1.5 ft. Left Side	5	0	0	100
		2.5 ft. Straight 2.5 ft. Right	5	0/4/5	10	0
		Side	5	0	0	40
		2.5 ft. Left Side	5	-	-	0
		3.5 ft. Straight	5	0	0	0
		3.5 ft. Right				
		Side	5	0	0	0
		3.5 ft. Left Side	5	-	-	0
						Falsa
Person	Trial				Prediction Rate	False Positives
4:	1:	Position	Expected Prediction Results	Actual Prediction Results	(%)	Rate (%)
		1.5 ft. Straight	0	0	100	100
		1.5 ft. Right		a / i		
		Side	0	0/4	90	0
		1.5 ft. Left Side	0	0	100	30
		2.5 ft. Straight 2.5 ft. Right	0	0	100	5
		Side	0	0	100	0
		2.5 ft. Left Side	0	-	-	0
						-
		3.5 ft. Straight	0	0	100	0
		3.5 ft. Straight 3.5 ft. Right		0		0
		3.5 ft. Straight 3.5 ft. Right Side	0	-	-	0 70
		3.5 ft. Straight 3.5 ft. Right		0 - -		0
	Trial	3.5 ft. Straight 3.5 ft. Right Side	0	-	-	0 70
	Trial 2:	3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight	0	-	-	0 70
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right	0 0 0	0		0 70 5 90
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side	0 0 0	- - 0	- - 100 100	0 70 5 90 40
		 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 	0 0 0 0	- - 0 0/2/4	- - 100 100 50	0 70 5 90 40 0
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side	0 0 0	- - 0	- - 100 100	0 70 5 90 40
		 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 	0 0 0 0	- - 0 0/2/4	- - 100 100 50	0 70 5 90 40 0
		 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right 	0 0 0 0 0 0 0 0	- - 0 0 0/2/4 0 0 0	- - 100 100 50 100	0 70 5 90 40 0 60 20 50
		 3.5 ft. Straight 3.5 ft. Right 3.5 ft. Left Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Left Side 3.5 ft. Straight 	0 0 0 0 0 0 0	- - 0 0/2/4 0 0	- - 100 100 50 100 100	0 70 5 90 40 0 60 20
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Left Side 2.5 ft. Right Side 2.5 ft. Straight 3.5 ft. Straight 3.5 ft. Right	0 0 0 0 0 0 0 0 0 0	- - 0 0 0/2/4 0 0 0 0 0	- - 100 100 50 100 100 100 100	0 70 5 90 40 0 60 20 50 0
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 2.5 ft. Left Side 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side	0 0 0 0 0 0 0 0 0 0 0 0	- - 0 0/2/4 0 0 0 0 0 0	- - 100 100 50 100 100 100 100 100	0 70 5 90 40 0 60 20 50 0 70
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Left Side 2.5 ft. Right Side 2.5 ft. Straight 3.5 ft. Straight 3.5 ft. Right	0 0 0 0 0 0 0 0 0 0	- - 0 0 0/2/4 0 0 0 0 0	- - 100 100 50 100 100 100 100	0 70 5 90 40 0 60 20 50 0
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 2.5 ft. Left Side 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side	0 0 0 0 0 0 0 0 0 0 0 0	- - 0 0/2/4 0 0 0 0 0 0 0	- - 100 100 50 100 100 100 100 100	0 70 5 90 40 0 60 20 50 0 70
	2:	 3.5 ft. Straight 3.5 ft. Right 3.5 ft. Left Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 2.5 ft. Left Side 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right 3.5 ft. Left Side 	0 0 0 0 0 0 0 0 0 0 0 0	- - 0 0/2/4 0 0 0 0 0 0	- - 100 100 50 100 100 100 100 100	0 70 5 90 40 0 60 20 50 0 70
	2: Trial	3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side 3.5 ft. Left Side 3.5 ft. Right Side 3.5 ft. Left Side	0 0 0 0 0 0 0 0 0 0 0 0 0	- - 0 0/2/4 0 0 0 0 0 0 0	- - 100 100 50 100 100 100 100 100	0 70 5 90 40 0 60 20 50 0 70 20

1.5 ft. Left Side	0	0	100	40
2.5 ft. Straight 2.5 ft. Right	0	0	100	100
Side	0	0	100	0
2.5 ft. Left Side	0	0	100	50
3.5 ft. Straight 3.5 ft. Right	0	0	100	10
Side	0	0	100	90
3.5 ft. Left Side	0	0	100	20

APPENDIX D

1:N LOCAL BINARY PATTERN (MODIFIED) RESULTS

			Local Binary Pattern His	ern Histogram (Modified)		
Person 1:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	False Positive Rate (%
		1.5 ft. Straight	2	0/2/3	40	20
		1.5 ft. Right		2/2/4	20	
		Side	2	2/3/4	20	40
		1.5 ft. Left Side	2	1/4 1/2/4	0 50	80 30
		2.5 ft. Straight 2.5 ft. Right	2	1/2/4	50	30
		Side	2	2/3/4	40	10
		2.5 ft. Left Side	2	3/4/5	0	40
		3.5 ft. Straight	2	1/3/4/5	0	20
		3.5 ft. Right	2	4	0	10
		Side	2	4	0	10 30
		3.5 ft. Left Side	2	1/2	5	30
	Trial					
	2:	1.5 ft. Straight	2	2/3/4	10	60
		1.5 ft. Right		- 4-	_	
		Side	2	3/4	0	40
		1.5 ft. Left Side	2	0/2/3	30	20
		2.5 ft. Straight 2.5 ft. Right	2	2/3	10	40
		Side	2	2/3/4	20	30
		2.5 ft. Left Side	2	0/3	0	20
		3.5 ft. Straight 3.5 ft. Right	2	1/2/3/5	30	80
		Side	2	0/3/4	0	20
		3.5 ft. Left Side	2	2/3/4	30	10
	Trial 3:	1.5 ft. Straight	2	2/4	40	60
	5.	1.5 ft. Right	2	2/4	40	00
		Side	2	0/2/3/4	20	60
		1.5 ft. Left Side	2	4	0	70
		2.5 ft. Straight	2	1/4/5	0	30
		2.5 ft. Right		2/4	40	20
		Side	2	2/4	40	20
		2.5 ft. Left Side	2	4/5	0	40
		3.5 ft. Straight 3.5 ft. Right	2	1/2/3/4	10	80
		Side	2	2/3/4	30	20
		3.5 ft. Left Side	2	4	0	70
						False
Person	Trial	Desition	Eveneted Duadiction Data Its	Actual Dradiction Description	Prediction Rate	Positive
2:	1:	Position	Expected Prediction Results	Actual Prediction Results	(%)	Rate (%
		1.5 ft. Straight 1.5 ft. Right	1	1/4/5	30	0
		Side	1	0/3/4/5	0	5
		1.5 ft. Left Side	1	-	-	20
		2.5 ft. Straight 2.5 ft. Right	1	3/4	0	10
		Side	1	0/3/5	0	5

			1			100
		2.5 ft. Left Side 3.5 ft. Straight	1	- 2/3/4/5	- 0	0
		3.5 ft. Right	I	2/3/4/5	0	0
		Side	1	0/1/4/5	25	20
		3.5 ft. Left Side	1	1/4/5	20	10
	Tuint					
	Trial 2:	1.5 ft. Straight	1	1/4/5	10	0
		1.5 ft. Right				
		Side	1	0/5	0	0
		1.5 ft. Left Side	1	1/3/4	10	10
		2.5 ft. Straight 2.5 ft. Right	1	0/3/5	0	0
		Side	1	0/5	0	10
		2.5 ft. Left Side	1	0/1/4	50	0
		3.5 ft. Straight 3.5 ft. Right	1	3	0	0
		Side	1	1/4/5	10	0
		3.5 ft. Left Side	1	1/4/5	50	10
	Trial 3:	1 E ft Straight	1	0/2/5	0	10
	5.	1.5 ft. Straight 1.5 ft. Right	1	0/3/5	0	10
		Side	1	1/4/5	40	0
		1.5 ft. Left Side	1	1/4	50	20
		2.5 ft. Straight	1	0/2	0	0
		2.5 ft. Right Side	1	0/1/4	50	10
		2.5 ft. Left Side	1	1/4/5	15	20
		3.5 ft. Straight	1	0/1/3/4/5	25	10
		3.5 ft. Right Side	1	1/2/5	20	5
		3.5 ft. Left Side	1	1/3/5 1/4	20 50	5 10
		<u>- 5.5 II. Eelt 5146</u>	-	±/ ·	50	10
						False
Person	Trial	Desitien	Fundation Devides	Astual Desidiation Desults	Prediction Rate	Positives
3:	1:	Position	Expected Prediction Results	Actual Prediction Results	(%)	Rate (%)
		1.5 ft. Straight 1.5 ft. Right	8	0/1/5	30	20
		Side	8	1/2/5	50	0
		1.5 ft. Left Side	8	3/4	0	60
		2.5 ft. Straight	8	0/2/3	0	20
		2.5 ft. Right Side	8	0/2/5	60	10
						0
		2.5 ft. Left Side	8	1/3/4/5	25	0
		2.5 ft. Left Side 3.5 ft. Straight	8	1/3/4/5 3	25 0	0
		3.5 ft. Straight 3.5 ft. Right	8	3	0	0
		3.5 ft. Straight 3.5 ft. Right Side	8	3 0/2	0 0	0 0
		3.5 ft. Straight 3.5 ft. Right	8	3	0	0
	Trial	3.5 ft. Straight 3.5 ft. Right Side	8	3 0/2	0 0	0 0
	Trial 2:	3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight	8	3 0/2	0 0	0 0
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right	8 8 8 8	3 0/2 3/4 2/5	0 0 0 90	0 0 0 15
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side	8 8 8	3 0/2 3/4	0 0 0 90 30	0 0 0
		3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right	8 8 8 8 8	3 0/2 3/4 2/5 0/1/5	0 0 0 90	0 0 0 15 10

		2.5 ft. Right				
		Side	8	0/2/5	30	5
		2.5 ft. Left Side	8	3/4	0	0
		3.5 ft. Straight 3.5 ft. Right	8	2/5	75	10
		Side	8	1/2/4/5	25	5
		3.5 ft. Left Side	8	1/3/4/5	20	5
	Trial					
	3:	1.5 ft. Straight	8	0/2	0	30
		1.5 ft. Right Side	8	1/2	0	20
		1.5 ft. Left Side	8	1/7	0	80
		2.5 ft. Straight	8	0/1/3	0	20
		2.5 ft. Right		-, _, _		
		Side	8	2/3/5	50	10
		2.5 ft. Left Side	8	3/4	0	0
		3.5 ft. Straight 3.5 ft. Right	8	0/1/5	50	5
		Side	8	1/2/5	75	5
		3.5 ft. Left Side	8	4	0	10
						False
Person	Trial	D	For the distribution in the	A deal Deal's the Dealer	Prediction Rate	Positives
4:	1:	Position	Expected Prediction Results	Actual Prediction Results	(%)	Rate (%)
		1.5 ft. Straight 1.5 ft. Right	0	0/2/3	25	0
		Side	0	2/4	0	0
				- 1 - 1-		_
		1.5 ft. Left Side	0	0/1/2	50	0
		2.5 ft. Straight	0	0/1/2 0/2/3	50 50	0 10
				0/2/3		
		2.5 ft. Straight 2.5 ft. Right	0		50	10
		2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight	0	0/2/3 2/3/4	50 0	10 0
		2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right	0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5	50 0 50 20	10 0 100 0
		2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side	0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3	50 0 50	10 0 100 0 5
		2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right	0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5	50 0 50 20 15	10 0 100 0
	Trial	2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side	0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3	50 0 50 20 15	10 0 100 0 5
	Trial 2:	2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight	0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3	50 0 50 20 15	10 0 100 0 5
		2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right	0 0 0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3 0/1 0/3/5	50 0 50 20 15 60	10 0 100 0 5 5 100
		2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side	0 0 0 0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3 0/1 0/3/5 2/3/4	50 0 50 20 15 60 60 0	10 0 100 0 5 5 100 50
		2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right	0 0 0 0 0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3 0/1 0/3/5 2/3/4 1/2/5	50 0 50 20 15 60 60 0 0	10 0 100 0 5 5 100 50 100
		2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Straight 2.5 ft. Right	0 0 0 0 0 0 0 0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3 0/1 0/3/5 2/3/4 1/2/5 0/2/3	50 0 50 20 15 60 0 0 50	10 0 100 0 5 5 100 50 100 0
		2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 2.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side	0 0 0 0 0 0 0 0 0 0 0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3 0/1 0/3/5 2/3/4 1/2/5 0/2/3 2/3/4	50 0 50 20 15 60 60 0 0 50 0	10 0 100 0 5 5 100 50 100 0 10
		2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Straight 2.5 ft. Right	0 0 0 0 0 0 0 0 0 0 0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3 0/1 0/3/5 2/3/4 1/2/5 0/2/3 2/3/4 1/3/5	50 0 50 20 15 60 60 0 50 0 50 0 0 50 0 0 0 0 0 0 0 0 0 0 0	10 0 100 0 5 5 100 50 100 0 10 50
		2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 2.5 ft. Left Side 2.5 ft. Straight 2.5 ft. Right Side	0 0 0 0 0 0 0 0 0 0 0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3 0/1 0/3/5 2/3/4 1/2/5 0/2/3 2/3/4	50 0 50 20 15 60 60 0 0 50 0	10 0 100 0 5 5 100 50 100 0 10
		2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Straight 2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Left Side 3.5 ft. Straight	0 0 0 0 0 0 0 0 0 0 0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3 0/1 0/3/5 2/3/4 1/2/5 0/2/3 2/3/4 1/3/5	50 0 50 20 15 60 60 0 50 0 50 0 0 50 0 0 0 0 0 0 0 0 0 0 0	10 0 100 0 5 5 100 50 100 0 10 50
		2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 2.5 ft. Left Side 2.5 ft. Straight Side 2.5 ft. Straight Side 3.5 ft. Straight Side 3.5 ft. Straight Side	0 0 0 0 0 0 0 0 0 0 0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3 0/1 0/3/5 2/3/4 1/2/5 0/2/3 2/3/4 1/3/5 0/1/2/3	50 0 50 20 15 60 0 50 0 50 0 50 0 50 50 50 50	10 0 100 0 5 5 100 50 100 0 10 50 0 0
	2:	2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 2.5 ft. Straight 2.5 ft. Right Side 3.5 ft. Left Side 3.5 ft. Left Side 3.5 ft. Straight Side 3.5 ft. Straight 3.5 ft. Right Side	0 0 0 0 0 0 0 0 0 0 0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3 0/1 0/3/5 2/3/4 1/2/5 0/2/3 2/3/4 1/3/5 0/1/2/3 2/3/4	50 0 50 20 15 60 60 0 50 0 50 0 50 0 0 50 0 0 0 0 0 0 0 0 0 0 0 0 0	10 0 100 0 5 5 100 50 100 0 10 50 0 0 0 0
	2: Trial	2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 2.5 ft. Left Side 2.5 ft. Left Side 3.5 ft. Left Side 3.5 ft. Right Side 3.5 ft. Left Side 3.5 ft. Left Side	0 0 0 0 0 0 0 0 0 0 0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3 0/1 0/3/5 2/3/4 1/2/5 0/2/3 2/3/4 1/3/5 0/1/2/3 2/3/4 0/1/2/4	50 0 50 20 15 60 60 0 50 0 50 0 50 0 0 50 0 75	10 0 100 0 5 5 100 50 100 0 10 50 0 0 0 0 0 0 0
	2:	2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 2.5 ft. Left Side 2.5 ft. Right Side 3.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Straight Side 3.5 ft. Left Side	0 0 0 0 0 0 0 0 0 0 0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3 0/1 0/3/5 2/3/4 1/2/5 0/2/3 2/3/4 1/3/5 0/1/2/3 2/3/4	50 0 50 20 15 60 60 0 50 0 50 0 50 0 50 0 50 0 50 0 0 50 0 0 50 0	10 0 100 0 5 5 100 50 100 0 10 50 0 0 0 0
	2: Trial	2.5 ft. Straight 2.5 ft. Right Side 2.5 ft. Left Side 3.5 ft. Straight 3.5 ft. Right Side 3.5 ft. Left Side 1.5 ft. Straight 1.5 ft. Right Side 2.5 ft. Left Side 2.5 ft. Left Side 3.5 ft. Left Side 3.5 ft. Right Side 3.5 ft. Left Side 3.5 ft. Left Side	0 0 0 0 0 0 0 0 0 0 0 0 0 0	0/2/3 2/3/4 0/2/5 0/2/5 0/2/3 0/1 0/3/5 2/3/4 1/2/5 0/2/3 2/3/4 1/3/5 0/1/2/3 2/3/4 0/1/2/4	50 0 50 20 15 60 60 0 50 0 50 0 50 0 0 50 0 75	10 0 100 0 5 5 100 50 100 0 10 50 0 0 0 0 0 0 0

1.5 ft. Left Side	0	0/2	50	80
2.5 ft. Straight 2.5 ft. Right	0	2/3	0	5
Side	0	2/3/4	0	20
2.5 ft. Left Side	0	0/3	60	100
3.5 ft. Straight 3.5 ft. Right	0	1/2/5	0	0
Side	0	0/2/3/4	30	0
3.5 ft. Left Side	0	1/2	0	30

APPENDIX E

1:1 EIGENFACES RESULTS

			Eigenfa	ice		
Person 1:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	False Positives Rate (%)
		1.5 ft. Straight 1.5 ft. Right	2	2	100	20
		Side	2	2	100	60
		1.5 ft. Left Side	2	2	40	30
		2.5 ft. Straight 2.5 ft. Right	2	2	100	70
		Side	2	2	70	100
		2.5 ft. Left Side	2	2	10	80
		3.5 ft. Straight 3.5 ft. Right	2	2	100	20
		Side	2	2	100	10
		3.5 ft. Left Side	2	2	10	70
	Trial			2	100	00
	2:	1.5 ft. Straight 1.5 ft. Right	2	2	100	80
		Side	2	2	95	10
		1.5 ft. Left Side 2.5 ft. Straight	2 2	2 2	10 100	50 40
		2.5 ft. Right Side	2	2	100	60
		2.5 ft. Left Side	2	2	30	40
		3.5 ft. Straight 3.5 ft. Right	2	2	100	100
		Side	2	2	90	10
		3.5 ft. Left Side	2	2	95	10
	Trial 3:	1.5 ft. Straight	2	2	100	100
	э.	1.5 ft. Right Side	2	2	100	20
		1.5 ft. Left Side	2	2	0	10
		2.5 ft. Straight 2.5 ft. Right	2	2	100	100
		Side	2	2	95	100
		2.5 ft. Left Side	2	2	0	100
		3.5 ft. Straight 3.5 ft. Right	2	2	100	10
		Side	2	2	100	10
		3.5 ft. Left Side	2	2	80	20

Person 2:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	False Positives Rate (%)
		1.5 ft. Straight 1.5 ft. Right	-	2	0	0
		Side	-	2	0	0
		1.5 ft. Left Side	-	-	100	0

			I			
		2.5 ft. Straight 2.5 ft. Right	-	2	0	0
		Side	-	2	0	0
		2.5 ft. Left Side	-	2	0	0
		3.5 ft. Straight 3.5 ft. Right	-	2	0	0
		Side	-	2	0	100
		3.5 ft. Left Side	-	2	0	0
	Trial					
	2:	1.5 ft. Straight 1.5 ft. Right	-	2	0	0
		Side	-	2	0	20
		1.5 ft. Left Side	-	2	0	50
		2.5 ft. Straight 2.5 ft. Right	-	2	0	10
		Side	-	2	0	10
		2.5 ft. Left Side	-	2	0	0
		3.5 ft. Straight 3.5 ft. Right	-	2	0	20
		Side	-	2	0	20
		3.5 ft. Left Side	-	2	20	10
	Trial					
	3:	1.5 ft. Straight 1.5 ft. Right	-	2	0	10
		Side	-	2	0	10
		1.5 ft. Left Side	-	2	0	10
		2.5 ft. Straight 2.5 ft. Right	-	2	0	0
		Side	-	2	50	0
		2.5 ft. Left Side	-	2	100	10
		3.5 ft. Straight 3.5 ft. Right	-	2	0	0
		Side	-	2	0	20
		3.5 ft. Left Side	-	2	0	10
						False
Person 3:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	Positives Rate (%)
		1.5 ft. Straight	-	2	0	10
		1.5 ft. Right				•
		Side	-	-	100	0
		1.5 ft. Left Side 2.5 ft. Straight	-	-/2 2	50	80
		2.5 ft. Right	-	Z	0	0
		Side	-	-	100	0
			-	-	100	20
		2.5 ft. Left Side				
		3.5 ft. Straight 3.5 ft. Right	-	2	0	0
		3.5 ft. Straight	-	2	0 100 100	0 20 100

Trial					
2:	1.5 ft. Straight 1.5 ft. Right	-	2	0	20
	Side	-	-	100	20
	1.5 ft. Left Side	-	-	100	30
	2.5 ft. Straight 2.5 ft. Right	-	2	0	0
	Side	-	-	100	0
	2.5 ft. Left Side	-	2	0	25
	3.5 ft. Straight 3.5 ft. Right	-	2	0	10
	Side	-	-	0	10
	3.5 ft. Left Side	-	-/2	75	20
Trial 3:	1.5 ft. Straight 1.5 ft. Right	-	2	0	0
	Side	-	-	100	10
	1.5 ft. Left Side	-	-/2	25	20
	2.5 ft. Straight 2.5 ft. Right	-	2	0	0
	Side	-	-	100	0
	2.5 ft. Left Side	-	-/2	50	80
	3.5 ft. Straight 3.5 ft. Right	-	2	0	0
	Side	-	-	100	0
-	3.5 ft. Left Side	-	-	100	80

APPENDIX F

1:1 LOCAL BINARY PATTERN (ORIGINAL) RESULTS

			Local Binary Pattern His	togram (Original)		
Person 1:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	False Positives Rate (%)
		1.5 ft. Straight 1.5 ft. Right	2	2	100	5
		Side	2	2	100	0
		1.5 ft. Left Side	2	2	100	0
		2.5 ft. Straight 2.5 ft. Right	2	2	100	100
		Side	2	2	100	100
		2.5 ft. Left Side	2	2	100	70
		3.5 ft. Straight 3.5 ft. Right	2	2	100	80
		Side	2	2	100	20
		3.5 ft. Left Side	2	2	100	80
	Trial					
	2:	1.5 ft. Straight 1.5 ft. Right	2	2	100	20
		Side	2	2	100	5
		1.5 ft. Left Side	2	2	20	90
		2.5 ft. Straight 2.5 ft. Right	2	2	100	20
		Side	2	2	100	80
		2.5 ft. Left Side	2	2	100	10
		3.5 ft. Straight 3.5 ft. Right	2	2	100	100
		Side	2	2	100	20
		3.5 ft. Left Side	2	2	100	100
	Trial					
	3:	1.5 ft. Straight 1.5 ft. Right	2	2	100	0
		Side	2	2	100	10
		1.5 ft. Left Side	2	2	80	80
		2.5 ft. Straight 2.5 ft. Right	2	2	100	70
		Side	2	2	100	80
		2.5 ft. Left Side	2	2	100	10
		3.5 ft. Straight 3.5 ft. Right	2	2	100	30
		Side	2	2	100	70
		3.5 ft. Left Side	2	2	100	50

Person 2:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	False Positives Rate (%)
		1.5 ft. Straight 1.5 ft. Right	-	2	0	100
		Side	-	2	0	5
		1.5 ft. Left Side	-	2	0	20

Trial				Prediction Rate	False Positives
	3.5 ft. Left Side	-	2	30	0
	Side	-	2	0	0
	3.5 ft. Straight 3.5 ft. Right	-	2	0	0
	2.5 ft. Left Side	-	2	0	0
	2.5 ft. Right Side	-	2	0	0
	2.5 ft. Straight	-	2	0	0
	1.5 ft. Left Side	-	2	0	0
	1.5 ft. Right Side	-	2	0	0
Trial 3:	1.5 ft. Straight	-	2	0	0
	3.5 ft. Left Side	-	2	0	10
	3.5 ft. Straight 3.5 ft. Right Side	-	2 2	0	0 0
	2.5 ft. Left Side	-	2	0	0
	Side	-	2	0	0
	2.5 ft. Straight 2.5 ft. Right	-	2	0	0
	1.5 ft. Left Side	-	2	10	20
2:	1.5 ft. Straight 1.5 ft. Right Side	-	2 2	0	0 0
Trial				0	
	3.5 ft. Left Side	-	2	0	0
	3.5 ft. Straight 3.5 ft. Right Side	-	2 2	0	0 0
	2.5 ft. Left Side	-	2	0	0
	2.5 ft. Right Side	-	2	0	20
	2.5 ft. Straight	-	2	0	0

Person 3:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	False Positives Rate (%)
		1.5 ft. Straight 1.5 ft. Right	-	2	0	0
		Side	-	-	100	25
		1.5 ft. Left Side	-	-/2	50	50
		2.5 ft. Straight 2.5 ft. Right	-	2	0	20
		Side	-	-	100	25
		2.5 ft. Left Side	-	-/2	50	20
		3.5 ft. Straight 3.5 ft. Right	-	2	0	0
		Side	-	2	0	0
		3.5 ft. Left Side	-	2	0	0

Trial					
2:	1.5 ft. Straight 1.5 ft. Right	-	2	0	10
	Side	-	-	100	0
-	1.5 ft. Left Side	-	-	100	80
	2.5 ft. Straight 2.5 ft. Right	-	2	0	0
	Side	-	-/2	20	10
-	2.5 ft. Left Side	-	2	0	0
	3.5 ft. Straight 3.5 ft. Right	-	2	0	0
	Side	-	-/2	50	0
-	3.5 ft. Left Side	-	-/2	50	20
Trial			2	0	•
3:	1.5 ft. Straight 1.5 ft. Right	-	2	0	0
	Side	-	-	100	100
_	1.5 ft. Left Side	-	-	100	100
-	2.5 ft. Straight 2.5 ft. Right	-	2	0	0
	Side	-	-	100	10
-	2.5 ft. Left Side	-	-	100	100
	3.5 ft. Straight 3.5 ft. Right	-	2	0	0
	Side	-	-	100	0
_	3.5 ft. Left Side	-	-	100	100

APPENDIX G

1:1 LOCAL BINARY PATTERN (MODIFIED) RESULTS

			Local Binary Pattern Hist	togram (Modified)		
Person 1:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	False Positives Rate (%)
		1.5 ft. Straight 1.5 ft. Right	2	2	100	5
		Side	2	2	100	0
		1.5 ft. Left Side	2	2	100	0
		2.5 ft. Straight 2.5 ft. Right	2	2	100	0
		Side	2	2	100	80
		2.5 ft. Left Side	2	2	100	20
		3.5 ft. Straight 3.5 ft. Right	2	2	100	20
		Side	2	2	100	20
		3.5 ft. Left Side	2	2	60	30
	Trial					
	2:	1.5 ft. Straight 1.5 ft. Right	2	2	100	100
		Side	2	2	10	60
		1.5 ft. Left Side	2	2	100	60
		2.5 ft. Straight 2.5 ft. Right	2	2	100	95
		Side	2	2	100	20
		2.5 ft. Left Side	2	2	100	90
		3.5 ft. Straight 3.5 ft. Right	2	2	100	90
		Side	2	2	80	80
		3.5 ft. Left Side	2	2	95	10
	Trial					
	3:	1.5 ft. Straight 1.5 ft. Right	2	2	100	100
		Side	2	2	100	100
		1.5 ft. Left Side	2	2	95	70
		2.5 ft. Straight 2.5 ft. Right	2	2	100	95
		Side	2	2	100	100
		2.5 ft. Left Side	2	2	70	90
		3.5 ft. Straight 3.5 ft. Right	2	2	100	5
		Side	2	2	100	70
		3.5 ft. Left Side	2	2	100	95

Person 2:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	False Positives Rate (%)
		1.5 ft. Straight 1.5 ft. Right	-	2	0	0
		Side	-	2	0	20
		1.5 ft. Left Side	-	2	20	50

			I			
		2.5 ft. Straight	-	2	0	0
		2.5 ft. Right Side	-	2	20	0
		2.5 ft. Left Side	-	2	0	0
		3.5 ft. Straight 3.5 ft. Right	-	2	0	0
		Side	-	2	0	0
		3.5 ft. Left Side	-	2	0	0
	Trial 2:	1.5 ft. Straight 1.5 ft. Right	-	2	0	0
		Side	-	2	0	0
		1.5 ft. Left Side	-	2	0	0
		2.5 ft. Straight 2.5 ft. Right	-	2	0	0
		Side	-	2	0	10
		2.5 ft. Left Side	-	2	0	10
		3.5 ft. Straight 3.5 ft. Right	-	2	0	10
		Side	-	2	0	0
		3.5 ft. Left Side	-	2	0	0
	Trial					
	3:	1.5 ft. Straight 1.5 ft. Right	-	2	0	0
		Side	-	2	0	0
		1.5 ft. Left Side	-	2	0	0
		2.5 ft. Straight 2.5 ft. Right	-	2	0	0
		Side	-	2	0	0
		2.5 ft. Left Side	-	2	0	0
		3.5 ft. Straight 3.5 ft. Right Side	-	2	0	0
		3.5 ft. Left Side	-	2	0	0
					-	
Person 3:	Trial 1:	Position	Expected Prediction Results	Actual Prediction Results	Prediction Rate (%)	False Positives Rate (%)
-		1.5 ft. Straight	-	2	0	0
		1.5 ft. Right				
		Side	-	-	100	20
		1.5 ft. Left Side	-	-/2	25	100
		2.5 ft. Straight 2.5 ft. Right	-	2	0	0
		Side	-	-	100	30
		2.5 ft. Left Side	-	-/2	25	85
		3.5 ft. Straight 3.5 ft. Right	-	2	0	0
		Side	-	-	100	0
		3.5 ft. Left Side	-	-/2	50	0

Trial					
2:	1.5 ft. Straight 1.5 ft. Right	-	2	0	0
	Side	-	-/2	75	20
	1.5 ft. Left Side	-	2	0	80
	2.5 ft. Straight 2.5 ft. Right	-	2	0	0
	Side	-	-	100	50
	2.5 ft. Left Side	-	2	0	20
	3.5 ft. Straight 3.5 ft. Right	-	2	0	10
	Side	-	-	100	20
	3.5 ft. Left Side	-	2	0	80
Trial					
3:	1.5 ft. Straight 1.5 ft. Right	-	2	0	10
	Side	-	-/2	25	0
	1.5 ft. Left Side	-	-/2	10	10
	2.5 ft. Straight 2.5 ft. Right	-	2	0	0
	Side	-	-/2	75	10
	2.5 ft. Left Side	-	2	0	0
	3.5 ft. Straight 3.5 ft. Right	-	2	0	10
	Side	-	-	100	10
-	3.5 ft. Left Side	-	2	0	0

REFERENCES

- [1] Michael L. Rich, Machine Learning, "Automated Suspicion Algorithms, and the Fourth Amendment," *University of Pennsylvania Law Review*, vol. 164, pp. 871-929, 2016.
- [2] Rabia Jafri and Hamid R. Arabnia, "A Survey of Face Recognition Techniques," *Journal of Information Processing Systems*, vol. 5, no. 2, pp. 41-68, June 2009.
- [3] Andrea F. Abate et al, "2D and 3D face recognition: A survey," *Science Direct: Pattern Recognition Letters*, vol. 28, pp. 1885-1906, January 2007.
- [4] Matthew A. Turk and Alex P. Pentland. "Face Recognition Using Eigenfaces," presented at the 1991 IEEE Computer Society Conference on Computer Vision and Pattern Recognition, June 3-6, 1991, pp. 586-591.
- [5] Md. Abdur Rahim et al, "Face Recognition using Local Binary Patterns (LBP)," Global Journal of Computer Science and Technology Graphics & Vision, vol. 13, no. 4, pp. 1-8, 2013.
- [6] C. G. Tredoux et al., "Face Reconstruction using a Configural, Eigenfacebased Composite System," 3rd Biennial Meeting of the Society for Applied Research in Memory and Cognition (SARMAC). Boulder, Colorado, USA, 1999.
- [7] CNN, "Education School Face Scanner to Search for Sex Offenders," Phoenix, Arizona: *The Associated Press*, 2003.

- [8] D. McCullagh, "Call It Super Bowl Face Scan 1," Wired Magazine, 2001.
- [9] E. Acosta et al, "An Automatic Face Detection and Recognition System for Video Indexing Applications," *Proceedings of the IEEE International Conference on Acoustics, Speech and Signal Processing*, Vol.4. Orlando, Florida, 2002, pp.3644-3647.
- [10] Fatma Zohra Chelali and Amar Djeradi, "CSLBP and OCLBP Local Descriptors for Speaker Identification from Video Sequences," in *Third World Conference on Complex Systems (WCCS) 2015*, 2015.
- [11] H. Moon, "Biometrics Person Authentication Using Projection-Based Face Recognition System in Verification Scenario," *International Conference on Bioinformatics and its Applications*, Hong Kong, China, 2004, pp.207-213.
- [12] J.-H. Lee and W.-Y. Kim, "Video Summarization and Retrieval System Using Face Recognition and MPEG-7 Descriptors," *Image and Video Retrieval*, Vol.3115, Lecture Notes in Computer Science: Springer Berlin / Heidelberg, 2004, pp.179-188.
- [13] J. N. K. Liu et al, "iBotGuard: An Internet-Based Intelligent Robot Security System Using Invariant Face Recognition Against Intruder," IEEE Transactions on Systems Man And Cybernetics Part C-Applications And Reviews, Vol.35, pp.97-105, 2005.

- [14] K. Kim, "Intelligent Immigration Control System by Using Passport Recognition and Face Verification," *International Symposium on Neural Networks*. Chongqing, China, 2005, pp.147-156.
- [15] Li Liu, Lingjun Zhao et al, "Extended Local Binary Patterns for Texture Classification," *Image and Vision Computing*, Vol.30, no.2, pp. 86-99, February 2012.
- [16] Li Liu, Songyang Lao et al, "Median Robust Extended Local Binary Pattern for Texture Classification," Vol.25, pp. 1368-1381, March 2016.
- [17] P. J. Phillips et al, "The FERET Evaluation Methodology for Face Recognition Algorithms," IEEE Transactions on Pattern Analysis and Machine Intelligence, Vol.22, pp.1090-1104, 2000.
- [18] Peter N. Belhumeur et al, "Eigenfaces vs Fisherfaces: Recognition Using Class Specific Linear Projection," *IEEE Transactions on Pattern Analysis* and Machine Intelligence, Vol. 19, no.7, pp. 711-720, July 1997.
- [19] Rob Schapire, "Theoretical Machine Learning," http://www.cs.princeton.edu/courses/archive/spr08/cos511/, February 2008.
- [20] S. L. Wijaya et al, "Illumination-Tolerant Face Verification of Low-Bitrate JPEG2000 Wavelet Images with Advanced Correlation Filters for Handheld Devices," *Applied Optics*, Vol.44, pp.655-665, 2005.

- [21] T. Choudhry et al, "Multimodal Person Recognition Using Unconstrained Audio and Video," Proceedings, International Conference on Audio and Video-Based Person Authentication, 1999, pp.176-181.
- [22] Timo Ahonen et al, "Face Description with Local Binary Patterns: Application to Face Recognition," *IEEE Transactions on Pattern Analysis* and Machine Intelligence, Vol.28 no.12, pp. 2037-2041, December 2006.
- [23] Xiaofeng Fu and Wei Wei, "Centralized Binary Patterns Embedded with Image Euclidean Distance for Facial Expression Recognition," in *Proc. International Conference on Natural Computation*, Vol. 4, pp. 115-119, 2008.