



NATIONAL AERONAUTICS AND SPACE ADMINISTRATION

Technical Library, Bellcomm, Inc.

SEP 25 1969


# CSM/LM SPACECRAFT OPERATIONAL DATA BOOK

## VOLUME IV EMU DATA BOOK

REVISION 1


SEPTEMBER 2, 1969

(NASA-TM-X-69018) CSM/LM SPACECRAFT  
OPERATIONAL DATA BOOK. VOLUME 4: EMU  
DATA BOOK (NASA) 2 Sep. 1969 341 p



X73-70103

Unclas  
00/99 37778  
1920212223



MANNED SPACECRAFT CENTER  
HOUSTON, TEXAS

CSM/IM SPACECRAFT OPERATIONAL DATA BOOK

VOLUME IV

EMU DATA BOOK

PREPARED BY

APOLLO SUPPORT BRANCH

CREW SYSTEMS DIVISION

ENGINEERING AND DEVELOPMENT DIRECTORATE

MANNED SPACECRAFT CENTER

Concurrence *C. C. Kraft, Jr.*  
C. C. Kraft, Jr., Director  
Flight Operations

Approved by *R. E. Smylie*  
R. E. Smylie, Chief  
Crew Systems Division

Concurrence *D. K. Slayton*  
D. K. Slayton, Director  
Flight Crew Operations

Approved by *M. A. Faget*  
M. A. Faget, Director  
Engineering and Development

Approved by *George M. Low*  
George M. Low, Manager  
Apollo Spacecraft Program

## PREFACE

This document is the first revision issue of the EMU Data Book. This revision incorporates Amendments 1 through 22. Amendments released subsequent to the publication of this revision will be numbered sequentially with the next amendment number (i.e., 23 and on).

Volume IV EMU Data Book  
Table of Contents

Amendment 24  
11/12/69

<u>PARAGRAPH</u> <u>NO.</u>	<u>TITLE</u>	<u>PAGE</u> <u>NO.</u>
1.0	INTRODUCTION . . . . .	1-1
1.1	Purpose . . . . .	1-1
1.2	Content . . . . .	1-2
1.3	Amendments . . . . .	1-3
1.4	Selected Abbreviations . . . . .	1-4
2.0	EXTRAVEHICULAR MOBILITY UNIT CONFIGURATION . . . . .	2.1-1
2.1	Extravehicular Mobility Unit Configuration . . . . .	2.1-1
2.2	Pressure Garment Assembly Configuration . . . . .	2.2-1
2.3	Constant Wear Garment . . . . .	2.3-1
2.4	Liquid Cooling Garment . . . . .	2.4-1
2.5	Urine Collection and Transfer Assembly . . . . .	2.5-1
2.6	Biomedical Instrumentation System . . . . .	2.6-1
2.7	Portable Life Support System Configuration . . . . .	2.7-1
2.8	Oxygen Purge System Configuration . . . . .	2.8-1
2.9	Feedwater Collection Bag . . . . .	2.9-1
2.10	Unit Weights . . . . .	2.9-1
3.0	OPERATIONAL CONSTRAINTS AND LIMITATIONS . . . . .	3.1-1
3.1	Crewman/Extravehicular Activity . . . . .	3.1-1
3.2	Extravehicular Pressure Garment Assembly . . . . .	3.2-1
3.3	Intravehicular Pressure Garment Assembly . . . . .	3.3-1
3.4	Portable Life Support System . . . . .	3.4-1
3.5	Oxygen Purge System . . . . .	3.5-1
3.6	Extravehicular Communications System . . . . .	3.6-1
4.0	SUBSYSTEM PERFORMANCE DATA . . . . .	4.0-1
4.1	Pressure Garment Assembly . . . . .	4.1-1
4.2	Liquid Cooling Garment . . . . .	4.2-1
4.3	UCTA . . . . .	4.3-1
4.4	BIS . . . . .	4.4-1
4.5	PLSS Performance Data . . . . .	4.5-1
4.5.1	Extravehicular Communications System . . . . .	4.5-1
4.5.2	PLSS Electrical Subsystem . . . . .	4.5-21
4.5.3	Ventilation Loop . . . . .	4.5-29
4.5.4	Liquid Transport Loop . . . . .	4.5-45
4.5.5	Feedwater Supply Loop . . . . .	4.5-53
4.5.6	Primary Oxygen Subsystem . . . . .	4.5-63
4.6	OPS . . . . .	4.6-1
Appendix - Mission G (Apollo 11) . . . . .		G-0
Appendix - Mission H (Apollo 12) . . . . .		H-0



Volume IV EMU Data Book  
Introduction

1.0 INTRODUCTION

1.1 Purpose

This document presents performance information regarding the mission capabilities and limitations of the Extravehicular Mobility Unit (EMU). This information is intended for use in nominal mission planning and to provide the performance characteristics of the EMU during normal mission operations.

## Volume IV EMU Data Book

### Introduction

#### 1.2 Content

The complete Data Book for manned missions will consist of five separate volumes, defines as follows:

Volume I - CSM Data Book - Part 1 Performance, Part 2 Launch Rules

Volume II - LM Data Book - Part 1 Performance, Part 2 Launch Rules

Volume III - Mass Properties Data Book

Volume IV - EMU Data Book

Volume V - ALSEP Data Book

This volume, Volume IV, is divided into four sections, plus an appendix for each individual mission which contains consumable data and performance information for each flight EMU. The volume presents the EMU system and subsystem performance data for Zero-G and lunar excursion missions. A brief discussion of the scope of the sections of Volume IV follows.

##### 1.2.1 Section 1.0, Introduction

The introduction describes the purpose and scope of the overall data book, and summarizes the content of the remaining sections. It includes a list of abbreviations used in this volume.

##### 1.2.2 Section 2.0, EMU Configuration

This section contains pictorial representations of the EMU and its sub-assemblies. These data are intended as reference material for use throughout the data book.

##### 1.2.3 Section 3.0, EMU Constraints and Operational Limitations

The restrictions, limitations, and special recommendations on the use of the EMU and its subsystems are contained in this section.

##### 1.2.4 Section 4.0, Subsystem Performance Data

This section presents data concerning subsystem performance so that the mission planner and monitor can be familiar with system capabilities and normal operating characteristics.

Volume IV EMU Data Book  
Introduction

1.2.5 Appendices

An appendix is presented for each mission. Each appendix presents data applicable to specific flight EMU's. PIA data are entered in these appendices as it becomes available. The data presented also contains consumable information applicable to that mission.

1.3 Amendments

Amendments to this document will be made by page additions or replacements. Data changed by an amendment will be denoted by an amendment date and number in the upper right-hand corner of the page, and a vertical bar in the page margin to locate the change. The vertical bar will only be used, however, when the change is made to verbal descriptive material. A revision page identifying the accumulative changes that have been made will be issued with each amendment. This page should be placed just behind the title page, and will provide an up-to-date listing of all amendments.

Volume IV EMU Data Book  
Introduction

1.4 Selected Abbreviations and Acronyms

C

CDR	Commander
CM	Command Module
CMP	Command Module Pilot
CSM	Command and Service Module
CWG	Constant Wear Garment

E

EKG	Electrocardiogram
EMU	Extravehicular Mobility Unit
EV	Extravehicular
EVA	Extravehicular Activity
EVCS	Extravehicular Communications System
EVT	Extravehicular Transfer

F

F/W	Feedwater
-----	-----------

I

ITMG	Integrated Thermal Micrometeoroid Garment
IV	Intravehicular

L

LCG	Liquid Cooling Garment
LEVA	Lunar Extravehicular Visor Assembly
LiOH	Lithium Hydroxide
LM	Lunar Module
LMP	Lunar Module Pilot

M

MSC	Manned Spacecraft Center
MSFN	Manned Space Flight Network

N

NASA	National Aeronautics and Space Administration
------	---

Volume IV EMU Data Book  
Introduction

O

OPS                    Oxygen Purge System

P

PGA                    Pressure Garment Assembly  
PIA                    Pre-Installation Acceptance  
PLSS                   Portable Life Support System

R

RCU                   Remote Control Unit  
RF                    Radio Frequency

S

S/C                    Spacecraft

T

TBD                   To Be Determined  
TM                    Telemetry  
T/W                   Transport Water


U

UCTA                   Urine Collection and Transfer Assembly  
UV                    Ultraviolet

2.0 EXTRAVEHICULAR MOBILITY UNIT CONFIGURATION

2.1 Extravehicular Mobility Unit Configuration

Figures 2.1-1 and 2.1-2 show the EMU configuration. The function of the EMU is to provide the Apollo extravehicular crewman with a habitable environment with sufficient mobility to perform EVA tasks for a design EVA period of four hours. The system is capable of performing in free space or on the lunar surface. It can be replenished from LM supplies for performing three additional EVA missions.



\* IDENTIFICATION STRIPES ON CDR EMU ONLY

Figure 2.1-1.- Extravehicular Mobility Unit (lunar surface configuration).




Figure 2.1-2 Extravehicular Mobility Unit Major Subsystems



Volume IV EMU Data Book  
EMU Configuration - PGA

2.2 Pressure Garment Assembly Configuration

The PGA consists of a pressure helmet, torso limb suit, gloves, boots, and various PGA controls. The function of the PGA is to enclose the crewman in a pressurized environment and permit performance of mission tasks in vacuum ambient pressure conditions. Two configurations of the PGA are utilized. The extravehicular (EV) PGA is worn by the LMP and CDR for use during EVA. The intravehicular (IV) PGA is worn by the CMP for intravehicular operations within the CM. A dimensional view of a typical PGA is shown in Figure 2.2-1.

2.2.1 Pressure Helmet

The pressure helmet shown in Figure 2.2-2 is a detachable transparent enclosure with provisions for feeding, drinking, and LEVA attachment.

2.2.2 Torso Limb Suit

The torso limb suit shown in Figure 2.2-3 incorporates a ventilation system shown in Figures 2.2-4 and 2.2-5 which provides a path for oxygen used for respiration, helmet defogging, and cooling. A biomedical injection patch is included to permit a crewman to self-administer a hypodermic injection.

2.2.3 Extravehicular PGA

The EV PGA shown in Figure 2.2-6 provides the crewman with a pressurized environment and thermal and micrometeoroid protection required when worn as a subassembly of the EMU for EVA portions of the mission. It incorporates the pressure helmet and torso limb suit discussed in sections 2.2.1 and 2.2.2 with the following additions.

- (a) An integrated thermal micrometeoroid garment (ITMG), shown in Figure 2.2-7, provides protection against temperature extremes, micrometeoroid impact, and ultraviolet rays in addition to fire and abrasion resistance.
- (b) A pressure relief valve protects the PGA from overpressurization.
- (c) A removable purge valve, shown in Figure 2.2-8, located in the unused outlet gas connector, provides carbon dioxide washout and minimum cooling during contingency or emergency operation.
- (d) Lunar boots, shown in Figure 2.2-9, provide thermal and abrasive protection for the PGA/ITMG boots during lunar surface operations.

- (e) The EV Glove Assembly, shown in Figure 2.2-10, is a protective hand covering which is interfaced with the EV PGA prior to egress for extravehicular operations. The EV Glove provides increased thermal and abrasive protection during EVA. A cover glove constructed of a single layer of silicone coated Nomex is provided with each EV glove to provide increased abrasion protection during EV operation of the core driller. Each cover glove is fingertip-less to maintain the original tactility of the EV glove and has provision for utilizing the EV glove palm restraint access flap to secure the cover glove in such a way that access to the palm restraint strap is retained. The cover glove is required only for the core drilling operation and is expendable after that time.
- (f) The lunar extravehicular visor assembly, shown in Figure 2.2-11, provides visual attenuation, thermal protection, and micrometeoroid impact protection during EVA. The LEVA also protects the pressure helmet from direct contact with the lunar surface during accidental impact.

#### 2.2.4 Intravehicular PGA

The IV PGA shown in Figure 2.2-12 provides the crewman with a pressurized environment when worn as a subassembly of the EMU for IV portions of the mission. Beside incorporating the pressure helmet and torso limb suit discussed in sections 2.2.1 and 2.2.2, it incorporates an IV cover layer. The IV cover layer provides abrasion and fire protection for intravehicular activity.




Figure 2.2-1 Typical A7L PGA Dimensions (pressurized) for a 5 1/2 foot tall crewman





Figure 2.2-2 Pressure Helmet



**NOTE**

The IV torso suit has the following items removed:

1. Left inlet and outlet gas connectors
2. Multiple water connector
3. Pressure relief valve
4. LM restraints
5. Upper and lower PLSS attachments

Figure 2.2-3 Extravehicular Configuration of the Torso Limb Suit




Figure 2.2-4 Ventilation Systems of the Torso Limb Suit

**NOTE: THE IV PGA  
HAS PLENUM  
CHAMBER AND  
LEFT GAS  
CONNECTORS  
REMOVED**




Figure 2.2-5 Ventilation Flow Diagram

Volume IV EMU Data Book  
EMU Configuration - PGA




Figure 2.2-6 Extravehicular PGA Configuration








Figure 2.2-7 Integrated Thermal Micrometeoroid Garment



**PURGE MODE**



**UNACTIVATED  
(ROTATED 180° FROM PURGE MODE VIEW)**

Figure 2.2-8 Purge Valve




Figure 2.2-9 Lunar Boots




Figure 2.2-10 EV Glove





Figure 2.2-11 Lunar Extravehicular Visor Assembly

Volume IV EMU Data Book  
EMU Configuration - PGA




Figure 2.2-11 Intravehicular PGA Configuration

Volume IV EMU Data Book  
EMU Configuration - CWG

2.3 CONSTANT WEAR GARMENT

The constant wear garment, shown in Figure 2.3-1, is a cotton fabric undergarment worn next to the skin under the PGA or inflight coverall garment during intravehicular CM operation. It provides general comfort and perspiration absorption, and supports the bioinstrumentation system.




Figure 2.3-1 Constant Wear Garment

2.4 Liquid Cooling Garment

The liquid cooling garment configuration is shown in Figures 2.4-1 and 2.4-2. The LCG is worn by the IM crewman (CDR and IMP) during all IM operations, and during all EVA portions of the mission, but under normal circumstances, is operational only when used in conjunction with the PLSS. The LCG provides a means for circulation of water over the crewman's body for removal of metabolic heat.






Figure 2.4-1 Liquid Cooling Garment

Volume IV EMU Data Book  
EMU Configuration - LCG




Figure 2.4-2 Coolant System of the LCG




Figure 2.4-3 LCG Circulation System

Volume IV EMU Data Book  
EMU Configuration - UCTA

2.5 Urine Collection and Transfer Assembly

The UCTA, shown in Figure 2.5-1, collects and provides intermediate storage of crewman's urine during launch, EVA, or emergency modes when the spacecraft waste management system cannot be used.




Figure 2.5-1 Urine Collection Transfer Assembly

## 2.6 Biomedical Instrumentation System

The BIS provides a means for monitoring the biomedical status of the astronauts during all phases of the Apollo mission.




Figure 2.6-1 Bioinstrumentation System

Volume IV EMU Data Book  
EMU Configuration - PLSS (SV706100-6)

2.7 Portable Life Support System Configuration

The configuration of the PLSS is shown in Figures 2.7-1 through 2.7-6. The function of the PLSS is to provide life support, communications, and telemetry during extravehicular portions of the Apollo mission. The following life support functions are performed:

- (a) Pressure control
- (b) Breathing oxygen supply
- (c) Ventilation
- (d) Humidity control
- (e) Contaminant control
- (f) Thermal control

The PLSS, shown schematically in Figure 2.7-7, consists of the following subsystems jointly satisfying the performance requirements of the PLSS. A brief description of each subsystem follows.

2.7.1 Communication and Telemetry

Three modes of two-way voice communications are provided between the PLSS and the LM for relay to MSFN. In addition, an FM link is provided directly between the two EV crewmen. The system performance of each PLSS is monitored in eight areas with the information commutated on one subcarrier unique to each crewman, and telemetered to earth via the LM. In addition, the EKG information for each crewman is sampled continuously and telemetered to earth via the LM. The various combinations of communications modes are pictorially represented in Figures 2.7-8 through 2.7-10. An audible tone is also provided to alert the EV crewman of the occurrence of one or more of four unsafe conditions.

2.7.2 Electrical Supply and Distribution Subsystem

The PLSS electrical supply and distribution subsystem consists of a replaceable power source (battery) and the necessary controls, terminal boxes, current limiters, and wiring required to satisfy the PLSS electrical requirements.

2.7.3 Oxygen Ventilating Circuit

The Oxygen Ventilation Circuit circulates a fresh, refrigerated oxygen supply through the PGA. The  $O_2$  from the PGA passes to the contaminant control assembly where odors, foreign particles, and  $CO_2$  are removed. The  $O_2$  passes then to a sublimator where it is cooled. From the sublimator, it passes to a water separator, then to a fan which circulates the  $O_2$  back to the PGA along with makeup  $O_2$ .

2.7.4 Water Transport Loop

The water transport loop circulates water through the LCG for the absorption of metabolic heat and dissipates the heat in the PLSS.

2.7.5 Feedwater Supply Loop

The feedwater supply loop provides a supply of expendable water used for the dissipation by sublimation of all heat entering into or generated by the EMU.

2.7.6 Primary Oxygen Subsystem

The primary oxygen subsystem provides a rechargeable supply of gaseous oxygen and maintains PGA and ventilation loop pressures at 3.70 to 4.00 psia during normal extravehicular operation. If leakage goes out of specification, causing a high O<sub>2</sub> flow, the pressure may drop to 3.5 psia. The primary oxygen subsystem contains one pressure bottle with a volume of 378 cubic inches.






Figure 2.7-1 Portable Life Support System (PLSS)




Figure 2.7-2 PLSS (Cont'd)

Volume IV EMU Data Book  
 EMU Configuration - PLSS




Figure 2.7-3 PLSS (Cont'd)

Volume IV EMU Data Book  
 EMU Configuration - PLSS




Figure 2.7-4 PLSS (Cont'd)

Volume IV EMU Data Book  
 EMU Configuration - PLSS




Figure 2.7-5 PLSS (Cont'd)




Figure 2.7-6 Remote Control Unit




Figure 2.7-7 PLSS Functional Diagram

Volume IV EMU Data Book  
EMU Configuration - PLSS




Figure 2.7-8 EVCS Pictorial Diagram: Dual-Dual



Volume IV EMU Data Book  
EMU Configuration - PLSS




Figure 2.7-9 EVCS Pictorial Diagram: Dual-Sec



## 2.8 Oxygen Purge System Configuration

The OPS configuration is shown in Figure 2.8-1. The purpose of the OPS (shown schematically in Figure 2.8-2) is to perform short-term life support functions in the event of specific EMU failures. The OPS maintains a regulated pressure of 3.4 to 4.0 psia when activated during EVA. It contains two pressure bottles with a combined volume of 322 cubic inches.





Figure 2.8-1 Oxygen Purge System - Major Components



Note: There is a filter on both sides of the shut-off valve and at the input side of the regulator.

Figure 2.8-2 Oxygen Purge System

## 2.9 PLSS Feedwater Collection Bag

The PLSS feedwater collection bag is capable of containing the feedwater remaining in the PLSS upon completion of lunar activity. The bag contains a connector which mates with the PLSS feedwater fill connector. After accepting the surplus feedwater, the bag maintains it in a sealed condition. The bag is designed to be used with a spring-type scale to measure the amount of feedwater collected. The weighing operation is performed in the lunar environment by a suited astronaut. Accuracy of the scale is verified by calibration with dead loads and shall be no worse than 3% of full scale in 1/6 g.

The PLSS feedwater collection bag is constructed of two layers. The inner layer is neoprene coated nylon tricot and the outer restraint layer is Nomex cloth. The bag is tubular in shape and has a hole or scale attachment point at one end and a connector which interfaces with the PLSS at the other. The bag holds approximately 5.8 lbs. of water at 1 g. The feedwater residual after draining into the feedwater collection bag is approximately 0.83 lbs.

### 2.9.1 Feedwater Usage Analysis

Since no direct method of measuring feedwater usage in real-time is available, the estimated computational accuracy is required. This accuracy is determined by comparing the measured feedwater remaining, using the feedwater collection bag and scale, and the calculated quantity used. The following method is used to determine the error of the calculated water usage.

- a. The percent error is determined by

$$\% \text{ Error} = \frac{\text{Actual Used} - \text{Calculated Used}}{\text{Actual Used}} \times 100$$

A positive percent error indicates that more water was actually used than the real-time calculations revealed (under estimate of the actual value), whereas a negative percent error reveals an over estimate.

- b. The actual water used is determined by weighing the water after the EVA and subtracting this plus the residual from the amount loaded. The value of the residual is 0.83 lbs. If real-time circumstances reveal a sublimator dry out (e.g. early shut off of the water valve), metabolic estimations will be continued and the initial loading of a subsequent EVA will be adjusted so that no error will be attributed to the water usage after the water valve shut off.

$$\text{Actual Used} = \text{Total Loaded} - \text{Weighed} - \text{Residual}$$

#### 2.9.1 Feedwater Usage Analysis (Continued)

- c. The calculated water used is derived from the Medical Research and Operations Directorate's (MROD) assessment of metabolic rate. MROD's assessment of metabolic rate is used by FCD in conjunction with the equipment and environmental heat loads in determining an  $H_2O$  quantity usage during a given time period, and the total calculated used is equal to the total loaded minus the remaining quantity at the end of the EVA.

Calculated Used = Total Loaded - Remaining

Table 2.10-1 Unit Weights

ITEM	SPEC WEIGHT	ACTUAL WEIGHT
EV-PGA (with ITMG)	46.47 lbs	42.80 lbs
IV-PGA (with IVCL)	35.52 lbs	34.08 lbs
PLSS/EVC-1 (with O <sub>2</sub> , H <sub>2</sub> O, Battery, LiOH and RCU)	88.26 lbs	85.77 lbs
PLSS/EVC-2 (with O <sub>2</sub> , H <sub>2</sub> O, Battery, LiOH and RCU)	88.14 lbs	85.88 lbs
OPS	41.00 lbs	40.89 lbs
Lunar Boots (pair)	4.90 lbs	4.50 lbs
EV Gloves (pair)	2.50 lbs	2.15 lbs
LEVA	4.40 lbs	4.10 lbs
LCG	4.90 lbs	4.45 lbs
CWG	0.90 lbs	0.78 lbs
UCTA	0.53 lbs	0.52 lbs
FCS	0.50 lbs	0.32 lbs
Bioinstrumentation System	1.10 lbs	1.10 lbs
Communications Carrier	1.63 lbs	1.58 lbs
Feedwater Collection Bag (w/o scale)	TBD	0.47 lbs



## 2.11 Drinking Bag (In-Suit)

A drinking bag is provided to enable the individual crewman to have access to approximately 8 ounces of drinking water during an EVA. The bag is constructed of 10 mil. polyurethane and has a surgical rubber tube which extends into the bag and down one side to the bottom. There is a bite valve on the end of the tube exterior to the bag. The bag has a fill connector at the top on the other side which is identical to that used on the food bags. This allows the drinking bag to be refilled using the water dispenser/fire extinguisher prior to the next EVA. There is a heat seal along the vertical center line of the bag which does not extend completely to either the top or bottom, and prevents the bag from bulging excessively when it is charged. The top of the heat seal is used as an indication of a complete fill. When the water level within the bag is at the top of the heat seal, the bag contains approximately 8 ounces of water. Nylon Velcro hook and pile is incorporated along the top horizontal edge to provide for mounting the drinking bag between the comfort liner and bladder of the PGA in the chest area. The Velcro of the bag is sandwiched between that of the two suit layers at the neck opening. The drinking bag is installed in the PGA with the drinking tube on the crewman's left. To obtain water, the crewman bites gently on the mouthpiece and sucks the water as if using a straw.

Volume IV EMU Data Book  
Operational Constraints and Limitations

3.0 OPERATIONAL CONSTRAINTS AND LIMITATIONS

3.1 Crewman/Extravehicular Activity

OPERATIONAL LIMITATIONS OR PROCEDURE

RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

EV-1 Contingency EVA Configuration

Minimum EMU configuration for EVA is:

EVA crewman safety is compromised. Insufficient to afford adequate protection

1. EV-PGA
2. Pressure Helmet Assembly
3. LEVA or Helmet Shield
4. EV Gloves
5. PLSS/LCG or OPS/Purge Valve

EV-2 Lunar Surface Configuration

Minimum EMU configuration for Lunar EV is:

EVA crewman safety is compromised. Insufficient to afford adequate protection

1. EV-PGA
2. Pressure Helmet Assembly
3. LEVA
4. EV Gloves
5. Communications Carrier
6. Lunar Boots
7. LCG
8. Bio-belt Assembly
9. Bioinstrumentation Assembly
10. PLSS/LCG and OPS/Purge Valve
11. FCS
12. UCTA

Note: The PLSS, RCU, LEVA, and OPS are individually interchangeable between crewmen.

3.1 Crewman/Extravehicular Activity (Cont'd)

OPERATIONAL LIMITATIONS OR PROCEDURE

RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

EV-3 Crewman Sweating

The PLSS H<sub>2</sub>O separator can handle the maximum amount of sweat picked up in the gas stream.

N/A

EV-4 Distance from LM ECS

Crewmen EVA shall never be more than 30 minutes from connection to the LM ECS.

Possible inability of EV crewman to reach LM ECS before exhaustion of emergency O<sub>2</sub> supply.

EV-5 PGA Gas Diverter Valves (2)

Gas diverter valves must be in vertical position for EVA (for either OPS or PLSS operation)

Insufficient CO<sub>2</sub> washout

EV-6 Crewman Carried Objects

There is no way to describe the full range (weight, volume, shape, etc.) of objects which can successfully be carried on the lunar surface. Parameters vary with individual crewman size and capabilities.

N/A

EV-7 Reconfiguring From OPS to PLSS Operation

When reconfiguring the EMU from OPS to PLSS operation, the purge valve shall be closed and the locking pin replaced prior to OPS oxygen shut-off.

The PGA will depressurize.

3.1 Crewman/Extravehicular Activity (Cont'd)

OPERATIONAL LIMITATION OR PROCEDURE

RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

EV-8 Total EMU EVA Time

The total accumulative lunar surface EVA time for the EMU shall not exceed twelve (12) hours.

Exceeds the qualified use limits presented in the CTR's for Apollo 11 hardware.

EV-9 Purge Valve Position

The EVA pre-set position of the Purge Valve is in the LOW flow (4.0 lbs/hr) position. Use of the OPS for cooling purposes requires resetting the Purge Valve to HIGH (8.1 lbs/hr).

Time for crewman to react is not sufficient if purge valve opened to HIGH flow and OPS not actuated.

EV-10 Maximum Crewman Heat Storage

Heat storage by crewman's body should be limited to 300 Btu.

Possible physical harm or discomfort may occur to the crewman.

### 3.2 Extravehicular Pressure Garment Assembly

#### OPERATIONAL LIMITATION OR PROCEDURE

#### RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

##### EPG-1 Time in Uncooled PGA

The safe maximum time allowed in an uncooled pre-egress PGA is 30 minutes.

Heat buildup in the PGA above maximum comfort point. (80°F)

NOTE: Helmet, Gloves, and PLSS O<sub>2</sub> are on.

##### EPG-2 PGA/PLSS/OPS Pressure Integrity Checkout

With the S/C cabin at 5.0 psia, the maximum allowable pressure decay is 0.3 psi/minute at 8.8 psia in PGA.

After extensive study and test, it is concluded that there is no way to determine in real time the leak rate of the PGA (EMU). The only purpose accomplished by a pressure integrity check is to give confidence that gross leaks are not present.

##### EPG-3 LEVA Visor UV Exposure

Deleted

##### EPG-4 Helmet Fogging

The effective duration of the anti-fog compound is 6 hours: 2 hrs pre-helmet donning and 4 hrs after helmet donned.

Obstruction of the crewman's vision creating a safety hazard.

Volume IV EMU Data Book  
Operational Constraints and Limitations

3.2 Extravehicular Pressure Garment Assembly (Cont'd)

OPERATIONAL LIMITATION OR PROCEDURE

RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

EPG-5 Proximity to Thruster Plumes

Only marginal protection is afforded the LEVA if its proximity to the thruster plumes is as close as 5 ft. for 0.5 seconds.

Material will be degraded  
(Reference GE TIR 580-S-7168)

EPG-6 Gas Connector Dust Contamination

Excessive dust/dirt contamination of the gas connectors may prevent the locking ring to be cycled. (See EPG-7)

Crewman may not be able to reconnect O<sub>2</sub> umbilicals to the contaminated gas connector.

EPG-7 Connector Cleansing

In the event of gas connector contamination, the water dispenser should be used to clean the connector. The entire operation should be loosely surrounded by a towel to minimize loose water ejected into cabin.

Loose water may be ejected into cabin.

EPG-8 EVA Glove Contact

EVA Glove can sustain gripping of objects for 3 minutes at 250°.

Crewman hand becomes uncomfortable.

EPG-9 Unventilated PGA

The PGA with helmet and gloves donned is limited to 60 seconds without ventilation.

CO<sub>2</sub> buildup in the helmet may become excessive.

EPG-10 Helmet Rotation

Do not rotate helmet pas lock alignment marks.

Flow of oxygen to the helmet may be blocked and the neck ring seal and locking dogs may be damaged.

4/8/70

Volume IV EMU Data Book  
Operational Constraints and Limitations

### 3.2 Extravehicular Pressure Garment Assembly (Cont'd)

#### OPERATIONAL LIMITATION OR PROCEDURE

#### RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

##### EPG-11 Time in Pressurized PGA

In order for the crewman to remain comfortable and function properly during EVA the uninterrupted time in a pressurized PGA should be limited to 8 hours.

Additional time will cause excessive fatigue and discomfort and create undesirable risk

##### EPG-12 Helmet Crazing

Helmet crazing does not present a pressure constraint

N/A

##### EPG-13 Loss of Lunar Boot

There is no material constraint on the PGA boot; however, a potential constraint from heat leak to the crewman does exist although the onset rate will be slow. If the temperature becomes uncomfortable, then an effort should be made to don the lost boot. If this cannot be done, then abort. The PGA boot sole should be examined 5 minutes after lunar boot loss and every 15 minutes thereafter. If excessive abrasion occurs, then abort.

The temperature of the crewman's foot would exceed the comfort level. The PGA boot sole is not an integral part of the pressure envelope.

##### EPG-14 Cleaning and Lubrication of PGA Seals After Each EVA

The seals of the PGA gas connectors, wrist disconnects, neck ring, and pressure sealing closure (if the closure has been actuated) shall be cleaned and lubricated after each EVA.

Sluggish operation of the connectors and disconnects during engagement and disengagement will occur.

### 3.3 Intravehicular Pressure Garment Assembly

#### OPERATIONAL LIMITATION OR PROCEDURE

#### RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

##### IPG-1 PGA Pressure Integrity Checkout

With the S/C cabin at 5.0 psia, the maximum allowable pressure decay is 0.3 psid/minute at 8.8 psia in PGA.

After extensive study and test, it is concluded that there is no way to determine in real time during a mission the leak rate of the PGA (EMU). The only purpose accomplished by a pressure integrity check is to give confidence that gross leaks are not present.

##### IPG-2 EV Exposure

EV exposure of the IV crewman is not permitted without the LEVA or Helmet Shield. With the LEVA or Helmet Shield, exposure is limited to 30 minutes in earth orbital sunlight exposure and 20 minutes in earth shadow conditions.

Insufficient thermal protection to the crewman.

##### IPG-3 Helmet Shield UV Exposure

DELETED

##### IPG-4 IV Glove Contact

The maximum temperature allowed for IV glove contact is 130°F.

130°F results in discomfort to the crewman. The bladder degrades at 160°F.

##### IPG-5 Time in Pressurized PGA

DELETED



Volume IV EMU Data Book  
Operational Constraints and Limitations

3.4 Portable Life Support System

OPERATIONAL LIMITATION OR PROCEDURE

RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

PLS-1 Loss of Feedwater Pressure

The PLSS liquid transport loop will reject approximately 500 BTU of external heat after the feedwater warning tone actuates.

The temperature of the space suit environment will rise to an uncomfortable level (LCG inlet temp 80°F)

PLS-2 Deadhead Operation

There is no constraint on operation of the pump or the fan deadheaded in the stowed condition.

N/A

PLS-3 Sublimator Freeze-Up

When EV the pump should be on, and a heat load of 250 BTU/hr maintained in the liquid transport loop.

The sublimator will freeze up and the cooling function will be lost.

PLS-4 Sublimator Start-Up

For sublimator start-up, the ambient should be 1000 microns (.02 psia) or less, and the diverter valve should be set for minimum cooling.

Sublimator breakthrough could occur on start-up.

PLS-5 Sublimator Restart

The sublimator can be restarted at any time during the drying out process. For restart, the pressure should be 1000 microns (.02 psia) or less, and the diverter valve should be in the minimum cooling position (See PLS-4 and PLS-13).

Sublimator breakthrough could occur on restart.

PLS-6 Operation Without Cooling

No damage will be sustained by PLSS or EVCS components by PLSS operation without cooling.

N/A

### 3.4 Portable Life Support System (Cont'd)

#### OPERATIONAL LIMITATION OR PROCEDURE

#### RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

##### PLS-7A IM Repressurization - POS Pressure

A minimum pressure of 200 psia is required in the primary oxygen supply to maintain the PGA in a positive pressure condition during IM repressurization.

The crewman would be required to use a slower LM repressurization to maintain positive suit pressure. (Reference Figure 4.5-53).

##### PLS-7B LM Repressurization - Feedwater Valve Closure

The feedwater valve should be closed before repressurizing the IM.

Feedwater will be dumped in IM at a rate of .176 - .198 lbs/minute at a P of 3.8 psia. In any case, .288 to .331 pounds of water will be dumped upon subsequent LM Depress.

##### PLS-8 Fan and Pump Switch Off

Deleted.

##### PLS-9 LiOH Exposure to Vacuum

The LiOH Cartridge should not be exposed to an ambient pressure less than 0.5 psia for more than 15 minutes. (The stowed cartridge is sealed to the S/C environment).

Exposure to an ambient pressure less than 0.5 psia causes the water in the LiOH to vaporize limiting its use time in the EMU to 60 minutes maximum.

##### PLS-10 Diverter Position After Start-Up

The diverter valve can safely be placed in the desired cooling position 5 minutes after start-up in the event the pressure transducer fails and causes erroneous indications (see PLS-4 and PLS-5).

Sublimator breakthrough could occur.

Volume IV EMU Data Book  
Operational Constraints and Limitations

Amendment 29  
4/8/70

3.4 Portable Life Support System (Cont'd)

OPERATIONAL LIMITATION OR PROCEDURE

RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

PLS-11 POS Use After Recharge

There are no constraints on the use of the primary oxygen supply after recharge.

N/A

PLS-12 POS Contamination

There is no minimum pressure required to prevent back flow contamination of the primary oxygen supply. A filter prevents contamination.

N/A

PLS-13 Sublimator Breakthrough

If breakthrough occurs, these steps must be followed in order to accomplish restart:

1. Close feedwater valve.
2. Place diverter valve in max. cooling position.
3. Maintain activity for at least 5 minutes to facilitate sublimator dryout. (See Notes 1 & 2)
4. Place diverter valve in min. cooling position.
5. Open feedwater valve.
6. Desired diverter valve position may be selected when feedwater pressure is acquired indicating successful startup. (Approx. 5 minutes - see PLS-10).

Startup will not occur.

NOTE 1: The most recent flight data indicative of a wet sublimator restart shows that sublimator dry-out is not required for a successful restart for operation with low sublimator heat loads. A hot restart (high sublimator heat loads) will require sublimator dryout.

NOTE 2: An indication of sublimator dryout is the decay of feedwater pressure below the vapor pressure of water (0.5-0.7 psia).

PLS-14 Pump Shutdown

Pump shutdown while EVA shall be limited to 10 minutes maximum. Pump shutdown while inside the unpressurized IM is also 10 minutes.

Liquid transport water in sublimator will freeze rendering the liquid transport loop inoperable.

Volume IV EMU Data Book  
Operational Constraints and Limitations

3.4 Portable Life Support System (Cont'd)

OPERATIONAL LIMITATION OR PROCEDURE

RESULTS OF EXCEEDING LIMITA-  
TION OR NOT FOLLOWING PRO-  
CEDURE

PLS-15 Diverter Valve Positioning

Diverter valve positioning between de-  
tents does not shut off the transport  
water loop. Portions of each position  
will allow some flow.

N/A

PLS-16 Battery Storage

The battery shall be stored within the  
temperature limits of 0°F to 130°F.  
Plate warpage will occur at 160°F.

Possible degradation of bat-  
tery performance. Definite de-  
gradation if plate warpage  
occurs.

3.4 Portable Life Support System (Cont'd)

OPERATIONAL LIMITATION OR PROCEDURE

RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

PLS-17 LiOH Storage Temp

The LiOH Cartridge can be stored at temperatures within limits of figure 4.5-34, page 4.5-40.

Reduced LiOH efficiency.

PLS-18 LM ECS/PLSS Hybrid

Constraints associated with the following LM/ECS Hybrids:

- (a) Static PLSS oxygen ventilation loop. PLSS gas connectors must be connected to the PGA or the PLSS oxygen valve must be on.
- (b) Static PLSS liquid transport loop. (LTL) (Ref. PLS-14) Pump shutdown is limited to 10 minutes.
- (c) Static PLSS LTL and Sublimator. Eventual helmet fogging dependent on the metabolic load.

Water will not be expelled to the Sublimator.

Sublimator freeze up may damage sublimator and preclude subsequent restart. No damage is expected to the O<sub>2</sub> loop.

Loss of visibility through the helmet.

PLS-19 Feedwater Collection

The feedwater shall not be collected with the feedwater collection bag if the feedwater remaining is greater than 5.8 pounds.

Exceeds the feedwater collection bag capacity.

.4 Portable Life Support System (Cont'd)

OPERATIONAL LIMITATION OR PROCEDURE

RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

PLS-20 Contingency Retention of PLSS

In the event both PLSS's are retained to satisfy contingency EVA requirements, the following procedures must be followed:

Vital connectors and/or umbilicals could be damaged precluding their use. The LiOH could be degraded by residual moisture in the PLSS and rendered useless.

- (a) All connector caps shall be in place.
- (b) All umbilicals (including the battery cable) shall be in their respective stowage plates.
- (c) The LiOH Cartridge shall be removed from the PLSS and stowed in any bag where space is available.

PLS-21 Feedwater Replenish Temperature

The maximum temperature of water for feedwater replenish shall be 109°F.

Excess feedwater temperature will cause sublimator breakthrough.

PLS-22 Diverter Valve Position After Start-up

When the low feedwater pressure warning flag clears the diverter valve may be placed in any desired position.

Earlier diverter valve positioning will cause sublimator breakthrough.

PLS-23 Gas Separator EVA Bleed

There is no freezing constraint associated with the contingency bleeding of the gas separator during EVA.

N/A

3.4 Portable Life Support System (Cont'd)

OPERATIONAL LIMITATION OR PROCEDURE

RESULTS OF EXCEEDING LIMITA-  
TION OR NOT FOLLOWING PRO-  
CEDURE

PLS-24 Use of IM Urine Bags During Recharge

The IM urine bags shall not be used as a receptacle for the PLSS condensate during a feedwater recharge.

The condensate side of the bladder in the feedwater reservoir has an approximate volume of 4400 cc's which includes 875 cc's of condensate after a nominal mission. The urine bags have an approximate volume of 875 cc's. Since the feedwater is recharged to a pressure of 40 psi, which is the pressure forcing the condensate plus air into the urine bags, and since the urine bags are only proof pressurized to 10 psi, the consequence of attempting this operation would result in an exploded urine bag.

PLS-25 Thermal Load on Sublimator

A maximum thermal load at the sublimator of 8750 BTU/Hr. should not be exceeded.

Sublimator breakthrough will occur.

Volume IV EMU Data Book  
Operational Constraints and Limitations

3.5 Oxygen Purge System

OPERATIONAL LIMITATION OR PROCEDURE

RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

OPS-1 OPS Charge

The pressure of the OPS shall not exceed 6950 psia.

The regulator performance becomes erratic

OPS-2 OPS Actuation

The OPS hose shall be securely connected to its stowage plate, PGA, or held by the crewman before actuating the OPS.

The thrust developed is sufficient to cause damage.

OPS-3 OPS Heat Removal

The OPS is capable of heat removal at the rate of 600 to 800 BTU/hour. This limit is the result of the purge valve restricting flow.

The Astronaut becomes overheated.

OPS-4 OPS Unrestrained Flow

The OPS will empty all usable oxygen in 4.2 minutes when the flow is unrestrained.

N/A

OPS -5 OPS Electrical Checkout

Successful electrical checkout is not mandatory for manned operations

Crewman can tolerate temperatures of the gas with heater not operating



### 3.5 Oxygen Purge System (Cont'd)

#### OPERATIONAL LIMITATION OR PROCEDURE

#### RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

##### OPS-6 Intermittent Use of OPS

If the OPS is to be used temporarily to correct some minor difficulty such as helmet fogging, the PLSS O<sub>2</sub> shut-off valve must be turned off prior to actuating the OPS.

Because of the set points of the two regulators, the POS regulator will attempt to supply the 8.0 lbs/hr allowed by the purge valve. The OPS will supply only the difference. This will deplete the POS supply rapidly to a point severely restricting the mission profile and/or requiring a recharge of the PLSS O<sub>2</sub>.

Volume IV EMU Data Book  
Operational Constraints and Limitations

3.6 Extravehicular Communications System

OPERATIONAL LIMITATION OR PROCEDURE

RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

EVCS-1 Line of Sight

RF line of sight must exist between transmitting and receiving antenna for all communication.

Complete loss of communications.

EVCS-2 LM-MSFN-CSM Relay

While communicating with the CSM via the LM and MSFN relay, the EVA crew must allow 4.8 to 6.0 seconds for each reply. In communicating with MSC, 2.4 to 3.0 seconds must be allowed.

Lack of discipline results in loss of intelligent communication between the EV crewman, the CSM, and MSC.

EVCS-3 Proximity to LM VHF Antenna

There is no constraint as to nearness to the LM VHF antenna.

N/A

EVCS-4 Range

The range is limited to one mile between LM and EVC-1 (CDR) and one-half mile between Astronauts.

Probable loss of communications.

EVCS-5 Operation in LM

The EVCS is unrestricted for operation within the LM. (See EVCS-7)

N/A

EVCS-6 Operation Without Antenna

The EVCS should not be operated without the antenna.

Although the EVC's are capable of operating for four hours with the antenna terminals shorted or open, communication will be lost for the duration of the anomaly.

Volume IV EMU Data Book  
Operational Constraints and Limitations

Amendment 25

1/30/70

3.6 Extravehicular Communication System (Cont'd)

OPERATIONAL LIMITATION OR PROCEDURE

RESULTS OF EXCEEDING LIMITATION OR NOT FOLLOWING PROCEDURE

EVCS-7 Antenna Stowed

EVCS operation with the antenna stowed is an out of spec condition, and is an individual characteristic of each individual unit.

Possible loss of power and/or excessive voice distortion. If severe distortion encountered go to operationally unstowed mode.

EVCS-8 Mode Selection

The two EV communicators should never be in the Primary (A) or Secondary (B) modes simultaneously.

The frequencies will beat and a loud interfering signal will be produced.

EVCS-9 Mode Restriction on EVC-2

The EVC-2 communicator shall be switched to Primary (A) or Secondary (B) mode if and when the EVC-1 communicator is switched from the Dual (AR) mode. (Reference EVCS-8 above).

All communication from the EVC - 2 communicator will be lost.

EVCS-10 Proximity to Erectable S-Band Antenna

The crewman shall not get directly in front of S-Band antenna in the radiating path. No other constraint exists.

Getting in front of antenna sufficient to be dangerous would be very difficult. Touching from back-side would cause only slight temporary static.

EVCS-11 Failed EVA Antenna

With the EVA antenna failed transmission between crewman and LM inline with the fore or aft VHF inflight antenna is estimated to be limited to one-half mile.

Probable loss of communications with crewman.

#### 4.0 SUBSYSTEM PERFORMANCE DATA

This section presents data concerning the performance of EMU subsystems. The initial data presented is that which is applicable to the system as a whole. The ensuing paragraphs provide data of increased detail on the operating characteristics of the individual subsystems.

The EMU subsystems design/operational limits are provided in Table 4.0-1 and the proof and burst pressures of these subsystems are provided in Table 4.0-2. The EMU consumables management information is shown in Table 4.0-3. The EMU heat leak as a function of the sum angle is shown in Figure 4.0-1.

Table 4.0-1 EMU Subsystems Design/Operational Limits

PORTABLE LIFE SUPPORT SYSTEM									
SUBSYSTEM	VOLUME	TEMPERATURE		PRESSURE		LEAKAGE RATE	VOLTAGE		
		MAXIMUM	MINIMUM	MAXIMUM	MINIMUM				
Primary Oxygen	378 - 384 in <sup>3</sup>	110°F	35°F	1110 psia	100 psia	3 scc/min @ 1020 + 10 psia	----		
Feedwater	.135 - .143 ft <sup>3</sup>	109°F	35°F	3.7 psia	1.6 psia	1.64 cc/hr	----		
Power Supply	----	160°F	0°F	----	----	----	16.0 - 17.2 VEC		
Vent Loop	0.214 ft <sup>3</sup>	110°F	35°F	4.05 psia	3.5 psia	17 scc/min	----		
Transport Water	0.020 ft <sup>3</sup>	90°F	35°F	44 psia	3.5 psia	0.27 cc/hr	----		
OXYGEN PURGE SYSTEM									
Oxygen Supply	320 in <sup>3</sup>	+150°F*	-60°F*	6750 psia	500 psia-100 psia (make-up mode)	20 scc/hr	----		
Power Supply	----	160°F	0°F	----	----	----	25.2 - 28.0 VEC		
Low Pressure Vent System	----	80°F	30°F	4.0 psia	3.4 psia	3 scc/min	----		
PRESSURE GARMENT ASSEMBLY									
EV - PGA (total)	0.75 to 2.2 ft <sup>3</sup>	250°F	-290°F	5.5 psia	3.5 psig	180 scc/min	----		
Torso Limb Suit	----	----	----	----	----	145 scc/min	----		
Helmet	----	----	----	----	----	15 scc/min	----		
EV Gloves (each)	----	----	----	----	----	10 scc/min	----		
IV Gloves (each)	----	----	----	----	----	10 scc/min	----		

\* FAILED HEATER -on and off- NORMAL PURGE FLOW

Table 4.0-2 EMU Proof and Burst Pressures

SYSTEM	PROOF PRESSURE	BURST PRESSURE
<u>PLSS</u> Primary Oxygen Feedwater Vent Loop Transport Water	1665 psid 75 psid 9 psid 75 psid	2220 psid 100 psid 12 psid 100 psid
<u>OPS</u> Oxygen Supply Low Pressure Loop	10,130 psid 6 psid	13,500 psid 8 psid
<u>PGA</u> Pressure Garment Assembly*	8 psid	10 psid

\* THE PGA HAS A STRUCTURAL PRESSURE OF 6 psid.

Table 4.0-3 EMU Consumables

	PRIMARY OXYGEN PLSS ITEM	FEEDWATER RESERVOIR	LIQUID TRANSPORT LOOP	LIQUID COOLING GASMENT (LOG)	OPS O <sub>2</sub> BOTTLES	PLSS LiOH CARTRIDGE	PLSS BATTERY	OPS BATTERY
Volume (ft <sup>3</sup> )	0.219	0.139	0.02	N/A	0.185	N/A	N/A	N/A
Nominal Loading	1.237 lbs at 1020 psia, 70°F	8.55 lbs (6)	1.2#	0.77 lbs	5.82 lbs at 5880 psia, 70°F	3.0 lbs	16.5 amp hr at 16.8 VDC	2.6 amp hr at 27.0 VDC
Loading Inaccuracy	0.013 lbs at + 10 psia, 70°F	.06 lbs	+ 0.06#	N/A	.080 lbs at 80 psia, 70°F	N/A	N/A	N/A
Charged Storage Lifetime	N/A	14 days	14 days	14 days	N/A	N/A	12 days	24 days
Leak Rate	3 sec/min at 1020 + 10 psia	1.64 cc/hr at 50 psig	0.27 cc/hr at 25.5 psig	N/A	20 sec/hr at 6935 + 200 psig	N/A	N/A	N/A
Leakage Over 200-hr Period	0.101 lbs	0.13	N/A (1)	N/A	0.0117 lbs	N/A	N/A	N/A
Residual	0.123 lbs at 100 psia, 70°F	0.78 to 0.95 lbs (2)	N/A	N/A	500 psia - Purge 0.521 lbs, 70°F 0.642 lbs, -30°F 100 psia - Maximum 0.106 lbs, 70°F	Minimum 34% re- action efficiency	N/A	N/A
TM Inaccuracy	0.035 lbs at + 28 psia, 70°F	N/A	N/A	N/A	N/A	N/A	0.75 amp hr at 5 hrs (5)	N/A
O/B Inaccuracy (3)	0.0615 lbs at + 50 psia, 70°F	N/A	N/A	N/A	0.313 lbs at 300 psia, 70°F	N/A	N/A	N/A
TM Usable	0.964 lbs	N/A	N/A	N/A	N/A	N/A	15.75 amp hr	N/A
O/B Usable	0.937 lbs	*7.47-7.64	*1.25 lbs	*0.77 lbs	5.29 lbs	*4800 BTU	N/A	*2.6 amp hr

\*No method of consumable readout. Usable is loading less residual and leakage.

1. Leakage is part of 0.13 lbs. total leakage shown as feedwater reservoir leakage.

2. Residual includes quantity of water that fills sublimator in addition to reservoir expulsion inefficiency.

3. O/B denotes onboard readout accuracy.

4. 200 sec/min = 0.035 lb/hr O<sub>2</sub> and represents maximum specification EMU leakage.

5. Based upon 0.15 AMP/HR.

6. Subsequent to the first EVA the total loading of the recharged feedwater reservoir is 0.3 lbs in addition to that reported at pre-launch PLA. This addition represents H<sub>2</sub>O trapped between the S/O valve and the sublimator.




Figure 4.0-1 EMU Heat Leak versus Sun Angle



#### 4.1 Pressure Garment Assembly

The PGA consists of a pressure helmet, torso limb suit, intravehicular gloves, an external coverlayer, and various controls and instrumentation. The garment is designed to be worn for 115 hours at a regulated pressure of  $3.85 \pm 0.15$  psid in conjunction with either the LCG or the CWG.

Two configurations of the PGA are to be flown on all Apollo missions. In the intravehicular configuration, which is worn by the Command Module Pilot (CMP), the basic torso limb suit is covered by a fire and abrasion resistant coverlayer. Redundant gas connectors and other extravehicular components have been removed to decrease weight and bulk. In the extravehicular configuration, an integrated thermal micrometeoroid garment (ITMG) is attached to the PGA for protection against thermal loads and micrometeoroid penetration, in addition to fire and abrasion protection. The weight and other leading particulars are given in Table 4.1-1.

##### 4.1.1 PGA Internal Volume

Because the internal volume of the PGA varies with the size of the crewman for whom it is constructed, the internal volume is considered to be 4.7 cubic feet  $\pm 10\%$ . Because the free volume (manned) varies also with the fit of suit to the crewman, the free volume is considered to be 2.2 cubic feet  $\pm 5\%$ .

##### 4.1.2 PGA Orifice Flow Rates

The PGA Pressure Relief Valve flow characteristics as a function of the PGA pressure is shown in Figure 4.1-1. The flow characteristics of the PGA Pressure Transducer porous plug as a function of the PGA pressure is shown in Figure 4.1-2.

Volume IV EMU Data Book  
Subsystem Performance Data - PGA

Table 4.1-1 PGA Performance Characteristics

ITEM	VALUE	
	IV-PGA	EV-PGA
Temperature Limitation	S/C Wall -20 to + 150°F	± 250°F
Leak Rate (Max) at 3.7 psid	180 scc/min.	180 scc/min.
Operating Pressure	3.75 ± .25 psid	3.75 ± .25 psid
Pressure Drop		
12 acfm, 3.9 psia, 50°F, inlet diverter valve in IV position.	4.70 in. H <sub>2</sub> O	4.70 in. H <sub>2</sub> O
6 acfm, 3.9 psia, 50°F, inlet diverter valve in EV position.		1.80 in. H <sub>2</sub> O
Pressure Relief Valve Flow Rate	3.6 + .2 lbs/hr. @ 5.5 psia	3.6 + .2 lbs/hr. @ 5.5 psia
Weight	34.13 lbs.	43.42 lbs.

Volume IV EMU Data Book  
Subsystem Performance Data - PGA

Amendment 29  
4/8/70




Figure 4.1-1 PGA Relief Valve Flow Characteristics




Figure 4.1-2 PGA Pressure Transducer - Low Pressure Transducer  
Porous Plug Flow Characteristics

#### 4.2 LCG

The LCG is worn next to the skin under the PGA during LM and EV activities. The LCG is made of nylon-spandex knitted material, and provides for general comfort, perspiration absorption, and thermal transfer between the crewman's body and the garment's cooling media. The garment provides a continuous flow of temperature controlled water through a network of polyvinyl chloride (PVC) tubing stitched to the inside surface of the open mesh fabric garment. A lightweight nylon comfort liner separates the body from the tubing network.

The LCG can remove heat at a maximum rate of 2000 BTU/hr. for 15 minute periods, or a continuous rate of 1700 BTU/hrr. (These parameters are dependent upon PLSS operational design). Leading particulars of the LCG are given in Table 4.2-1.

##### 4.2.1 LCG Pressure rofile

The LCG pressure profile in the various environments is as follows:

- a. Sea level charge pressure is 28.5 psia.
- b. While stowed in the CM, the LCG is in a bag evacuated to 2.85-5.0 psia. Based on test results, measurable loss in LCG weight or gas permeation into the LCG does not occur.
- c. Operating pressure in LM is 12-21 psig above cabin ambient of 5 psia.
- d. Operating pressure on lunar surface is 4 to 21 psia in 3.8 psia suit environment.

A typical LCG pressure profile prior to LCG/PLSS interfacing is depicted in Figure 4.2-1.

##### 4.2.2 LCG Internal Volume

The internal volume of the LCG tubing nominally is 350 cc. The range is approximately 310 - 380 cc.

Volume IV EMU Data Book  
Subsystem Performance Data - LCG

Table 4.2-1 LCG Performance Characteristics

ITEM	VALUE
Weight (Charged)	<sup>a</sup> 4.60 lbs.
Operating Pressure	4.2 to 23.0psid
Pressure Drop	
4.0 lbs/min. flow at 70° ± 10°F inlet temp.	3.2 psi including both halves of connector
Leak Rate (Maximum)	
19.0 psid pressure differ- ential @ 45°F	0.58 cc/hr.

<sup>a</sup>Design Value

NOTES:

1. No visible gas involvement in either LCG
2. Cabin Temp. 72-79°F
3. 192 H<sub>2</sub>O Temp. 72-77°F




Figure 4.2-1 LCG and 192 Liquid Loop Pressure Vs. Mission Time

Volume IV EMU Data Book  
Subsystem Performance Data - UCTA

4.3 Urine Collection and Transfer Assembly (UCTA)

The UCTA collects and provides intermediate storage of a crewman's urine during launch, EVA, or emergency modes when the spacecraft waste management system cannot be used. The UCTA will accept urine at rates up to 30 cc/sec with a maximum stored volume of 950 cc. No manual adjustment or operation by the crewman is required while the UCTA is collecting urine. Pressure relief valves are incorporated in the urine collection bag to prevent exposure of the penis to pressure differentials of  $\pm 1$  inch  $H_2O$  between the collection bag and the PGA. The valves open automatically as required to increase pressure within the collection bag. A flapper check valve prevents reverse flow from the collection bag to the urinal portion of the UCTA. The stored urine can be transferred through the suit wall by hose when feasible to the CM or LM during both pressurized and depressurized cabin operation.

The UCTA is worn over the CWG or the LCG, and is connected by hose to the urine transfer connector on the PGA. This urine transfer connector is a quick-disconnect fitting which is used for the transfer of urine from the UCTA to the spacecraft waste management system.



Volume IV EMU Data Book  
Subsystem Performance Data - BIS

4.4 Bioinstrumentation System (BIS)

The bioinstrumentation system is attached to either the CWG or LCG, and contains the necessary bioinstrumentation for crew status check. The bioinstrumentation, connected to the PGA electrical harness, consists of an EKG signal conditioner, impedance pneumograph (ZPN) signal conditioner, dc-dc converter, and axillary and sternal electrodes.

Electrocardiogram Signal Conditioner - The EKG signal conditioner has a signal wave ranging between 0 and 5 volts peak-to-peak which is representative of inflight heart activity.

Impedance Pneumograph Signal Conditioner - The ZPN signal conditioner and associated electrodes provides flight measurement of transthoracic impedance change. A pair of electrodes are used to measure respiration rate over a wide dynamic range of activity. This conditioner is not used during EVA.

The dc-dc Power Converter - The dc-dc power converter delivers a + 10 and - 10 volt power to each signal conditioner. It converts the single ended 16.8 volt power to the + 10 and - 10 volt power required by the bioinstrumentation systems.

Electrodes - The electrodes are attached directly to the skin with an adhesive disk filled with conductive paste. The EKG sternal electrodes are attached to the EKG signal conditioner and EKG axillary electrodes are attached to the ZPN signal conditioner.

#### 4.5 PLSS Performance Data

A PLSS system flow chart is presented in Figure 4.5-0.1. More detailed performance data of the individual subsystems is presented in the following paragraphs.

##### 4.5.1 Extravehicular Communication System (EVCS)

###### 4.5.1.1 Modes

The EVCS operational modes are defined in Figure 4.5-1. These modes are manually selected by the EVA crewman. The principal operating mode is for both crewmen to be in the dual (AR) mode. This is the only mode in which both crewmen can be received simultaneously. Crewmen should never simultaneously be in either the primary (A) mode or the secondary (B) mode.

###### 4.5.1.2 Voice Communications

The EVCS provides for duplex voice communications between earth and at least one crewman. It also provides for uninterrupted voice communications between both crewmen. The performance requirements of the primary and secondary transceivers are summarized in Table 4.5-1A. FM transmitter and receiver performance requirements are summarized in Table 4.5-1B.

###### 4.5.1.3 Telemetry

The telemetry parameters are identified in Table 4.5-2. In addition, the normal operating ranges of each parameter are listed for pre-egress checkout and for extravehicular activity. The calibration curves for the individual sensors are presented in Figures 4.5-2 through 4.5-8. Telemetry inaccuracies attributed to the sensors and the EVCS are presented in Table 4.5-3.

Table 4.5-3.1 presents the overall accuracy of the EMU biomedical and suit data from the lunar surface to the Mission Control Center. The table is a summary of the estimated errors contributed by each section of the telemetry link for the PLSS and EKG. The last column of the table shows the three sigma accuracy estimate (3  $\sigma$ ) for each parameter. This accuracy is expressed as a percent of full scale.

All telemetry data from each crewman is commutated on a single subcarrier except EKG data. Each crewman's EKG information is continuously sampled on its own subcarrier. The telemetry channel assignments are given in Table 4.5-4.

Telemetry data is not transmitted when the mode selected is the secondary or "B" mode.

#### 4.5.1.4 Antenna

All EMU communications are transmitted and received via the EMU antenna. The antenna is mounted on the OPS. When mounted with coaxial cable and input connector, it has a VSWR of 2.0:1 or less. The antenna is vertically polarized. A description of the antenna coverage factor is presented in Table 4.5-5.

If the EVC is operated with the EMU antenna stowed, the range from the IM is limited to  $\frac{1}{4}$  mile with the possibility of extreme transmitter distortion.

If the EVA antenna on the IM fails during lunar operations, the EV crewmen can maintain communications with MSFN at an estimated maximum range of  $\frac{1}{2}$  mile in-line with either the front or aft VHF inflight antenna.

#### 4.5.1.5 EMI Suppression

All lines in and out of each EVC is filtered for EMI suppression, except the left and right microphone wires and the biomedical primary power wire. These three wires just loop through each EVC.

Each communicator is spec'd and tested to accept on the battery supply line a 1.1 volt peak-to-peak noise signal between the frequencies of 250 Hz and 15 KHz, and a 0.55 peak-to-peak noise signal between 30 Hz and 250 Hz.

#### 4.5.1.6 Temporary Out-of-Spec Temperature Indications

When the water diverter valve is first turned to maximum cooling, the LCG differential temperature transducer produces a signal as much as 200% of nominal maximum. This relatively high voltage is fed through to the other temperature transducers driving them out of range. This is only a temporary out-of-spec occurrence, and causes no equipment failure. The condition exists on the PLSS O<sub>2</sub> and LCG inlet H<sub>2</sub>O temperature readings for 8 to 10 seconds. The condition exists on the LCG differential temperature readout for 15 to 20 seconds.

Design average heat loads		
Description	Units	Value
Metabolic heat rate	BTU/hr	1200
Oxygen consumption	lb/hr	0.195
O <sub>2</sub> production	lb/hr	0.235
System heat load	BTU/hr	1179.2
Total system (design point) load	BTU	7116.8
Initial water storage	lb	6.62
Minimum water separated	lb	0.35
Maximum water separated	lb	2.03
Initial power required	watts	52.16
System electrical energy	watt-hr	208.64
System electrical heat load	BTU/hr	200.97

\*The system is designed for no perspiration. However the O<sub>2</sub> sublimator must be capable of handling 100 cc/hr of perspiration

General design data		
Description	Units	Value
Design point mission time	hrs	4.0
Maximum mission time	hrs	4.0
Combined fan/motor efficiency		14
Pump efficiency		11
Compressor efficiency		0.88
Pressure ratio		1.051
Fan/motor power	watts	30.0
Pump power	watts	10.0
CS and electrical components	watts	12.56
Oxygen flex hose I.D.	in.	0.750
Oxygen hardline O.D.	in.	0.750
Liquid flex hose I.D.	in.	0.305

Design point pressure loss	
Oxygen loop (at 6.0 CFM)	in. H <sub>2</sub> O
Pressure garment assembly (spec)	1.65
Gas connectors (suit and PLSS)	1.10
LiOH canisters	1.10
Sublimator	1.21
Vent flow sensor	0.20
Water separator	0.32
Ducting	0.32
Backflow check valve	0.25
Pressure rise across fan	5.25
Liquid loop (at 4 lb/min)	psi
Liquid cooling garment	1.780
Connectors	0.800
Diverter valve	0.360
Sublimator	0.795
Fan motor cooling jacket	0.054
Ducting	0.893
Pressure rise across pump	4.682

Figure 4.5-0.1 Apollo EMU Program - PLSS System Flow Chart

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS

EVC UNIT	EVCs FUNCTIONS	MODE	FUNCTION	MODE SELECTOR SWITCH POSITION	NOTES
EVC-1	<p>Diagram for EVC-1: The frequency spectrum from 3.9 to 296.8 MHz is divided into three main sections. The lower section (3.9-10.5 MHz) contains EKG and PLS Data. The middle section (10.5-259.7 MHz) contains Voice and TM. The upper section (259.7-296.8 MHz) contains Voice and TM. A break symbol is shown between 10.5 and 259.7 MHz.</p>	Primary transmitter, FM receiver, and telemetry ON	Voice and telemetry to LM for transmission to MSFN; voice to EVC-2 Voice from LM or EVC-2	AR (Dual Mode)	Transmitter continually operative (not activated by voice operated switch)
EVC-2	<p>Diagram for EVC-2: Similar to EVC-1, but the middle section (10.5-259.7 MHz) also includes a TM channel. The upper section (259.7-296.8 MHz) contains Voice and TM. A break symbol is shown between 10.5 and 259.7 MHz.</p>	FM transmitter, Primary & Secondary Receivers, and telemetry ON	Voice and telemetry to EVC-1 for transmission to LM Voice from LM and EVC-1	AR (Dual Mode)	Transmitter continually operative (not activated by voice operated switch)
EVC-1 or EVC-2	<p>Diagram for EVC-1 or EVC-2: Similar to EVC-2, but the middle section (10.5-259.7 MHz) also includes a PLS Data channel. The upper section (259.7-296.8 MHz) contains Voice and TM. A break symbol is shown between 10.5 and 259.7 MHz.</p>	Primary transmitter, FM receiver and telemetry ON	Voice and telemetry to LM for transmission to MSFN Voice from other EVC and LM	A (Primary Mode)	Transmitter continually operative (not activated by voice operated switch)
EVC-1 or EVC-2	<p>Diagram for EVC-1 or EVC-2: Similar to EVC-2, but the middle section (10.5-259.7 MHz) also includes a PLS Data channel. The upper section (259.7-296.8 MHz) contains Voice and TM. A break symbol is shown between 10.5 and 259.7 MHz.</p>	Secondary transmitter ON	Voice to LM for transmission to MSFN Voice from LM (Backs up primary transmitter for emergency voice communication)	B (Secondary Mode)	No telemetry capability Transmitter inoperative unless activated by voice operated switch or manual switch

Figure 4.5-1 Extravehicular Communications System  
Operational Modes

Table 4.5-1A Voice Communications -  
Amplitude Modulated

RECEIVER	PRIMARY	SECONDARY
Frequency	296.8 MHz $\pm$ 9 KHz	259.7 MHz $\pm$ 7.8 KHz
Bandwidth	Superheterodyne 70 KHz IF at 6 db min	Superheterodyne 70 KHz IF at 6 db min
Output	12.6 mw min to helmet isolation network	12.6 mw min to helmet isolation network
<hr/>		
TRANSMITTER		
Frequency	259.7 MHz $\pm$ 7.8 KHz	296.8 MHz $\pm$ 9 KHz
Bandwidth	Compatible with data being transmitted	Down 2 db maximum at 300 Hz and 2.3 KHz
Power Output	250 mw min unmodulated at antenna terminal	250 mw min unmodulated at antenna terminal
<hr/>		

Table 4.5-1B Voice Communications -  
Frequency Modulated

RECEIVER (EVC-1)

Frequency	279.0 MHz $\pm$ 8.4 KHz
Bandwidth	125 KHz IF at 3 db min
Power Output	12.6 mw min to helmet isolation network

TRANSMITTER (EVC-2)

Frequency	279.0 MHz $\pm$ 8.4 KHz
Bandwidth	Compatible with data being transmitted
Power Output	316 mw min unmodulated at antenna terminal

Table 4.5-2 Telemetry

TELEMETRY IDENTIFICATION	PARAMETER	PRE-EGRESS CHECKOUT	EXTRAVEHICULAR ACTIVITY
GT 8110P/8210P	Feedwater Pressure	1.6 to 3.5 psia	1.6 - 3.5 psia
GT 8124J/8224J	Electrocardiogram		
GT 8140C/8240C	PLSS Battery Current	EVC only - 0.6 amps EVC and fan - 1.9 amps EVC fan & pump - 2.4 amps	2.0 - 3.0 amperes
GT 8141V/8241V	PLSS Battery Voltage	16.0 - 20.5	16.0 - 20.5
GT 8154T/8254T	ICG Inlet Water Temperature	40° - 90°F	40° - 90°F
GT 8168P/8268P	PGA Pressure	3.75 to 5.0 psia	3.75 to 4.0 psia
GT 8182P/8282P	PLSS O <sub>2</sub> Pressure	850 to 950 psia	350 to 950 psia
GT 8196T/8296T	ICG H <sub>2</sub> O $\Delta$ T	0° - 15°F	0° - 15°F
GT 8170T/8270T	PLSS O <sub>2</sub> Temperature	38 - 52°F	38 - 52°F
GT 8100X/8200X	EVC Sync	N/A	N/A
GT8101V/8201V	Zero Calibration	N/A	N/A
GT8102V/8202V	Full Scale Calibration	N/A	N/A



Table 4.5-2 Telemetry

TELEMETRY IDENTIFICATION	PARAMETER	PRE-EGRESS CHECKOUT	EXTRAVEHICULAR ACTIVITY
GT 8110P/8210P	Feedwater Pressure	1.6 to 3.5 psia	1.6 - 3.5 psia
GT 8124J/8224J	Electrocardiogram		
GT 8140C/8240C	PLSS Battery Current	EVC only - 0.6 amps EVC and fan - 1.9 amps EVC fan & pump - 2.4 amps	2.0 - 3.0 amperes
GT 8141V/8241V	PLSS Battery Voltage	16.0 - 20.5	16.0 - 20.5
GT 8154T/8254T	LCG Inlet Water Temperature	40° - 90°F	40° - 90°F
GT 8168P/8268P	PGA Pressure	3.75 to 5.0 psia	3.75 to 4.0 psia
GT 8182P/8282P	PLSS O <sub>2</sub> Pressure	850 to 950 psia	350 to 950 psia
GT 8196T/8296T	LCG H <sub>2</sub> O Δ T	0° - 15°F	0° - 15°F
GT 8170T/8270T	PLSS O <sub>2</sub> Temperature	38 - 52°F	38 - 52°F
GT 8100X/8200X	EVC Sync	N/A	N/A
GT8101V/8201V	Zero Calibration	N/A	N/A
GT8102V/8202V	Full Scale Calibration	N/A	N/A

Table 4.5-3 PLSS-SV706100-6 EVCS/Sensor Instrumentation Inaccuracies

PARAMETER	TM CODE NUMBER	ALLOWABLE INACCURACIES	
		ENGINEERING UNITS	% OF FULL SCALE
PGA Pressure	GT8168P/GT8268P	+ .1 psi	+ 4%
Feedwater Pressure	GT8110P/GT8210P	+ .15 psi	+ 3%
Battery Current	GT8140C/GT8240C	+ .15 A	+ 1.5%
Battery Voltage	GT8141V/GT8241V	+ .277 V	+ 3.18%
PLSS O <sub>2</sub> Pressure	GT8182P/GT8282P	+ 27.5 psi	+ 2.5%
LCG <b>A</b> T	GT8196T/GT8296T	+ 0.5°F	+ 3.3 %
LCG Inlet Temp.	GT8154T/GT8254T	+ 3.96°F	+ 4.4%
PLSS O <sub>2</sub> Temp.	GT8170T/GT8270T	+ 3.96°F	+ 4.4%

Table 4.5-3.1 Overall Accuracy of EMU Telemetry Data (Est.)

PARAMETER	E M U			R. F. Links		MSFN Low Pass Filter		PAM/PCM Converter		MSFN SCO		MCC Discriminator		MCC Low Pass Filter		$\Delta e_T$		$3e_T$
	Full Scale	Accuracy Limits	$e^2$ (%) $\times 10^{-4}$	$e^2$ (%) $\times 10^{-4}$	$e^2$ (%) $\times 10^{-4}$	$e^2$ (%) $\times 10^{-4}$	$e^2$ (%) $\times 10^{-4}$	$e^2$ (%) $\times 10^{-4}$	$e^2$ (%) $\times 10^{-4}$	$e^2$ (%) $\times 10^{-4}$	$e^2$ (%) $\times 10^{-4}$	$e^2$ (%) $\times 10^{-4}$	$e^2$ (%) $\times 10^{-4}$	$e^2$ (%) $\times 10^{-4}$	$e^2$ (%) $\times 10^{-4}$	$e_T$	%	
Primary Oxygen Pressure	0-1110 psia	$\pm 2.5$ %	0.83	0.694	0.50	0.250	0	0	0.40	0.160	--	--	--	--	--	1.104	1.05	3.15
Sublimator Feedwater Pressure	0-5 psia	$\pm 3.0$ %	1.00	1.000	0.50	0.250	0	0	0.40	0.160	--	--	--	--	--	1.440	1.19	3.57
LCG Inlet Temperature	40-90°F	$\pm 4.4$ %	1.47	2.151	0.50	0.250	0	0	0.40	0.160	--	--	--	--	--	2.561	1.60	4.80
LCG Differential Temperature	0-15° F	$\pm 3.3$ %	1.10	1.210	0.50	0.250	0	0	0.40	0.160	--	--	--	--	--	1.620	1.27	3.81
PCA Pressure	2.5-5.0 psia	$\pm 4.0$ %	1.33	1.778	0.50	0.250	0	0	0.40	0.160	--	--	--	--	--	2.188	1.48	4.44
PLSS Oxygen Temperature	40-90°F	$\pm 4.4$ %	1.47	2.151	0.50	0.250	0	0	0.40	0.160	--	--	--	--	--	2.561	1.60	4.80
Battery Current	0-10 amps	$\pm 1.5$ %	0.50	0.250	0.50	0.250	0	0	0.40	0.160	--	--	--	--	--	0.660	0.81	2.43
Battery Voltage	12.0-20.5 VDC	$\pm 3.18$ %	1.06	1.124	0.50	0.250	0	0	0.40	0.160	--	--	--	--	--	1.534	1.24	3.72
EKG (Commander)	---	---	1.00	1.000	0.68	0.455	0.38	0.144	---	---	1.0	1.000	0.18	0.032	2.00	6.631	2.57	7.71
EKG (LM Pilot)	---	---	1.00	1.000	0.68	0.455	0.38	0.144	---	---	1.0	1.000	0.18	0.032	1.10	3.841	1.96	5.88

NOTE: This table is based upon information and procedures outlined in TRW Report, "Overall Accuracy of EMU Biomedical Suit Data," TRW No. 11176-H241-RO-00, dated June 2, 1969

Volume IV EMU Data Book  
Subsystem Performance Data-PLSS

TABLE 4.5-4 - PLSS/EVCS COMMUNICATIONS TELEMETRY CHARACTERISTICS

Measurement title	Instrumentation range	Discriminator output voltage range (DC)	Commutator channels
Zero calibration	0 VDC	0	1
Full scale calib	5 VDC	5	2
PGA pressure	2.5 to 5.0 psid	0-5	3,14,21,24,27
Feed water press.	0 to 5.0 psia	0-5	4,15,22,25,26
Battery current	0 to 10 amps	0-5	5,11
Battery voltage	15.5 to 20.5 volts DC	0-5	6,20
Water diff. temp	0 to 15 F. deg.	0-5	8,19
LCG inlet temp.	40° to 90° F	3.13 to 1.86	9,17
Sublimator gas outlet temp.	40° to 90° F	3.13 to 1.86	10,16
Primary O <sub>2</sub> press.	0 - 1110 psia	0-5	7,12, 13, 18,23,28
Synchronization	_____	Double width pulse	29,30




Figure 4.5-4 Battery Current Calibration Curve




Figure 4.5-5 Battery Voltage Calibration Curve

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-3 Battery Voltage Calibration Curve




Figure 4.5-4 . POS Pressure Calibration Curve






Figure 4.5-8 PGA Pressure Differential Pressure Calibration Curve




Figure 4.5-9 LCG Inlet H<sub>2</sub>O Temperature Calibration Curve




Figure 4.5-10 PLSS O<sub>2</sub> Temperature Calibration Curve

Figures 4.5-11 through 4.5-18

Pages 4.5-16 through 4.5-24

INTENTIONALLY LEFT BLANK

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS

4.5.1.5 EMU Warning System

The EMU Warning System characteristics are summarized in Table 4.5-6 on page 4.5-19.

General Description

Four sensors are situated at various points in the PLSS to give warning of potentially dangerous conditions. If one of these transducers senses a dangerously low pressure or a high or low flow rate, it signals the PLSS Alarm Control Module. The Alarm Control Module generates a warble warning tone through the Extravehicular Communications System to the Astronaut's earphones. It also activates one of five visual warning indicators which are located on the Remote Control Unit at the front of the space suit.

The "High Primary Oxygen Flow" Warning

One of the four sensors is located just downstream of the Primary Oxygen Pressure Regulator. If the regulator passes a flow which exceeds 0.50 to 0.65 lbs/hour for a period of time greater than five seconds, the warning tone will sound in the crewman's earphones, and the visual warning flag labeled "O<sub>2</sub>" will pop up on the RCU. This warning flag will reveal a lighted symbol "O," which indicates "OPS" actuation needed. After 10 + 2 seconds, the tone will stop sounding, but the flag will remain raised until the flow is less than 0.50 to 0.65 lbs/hour. Then, the flag will drop automatically.

The "Low PGA Pressure" Warning

To give warning of low suit pressure, a low pressure switch is located in the primary oxygen make-up flow line of the PLSS. This transducer is just downstream of the High Primary Oxygen Flow Sensor discussed above. Upon sensing a pressure lower than 3.10 to 3.40 psid, the switch actuates the warning tone, and the warning flag labeled "Press." on the RCU in the manner described above. This warning flag will reveal a lighted symbol "O" meaning "Actuate OPS." As in all the warning tone soundings, the tone will last 10 + 2 seconds, regardless of when the PGA pressure goes back to above 3.10 to 3.40 psid, but as with all the warning flags, this flag will remain raised until the PGA pressure returns to 3.10 to 3.40 psid or higher at which time it will drop automatically.

The "Low Vent Flow" Warning

A transducer is located just downstream of the Fan in the PLSS vent loop. If this transducer senses a flow rate lower than 4.0 to 5.3

acfm for a period of time greater than five seconds, the warning tone will sound for  $10 + 2$  seconds. The warning flag labeled "Vent" on the RCU will pop up and reveal a lighted symbol "P" meaning "Purge." The flag will remain raised until the fan flow returns to 4.0 to 5.3 or higher, at which time it will drop to the closed position.

Prior to flight, the sensor activation and deactivation points are required to be between 4.7 and 5.0 acfm; however, for the second EVA, these points nominally experience a 0.1-0.2 cfm downward shift depending upon the amount of water condensed in the electronic element.

#### The "Low Feedwater Pressure" Warning

The fourth transducer is located in the feedwater line just upstream of the sublimator. If the feedwater pressure drops below 1.30 to 1.60 psia, the warning tone will sound for  $10 + 2$  seconds and an RCU flag will pop up to reveal a lighted "A" symbol indicating "Abort." The flag will remain raised until the feedwater pressure is again higher than 1.30 to 1.60 psia. This same transducer is used to telemeter the feedwater pressure reading to ground control.

#### Additional Warning System Characteristics

Although there are five warning flags on the RCU, only the four described above are operational. The fifth flag, labeled "CO<sub>2</sub>," is intended for use on later models of the EMU. Each warning flag is lighted by a Beta light source capsule which requires no electric power.

If the EVCS mode selector switch position is changed, the warning tone will again come on for  $10 + 2$  seconds, provided one of the four transducers is still signaling for a warning tone.

The warning tone is a 1.5 KHz frequency tone which is interrupted fifteen times per second to give a warbling sound. The tone is clearly audible above the transceiver output in transmitting, receiving, or standby operations.

Table 4.5-6 Warning System

PARAMETER	ACTUATION AND DEACTUATION BAND	WARNING TONE		WARNING FLAG			REMARKS
		FREQUENCY	DURATION	OUTER LABEL	INNER SYMBOL	DURATION	
High Oxygen Flow	> 0.50 - 0.65 lbs/hour	1.5 KHz	10+2 sec.	O <sub>2</sub>	0	Until flow < 0.50-0.65 lbs/hr.	5 second time delay
Low PGA Pressure	< 3.10-3.40 psid	1.5 KHz	10+2 sec.	Pres.	0	Until pressure > 3.10-3.40 psid	
Low Vent Flow	< 4.0-5.3 acfm	1.5 KHz	10+2 sec.	Vent	P	Until flow > 4.0-5.3 acfm	5 second time delay
Low Feedwater Pressure	< 1.30 - 1.60 psid	1.5 KHz	10+2 sec.	H <sub>2</sub> O	A	Until pressure > 1.30-1.60 psid	

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS

THIS PAGE INTENTIONALLY LEFT BLANK



Volume IV EMU Data Book  
Subsystem Performance Data - PLSS

4.5.2 PLSS Electrical Subsystem

4.5.2.1 Battery

The PLSS power supply is a replaceable silver zinc battery with a two sigma capacity of 279 watt-hours (16.5 amp-hours) and an operational output voltage of 16.0 to 20.5 volts. The battery is composed of eleven cells, each cell having a pressure differential of  $8.0 \pm .3$  psid. This relief capability is provided by an unsophisticated valve verified only at the time of delivery by the battery supplier. The total battery is contained in a sealed case that incorporates a pressure relief valve which maintains the pressure differential between 4.9 and 8.0 psid.

The output voltage and capacity vary with temperature as shown in Figure 4.5-17. This figure was determined for a 60 watt load which represents the load for which the battery was designed. Figure 4.5-18 shows the discharge curve for the battery with a 40 watt load discharged under ambient conditions. The 40 watt load is representative of the nominal load imposed by the PLSS and EV communicator (reference Table 4.5-8).

To prevent battery degradation due to time-temperature limitation, the battery should be stored and used in accordance with Table 4.5-7.

Figures 4.5-17 and 4.5-18 show that the battery voltage begins to fall sharply approximately thirty minutes before exhaustion of the power supply (16.0 vdc).

4.5.2.2 Current Limiters

Current limiters are used in the PLSS to protect the circuits shown in Table 4.5-9. These current limiters can withstand current loadings in excess of their rating for short time periods as shown in Figure 4.5-20.

#### 4.5.2.3 Voltage Degradation Effects

A test was performed at NASA/CSD to determine the effect of degrading voltage upon the EMU subsystems performance. The test started with a voltage of 17.1 volts which was decreased at 0.1 volt increments. The low vent flow flag and warning tone actuated at 14.2 volts. This was attributed to degraded fan performance and the actuation was normal when flow was reduced. No tests were conducted below 14.2 volts to check the warning tone or flag actuations; however, all flags remained in the cleared position throughout the test. No significant degradation of communication or telemetry was evident until the supply voltage was reduced to 13.6 vdc. At this point, the signal from the PLSS/EVCS had degraded to the extent that the RF ground station could not translate the telemetered data. At 12.5 vdc, the voice comm transmitted by the PLSS/EVCS was unintelligible. The EKG and all transmitting power was lost at 12.0 vdc. The voice comm received by the PLSS/EVCS was understandable until the voltage reached 9.5 vdc.

Throughout the test, fan and pump degradation was evident by progressively lower flow rates and Delta P's in the gas and transport loops.

At the conclusion of the test, the voltage was returned to 17.0 volts and normal operation was obtained.




Figure 4.5-17 Voltage Discharge Profile

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-18 PLSS Battery Voltage Versus Discharge Time

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-19 PLSS Battery Ampere-Hours Remaining Vs. Time Remaining

Table 4.5-7 PLSS Power Supply Storage and  
Usage Time-Temperature Limitations

CONDITION OF POWER SUPPLY	TEMPERATURE LIMITATION	TIME AT TEMPERATURE LIMIT
Storage, Unactivated	35° to 110°F	1 year maximum
Storage, Activated		12 days total life
(a)	50° to 80°F	12 days maximum
(b)	0° to 50°F 80° to 100°F	5 days maximum
(c)	100° to 130°F	2 days maximum
Operation		
(a)	50° to 90°F	At start
(b)	70° to 160°F	Between 2.0 and 4.0 hours

CAUTION: The battery should not be allowed to exceed 160°F as  
plate warpage and battery degradation will occur.

Table 4.5-8 PLSS Power Profile

	<u>Nominal Current</u>	<u>Electrical Heat Loading</u>
Fan	1.3 amps	74.5 BTU/Hr
Pump	0.5 amps	28.6 BTU/Hr
EVC		
Dual Mode	0.6 amps	34.4 BTU/Hr
Primary Mode	0.6 amps	34.4 BTU/Hr
Secondary Mode	0.5 amps	28.6 BTU/Hr
TOTAL (EVC in Dual or Primary Mode)	2.4 amps	137.6 BTU/Hr
TOTAL (EVC in Secondary Mode)	2.3 amps	131.9 BTU/Hr

NOTE: For real-time consumables evaluation, the telemetry data should be used.

Table 4.5-5 Current Limiter Usage and Ratings

COMPONENT(S) PROTECTED	RATING
Fan	Current protection not provided* (#22 gage wire)
Pump	Current protection not provided* (#22 gage wire)
Vent Flow Sensor	1/16 amp (62.5 ma)
Time Delay Module (Vent Flow Sensor)	1/16 amp (62.5 ma)
High O <sub>2</sub> Flow Sensor	None externally - has 50 ma limiter built in
Time Delay Module (High O <sub>2</sub> Flow Sensor)	1/16 amp (62.5 ma)
Left Microphone	1/8 amp (125 ma) with series 32.4-39.2 ohm $\frac{1}{2}$ watt resistor
Right Microphone	1/8 amp (125 ma) with series 32.4-39.2 ohm $\frac{1}{2}$ watt resistor
EVC Warning Tone Generator	1/16 amp (62.5 ma)
Alarm Module	$\frac{1}{2}$ amp (500 ma)
EVC Telemetry Voltage Regulator	1 amp
EKG	$\frac{1}{4}$ amp (250 ma) with series 32.4-39.2 ohm $\frac{1}{2}$ watt resistor
Transducer Voltage Regulators	One only current limiter rated at $\frac{3}{4}$ amp (750 ma)
EVC Dual-Primary Mode Voltage Regulator	2 amp
EVC Secondary Mode Voltage Regulator	2 amp

\*Maximum overload current approximately 40 amps



Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-20 Current Limiter Rating Versus Time

#### 4.5.3 Ventilation Loop

The pressure rise versus flow characteristics of the PLSS ventilation loop are shown in Figure 4.5-25. Superimposed on this figure is the pressure drop of the PGA.

##### 4.5.3.1 Fan Performance

The PLSS fan circulates PGA life supporting atmosphere gasses through the PLSS ventilation loop for cooling and for carbon dioxide, odor, and moisture removal within the PGA. The fan operates in gasses which are at  $3.85 \pm .15$  psia pressure, and 38 to 52°F temperature on the inlet side. The gas pressure rise due to the fan is compared to the pressure drop in the PGA for a range of flow rates as shown in Figure 4.5-25. Nominally a minimum flow of 5.5 acfm at 1.5 inches of water pressure rise will be delivered by the fan. CO<sub>2</sub> washout capability as a function of fan flow rate is given in Figure 4.5-25.1. CO<sub>2</sub> buildup as a function of time for the zero ventilation flow condition is shown in Figure 4.5-25.2.

The fan is driven by a dc motor which operates at a nominal 16.8 volts with 1.3 amperes current draw. The relationship between fan current and O<sub>2</sub> vent loop pressure is shown in Figure 4.5-26, while the fan power consumption versus flow rate (at constant voltage) is given in Figure 4.5-27. Figure 4.5-28 relates fan pressure rise to flow rate for three operating voltages.

The fan/motor operates at a speed of  $18,600 \pm 600$  RPM under normal loads. The relationship between voltage and RPM at several constant torques are given in Figure 4.5-29.

##### 4.5.3.2 LiOH Cartridge

The PLSS LiOH Cartridge performance characteristics are shown in Figure 4.5-30. This figure results from limited test data, and is included to define the operating characteristics rather than predict cartridge operating time remaining. Water production rates and heat production rates versus CO<sub>2</sub> production rates are given in Figures 4.5-31 and 4.5-32, respectively. CO<sub>2</sub> production, as a function of the metabolic rate, is shown in Figure 4.5-33. For discussion of the physiological effects CO<sub>2</sub> refer to NASA SP-3006, "Bioastronautics Data Book", Section I, page 8.

The allowable time/temperature envelope for LiOH storage is given in Figure 4.5-34.

##### 4.5.3.3 Ventilation Loop Sublimator

The ventilation loop portion of the sublimator cools the recirculating oxygen and condenses water vapor. The heat loads on the ventilation

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS

4.5.3.3 Ventilation Loop Sublimator (Cont'd)

loop sublimator, as a function of metabolic rate, are shown in Figure 4.5-35. The figure includes the latent perspiration load which results from a perspiration rate of 100 cc/hour. Although the liquid cooled system is designed to prevent perspiration, the sublimator is designed to handle 100 cc/hour of perspiration.

Ventilation loop sublimator performance data is provided in Figures 4.5-36 through 4.5-38.

4.5.3.4 Ventilation Flow Sensor

The ventilation flow sensor actuates a warning tone at ventilation flow rates of 4.0 to 5.3 acfm for EVA initiated in a IM environment between 60 and 90°F. For EVA initiated in abnormal IM environment, the sensor actuates at flows of 3.5 to 5.4 acfm.




Figure 4.5-25 EMU OXYGEN FLOW PERFORMANCE




Figure 4.5-25.1 Oral-Nasal CO<sub>2</sub> Levels For  
Various Metabolic Rates




Figure 4.5-25.2 Suit Helmet CO<sub>2</sub> Buildup  
Without Ventilation Flow




Figure 4.5-26 O<sub>2</sub> Ventilation Loop Pressure Vs. Fan Current Drain




Figure 4.5-28.1 Torque vs Speed for PLSS fan



Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-29 Fan Motor RPM Vs. Supply Voltage

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-30 LMP and CDR CO<sub>2</sub> Buildup (LiOH Depletion)




Figure 4.5-30.1 LiOH Cartridge Time Versus  
Average Metabolic Rate

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-31 LiOH-CO<sub>2</sub> Water Production Rate Vs. CO<sub>2</sub> Production Rate




Figure 4.5-32 LiOH Cartridge Heat Production

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-33 CO<sub>2</sub> Production Versus Metabolic Rate




Figure 4.5-34 Allowable Time/Temperature  
Envelope for LiOH Storage



Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-35 Ventilation Loop Sublimator Heat Loads Versus Metabolic Rate



Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-36 Sublimator Outlet Temperature Versus Flow Rate

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-37 Sublimator Oxygen Outlet Temperature Versus Inlet Temperature

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-38 Sublimator Oxygen Outlet Temperature Versus Inlet Dew Point

#### 4.5.4 Liquid Transport Loop

The PLSS liquid transport circuit pressure rise and flow characteristics are shown in Figure 4.5-39.

##### 4.5.4.1 Pump

Figure 4.5-40 shows the pressure rise/flow characteristics of the PLSS pump and corresponding power consumptions.

##### 4.5.4.2 Liquid Transport Circuit Sublimator

The heat load applied to the sublimator as a function of metabolic load and ambient conditions is shown in Figure 4.5-41.

Liquid transport loop sublimator performance data is provided in Figure 4.5-42.

##### 4.5.4.3 Diverter Valve

The diverter valve controls the water temperature by causing the recirculatory water to bypass the sublimator. The valve design prevents deadheading the pump. The flow splits of the diverter valve are shown in Table 4.5-10.

##### 4.5.4.4 Restricted Flow

With the diverter valve in minimum cooling, and with little or no air in the system, sublimator flow ceases at a water loop flow of 1.2 to 1.4 lbs/min. With the diverter valve in intermediate cooling, sublimator flow will continue down to a water loop flow of 1.0 lb/min. (Flows below 1.0 lb/min. have not been checked).

##### 4.5.4.5 Gas Separator

The gas separator functions to remove free gas from the LCG and PLSS transport water loop. Free gas may be evolved within the LCG thru use with the LM 192 or may come from leakage while stowed. Evaluation data of the LM 192 liquid loop showed 5 to 14 cc of evolved gas. Data on LCG leakage during stowage may be found in paragraph 4.2.1 of this book. The Free gas removed by the gas separator is stored in the gas separator housing until manually vented. Venting is normally accomplished in the pressurized LM cabin during PLSS recharge. Limitations on venting during EVA are noted in PLS-23, paragraph 3.4 of this book. The design criteria for the gas separator requires a collection capacity of 30 actual cubic centimeters minimum. Data indicates that in excess of 37 acc's may be collected prior to breakthrough. The characteristic

#### 4.5.4.5 Gas Separator (cont'd)

flow rates for venting of oxygen, water vapor and water from the separator are provided in Figures 4.5-43 and 4.5-43.1.

#### 4.5.4.6 Operating Pressure

- A) The possible operating pressure range for lunar surface EVA is 4 to 21 psia.
- B) The expected operating pressure at the start of the first EVA is 17.0 psia to 19.5 psia based on the following conditions:
  - (1) The PLSS is charged from the ground facility with water at a pressure 1.0 to 3.0 psi above sea level pressure within T-76 to T-72 hours (T=0 for launch).
  - (2) EVA 1 is at T + 110 hours
  - (3) LM environment is uncontrolled after initial pressurization to 5 psia in earth orbit. Cabin temperature increases in accordance with ICD upper limit.
  - (4) Prior to interfacing with the PLSS, the LCG is operating on the LM 192 system which results in an LCG pressure of 18 to 20 psia (based on a full accumulator in the LM-192 and the LM-192 system pressure decay associated with the interface of both LCG's).

Note: The most significant effect on the actual PLSS/LCG operating pressure is the pressure of the LCG just prior to interface with the PLSS (i.e. pressure retained from the LM-192 system). Test data indicates that the resultant PLSS/LCG operating pressure is 80% LCG pressure and 20% PLSS pressure.




Figure 4.5-39 PLSS Transport Water Loop  $\Delta P$  Versus Flow




Figure 4.5-39.1 Pump Degradation and Cavitation (Pump Pressure Rise)  
Versus Transport Water Aeration (Volume of Injected Gas)






Figure 4.5-39 PLSS Transport Water Loop  $\Delta P$  Versus Flow



Volume IV EMU Data Book  
Subsystem Performance Data - PLSS





Figure 4.5-40 Water Flow Versus Power Input and Pressure Rise

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-41 Liquid Transport Loop Sublimator Heat Loads Versus Metabolic Rate and Ambient Conditions

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-42 Sublimator Transport Water Inlet Temperature Versus Outlet Temperature




Figure 4.5-43 Transport Water Gas Separator Water Bleed Flow  
Versus Differential Pressure

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS





Figure 4.5-42 Sublimator Transport Water Inlet Temperature Versus Outlet Temperature

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS

TBD

Figure 4.5-43 LCG Inlet Temperature Versus Metabolic Rate



- NOTE:
1. This curve obtained analytically for gas or water vapor flow at 70°F.
  2. Actual hole diameter is 0.032 inches.
  3. Ambient pressure is 5.0 psia.
  4.  $C_f = 0.65$

Figure 4.5-43.1 Transport Water Gas Separator Gas Bleed  
Flow Vs. Transport Water Loop Pressure

**Volume IV EMU Data Book**  
**Subsystem Performance Data - PLSS**

Table 4.5-10 Diverter Valve Flows

VALVE POSITION	NOMINAL FLOW RATES - LB/MIN.		
	TO LCG	FROM BYPASS	FROM SUBLIMATOR
Max.	4.0	0	4.0
Int.	4.0	3.50	0.50
Min.	4.0	3.86	0.14



Volume IV EMU Data Book  
Subsystem Performance Data - PLSS

THIS PAGE INTENTIONALLY LEFT BLANK

#### 4.5.5 Feedwater Supply Loop

The PLSS feedwater system supplies the expendable water to the sublimator where it freezes and sublimates to the vacuum environment in which the EMU is operating. The cooling resulting from the sublimation is used to dissipate the heat generated within the EMU and the heat entering the EMU. These heat loads are given in Figure 4.5-44 and the feedwater usage rate versus heat load is given in Figure 4.5-45. An orifice restricting the flow of feedwater is located between the sublimator and the feedwater shut-off valve. The flow characteristics of this orifice are presented in Figure 4.5-46.

Feedwater pressure at the entrance to the sublimator is monitored by a single transducer. This transducer provides a signal for telemetry readout of the pressure via the EVCS and also provides a signal to the EMU Warning System described in paragraph 4.5.1.5. The low feedwater pressure warning is initiated when the pressure falls below 1.30 to 1.60 psia. This corresponds to a water quantity of approximately 0.6 pounds downstream of the feedwater shut off valve assuming the system is operating normally. The feedwater pressure readout from telemetry and the low feedwater warning switch provide verification of sublimator startup and sublimator operation as well as feedwater depletion. The sublimator has demonstrated "start up" capability at vent loop pressures of 6.0 psia. The pressure of the feedwater is shown in Figure 4.5-47. Figure 4.5-47.1 illustrates this same pressure at sublimator shutdown.

Sublimator operating characteristics through feedwater depletion and beyond for a metabolic rate of 1200 BTU/Hr and 1600 BTU/Hr are shown in Figures 4.5-48 and 4.5-48.1.

The feedwater reservoir is filled with 8.5 plus pounds of water prior to launch and can be recharged in the LM through the feedwater fill connector. A feedwater fill of 8.5 pounds may not be possible in all cases as this was not a design requirement. There is also a GSE instrument inaccuracy of  $\pm 1$  ounce associated with the feedwater fill capacity. The time required to fill the reservoir can be determined from Figure 4.5-49 for a given charging pressure differential. A visual indicator is located in the bladder vent line to give further indication of completion of recharge. The visual indicator is similar to a sight glass. The recharge is complete when the gas bubbles disappear and only feedwater appears in the visual indicator. The flow rate of water through the vent line as a function of pressure differential is shown in Figure 4.5-49.1.

- 4.5.5 A branch of the feedwater loop is connected to the transport water loop through a check valve. In the event the transport water pressure is reduced by leakage or other malfunction, the feedwater loop will supply makeup water through the one-way check valve. The performance characteristics of the check valve are given in Figure 4.5-50.

After the crewmen ingress the LM subsequent to EVA and the LM cabin is sealed, the water vapor produced as a result of sublimation will increase the LM cabin pressure at a rate described in Figure 4.5-51. Normal sublimator action ceases when the ambient pressure rises above 1000 microns.

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-44 Sublimator Total Heat Load Versus Metabolic Rate

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-45 Sublimator Total Heat Load Versus Feedwater Usage Rate

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-46 Sublimator Flow Limiter (Viscojet) Characteristics - Design Parameters




Figure 4.5-47 Feedwater Pressure at Sublimator  
 Versus Starting Time




Figure 4.5-47.1 Feedwater Pressure Characteristics at Sublimator Shutdown






Figure 4.5-48 Feedwater Depletion Characteristics  
Vs. Time with a 1200 BTU/Hr. Metabolic  
Load (Max. Diverter Valve Position)




Figure 4.5-48.1 Feedwater Depletion Characteristics  
Vs. Time with a 1600 BTU/Hr. Metabolic  
Load (Max. Diverter Valve Position)




Figure 4.5-49 PLSS Feedwater Reservoir Fill Time Versus Pressure Differential




Figure 4.5-49.1 Feedwater Vent System Flow  
Restrictor Characteristics

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-50 Check Valve Pressure Differential Versus Flow Rate

VOLUME IV EMU DATA BOOK  
SUBSYSTEM PERFORMANCE DATA - PLSS




Figure 4.5-51 Rate of Increase of LM Cabin Pressure  
Due to EMU Sublimator Vapor

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS

THIS PAGE INTENTIONALLY LEFT BLANK

#### 4.5.6 Primary Oxygen Subsystem

The PLSS primary oxygen subsystem provides a supply of breathable oxygen and pressure regulation of ventilating oxygen.

##### 4.5.6.1 Oxygen Supply

Figure 4.5-52 shows the oxygen usage rate as a function of metabolic rate and maximum allowable EMU leakage rate.

The oxygen quality indicator provides a visual display of the oxygen bottle pressure within the accuracy requirements of Table 4.5-11.

Figure 4.5-53 shows the effects of POS bottle pressure on suit absolute and differential pressures during LM repressurization.

Figure 4.5-53.1 shows the effect on POS bottle pressure from PGA pressurization in a 5.0 psia ambient with an initial POS pressure of 1030 psia (ground charge). Figure 4.5-53.2 shows the same effect with an initial POS pressure of 950 psia (LM recharge).

Figures 4.5-53.3 through 4.5-53.5 show the relationship between suit pressure and LM repress cabin pressure for various initial POS pressures (150, 300, and 450 psia).

The primary oxygen pressure required to maintain suit regulated pressure during LM repressurization is tabulated below for several LM repressurization times. The repressurization time is for a cabin pressure increase of .5 psia to 5.0 psia.

<u>LM Repressurization Time Seconds</u>	<u>Required Primary Oxygen Pressure</u>
100	527 psia
104	511 psia
120	422 psia
140	382 psia

The drop in POS pressure to pressurize the PGA from 5.0 psia to 8.85 psia and from 3.85 to 6.0 psia is given below for manned suit volumes of 2.0, 2.2, and 2.4 cubic feet.

<u>Suit Volume, FT<sup>3</sup></u>	<u>Drop in POS Pressure, PSI</u>	
	<u>5.0 to 8.85 psia</u>	<u>3.85 to 6.0 psia</u>
2.0	34.4	19.2
2.2	37.8	20.1
2.4	41.2	23.0



Since the PLSS O<sub>2</sub> regulator maintains the suit pressure at 3.85 psi above ambient, the suit pressure would be greater than the LM cabin pressure after cabin repressurization has been effected. This would require a crewman to either "pop a glove" or open the purge valve prior to attempting to remove his suit. Figures 4.5-53.6 through 4.5-53.8 show the LM cabin pressure at which to shut-off the PLSS O<sub>2</sub> in order for a negligible pressure differential to exist at the instant the LM completes repress as a function of the PLSS O<sub>2</sub> supply pressure. Figures 4.5-53.9 and 4.5-53.10 show the curves and method used to derive the three working curves.

#### 4.5.6.2 Oxygen Supply Residual

The residual oxygen for nominal depletion of the POS is .123 lbs which corresponds to a pressure of 100 psia at a temperature of 70°F.

#### 4.5.6.3 Pressure Regulation

The PLSS primary oxygen regulator characteristics are shown in Figure 4.5-54.

Figure 4.5-55 defines the bellows orifice flow rate at various ambient pressures.

Figures 4.5-56 and 4.5-56.1 illustrate the POS purge time and maximum flow rate with a failed open regulator as a function of source pressure.

Figure 4.5-56.2 illustrates the time from regulator failed closed condition until activation of the low pressure warning. This time is dependent upon metabolic rate, suit leakage, and PGA/PLSS free volume. The figure presents this time for various metabolic rates, for a suit leakage of zero, and a PGA/PLSS free volume of 2.2 cubic feet. The pressure in a PGA with maximum allowable PIA leakage will decay at 0.0114 psi/minute faster.

#### 4.5.6.4 Initial Charge and Pressure Decay Prior to Use

The ground charging characteristics of the PLSS primary oxygen supply are shown in Figure 4.5-57.

Pressure decay characteristics of the POS between charging and use are given by Figure 4.5-57.1.

#### 4.5.6.5 Recharge

The recharge characteristics of the PLSS primary oxygen supply are shown in Figure 4.5-58.

#### 4.5.6 Primary Oxygen Subsystem

The PLSS primary oxygen subsystem provides a supply of breathable oxygen and pressure regulation of ventilating oxygen.

##### 4.5.6.1 Oxygen Supply

Figure 4.5-52 shows the oxygen usage rate as a function of metabolic rate and maximum allowable EMU leakage rate.

The oxygen quality indicator provides a visual display of the oxygen bottle pressure within the accuracy requirements of Table 4.5-11.

Figure 4.5-53 shows the effects of POS bottle pressure on suit absolute and differential pressures during LM repressurization.

Figure 4.5-53.1 shows the effect on POS bottle pressure from PGA pressurization in a 5.0 psia ambient with an initial POS pressure of 1030 psia (ground charge). Figure 4.5-53.2 shows the same effect with an initial POS pressure of 950 psia (LM recharge).

Figures 4.5-53.3 through 4.5-53.5 show the relationship between suit pressure and LM repress cabin pressure for various initial POS pressures (150, 300, and 450 psia).

The primary oxygen pressure required to maintain suit regulated pressure during LM repressurization is tabulated below for several LM repressurization times. The repressurization time is for a cabin pressure increase of .5 psia to 5.0 psia.

<u>LM Repressurization Time Seconds</u>	<u>Required Primary Oxygen Pressure</u>
100	527 psia
104	511 psia
120	422 psia
140	382 psia

The drop in POS pressure to pressurize the PGA from 5.0 psia to 8.85 psia and from 3.85 to 6.0 psia is given below for manned suit volumes of 2.0, 2.2, and 2.4 cubic feet.

<u>Suit Volume, FT<sup>3</sup></u>	<u>Drop in POS Pressure, PSI</u>	
	<u>5.0 to 8.85 psia</u>	<u>3.85 to 6.0 psia</u>
2.0	34.4	19.2
2.2	37.8	20.1
2.4	41.2	23.0

Since the PLSS O<sub>2</sub> regulator maintains the suit pressure at 3.85 psi above ambient, the suit pressure would be greater than the LM cabin pressure after cabin repressurization has been affected. This would require a crewman to either "pop a glove" or open the purge valve prior to attempting to remove his suit. Figures 4.5-53.6 through 4.5-53.8 show the LM cabin pressure at which to shut-off the PLSS O<sub>2</sub> in order for a negligible pressure differential exists at the instant the LM completes repress as a function of the PLSS O<sub>2</sub> supply pressure. Figures 4.5-53.9 and 4.5-53.10 show the curves and method used to derive the three working curves.

#### 4.5.6.2 Oxygen Supply Residual

The residual oxygen for nominal depletion of the POS is .123 lbs which corresponds to a pressure of 100 psia at a temperature of 70°F.

#### 4.5.6.3 Pressure Regulation

The PLSS primary oxygen regulator characteristics are shown in Figure 4.5-54.

Figure 4.5-55 defines the bellows orifice flow rate at various ambient pressures.

Figures 4.5-56 and 4.5-56.1 illustrate the POS purge time and maximum flow rate with a failed open regulator as a function of source pressure.

Figure 4.5-56.2 illustrates the time from regulator failed closed condition until activation of the low pressure warning. This time is dependent upon metabolic rate, suit leakage, and PGA/PLSS free volume. The figure presents this time for various metabolic rates, for a suit leakage of zero, and a PGA/PLSS free volume of 2.2 cubic feet. The pressure in a PGA with maximum allowable PIA leakage will decay at 0.0114 psi/minute faster.

#### 4.5.6.4 Initial Charge and Pressure Decay Prior to Use

The ground charging characteristics of the PLSS primary oxygen supply are shown in Figure 4.5-57. Pressure decay characteristics of the POS between charging and use are given by Figure 4.5-57.1.

#### 4.5.6.5 Recharge

The recharge characteristics of the PLSS primary oxygen supply are shown in Figure 4.5-58.

4.5.6.6 Pressure/Mass Relationship

The PLSS oxygen quantity (mass) as a function of the POS source pressure is shown in Figure 4.5-59. Steady state temperature values were assumed in preparing the family of curves.

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS





Figure 4.5-52 Oxygen Usage Rate Versus Metabolic Rate

**Volume IV EMU Data Book**  
**Subsystem Performance Data - PLSS**

Table 4.5-11 Oxygen Quantity Indicator Markings and Accuracies



MARKING	OXYGEN BOTTLE PRESSURE RANGE	
	HORIZONTAL POSITION AND ZERO G	ALL OTHER POSITIONS
0	160 psia Maximum 110 psia Nominal 60 psia Minimum	187 psia Maximum 110 psia Nominal 33 psia Minimum
1/4	410 psia Maximum 360 psia Nominal 310 psia Minimum	437 psia Maximum 360 psia Nominal 283 psia Minimum
1/2	660 psia Maximum 610 psia Nominal 560 psia Minimum	687 psia Maximum 610 psia Nominal 533 psia Minimum
3/4	910 psia Maximum 860 psia Nominal 810 psia Minimum	937 psia Maximum 860 psia Nominal 783 psia Minimum
F	1160 psia Maximum 1110 psia Nominal 1060 psia Minimum	1187 psia Maximum 1110 psia Nominal 1033 psia Minimum

Each increment of indicator represents 50 psia.

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-53 LM Repress Cabin Pressure Vs. Suit Pressure on PLSS




Figure 4.5-53.1 POS and PGA Pressure versus Time for PGA Pressurization  
Initial POS Pressure - 1030 psia

5.0 psia Ambient






Figure 4.5-53.2 POS and PGA Pressure versus Time for PGA Pressurization  
Initial POS Pressure - 950 psia

5.0 psia Ambient




Figure 4.5-53.3 Suit Pressure versus Time for LM Repress  
On PLSS - Initial POS Pressure - 150 psia




Figure 4.5-53.4 Suit Pressure versus Time for LM Repress - On PLSS  
Initial POS Pressure - 300 psia




Figure 4.5-53.5 Suit Pressure versus Time for LM Repress - On PLSS  
Initial POS Pressure - 450 psia




Figure 4.5-53.6 IM Cabin Pressure at which to Terminate PLSS O<sub>2</sub> During IM Cabin Repress (Final IM Pressure = 4.50 psia)




Figure 4.5-53.7 IM Cabin Pressure at which to Terminate  
PLSS O<sub>2</sub> During IM Cabin Repress (Final  
IM Pressure = 4.70 psia)






Figure 4.5-53.8 IM Cabin Pressure at which to Terminate  
PLSS O<sub>2</sub> During IM Cabin Repress (Final  
IM Pressure = 4.90 psia)




Figure 4.5-53.9 IM Cabin Pressure and Suit Pressure  
(With Breathe Down Effects Indicated)  
Versus Time






Figure 4.5-53.10 Demonstration of Method Used to Derive Working Curves  
(Figures 4.5-53.6 through 4.5-53.8) From Figure  
4.5-53.9




Figure 4.5-53.10 Demonstration of Method Used to Derive Working Curves  
(Figures 4.5-53.b through 4.5-53.8) From Figure  
4.5-53.9

Scout 2001e




Figure 4.5-54 Primary O<sub>2</sub> Regulator Performance




Figure 4.5-55 POS Bellows Orifice Characteristic




Figure 4.5-56 POS Purge Time with Failed Open Regulator






Figure 4.5-56.1 O<sub>2</sub> Bottle Pressure Vs. Maximum Regulator Flow in Failed Open Position




Figure 4.5-56.2 Time Prior to Low Pressure Warning  
With Failed Closed POS Regulator




Figure 4.5-57 POS Bottle Temperature Vs. Pressure - Ground Charging



NOTE: PLSS POS Leakage

1. Spec. Max. = 0.424 psia/Hr.
2. Nominal = 0.212 psia/Hr.




Figure 4.5-57.1 PLSS POS Bottle Pressure Vs. Stowage Time

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-58C POS Charge Curves (Cont'd)

Volume IV EMU Data Book  
Subsystem Performance Data - PLSS




Figure 4.5-58D POS Charge Curves (Cont'd)




Figure 4.5-58E POS Charge Curves (Cont'd)




Figure 4.5-59 O<sub>2</sub> Bottle Pressure Vs. O<sub>2</sub> Quantity

#### 4.6 OPS

The OPS is required to provide pressure control for all operational modes. When used during purge mode, it also provides contaminant control. Although the system is not required to provide thermal control, some metabolic heat can be absorbed depending upon the dew point temperature at the purge port, the flow rate, and the temperature rise across the PGA as shown in Figures 4.6-1 and 4.6-2. Figure 4.6-2.1 shows the crewman heat storage at various metabolic rates with OPS purge.

##### 4.6.1 Oxygen Supply

When the OPS oxygen supply is fully charged, the supply pressure varies with temperature as shown in Figure 4.6-3. From the time of charging until mission use, the OPS supply pressure will vary as noted on Figure 4.6-3.1. The oxygen quantity (mass) as it relates to bottle pressure at various steady state gas temperatures is shown in Figure 4.6-3.2. The actual supply pressure is displayed by the OPS bottle pressure gage whose accuracy and configuration is shown in Figure 4.6-4. With the OPS mounted on the suit, and during the purge mode of OPS operation, the bottle pressure can be monitored by the crewman. The duration of the OPS oxygen is dependent upon the oxygen usage rate as shown in Figure 4.6-5. The bottle pressure decay during this mode, with a nominal flow rate of 8.0 lb/hr, will be similar to that shown in Figure 4.6-6, and with a flow rate of 4.2 lb/hr, will be as shown in Figure 4.6-6.1. Figure 4.6-7 shows the  $O_2$  flow rate through the purge valve during purge valve operation, at high flow position, as a function of the suit pressure. The OPS blowdown time as a function of the supply pressure is given in Figure 4.6-8. The PGA pressure variation with time for a partial blowdown with failed open OPS regulator is shown in Figure 4.6-8.1 (results of a single test only).

##### 4.6.2 Oxygen Supply Residuals

The residual oxygen in the OPS for the make-up mode of operation is 0.106 lb which corresponds to a pressure 100 psia at a temperature of 64° F. The residual oxygen for the 8.4 lb/hr purge mode of operation is 0.773 lb which corresponds to a pressure of 500 psia at a temperature of -60° F. The residual oxygen for the 4.2 lb/hr purge mode is 0.445 lb, which corresponds to a pressure of 300 psia at -60° F. (The -60° F temperatures refer to the gas temperatures in the OPS storage bottles.)

#### 4.6.3 Oxygen Pressure Regulation

The regulator outlet pressure as a function of the supply pressure and ambient pressure is shown in Figure 4.6-9. The OPS pressure regulator characteristics as a function of supply pressure, supply temperature, and flow rate are shown in Figures 4.6-10 and 4.6-11. The performance of the OPS regulator can be verified during OPS checkout by monitoring the regulator checkout pressure gage which possesses the accuracy characteristics and configuration as shown in Figure 4.6-12. The OPS checkout orifice characteristics and bleed-down times are shown in Figures 4.6-13 and 4.6-14.

The pressure regulation is controlled by a metallic bellows. The pressure is referenced to ambient by means of an orifice in the bellows. In the unlikely event of a leak in the bellows, the flow rate of the PGA oxygen through the orifice versus the bellows inlet pressure will be as shown in Figure 4.6-17.

#### 4.6.4 Temperature Control

There are no temperature control devices in the OPS, except thermal insulation, because they are not needed. The regulator outlet, helmet duct, and crewman temperatures versus OPS discharge time are shown in Figures 4.6-15 and 4.6-16 for the warm and cold initial O<sub>2</sub> supply conditions, respectively.



Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.6-1A Latent Heat Absorbed Vs. PGA Outlet Dewpoint



Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.6-1B Latent Heat Absorbed Vs. PGA Outlet Dewpoint

Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.6-1C Latent Heat Absorbed Vs. PGA Outlet Dewpoint

Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.6-2 OPS Sensible Heat Absorption Capabilities




Figure 4.6-2.1 Crewman Heat Storage Vs. Time

Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.6-3 OPS Bottle Temperature Vs. Pressure - Ground Charging

NOTE: OPS LEAKAGE

1. Spec. Max. = 20 scc/Hr.  
Equivalent to 0.075 psia/Hr.
2. Temp. Effects are not significant  
because of low leakage rate.
3. For regulator checkout, bottle  
pressure will degrade at approx.  
24 psia/checkout for the following  
conditions:
  - A. OPS Pressure = 5000-6000 psia
  - B. Temp. = 70°F
  - C. Flow = 0.48 lbs/Hr. for 3 Min.




Figure 4.6-3.1 OPS Oxygen Bottle Pressure  
Vs. Stowage Time





Figure 4.6-3.2 OPS O<sub>2</sub> Bottle Pressure Vs. Oxygen Quantity

**Volume IV EMU Data Book**  
**Subsystem Performance Data - OPS**



**ACCURACY  $\pm$  300 PSIA**

Figure 4.6-4 Oxygen Purge System High Pressure Oxygen Gage



Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.6-5 OPS Oxygen Supply Duration Vs. Usage Rate

Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.6-6 OPS Bottle Pressure Decay Vs. Purge Time

Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.6-7 OPS FLOW RATE VERSUS PRESSURE AS DICTATED BY  
PURGE VALVE

Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.6-8 OPS Bottle Pressure and Flow Rate  
Vs. Blowdown Time - Full Open Reg.

Volume IV EMU Data Book  
 Subsystem Performance Data - OPS




Figure 4.6-9 OPS Regulated Outlet Pressure Vs. Source Pressure

Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.6-10 OPS O<sub>2</sub> Supply Temperature and Outlet Pressure Versus Flow (60° Average Supply Temperature)

Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.6-11 OPS O<sub>2</sub> Supply Temperature and Outlet Pressure Versus Flow (35 - 60° Temperature Range)

Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.6-12 Oxygen Purge System Low Pressure Checkout Gage



Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.6-13 OPS Checkout Orifice Characteristics




Figure 4.6-14 OPS Checkout Orifice Bleed-Down Time

Volume IV EMU Data Book  
Subsystem Performance - OPS




Figure 4.6-15 Regulator Outlet, Helmet Duct, and Crewman Temperatures Without OPS Heater Vs. Time (Warm Condition)

Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.6-16 Regulator Outlet, Helmet Duct, and Crewman Temperatures Without OPS Heater Vs. Time (Cold Condition)

Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.5-17 OPS Battery Current Vs. Time  
(Typical Purge Operation)

Volume IV EMU Data Book  
Subsystem Performance Data - OPS




Figure 4.6-18 OPS Battery Discharge Characteristics

Volume IV EMU Data Book  
Subsystem Performance Data - OPS

Table 4.6-1 OPS Power Supply Storage and Usage  
Time - Temperature Limitations

CONDITION OF POWER SUPPLY	TEMPERATURE LIMITATIONS	TIME AT TEMPERATURE LIMITATIONS
Storage, unactivated	40 - 100°F	1 year maximum
Storage, activated		24 days total life
(a)	60 - 90°F	24 days maximum
(b)	40 - 60°F 90 - 110°F	6 days maximum
(c)	110 - 130°F	4 days maximum
Operation	35 - 130°F	




Figure 4.6-3 OPS Bottle Temperature Vs. Pressure - Ground Charging

NOTE: OPS LEAKAGE

1. Spec. Max. = 20 scc/Hr.  
Equivalent to 0.075 psia/Hr.
2. Temp. Effects are not significant  
because of low leakage rate.
3. For regulator checkout, bottle  
pressure will degrade at approx.  
24 psia/checkout for the following  
conditions:
  - A. OPS Pressure = 5000-6000 psia
  - B. Temp. = 70°F
  - C. Flow = 0.48 Lbs/Hr. for 3 Min.




Figure 4.6-3.1 OPS Oxygen Bottle Pressure  
Vs. Stowage Time







Figure 4.6-3.2 OPS O<sub>2</sub> Bottle Pressure Vs. Oxygen Quantity

Volume IV EMU Data Book  
Subsystem Performance Data - OPS



Accuracy  $\pm 300$  psia

Figure 4.6-4 Oxygen Purge System High Pressure Oxygen Gage




Figure 4.6-8.1 Suit Inlet Pressure Versus Time -  
Failed Open OPS Regulator

G MISSION APPENDIX

APOLLO 11

Volume IV EMU Data Book  
Equipment Matrix - Mission G

Equipment Assignment Matrix and Appendix Data Location

Crewman Equipment	CMP		LMP		CDR	
	S/N	Page	S/N	Page	S/N	Page
PLSS*	---	---	014	G-3	015	G-22
OPS*	---	---	008	G-10	013	G-29
PGA	033	G-2	077	G-11	056	G-30
LCG	---	---	079	G-12	077	G-31
EVCS**	---	---	EVC-2 1967B	---	EVC-1 1966B	---
LEVA*	---	---	006	---	005	---
Purge Valve*	---	---	157	G-13	155	G-32
Consumables	---	---	---	G-14	---	G-33

\* Interchangeable between crewmen

\*\* Communications data combined with PLSS data

Volume IV EMU Data Book  
PGA and Accessories Characteristics-Mission G-1

Amendment  
7/16/69

APOLLO 11

FLIGHT PGA CHECKOUT DATA

A7L-033  
PGA S/N

COLLINS  
CREWMAN

ITEM	SPEC. REQUIREMENT	FACTORY PDA	CAT PIA	FLIGHT PIA	FLIGHT DAY	REMARKS
Relief Valve	S/N <u>N/A</u>					
Crack	5.5 psi	<u>N/A</u>	<u>N/A</u>	<u>N/A</u>		
Reseat	4.8 psi	<u>N/A</u>	<u>N/A</u>	<u>N/A</u>		
Flowrate		<u>N/A</u>	<u>N/A</u>	<u>N/A</u>		
Pressure Gage	S/N <u>248</u>	ORIG GAGE	N/A	CONSOLE READING		
3.0 psi	+ .15 psi			<u>3.0</u>		
3.5 psi	+ .15 psi	REPLACED		<u>3.5</u>		
4.0 psi	+ .15 psi			<u>4.0</u>		
4.5 psi	+ .15 psi			<u>4.5</u>		
5.0 psi	+ .15 psi			<u>5.0</u>		
6.0 psi	+ .15 psi			<u>6.0</u>		
<del>7.5 psi</del>	+ .15 psi			<u>4.03</u>		
<del>8.5 psi</del>				<u>3.53</u>		
Leakage						
18 <del>psi</del>	180 sec	<u>19 sec/m</u>	<u>N/A</u>	<u>60 SCFM</u>		
3.75 psi	180 sec	<u>100 sec/m</u>	<u>048 sec/m</u>	<u>70 SCFM</u>		
Pressure Drop		SUIT				
AP (1n H <sub>2</sub> O)		<u>SUIT</u>				
Flowrate scfm		NOT				
Suit press. psia		<u>AVAIL</u>				

12.0 CFM  
.15 psi 11 in. H<sub>2</sub>O  
3.5 psi 10 in. H<sub>2</sub>O

7/14/69  
DATE

PER MISSION MANAGER

Volume IV EMU Data Book  
PLSS S/N 00014 Characteristics

<u>Channel</u>	<u>Actual Reading</u>	<u>Correspondence Value</u>	<u>Telemetry</u>	<u>Date</u>
3	4.00 PSID	$60 \pm 4$	59.5	5/4/69
3	3.00 PSID	$20 \pm 4$	18.3	3/4/69
4	100 mmHg	$38.5 \pm 3$	38.3	5/4/69
4	200 mmHg	$77 \pm 3$	77.2	5/4/69
5	1.05 amp	$10.5 \pm .5$	10.3	5/3/69
5	.65 amp	$6.5 \pm .5$	6.0	5/3/69
6	16	$48 \pm 3.18$	48.0	5/4/69
6	18	$70.7 \pm 3.18$	70.5	5/4/69
7	950	$86.5 \pm 2.5$	86.3	5/4/69
7	590	$54 \pm 2.5$	55.5	5/4/69
7	150	$13.5 \pm 2.5$	15.4	5/4/69
8	Hot Hand Test Yes - Passed			5/4/69
9	77° F	$86 \pm 4.4$	88	5/4/69
10	77° F	$86 \pm 4.4$	87.7	5/4/69
<hr/>				
Warning Indicator				
HiO <sub>2</sub> Flow		Act 0.61 pph Deact. - .60		
Low Vent Flow		Act. 4.62 acfm Deact. - 4.77		
PGA Pressure		Act. 3.20 psid Deact. - 3.35 psid		
Feedwater		Act. 1.47 psia Deact. - 1.520 psia		


Table G-1 PLSS S/N 00014 Telemetry Readouts and  
Warning Indicator Actuation Points

Volume IV EMU Data Book  
PLSS S/N 00014 Characteristics

Figure 7.0-1 Line Voltage Vs. Telemetry Signal Amplitude

EVC2 serial 1961B

S/N 00014 PLSS





Volume IV EMU Data Book  
PLSS S/N 00014 Characteristics




Figure G-2 PLSS S/N 014, SUBLIMATOR CALIBRATION CURVES WITH THE DIVERTER VALVE IN THE 'MAXIMUM' POSITION

Volume IV EMU Data Book  
PLSS S/N 00014 Characteristics

PLSS 14

Low Pressure O <sub>2</sub> Loop Leakage	4.0 scc/min
POS Leakage	.405 psi/hr
Regulator Internal Leakage	0
OPS Backflow Check Valve Leakage	.06 lb/hr
Feedwater Loop External Leakage	.018 $\frac{\text{inches H}_2\text{O}}{\text{minute}}$
Feedwater to O <sub>2</sub> Loop Leakage	0
Feedwater and Transport Loop Leakage	1.07 cc/hr
Transport Loop Leakage	.107 cc/hr
Water Shutoff and Relief Valve	Relief 56.0 psig Reseat 54.0 psig
Feedwater Quantity	8.5 lb.
High O <sub>2</sub> Flow Sensor	Actuation .54 lb/hr Deactuation .54 lb/hr
Low Vent Flow Sensor	Actuation 4.78 acfm Deactuation 5.00 acfm
Low PGA Pressure Switch	Actuation 3.17 psid Deactuation 3.30 psid
Low Feedwater Pressure Switch	Actuation 1.40 psia Deactuation 1.52 psia

O<sub>2</sub> Regulator Performance

<u>Bottle Pressure (Psig)</u>	<u>Flow (lb/hr)</u>	<u>Regulated Pressure (Psid)</u>
86	.07	3.84
86	.36	3.80
89	.07	3.86
235	.07	3.90
230	.70	3.79
235	.07	3.85
1105	.07	3.90
1104	2.00	3.72
1105	.07	3.85

Pump Performance - see Curve

Fan Performance - see curve

Volume IV EMU Data Book  
PLSS S/N 00014 Characteristics

Figure G-3 PLSS 0014 Pressure Rise Vs. Flow

FAN FLOW TEST  
PER CHD-A-394

TPS REF. KSC P1A

DATE 6-20-69


PLSS S/N 00014

BATTERY S/N

(IF APPLICABLE)


CARTRIDGE S/N

(IF APPLICABLE)



APOLLO EMU  
 LIQUID TRANSPORT LOOP  
 SYSTEM PERFORMANCE  
 PLSS  
 S/N 00014  
 Date 6/22/69  
 LCG  
 S/N 079  
 Date 7/12/69  
 CREWMAN ALDRIN

Figure G-4 PLSS OCL4 Liquid Transport  
 Loop Pressure Rise Vs. Flow



AQUABEE

MADE IN USA

DRAWING PAPER NO. 1280-10-5

TRACING PAPER NO. 1227-10-5

CROSS SECTION-10X10 TO 1 INCH

SYN LINE ACCT'D, 10TH HEAVY

Volume IV EMU Data Book  
OPS Characteristics

OPS PREFLIGHT PIA DATA

KEY PERFORMANCE CHARACTERISTICS

OPS S/N 0008

- |   | <u>Actual <math>\Delta P</math></u> | <u>Indicated <math>\Delta P</math></u> |
|---|-------------------------------------|--|
| 1. Checkout gage accuracy -   | 3.43<br>3.75                        | 3.5<br>3.8                             |
| 2. Low pressure external leakage indicated leakage - $1.386 \times 10^{-4}$ cc/sec<br>at 4.25 psid.   |                                     |  |
| 3. High pressure external leakage indicated leakage - $0.14 \times 10^{-4}$ cc/sec<br>at 6750 psid.   |                                     |  |
| 4. Internal leakage (across regulator) indicated leakage - zero   |                                     |  |
| 5. Purge flow performance   |                                     |  |
| Thirty minute flow at 8 lb/hr.<br>Bottle pressure decayed from approximately 6400 psig to 1700 psig.<br>Regulated $\Delta P$ varied from a maximum of 3.68 psid to a minimum of<br>3.43 psid. |                                     |  |
| 6. Make-up flow performance -   |                                     |  |
| With bottle pressure of 5750 psig and flow of 0.08 lb/hr., the<br>regulated $\Delta P$ range between 3.63 psid and 3.775 psid.  |                                     |  |

APOLLO 11

ALDRIN  
(CHINA)

PGA S/N

ITEM	SPEC. REQUIREMENT	FACTORY PDA	CAT PIA	FLIGHT PIA	FLIGHT DAY	REMARKS
Relief Valve	S/N <u>2108</u>					
Crack	5.5 psi	<u>4.9 PSI</u>		<u>4.80 PSI</u>	5.1 psi	
Reseat	4.8 psi	<u>4.8 PSI</u>		<u>4.81 PSI</u>	4.69 psi	
Flowrate @ 5.5 psi		<u>2.0 scfm</u>		<u>1.9 scfm</u>	3.0 CFM	
Pressure Gage	S/N <u>247</u>					
3.0 psi	+ .15 psi			CONSOLID READING <u>3.02</u>		
3.5 psi	+ .15 psi			<u>3.56</u>		
4.0 psi	+ .15 psi			<u>4.0</u>		
4.5 psi	+ .15 psi			<u>4.5</u>		
5.0 psi	+ .15 psi			<u>5.0</u>		
6.0 psi	+ .15 psi			<u>6.0</u>		
3.75 psi	+ .15 psi					
Leakage						
<u>4.2 in H<sub>2</sub>O</u>						
<u>0.7 psi</u>	180 sec	<u>8 sec/m</u>		<u>8 sec/m</u>		
3.75 psi	180 sec	<u>60 sec/m</u>	<u>31 scfm</u>	<u>9.5 scfm</u>		
Pressure Drop						
AP (in H <sub>2</sub> O)						
Flowrate scfm						
Suit press. psia						

**TO VARIOUS MINISTERS:**

7/14/69

DATE \_\_\_\_\_

Volume IV EMU Data Book  
 PGA and Accessories Characteristics-Mission G-1

APOLLO 11

FLIGHT LOG CHECKOUT DATA

ALDRIN  
 CREWMAN

079  
 LOG S/N

EX.	SPEC. REQUIREMENT	FACTORY PDA	CAT PIA	FLIGHT PIA	FLIGHT DAY	REMARKS
eight	gms			4.02 lb		
eight	gms			5.16 2oz		
c Pressure	psig					
e Date/Time				22:20 7/12/69		
ure drop			psid			
Flowrate indicated	3.0 $\pm$ .1 lb/min			1.3 psid		
	3.5 $\pm$ .1 lb/min			1.7 psid		
	3.8 $\pm$ .1 lb/min			2.0 psid		
	4.0 $\pm$ .1 lb/min			2.1 psid		
	4.3 $\pm$ .1 lb/min			2.4 psid		
	4.5 $\pm$ .1 lb/min			2.6 psid		
	5.0 $\pm$ .1 lb/min			3.1 psid		

7/14/69  
 DATE



Volume IV EMU Data Book  
PGA and Accessories Characteristics - Mission G-1

Purge Valve 157

Flow Rate = 8.2 lbs/hr. O<sub>2</sub> at 90°F

Leakage Rate = 0 scc/minute at 3.75 ± .25 psig

Volume IV EMU Data Book  
Consumables Data - Mission G-1




Figure G-5 LMP and CDR CO<sub>2</sub> Buildup (LiOH Depletion)




Figure G-6 PLSS CO<sub>2</sub> Partial Pressure Versus Time

Volume IV EMU Data Book  
Consumables Data - Mission G-1

JULY 14, 1969

APOLLO 11 CRITICAL DATA SUMMARY SHEET

	<u>PLSS 014</u>	<u>PLSS 015</u>	<u>PLSS 019</u>	<u>OPS 008</u>	<u>OPS 013</u>	<u>OPS 011</u>
Dry Weight* (lbs.)	54.9375	55.1681	62.375	29.6251	29.5625	29.5000
Charged Weight** (lbs.)	79.625	79.625	N/A	40.25	40.0	N/A
O <sub>2</sub> Pressure (psia)	1024.7	1022	1027	5950 @ 74° F	5950 PSI @ 74° F	5960 @ 74° F
Battery Activation Date	7/13/69	7/13/69	N/A	7/10/69	7/11/69	N/A
Lanyard Slide (in.)	N/A	N/A	N/A	.6175	.618	.606
Switch Overtravel (in.)	N/A	N/A	N/A	.010	.012	.017
F/W Quantity (lbs.)	3.5625	3.6251	8.5625	N/A	N/A	N/A
T/W Quantity (lbs.)	1.4375	1.2500	1.3125	N/A	N/A	N/A
LiOH Weight (lbs.)	4.6000	4.6875	N/A	N/A	N/A	N/A
RCU Weight (lbs.)	5.125	5.188	N/A	N/A	N/A	N/A
Battery Shelf Life	Sept. 1968	Sept 1968	N/A	Jan. 1969	Jan. 1969	N/A
RCU Serial No.	008	010	N/A	N/A	N/A	N/A
Battery Serial No.	S-147	S-139	N/A	S-47	S-46	N/A
LiOH Cartridge Serial Number	136	138	N/A	N/A	N/A	N/A

\* Less RCU, Thermal Cover, Harness, Battery and Cartridge  
\*\* Completely Flight Configured, Less RCU





Figure G-7 LMP Feedwater Depletion Rate

LMP-Oxygen G Mission (Apollo 11)


ASSUMPTIONS:

BOTTLE 378 IN<sup>3</sup>  
EMU LEAK 0.034 LB/HR  
JUNE 2, 1969 MET RATE (FIG. 5.0-7)  
155 PSIA UNUSABLE



SNA-8-D-027 (IV) REV 1

Figure G-8 LMP Oxygen Depletion Rate



SNA-8-D-027 (IV) REV 1

Figure G-9 LMP and CDR PLSS Battery Depletion Rate

LMP  
NOMINAL LUNAR SURFACE EVA  
METABOLIC PROFILE  
1265 BTU/HR AVG  
2 June 69




Figure G-10 LMP Nominal Lunar Surface EVA Metabolic Profile






Figure G-11 LMP Nominal Lunar Surface EVA Metabolic Profile (Cont'd)

Volume IV EMU Data Book  
Consumables Data - Mission G-1




Figure G-12 LMP Nominal Lunar Surface EVA Metabolic Profile (Cont'd)

Volume IV EMU Data Book  
PLSS S/N 00015 Characteristics


<u>Channel</u>	<u>Actual Reading</u>	<u>Correspondence Value</u>	<u>Telemetry</u>	<u>Date</u>
3	4.0 psid	60% $\pm$ 4	58.8	4/30/69
3	3.0 psid	20 $\pm$ 4	18.1	4/30/69
4	101 mmHg	39 $\pm$ 3	38.4	4/30/69
4	200 mmHg	77 $\pm$ 3	76.75	4/30/69
5	1.1 amp	11 $\pm$ .5%	10.1	4/30/69
5	.58 amp	5.8 $\pm$ .5%	5.8	4/30/69
6	16 volts	48 $\pm$ 3.18	48.8	4/30/69
6	18 volts	71 $\pm$ 3.18	70.90	4/30/69
7	950 psig	87 $\pm$ 2.8	85.7	4/30/69
7	600 psig	55 $\pm$ 2.8	57.4	4/30/69
7	150 psig	14 $\pm$ 2.5	16.0	4/30/69
8	Hot Hand Test - Passed			4/30/69
9	77.2° F	86 $\pm$ 4.4%	87.7	4/30/69
10	77.2° F	86 $\pm$ 4.4%	85.7	4/30/69

Warning Indicators

Hi O <sub>2</sub> Flow	Act. 0.59 pph Deact.- 0.56 pph	4/30/69
Low Vent Flow	Act. 4.79 acfm Deact.- 4.88 acfm	4/30/69
PGA Pressure	Act. 3.29 psid Deact.- 3.34 psid	4/30/69
Feedwater	Act. 1.33 psia Deact.- 1.46 psia	4/30/69

Table G-2 PLSS S/N 00015 Telemetry Readouts and  
Warning Indicator Actuation Points

Figure G-13 Line Voltage Vs. Telemetry Amplitude  
 EVC-1 Serial 1966B



Volume IV EMU Data Book  
PLSS S/N 00015 Characteristics




Figure G-14 PLSS S/N 015, SUBLIMATOR CALIBRATION CURVES WITH THE DIVERTER VALVE IN THE 'MAXIMUM' POSITION

Volume IV EMU Data Book  
PLSS S/N 00015 Characteristics

PLSS 15

Low Pressure O <sub>2</sub> Loop Leakage	4.5 $\frac{\text{scf}}{\text{min}}$
POS Leakage      * Actual reading - pressure increase of .05 $\frac{\text{psi}}{\text{hr}}$ MRB buy-off	0
Regulator Internal Leakage	0
OPS Back Flow Check Valve Leakage	.06 $\frac{\text{lb}}{\text{hr}}$
Feedwater Loop External Leakage	.004 $\frac{\text{inches H}_2\text{O}}{\text{minute}}$
Feedwater to O <sub>2</sub> Loop Leakage	0
Feedwater and Transport Loop Leakage	1.61 $\frac{\text{cc}}{\text{hr}}$
Transport Loop Leakage	.21 $\frac{\text{cc}}{\text{hr}}$
Water Shutoff and Relief	Relief      57 psig Reseat      54 psig
Feedwater Quantity	8.5 lb.
High O <sub>2</sub> Flow Sensor	Actuation .495 $\frac{\text{lb}}{\text{hr}}$ Deactuation .48 $\frac{\text{lb}}{\text{hr}}$
Low Vent Flow Sensor	Actuation 4.68 acfm Deactuation 4.92 acfm
Low PGA Pressure Switch	Actuation 3.20 psid Deactuation 3.27 psid
Low Feedwater Pressure Switch	Actuation 1.38 psia Deactuation 1.52 psia

O<sub>2</sub> Regulation Performance

<u>Bottle Pressure (psig)</u>	<u>Flow (lb/hr)</u>	<u>Regulated Pressure (psid)</u>
85	.07	3.90
88	.36	3.87
90	.07	3.92
238 <sup>1</sup>	.07	3.96
235	.70	3.88
235	.07	3.93
1105	.07	3.99
1102	1.97	3.83
1110	.07	3.97

Pump Performance - See curve

Fan Performance - See curve

Volume IV EMU Data Book  
PLSS S/N 00015 Characteristics

FAN FLOW TEST  
PER CSD-A-394

TPS REF. EVA-K-1005

DATE 7-2-69

PLSS S/N ~~1111~~ 15

BATTERY S/N NA  
(IF APPLICABLE)

CARTRIDGE S/N NA  
(IF APPLICABLE)

Figure G-15 PLSS 0015 Fan Pressure Rise Vs. Flow


PLSS PRESSURE RISE (IN. WATER)

5

4

3

2



MINIMUM PERFORMANCE POINT

(CURVE MUST NOT FALL

BELOW AND TO THE LEFT

OF THIS POINT)



Volume IV EMU Data Book  
PCA and Accessories Characteristics - Mission G-1

APOLLO EMU  
LIQUID TRANSPORT LOOP  
SYSTEM PERFORMANCE

PLSS


S/N 00015  
Date 6/1/64

LCG

S/N 074  
Date 7/1/64

CREWMAN: ARMSTRONG

Figure G-16 PLSS 0015 Liquid Transport Loop Pressure Rise Vs. Flow



AQUADEL

MADE IN USA

DRAWING PAPER NO. 1280-10-B  
TRACING PAPER NO. 1227-10-B  
EM-55 SECTION-10X10 TO 1 INCH  
50% LINE ACCT'D, 10% HEAVY

Volume IV EMU Data Book  
OPS Characteristics

OPS PREFLIGHT PIA DATA

KEY PERFORMANCE CHARACTERISTICS

OPS S/N 00013

- |  | <u>Actual</u> | <u>P</u> | <u>Indicated</u> | <u>P</u> |
|--|---------------|----------|------------------|----------|
| 1. Checkout gage accuracy -  | 3.5 psi       |          | 3.45 psi         |          |
|  | 3.8 psi       |          | 3.75 psi         |          |
| 2. Low pressure external leakage indicated leakage - zero cc/sec at<br>4.25 psi P.                   |               |          |                  |          |
| 3. High pressure external leakage indicated leakage - $1.03 \times 10^{-4}$ cc/sec<br>at 6750 psi P. |               |          |                  |          |
| 4. Internal leakage (across regulator) indicated leakage - 24 cc/min.                                |               |          |                  |          |
| 5. Purge flow performance -  |               |          |                  |          |

Thirty minute flow at 8 lb/hr

Bottle pressure decayed from approximately 6000 psig to 1200 psig  
Regulated P varied from a maximum of 3.655 psid to minimum  
of 3.45 psid.

6. Makeup flow performance -

With bottle pressure of 6750 psig and flow of 0.08 lb/hr., the  
regulated P ranged between 3.785 psid and 3.8 psid.

Volume IV. EMU Data Book  
PGA and Accessories Characteristics-Mission G-1.

APOLLO

FLIGHT PGA CHECKOUT DATA

ARMSTRONG  
CHECKMAN

056  
PGA S/N

ITEM	SPEC. REQUIREMENT	FACTORY PDA	CAT PIA	FLIGHT PIA	FLIGHT DAY	REMARKS
Relief Valve	S/N <u>2123</u>	PRV REPLACED	PRV REPLACED			
Crack	5.5 psi	<del>5.5</del>	<del>5.5</del>	4.90	4.85	psi
Reseat	4.8 psi	<del>4.8</del>	<del>4.8</del>	4.75	4.65	psi
Flowrate @ 5.5 psig					3.0 CFM	
Pressure Gage	S/N <u>249</u>	ORIG GAGE REPLACED	ORIG GAGE REPLACED	CONSOLE READING		
3.0 psi	+ .15 psi			3.10		
3.5 psi	+ .15 psi			3.58		
4.0 psi	+ .15 psi			4.08		
4.5 psi	+ .15 psi			4.60		
5.0 psi	+ .15 psi			5.10		
6.0 psi	+ .15 psi			6.10		
5.4 psi	+ .15 psi			3.60		
4.0				4.10		
Leakage						
0.18 psi	180 sec	38 sec/m	N/A	5 sec/m		
3.75 psi	180 sec	80 sec/m	45 sec/m	33 sec/m		1V GLOVES
3.75 psi				50 sec/m		EV GLOVES
Pressure Drop			NOT PERFORMED	NOT PERFORMED	12.0 CFM	
AP (in H <sub>2</sub> O)		SUIT SUBJECT NOT AVAILABLE @ PDA			.15 psig	10.5 in. H <sub>2</sub> O
Flowrate scfm					3.5 psig	8.6 in. H <sub>2</sub> O
Suit press. psia					10.0 CFM	
					3.9 psig	3.4 in. H <sub>2</sub> O

H. H. H.  
TEST DIRECTOR MANAGER

7/14/69  
DATE

Volume IV EMU Data Book  
PGA and Accessories Characteristics-Mission G-1

APOLLO 11

FLIGHT LCG CHECKOUT DATA

ARMSTRONG

CREWMAN

077  
LCG S/N

ITEM	SPEC. REQUIREMENT	FACTORY PDA	CAT PIA	FLIGHT PIA	FLIGHT DAY	REMARKS
Weight	gms			1762 gms		
Weight	gms			4 lb 14 oz		
Go Pressure	psig					
Go Date/Time				2107 7/14/69		
Pressure drop				PSID		
Flowrate indicated	3.0 ± .1 lb/min			1.3	<del>1.3</del>	
	3.5 ± .1 lb/min			1.8	<del>1.8</del>	
	3.8 ± .1 lb/min			1.95		
	4.0 ± .1 lb/min			2.35		
	4.3 ± .1 lb/min			2.5		
	4.5 ± .1 lb/min			2.6		
	5.0 ± .1 lb/min			3.4		

7/14/69

DATE


Volume IV EMU Data Book  
PGA and Accessories Characteristics - Mission G-1

Purge Valve 155

Flow Rate = 8.2 lbs/hr.  $O_2$  at  $90^{\circ}F$

Leakage Rate = 0 scc/minute at  $3.75 \pm .25$  psig.

CDR-WATER, G MISSION (APOLLO 11)



SNA-8-D-027 (IV) REV 1

Figure G-17 CDR Feedwater Depletion Rate

CDR - OXYGEN G MISSION (APOLLO 11)


ASSUMPTIONS

BOTTLE 378 IN<sup>3</sup>

EMU LEAK RATE 0.034 LB/HR

JUNE 2 1969 MET RATE (F16.3.0-5)


155 PSI UNUSABLE



SNA-8-D-027 (IV) REV 1

Figure G-18 CDR Oxygen Depletion Rate

CDR  
NOMINAL LUNAR SURFACE EVA  
METABOLIC PROFILE  
1360 BTU/HR AVG  
2 JUNE 69



Cont'd  
next  
page

Figure G-19 CDR Nominal Lunar Surface EVA Metabolic Profile






Figure G-20 CDR Nominal Lunar Surface EVA Metabolic Profile (Cont'd)

Volume IV EMU Data Book  
Consumables Data - Mission G-1




Figure G-21 CDR Nominal Lunar Surface EVA Metabolic Profile (Cont'd)

Amendment 24  
11/12/69

H MISSION APPENDIX

APOLLO 12

Equipment Assignment Matrix and Appendix Data Location

Crewman Equipment	CMP		LMP		CDR	
	S/N	Page	S/N	Page	S/N	Page
PLSS*	---	---	018	H-3	019	H-12
OPS*	---	---	018	H-8	011	H-17
PGA	066	H-2	067	H-9	065	H-18
LCG	---	---	093	H-10	091	H-19
EVCS**	---	---	1969B	---	1972B	---
LEVA*	---	---	011	---	012	---
Purge Valve*	---	---	139	H-11	138	H-20
Consumables	---	---	---	H-21	---	H-21

\* Interchangeables between crewmen

\*\* Communications data combined with PLSS data

APOLLO 12

FLIGHT PGA CHECKOUT DATA

R. GORPON, CMP  
CREWMAN

A7L-066  
PGA S/N

ITEM	SPEC. REQUIREMENT	FACTORY PDA	CAT PIA	FLIGHT PIA	FLIGHT DAY	REMARKS
1) Relief Valve	S/N <u>N/A</u>					
Crack	5.5 psi			<u>N/A</u>		
Reseat	4.8 psi			<u>N/A</u>		
Flowrate				<u>N/A</u>		
2) Pressure Gage	S/N <u>261</u>					
3.0 psi	+ .15 psi			<u>2.03</u>		
3.5 psi	+ .15 psi			<u>3.49</u>		
4.0 psi	+ .15 psi			<u>4.0</u>		
4.5 psi	+ .15 psi			<u>4.5</u>		
5.0 psi	+ .15 psi			<u>5.0</u>		
<del>6.0 psi</del> 5.5 psi	+ .15 psi			<u>5.49</u>		
<del>3.75 psi</del> 6.0 psi	+ .15 psi			<u>5.99</u>		
3) Leakage						
0.2 psi	180 sec			<u>5</u>		
3.75 psi	180 sec			<u>55</u>		
4) Pressure Drop						
$\Delta P$ (in H <sub>2</sub> O)				<u>10.0 N/A</u>		
Flowrate scfm				<u>12.0 N/A</u>		
Suit press. psia				<u>18.2 N/A</u>		

↑  
IV mode

CSD MISSION MANAGER

DATE

(THIS PAGE INTENTIONALLY LEFT BLANK)

PLSS

S/N 00018

Low Pressure O <sub>2</sub> Loop Leakage	0 SCC/Min.
POS Leakage	0.49 psi.hr
Regulator Internal Leakage	0 SCC/min.
OPS Back Flow Check Valve Leakage	0.2 pph
Feedwater Loop External Leakage	.0008 in. H <sub>2</sub> O/Min.
Feedwater to O <sub>2</sub> Leakage	65 SCC/Min.
Feedwater and Transport Loop Leakage	1.55 cc/hr.
Transport Loop Leakage	0.27 cc/hr
Water Shutoff and Relief	Relief 58 psi Reseat 49.5 psig
Feedwater Quantity	8.475 pounds
High O <sub>2</sub> Flow Sensor	Actuation 0.51 pph Deactuation 0.50 pph
Low Vent Flow Sensor	Actuation 4.01 acfm Deactuation 4.10 acfm
Low PGA Pressure Switch	Actuation 3.25 psid Deactuation 3.35 psid
Low Feedwater Pressure Switch	Actuation 1.43 psid Deactuation 1.51 psia

PLSS S/N 018


O<sub>2</sub> Regulation Performance

<u>Bottle Pressure (psig)</u>	<u>Flow (lb/hr)</u>	<u>Regulated Pressure (psid)</u>
82	.07	3.87
85	.350	3.85
90	.07	3.90
235	.07	3.9
235	.65	3.82
230	.07	3.90
1100	.07	3.92
1105	2.0	3.78
1110	.07	3.91

Pump Performance - See curve.

Fan Performance - See curve.





TRANSPORT LOOP FLOW TEST

PAT. CSD-A-394

APPENDIX G

PARAMETER 1.0

TPS REF

DATE

PLSS S/N 00018

BATTERY S/N  
 (IF APPLICABLE)

Δ MIN  
 ○ INT  
 □ MAX  
 X LCG ΔP  
 (SIN 93)

TRANSPORT FILTER LOOP PRESSURE RISE (PSI)

8

7

6

5

4

3

2

1

0

INT

MIN

MAX

LCG ΔP

MINIMUM PERFORMANCE POINT  
 (CURVE MUST NOT FALL BELOW  
 AND TO THE LEFT OF THIS  
 POINT)

MIN. COOLING

INT. COOLING

MAX. COOLING

0

1

2

3

4

5

OPS PRE FLIGHT PIA DATA

KEY PERFORMANCE CHARACTERISTICS

OPS S/N 018. SV 730101-2-15

1. CHECKOUT GAGE ACCURACY

Actual Delta P

3.5 psid

3.8 psid

Indicated Delta P

3.45 psid

3.73 psid

2. LOW PRESSURE EXTERNAL LEAKAGE

Indicated Leakage

0 cc/sec.

Delta P

4.25 psid

3. HIGH PRESSURE EXTERNAL LEAKAGE

Indicated Leakage

0 cc/sec.

Delta P

Full Charge

4. INTERNAL LEAKAGE (ACROSS REGULATOR)

Indicated Leakage

12.5 cc/min.

5. LARGE FLOW PERFORMANCE FOR THIRTY-MINUTE FLOW AT 8.3 LB/HR FLOW RATE

Bottle Pressure - Start

6500 psig

Stop

1400 psig

Regulator Delta P During Run

Maximum

3.68 psid

Minimum

3.53 psid

6. MAKE-UP FLOW PERFORMANCE

Bottle Pressure

6750 psig

Flow Rate

0.08 lb/hr

Regulated Delta P Range

3.73 PSID

Maximum

psid

Minimum

psid

Volume IV EMU Data Book  
LMP - Mission H-1  
APOLLO 12

Amendment 24  
11/12/69

FLIGHT PGA CHECKOUT DATA

A. BEAN, LMP  
CREWMAN

A7L-067  
PGA S/N

ITEM	SPEC. REQUIREMENT	FACTORY PDA	CAT PIA	FLIGHT PIA	FLIGHT DAY	REMARKS
1) Relief Valve	S/N <u>2080</u>					
Crack	5.5 psi			<u>5.05</u>		
Reseat	4.8 psi			<u>5.01</u>		
Flowrate				<u>4.8</u>		
2) Pressure Gage	S/N <u>143</u>					
3.0 psi	+ .15 psi			<u>2.96</u>		
3.5 psi	+ .15 psi			<u>3.47</u>		
4.0 psi	+ .15 psi			<u>3.98</u>		
4.5 psi	+ .15 psi			<u>4.5</u>		
5.0 psi	+ .15 psi			<u>5.0</u>		
6.0 psi	+ .15 psi			<u>5.00</u>		
3.75 psi	+ .15 psi			<u>N/A</u>		
3) Leakage						
0.2 psi	180 sec			<u>13.5</u>		
3.75 psi	180 sec			<u>51</u>		
4) Pressure Drop						
$\Delta P$ (in H <sub>2</sub> O)				<u>3.3</u>	<u>8.3</u>	
Flowrate scfm				<u>6.0</u>	<u>12.0</u>	
Suit press. psia				<u>18.7</u>	<u>18.3</u>	
				↑ EV mode	↑ IV mode	

CSD MISSION MANAGER

DATE

FLIGHT LCG CHECKOUT DATA

A. BEAN

CREWMAN

093

LCG S/N

TEM	SPEC. REQUIREMENT	FACTORY PDA	CAT PIA	FLIGHT PIA	FLIGHT DAY CHARGE	REMARKS
Weight	gms				1651 gms.	
weight	gms				1952 gms	
ge Pressure	psig				13.8 psig	
ge Date/Time					10 Nov 69	
sure drop					1905	
Flowrate indicated	3.0 + .1 lb/min			1.5		
	3.5 + .1 lb/min			1.9		
	3.8 + .1 lb/min			2.1		
	4.0 + .1 lb/min			2.3		
	4.3 + .1 lb/min			2.6		
	4.5 + .1 lb/min			2.8		
	4.8 + .1 lb/min			3.1		
	5.0 + .1 lb/min			3.2		

VE MISION MANAGER

DATE

Amendment 24  
11/12/69

Volume IV EMU Data Book  
PGA and Accessories Characteristics - Mission H-1

Purge Valve 139

Flow Rate = 7.9 lbs/hr O<sub>2</sub> at 90°F

Leakage Rate = 0 scc/minute at 3.85  $\pm$  .15 psig

PLSS 00019500018

Volume IV IMU Data Book

Amendment 21


CAF Mission II-1

11/12/69

Line Voltage Vs Telemetry Signal Amplitude

FVC-1 serial 1972B

1972B



Percent Signal Height of Channels  $\pm 20$

27 MAR 69 RKB

PLSS  
S/N 00019

Low Pressure O <sub>2</sub> Loop Leakage	0 SCC/Min.
POS Leakage	0.21 psi/hr
Regulator Internal Leakage	1 SCC/Min
OPS Back Flow Check Valve Leakage	0.9 pph
Feedwater Loop External Leakage	0.0016 in H <sub>2</sub> O/Min.
Feedwater to O <sub>2</sub> Leakage	56 SCC /Min.
Feedwater and Transport Loop Leakage	1.34 cc/hr
Transport Loop Leakage	0.27 cc/hr
Water Shutoff and Relief	Relief 57 psig Reseat 54 psig
Feedwater Quantity	8.500 pounds
High O <sub>2</sub> Flow Sensor	Actuation 0.55 pph Deactuation 0.60 pph
Low Vent Flow Sensor	Actuation 4.42 acfm Deactuation 4.45 acfm
Low PGA Pressure Switch	Actuation 3.19 psid Deactuation 3.28 psid
Low Feedwater Pressure Switch	Actuation 1.45 psia Deactuation 1.55 psia



PLSS 019

O<sub>2</sub> Regulation Performance

<u>Bottle Pressure (psig)</u>	<u>Flow (lb/hr)</u>	<u>Regulator Pressure (psid)</u>
85	.07	3.87
85	.35	3.84
85	.07	3.86
230	.075	3.88
230	.70	3.85
230	.08	3.86
1106	.08	3.89
1100	1.98	3.78
1105	.08	3.88

Pump Performance - See curve.

Fan Performance - See curve.

FAN FLOW TEST  
PER OSD-A-394

TES REQ.

DATE

PRESS S/N 00019


BATTERY S/N


(IF APPLICABLE)

CARTRIDGE S/N

(IF APPLICABLE)

FLOW PRESSURE RISE (IN. WATER)





Volume IV EMU Data Book  
CDR - Mission H-1

OPS PRE FLIGHT PIA DATA

KEY PERFORMANCE CHARACTERISTICS

OPS S/N 011 SV 730101-2-15

1. CHECKOUT GAGE ACCURACY

<u>Actual Delta P</u>	<u>Indicated Delta P</u>
<u>3.5</u> psid	<u>3.4</u> psid
<u>3.8</u> psid	<u>3.7</u> psid

2. LOW PRESSURE EXTERNAL LEAKAGE

Indicated Leakage	<u>0.0000333</u>
Delta P	<u>4.25</u> psid

3. HIGH PRESSURE EXTERNAL LEAKAGE

Indicated Leakage	<u>0.00000015</u>
Delta P	<u>Full Charge</u> psid

4. INTERNAL LEAKAGE (ACROSS REGULATOR)

Indicated Leakage	<u>Less Than 1.0</u> cc/min.
-------------------	------------------------------

5. PURGE FLOW PERFORMANCE FOR TETRA-MINUTE FLOW AT 8.3 Lb/hr FLOW RATE

Bottle Pressure - Start	<u>5900</u> psig
Stop	<u>1100</u> psig
Regulator Delta P During Run	
Maximum	<u>3.67</u> psid
Minimum	<u>3.60</u> psid

6. MAKE-UP FLOW PERFORMANCE

Bottle Pressure	<u>6750</u> psig
Flow Rate	<u>0.08</u> lb/hr
Regulated Delta P Range	<u>3.72</u> PSIA
Maximum	<u>        </u> psid
Minimum	<u>        </u> psid

APOLLO VII

FLIGHT PGA CHECKOUT DATA

CONRAD  
CREWMAN

A7L-065  
PGA S/N

ITEM	SPEC. REQUIREMENT	FACTORY PDA	CAT PIA	FLIGHT PIA	FLIGHT DAY	REMARKS
1) Relief Valve	S/N <u>2075</u>			1st 2nd		
Crack	5.5 psi			5.12	5.05	
Reseat	4.8 psi			4.86	4.88	
Flowrate				5.75	scfm	
2) Pressure Gage	S/N <u>231</u>					
3.0 psi	+ .15 psi			3.04		
3.5 psi	+ .15 psi			3.54		
4.0 psi	+ .15 psi			4.03		
4.5 psi	+ .15 psi			4.52		
5.0 psi	+ .15 psi			5.02		
5.5 <del>6.0</del> psi	+ .15 psi			5.52		
6.0 <del>3.75</del> psi	+ .15 psi			6.03		
3) Leakage						
0.2 psi	180 sec			16.5	sec/m	
3.75 psi	180 sec			10.5	sec/mm	
4) Pressure Drop						
$\Delta P$ (in H <sub>2</sub> O)				M/ 3.0	8.2	
Flowrate scfm				M/ 6.0	12.0	
Suit press. psia				M/ 18.7 PSIA	18.2 PSIA	
				↑	↑	
				EV mode	IV mode	

CSD MISSION MANAGER

DATE

FLIGHT LCG CHECKOUT DATA

C. CONRAD

CREWMAN

091  
 LCG S/N

ITEM	SPEC. REQUIREMENT	FACTORY PDA	CAT PIA	FLIGHT PIA	FLIGHT <del>DAY</del> CHARGE	REMARKS
Dry Weight	gms				1648gms	
Wet weight	gms				1936gms	
Charge Pressure	psig				13.8 PSIG	
Charge Date/Time					11 Nov 69 0315	
Pressure drop at Flowrate indicated		psid				
	3.0 $\pm$ .1 lb/min			1.33		
	3.5 $\pm$ .1 lb/min			1.75		
	3.8 $\pm$ .1 lb/min			2.0		
	4.0 $\pm$ .1 lb/min			2.2		
	4.3 $\pm$ .1 lb/min			2.39		
	4.5 $\pm$ .1 lb/min			2.65		
	4.8 $\pm$ .1 lb/min			2.95		
	5.0 $\pm$ .1 lb/min			3.1		

TEST MANAGER

DATE

Volume IV EMU Data Book  
PGA and Accessories Characteristics - Mission H-1

Purge Valve 138

Flow Rate = 8.0 lbs/hr O<sub>2</sub> at 90°F

Leakage Rate = 0 scc/minute at 3.85  $\pm$  .15 psig

APOLLO 12 CRITICAL DATA SUMMARY SHEET

	PLSS 018	PLSS 019	PLSS	OPS 011	OPS 018	OPS
Dry Weight* (lbs.)	54.733	55.750		29.875	30.188	
Charged Weight** (lbs.)	79.749	79.371		40.125	40.625	
O <sub>2</sub> Pressure (psia)(70°F)	1030	1020		5815	5815	
Battery Activation Date	11-10-69	11-10-69		11-6-69	11-7-69	
Lanyard Slide (in.)	-	-		0.615	0.034	
Switch Overtravel (in.)	-	-		0.017	0.012	
F/W Quantity (lbs.)	8.500	8.563		--	--	
T/W Quantity (lbs.)	1.375	1.375		--	--	
LiOH Weight (lbs.)	4.677	4.522		--	--	
RCU Weight (lbs.)	5.067	5.063		--	--	
Battery Shelf Life	12 Days	12 Days		23 Days	23 Days	
RCU Serial Number	00021	00016		--	--	
Battery Serial Number	S-181	S-183		S-61	S-60	
LiOH Cartridge Serial Number	00104	00110		--	--	

\* Less RCU, Thermal Cover, Harness, Battery and Cartridge

\*\* Completely Flight Configured, less RCU




Predicted Lunar Surface EVA Walking Metabolic Rates


Various activities such as Environmental Familiarization, ALSEP Return Traverse, Geological Traverse, Complete Geological Traverse are considered to be primarily walking modes of activity. The average metabolic rate for these activities based on predicted and real-time estimates is 1050 BTU/hour. It should be understood that this prediction is subject to future revision as further data becomes available. At present, data have not been obtained on Geological Traverses and ALSEP Traverses. Also, changes from expected walking speeds or terrains would affect the prediction.

Volume IV EMU Data Book  
Consumable - Mission H-1

NOMINAL LUNAR SURFACE EVA #1  
FIGURE 4-15. - CDR AND LMP - PLSS OXYGEN




NOMINAL LUNAR SURFACE EVA #1 AND #2  
Figure 4-14. - CDR AND LMP - PLSS WATER




NOTE: IF THE CREWMAN LEAVES THE S/C WITH HEAT STORAGE AND RETURNS SUBCOOLED, HE WILL USE MORE H<sub>2</sub>O THAN HIS METABOLIC O<sub>2</sub> CONSUMPTION INDICATES

NOMINAL LUNAR SURFACE EVA #1 AND #2  
FIGURE 4-17. - CDR AND LMP - PLSS LiOH




NOMINAL LUNAR SURFACE EVA #2

Figure 4-16. - CDR AND LMP - PLSS OXYGEN



NOMINAL LUNAR SURFACE EVA #1 AND #2

FIGURE 4-18. - CDR AND LMP - PLSS BATTERY



Amendment 30  
4/13/70

## H-2 MISSION APPENDIX

APOLLO 13

H2-0

SNA-8-D-027(IV) REV. 1

# CONTENTS

Loading Chart	Page H2-2
Consumables	Page H2-4
Performance	Page H2-10
PLSS	Page H2-10
OPS	Page H2-26
PGA	Page H2-38
LCG	Page H2-39
Purge Valve	Page H2-39
Thermal	Page H2-40

## CREW EQUIPMENT SERIAL NUMBERS

EQUIPMENT	CREWMAN		
	CDR	IMP	CMP
PLSS*	021	020	---
OPS*	015	030	---
PGA	078	061	088
LCG	095	086	---
LEVA*	010	015	---
Purge Valve*	146	147	---

\*INTERCHANGEABLE BETWEEN CREWMEN



LOADING CHART

SPEC	CDR		LMP		CMP	
	S/N	WGT LBS	S/N	WGT LBS	S/N	WGT LBS
EV/PGA with ITMG (including IV Gloves, Helmet, and Comm Carriers, EV Gloves, Lunar Boots)	55.29	078	53.79	061	53.49	
IV/PGA with IVCL (including IV Gloves, Helmet, and Comm Carriers)	37.15				082	37.64
LCG - Dry		095	3.833	086	4.131	
Wet	5.00	095	4.509	086	4.806	
H2O Wt.		095	0.677	086	0.679	
CWG	0.90	1144	.77	1230	.77	1293 .77
FCS	0.50	113	.38	115	.37	109 .32
UCTA	0.53	3963	.47	3965	.47	3964 .47
Bio-Belt	0.25	1399	.18	1408	.18	1403 .18
Bioinstrumentation Assembly	1.10	019	174.2gm	021	174.0gm	020 174.0gm
EV Gloves (pair)	2.5	075	2 lbs 7 oz	080	2 lbs 6 oz	
LEVA	5.90	010	5.75	015	5.75	
Helmet Protective Shield	0.95				085	.854
Lunar Boots	4.9		4 lbs 11 oz	035	4 lbs 9 oz	
Purge Valve	0.55	146	.494	147	.494	
PLSS, Dry* with O2 Charge		021	57.23	020	56.26	
PLSS, Fully Charged**	83.76	021	80.00	020	80.875	
	lbs <sub>max</sub>					
Feedwater Quantity	8.30	021	8.59	020	8.53	
	lbs <sub>min</sub>					
RCU	4.50	00019	5.11	00024	5.13	
	lbs <sub>max</sub>					

LOADING CHART  
(Continued)

SPEC WGT	CDR		LMP		CMP	
	S/N	WGT LBS	S/N	WGT LBS	S/N	WGT LBS

Batteries, PLSS

EVA I	5.55	S-198	5.3	S-190	5.52
	lbs <sub>max</sub>				
EVA II	5.55	S-206	5.48	S-209	5.47
	lbs <sub>max</sub>				

LiOH Cartridge

EVA I	4.63	149	4.58	147	4.56
	lbs <sub>max</sub>				
EVA II	4.63	150	4.56	151	4.60
	lbs <sub>max</sub>				

OPS, Uncharged

015	30 lbs	030	29 lbs
	4 oz		12 oz

OPS, Fully Charged

41	015	40 lbs	030	40 lbs
lbs <sub>max</sub>		11.2 oz		4.2 oz

Batteries, OPS

2428gm	S-089	2139gm	S-086	2162gm
--------	-------	--------	-------	--------

Delta Weight = O<sub>2</sub>

015	5.73 lbs	030	5.75 lbs
-----	----------	-----	----------

\* Less RCU, Thermal Cover, Harness, Battery, and Cartridge

\*\* Completely Flight Configured, less RCU

CONSUMABLES

		SPEC	CDR
			IMP
Batteries, PLSS			
EVA I			
S/N		S-198	S-190
Activation Date		4-7-70	4-7-70
Shelf Life		12 days	12 days
EVA II			
S/N		S-206	S-209
Activation Date		4-7-70	4-7-70
Shelf Life		12 days	12 days
LiOH Cartridge			
EVA I			
S/N		00149	00147
EVA II			
S/N		00150	00151
Feedwater Weight (lbs.)		8.59 lbs	8.53 lbs
Oxygen Pressure, PLSS (psia)	1020 $\pm$ 10 psia	1030 psia	1030 psia
Batteries, OPS			
S/N		S-089	S-086
Activation Date		4-3-70	4-3-70
Shelf Life		24 days	24 days
Oxygen Pressure, OPS (psia)	5880 $\pm$ 80 psi	5960 psi	5930 psi
OPS Gage	$\pm$ 300	6100 psi	5990 psi

Apollo 13 PLSS Expendables

Main Power Supply

The main power supply has a two sigma power rating of 279 watt-hrs. With a PLSS power consumption of 43.5 watts, based upon Apollo 13 crew training exercises in SESL, the power supply will last 5.75 hours with the following checkout data:

Checkout EVCS: 40 minutes @ 0.7 amps  
Fan : 30 minutes @ 2.0 amps  
Pump: 15 minutes @ 0.6 amps

NOTE: Above information based on voltage of 16.8 volts.

Feedwater

With an 8.5 lb charge and unusable water as follows, there is 7.54 lbs of usable feedwater.

Residual: 0.23 lbs  
Slave : 0.60 lbs  
Leakage : 0.13 lbs

See page H2-6 for curve of mission time versus metabolic rate.

Oxygen - EVA I

With a charge pressure of 1020 psia, there is 0.953 lbs (mass) usable. This is based on the following overhead requirements.

Instrument error: 50 psi  
Leakage check: 36 psi  
Metabolic (Fan on  
to Cabin Depress): 34 psi  
Cabin Repress: 21 psi


See page H2-7 for curve of mission time versus metabolic rate.

Oxygen - EVA II


With a charge pressure of 927 psia, there is 0.838 lbs (mass) usable. This is based on the same overhead requirements as for EVA I. The charge pressure is based on a 942 psia IM regulator performance and a 15 psi loss due to PLSS bottle cool down.

See page H2-8 for curve of mission time versus metabolic rate.

BEE 20x20 TO INCH



BEE 20x20 TO INCH




APOLLO 13 EXPENDABLES

OXYGEN

EVA 2

BEE 20120 TO 1474



Amendment 30  
4/13/70

INTENTIONALLY LEFT BLANK



Volume IV EMU Data Book  
PLSS Performance - Mission H-2

Amendment 30  
4/13/70

PERFORMANCE

PLSS

			SPEC	CDR	LMP
-S/N				021	020
-Leakage					
Low Pressure O <sub>2</sub> Loop	(SCC/Min.)	20 SCC/Min Max.		0.0 SCC/Min	0.0
POS Pressure	(PSI/Hr)	.5 PSI/Hr		.42 PSI/Hr	.22 PSI/Hr
Regulator Internal	(SCC/Min.)	25 SCC/Min		0.0	0.0
OPS Backflow Check Valve	(Lbs/Hr)	.5 Lbs/Hr		Below .06 Lbs/Hr	Below .06 Lbs/Hr
External Feedwater	(In H <sub>2</sub> O Min)	.034 In. H <sub>2</sub> O/ Min Max.		0.0	.00066 In. H <sub>2</sub> O/ Min.
Feedwater to O <sub>2</sub> Loop	(SCC/Min)	175 SCC/Min Max		82.5 SCC/Min	37 SCC/Min
Feedwater and Transport Loop	(CC/Hr)	1.65 CC/Hr Max		1.56 CC/Hr	1.45 CC/Hr
Liquid Transport Loop	(CC/Hr)	.27 CC/Hr Max		.16 CC/Hr	.05 CC/Hr
-Pressure Rise, Low Pressure O <sub>2</sub> Loop		N/A			
Fan performance at least five points of pressure rise vs flow at 3.85 ± 0.15 PSIA.					
1)	(ACFM/In. H <sub>2</sub> O)			5.50/3.28	5.5/2.9
2)				4.22/3.93	4.22/3.61
3)		SNA-8-D-027(IV) REV. 1		4.75/3.63	4.74/3.26
4)		H2-10		5.28/3.33	5.28/3.0
5)				6.04/2.86	6.02/2.5
6)				6.49/2.54	6.48/2.18
7)				0/4.90	0/4.87

Volume IV EMU Data Book  
PLSS Performance - Mission H-2

Amendment 30  
4/13/70

PLSS, (cont'd)	PERFORMANCE			
	SPEC.	CDR.	LMP.	
-Sensors		PLSS 021	PLSS 020	
High O <sub>2</sub> Flow				
Actuation	(Lbs/Hr)	.50-.65 Lbs/Hr.	.51 Lbs/Hr.	.525 Lbs/Hr.
Deactuation	(Lbs/Hr)	.50-.65 Lbs/Hr.	.50 Lbs/Hr.	.51 Lbs/Hr.
Low Vent Flow				
Actuation	(ACFM)	4.45-5.3 ACFM	4.45 ACFM 4.51 ACFM	4.45 ACFM 4.53 ACFM
Deactuation	(ACFM)			
Low PGA Pressure				
Actuation	(PSID)	3.10-3.40 PSID	3.20 PSID	3.22 PSID
Deactuation	(PSID)	3.40-3.10 PSID	3.25 PSID	3.28 PSID
Low Feedwater Pressure				
Actuation	(PSIA)	1.30 PSIA	1.35 PSIA	1.43 PSIA
Deactuation	(PSIA)	1.60 PSIA	1.39 PSIA	1.52 PSIA

PERFORMANCE

PLSS, (cont'd)

SPEC.

CDR.  
PLSS

LMP.  
PLSS

-Oxygen Regulator Characteristics

021

020

Give three regulation points at  
Low, High, and Low flows for  
three bottle pressures:

Bottle Pressure 100 PSIA

1) (Lbs/Hr/PSID)	.070-.080 Lbs /Hr	3.90 $\pm$ 0.15	3.87 PSID	3.84 PSID
2)	.35-.36 Lbs/Hr	3.90 $\pm$ 0.15	3.82 PSID	3.82 PSID
3)	.070-.080 Lbs/Hr	3.90 $\pm$ 0.15	3.88 PSID	3.84 PSID

Bottle Pressure 250 PSIA

1) (Lbs/Hr/PSID)	.070-.080 Lbs/Hr	3.90 $\pm$ 0.15	3.90 PSID	3.86 PSID
2)	.65-.75 Lbs /Hr	3.90 $\pm$ 0.15	3.84 PSID	3.84 PSID
3)	.070-.080 Lbs./Hr	3.90 $\pm$ 0.15	3.89 PSID	3.85 PSID

Bottle Pressure 1120 PSIA

1)	.070-.080 Lbs /Hr	3.90 $\pm$ 0.15	3.89 PSID	3.88 PSID
2)	1.90-2.0 Lbs /Hr	3.80 $\pm$ 0.25	3.74 PSID	3.74 PSID
3)	.070-.080 Lbs./Hr	3.90 $\pm$ 0.15	3.88 PSID	3.87 PSID

-Feedwater Vent Orifice

Flow at 49 PSID (CC/Min)	400-1400CC/ 2 Mins.	1250 CC/ 2 Mins.	1200 CC/ 2 Mins.
--------------------------	------------------------	---------------------	---------------------

Flow at 49 PSID (Lbs/Min)

-Stowage Plate Relief Valve

Cracking Pressure	4.5-6.0 PSID	6.0 PSID	5.2 PSID
-------------------	-----------------	----------	----------

PERFORMANCE  
SPEC.

CDR.

LMP.

PLSS, (cont'd)

PLSS

PLSS

-Pressure Rise, Liquid Transport Loop  
(Pump Performance) at least three  
points, for each Diverter Valve  
position, of Flow vs Pressure Rise:

021

020

Minimum Diverter Valve Position

1) (Lbs/Min./PSI)	3.7 Lbs/Min Min	1.9+0.1 -0.0	4.55 Lbs/Min 1.9 ΔP	4.5 Lbs/Min 1.9 ΔP
2)	↑	7.5+0.1	1.25 Lbs/Min 7.5 ΔP	2.6 Lbs/Min 7.5 ΔP
3)	N/A	5.5+0.1	3.0 Lbs/Min 5.5 ΔP	3.4 Lbs/Min 5.5 ΔP
4)	↓	3.5+0.1	4.1 Lbs/Min 3.5 ΔP	4.0 Lbs/Min 3.5 ΔP
5)		1.0+0.1	4.85 Lbs/Min 1.0 ΔP	4.7 Lbs/Min 1.0 ΔP

Intermediate Diverter Valve  
Position

1) (Lbs/Min./PSI)	3.7 Lbs/Min Min.	1.9+0.1 -0.0	4.75 Lbs/Min 1.9 ΔP	4.5 Lbs/Min 1.9 ΔP
2)	↑	7.5+0.1	1.3 Lbs/Min 7.5 ΔP	2.8 Lbs/Min 7.5 ΔP
3)	N/A	5.5+0.1	3.15 Lbs/Min 5.5 ΔP	3.6 Lbs/Min 5.5 ΔP
4)	↓	3.5+0.1	4.25 Lbs/Min 3.5 ΔP	4.0 Lbs/Min 3.5 ΔP
5)		1.0+0.1	4.85 Lbs/Min 1.0 ΔP	4.7 Lbs/Min 1.0 ΔP

Maximum Diverter Valve  
Position

1) (Lbs/Min./PSI)	3.7 Lbs/Min Min	1.9+0.1	4.8 Lbs/Min 1.9 ΔP	4.0 Lbs/Min 1.9 ΔP
2)	↑	7.5+0.1	2.2 Lbs/Min 7.52 ΔP	2.4 Lbs/Min 7.5 ΔP
3)	N/A	5.5+0.1	3.0 Lbs/Min 5.5 ΔP	3.0 Lbs/Min 5.5 ΔP
4)	↓	3.5+0.1	3.9 Lbs/Min 3.5 ΔP	3.85 Lbs/Min 3.5 ΔP

SNA-8-D-027(IV) REV. 1

H2-13

(cont.)

PERFORMANCE


	SPEC.	CDR.	LMP.
PLSS, (cont'd)		PLSS	PLSS
5)	1.0 $\pm$ 0.1	4.75 Lbs/Min 1.0 $\Delta$ P	4.4 Lbs/Min 1.0 $\Delta$ P
-Water Shutoff and Relief Valve			
Relief Pressure (PSID)	52.0-65.0 PSIG	63.0 PSIG	64.0 PSIG
Reseat Pressure (PSID).	40.0 Min.	52.0 PSIG	58.5 PSIG

APOLLO 13


TRANSDUCER END TO END CALIBRATION

PARAMETER	SPEC	CDR		LMP	
		Actual Input	TM Output	Actual Input	TM Output
PGA Pressure	2.95-3.13 PSID	3.0 PSID	3.025 PSID	3.0 PSID	3.06 PSID
	3.9-4.1 PSID	4.0 PSID	4.0 PSID	4.0 PSID	4.05 PSID
Feedwater Pressure	1-1.25 PSIA	1.0 PSIA	1.10 PSIA	1.0 PSIA	.90 PSIA
	3.56-3.83 PSIA	3.66 PSIA	3.70 PSIA	3.66 PSIA	3.63 PSIA
LCG Inlet Temp	70°F-75.25°F	72.3 °F	72.5 °F	73 °F	73.0 °F
	71°F-86.2°F	73.2 °F	73.5 °F	74.5 °F	75.0 °F
Sub. Gas Out. Temp.	70°F-75.25°F	72.3 °F	72.5 °F	73 °F	73.0 °F
	71°F-86.2°F	73.2 °F	73.5 °F	74.5 °F	75.0 °F
Battery Current	.55-.65 AMPS	.6 amps	.6 amps	.6 amps	.6 amps
Battery Voltage	15.8-17.8 volts	16.65 volts	16.7 volts	16.75 volts	16.75 volts
POS Pressure	915-980 PSIA	961 PSIA	955 PSIA	961 PSIA	944 PSIA
	597 1/2 - 661 PSIA	611 PSIA	633 PSIA	611 PSIA	611 PSIA
	137 1/2 - 200 PSIA	161 PSIA	178 PSIA	161 PSIA	155 PSIA


BEE 20x20 TO INCH




BEE 20x20 TO INCH









K-E  
 10 X 10 TO THE CM.  
 359-14G  
 KEUFFEL & ESSER CO.  
 MADE IN U.S.A.











K&E 10 X 10 TO 1/2 INCH 46 1473  
7 1/4 X 10 INCHES  
MADE IN U.S.A.  
KEUFFEL & ESSER CO.



K+E 10 X 10 TO THE CENTIMETER 46 1512  
 18 X 25 CM.  
 KEUFFEL & ESSER CO.






PIA DATA

CDR

100 PSIA  
250 PSIA  
1020 PSIA

PLSS S/N 00021




Primary O<sub>2</sub> Regulator Performance

APOLLO 13  
 PIA DATA

LMP

○ 100 PSIA  
 △ 250 PSIA  
 □ 1020 PSIA

PLSS S/N 00020



Primary O<sub>2</sub> Regulator Performance



Volume IV EMU Data Book  
OPS Performance - Mission H-2

Amendment 30

	PERFORMANCE SPEC.	CDR.	LMP.
OPS			
-S/N		015	030
-Leakage			
Low Pressure External			
At 4.25 PSID (SCC/Min)	.05 CC/Sec.	.0000192 CC/Sec.	.00478 CC/Sec.
High Pressure External			
At 6935 $\pm$ 200 PSIG (SCC/Hr)	.0056 CC/Sec.	.0009696 CC/Sec.	.000378 CC/Sec.
Internal Leakage			
Across Regulator (SCC/Min)	200 SCC/Min	0.0 SCC/Min	60 SCC/Min
-Purge Flow Characteristics			
Flow Rate (Lbs/Hr)	8.3 $\pm$ 1 Lb/Hr.	8.3 Lb/Hr	8.3 Lb/Hr
Bottle Pressure-Start (PSIA)	485 Min in 30 Mins	6700 PSIG	6200 PSIG
-Stop (PSIA)		1500 PSIG	1400 PSIG
Regulated Pressure - Maximum (PSID)	3.70 $\pm$ 0.3	3.68 PSID	3.65 PSID
-Minimum (PSID)		3.52 PSID	3.50 PSID
-Make-up Flow Characteristics			
Flow Rate (Lbs/Hr)	.08-.14 Lb/Hr	.08-.14	.08-.14
Bottle Pressure (PSIA)	--	6750 PSIG	6750 PSIG
Regulated Pressure -Maximum (PSID)	3.70 $\pm$ 0.3	3.825-	3.91-
-Minimum (PSID)		3.65	3.79
OPS Checkout Orifice			
Flow at 818 PSIA (Lbs/Hr)	0.3 Lb/Hr Max	.215	.220

SPEC.

CDR.

LMP.

OPS, (Cont'd)

-OPS Checkout Gage - Actual

Pressure when gage reads:

	SPEC.	CDR.	LMP.
1) 3.5 PSID	<u>+0.10</u>	3.43	3.49
2) 3.8 PSID	<u>+0.10</u>	3.82	3.79

OPS Quantity Gage

+300

Actual Press 6750

Actual Press 6750

OPS read 7000

OPS read 6800

OPS Purge Mode Duration


The data presented below, and in the curves which are referenced, are not meant for planning purposes but represent as precisely as possible the actual hardware characteristics of the Apollo 13 prime equipment. The data does not reflect any mission constraints or operating red lines.

Curve No. 1 - Purge Valve Flow vs. "Suit Pressure"  
Curve No. 2 - OPS Outlet Pressure vs. Bottle Pressure  
Curve No. 3 - OPS Bottle Pressure vs. Time


TO DETERMINE DURATION	PGA S/N 078 OPS S/N 00015	PGA S/N 061 OPS S/N 00030
A. Avg. OPS Outlet Press. (Curve #2)	3.67 psia	3.63 psia
B. Press. Drop Across Suit (OPS to Purge Valve)	.033 psi	.031 psi
C. Avg. "Suit Pressure" (A-B)	3.64 psia	3.60 psia
D. Actual Purge Flow (Curve #1)	7.50 lbs/hr	7.42 lbs/hr
E. Duration in Purge Mode (Inverse Ratio from Curve #3)	45.78 minutes	46.31 minutes

BASE 20x20 TO INCH

CURVE NO. 1




CURVE NO. 2



SEE 20120 TO INCH

CURVE NO. 3







APOLLO 13

CDR DATA 0

OPS S/N 00015



OPS O<sub>2</sub> Supply Temperature and Outlet Pressure Versus Flow (35 - 60° Temperature Range)



APOLLO 13

CDR

⊙

PIA DATA

OPS S/N 00015



OPS O<sub>2</sub> Supply Temperature and Outlet Pressure Versus Flow (60° Average Supply Temperature)





APOLLO 13 PIA DATA

LMP

OPS S/N 000 30

Volume IV EMU Data Book  
OPS Performance - Mission H-2



Amendment 30  
4/13/70



OPS O<sub>2</sub> Supply Temperature and Outlet Pressure Versus Flow (35 - 60° Temperature Range)


APOLLO 13  
PIA DATA  
LMP

OPS S/N 000 30




OPS O<sub>2</sub> Supply Temperature and Outlet Pressure Versus Flow (60° Average Supply Temperature)

AFULLU 13  
CDR  
OPS S/N 00015  
PURGE VALVE S/N 146



OPS FLOW RATE VERSUS PRESSURE AS DICTATED BY  
PURGE VALVE



OPS FLOW RATE VERSUS PRESSURE AS DICTATED BY  
PURGE VALVE

PERFORMANCE

SPEC	CDR	IMP	CMP
------	-----	-----	-----

PGA

S/N		078	061	088
Leakage (SCC/MIN)				
@3.75 psid	180scc/min	80	60	130
Pressure Drop (in. H <sub>2</sub> O)		73°F	74.3°F	
EV @ 6.0 scfm <u>18.6 + .1</u> psia	5.13 max in H <sub>2</sub> O (spec equivalent)	L.H. 3.0	L.H. 2.45	
AIR				
IV @ 12.0 scfm <u>18.2 + .1</u> psia	15.1 max in H <sub>2</sub> O (spec equivalent)	L.H. 6.3 R.H. 6.4	L.H. 6.15 R.H. 6.6	
O <sub>2</sub> - IV @ 12.0 scfm <u>18.2 + .1</u> psia	16.2 max in H <sub>2</sub> O (spec equivalent)	7.8	8.7	8.4
Relief Valve				
Flow Rate (scfm @ 5.5 psig suit pressure)		4.2	5.5	
Cracking Pressure (psid)	5.5 psi max	4.93	5.10	
Reseat Pressure (psid)	4.8 psi min	4.85	4.95	
PGA Cuff Gage Accuracy				
Actual Pressure when cuff gage reads: <u>± 0.15</u> psi				
1) 3.0 psid		3.04	3.0	3.04
2) 3.5 psid		3.52	3.52	3.53
3) 4.0 psid		4.02	4.02	4.05
4) 4.5 psid		4.55	4.5	4.52
5) 5.0 psid		5.02	5.0	5.0
5.5 psid		5.53	5.52	5.52
6) 6.0 psid		6.0	6.0	6.03

PERFORMANCE

SPEC	CDR	LMP	CMP
------	-----	-----	-----

LCG

S/N

095

086

Pressure Drop @ 19.0 psig inlet

At least six points of flow vs.  
pressure drop

1) (Lbs/Min) 3.0

1.3

1.3

2) 3.5

1.8

1.6

3) 3.8

2.0

1.8

4) 4.0

2.1

2.0

5) 4.3

2.4

2.3

6) 4.5

2.6

2.4

7) 4.8

2.9

2.8

8) 5.0

3.1

2.9

SPEC	CDR	LMP	CMP
------	-----	-----	-----

Purge Valve

S/N

146

147

Flow Rate @  $4.0 \pm 0.05$  psia (lb/  
Hr.)

$8.1 \pm 0.3$   
lbs<sub>m</sub>/Hr at  
90°F O<sub>2</sub> and  
 $4.0 \pm .05$   
psia

8.0 lbs<sub>m</sub>/Hr 8.0 lbs<sub>m</sub>/Hr

Leakage @  $3.85 \pm 0.15$   
(Valve Closed) (SCC/MIN)

4 scc/min

4

4

Apollo 13 Heat Leaks

The nominal heat leak for Apollo 13 EVA#1 is minus 75 Btu/hr.

The nominal heat leak for Apollo 13 EVA#2 is minus 10 Btu/hr.

The worst case heat leak for both EVA's is plus 280 Btu/hr.  
(Considering operation in some of the more severe craters in  
the landing site.)

APOLLO 13

STEADY STATE ENVIRONMENTAL HEAT LEAK\* (BTU/HR)

LCG INLET TEMPERATURE	EVA 1 ENVIRONMENT				EVA 2 ENVIRONMENT			
	MESA	LUNAR PLANE	LUNAR PLANE	LUNAR PLANE	LUNAR PLANE	LUNAR PLANE	4:1 CRATER	4:1 CRATER
	120° SUN 1	150° SUN 1	150° SUN 2	25° SUN 1	25° SUN 2	25° SUN 1	25° SUN 1	25° SUN 2
78-80°F	-38	-30	-13	-8	15	130	155	
57-60°F	-30	-25	-5	0	20	135	160	

\* Crewman metabolic rate assumed = 1000 Btu/hr.

1 - Clean ITMG

2 - "Dirty" ITMG - thermal properties degraded to Apollo 12 conditions