

Production and verification of stoichiometric uranium dioxide



Gregory Leinders

KU Leuven, Department of Chemistry
SCK•CEN, Institute for Nuclear Materials Sciences

University promoter: Prof. Dr. Koen Binnemans
SCK•CEN mentors: Prof. Dr. T. Cardinaels & Dr. M. Verwerft

Overview

- Scope of the study
- Background
- Production of stoichiometric UO_2
- Verification of stoichiometry
- Conclusions

Overview

- **Scope of the study**

 - Accurate lattice parameter measurement of stoichiometric UO_2**

- Background

- Production of stoichiometric UO_2

- Verification of stoichiometry

- Conclusions



Context: UO_2 lattice parameter

Objectives:

- Produce a stoichiometric UO_2 sample suitable for analysis
- Accurately measure the lattice parameter
- Accurately measure sample stoichiometry

Context: UO_2 lattice parameter

Objectives:

Produce a stoichiometric UO_2 sample suitable for analysis

Accurately measure the lattice parameter: completed

Accurately measure sample stoichiometry

Context: UO_2 lattice parameter

Objectives:

Produce a stoichiometric UO_2 sample suitable for analysis

Accurately measure the lattice parameter: completed

Accurately measure sample stoichiometry

Which parameters control deviation from stoichiometry?

How to prepare a stoichiometric sample?

How to accurately measure (verify) sample stoichiometry?


Overview

- Scope of the study
 - Accurate lattice parameter measurement of stoichiometric UO_2
- **Background**
 - U-O system**
- Production of stoichiometric UO_2
- Verification of stoichiometry
- Conclusions

U-O chemistry

UO₂ production

Ideally: Reduction of U₃O₈ to UO₂




U-O chemistry

UO₂ production

Ideally: Reduction of U₃O₈ to UO₂



Reality: oxidation, even at room temperature



UO_{2+x} powder


U-O chemistry

UO₂ production


Ideally: Reduction of U₃O₈ to UO₂



Reality: oxidation, even at room temperature



UO_{2+x} powder




Question (1/3)

Which parameters control deviation from stoichiometry?


Two stage reaction (1/2)

Low temperature oxidation reaction ($T < 200\text{ }^{\circ}\text{C}$)




Two stage reaction (1/2)

Low temperature oxidation reaction ($T < 200\text{ }^{\circ}\text{C}$)



→ Chemi- and physisorption of O_2 on surface of UO_2 grains




O_2 molecules

UO_2 grain


Two stage reaction (2/2)

Low temperature oxidation reaction ($T < 200\text{ }^{\circ}\text{C}$)



- Chemi- and physisorption of O_2 on surface of UO_2 grains
- Diffusion of oxygen into the bulk

Availability of oxygen
Reactivity of powder



Overview

- Scope of the study
 - Accurate lattice parameter measurement of stoichiometric UO_2
- Background
 - U-O system
- **Production of stoichiometric UO_2**
 - Sample preparation**
- Verification of stoichiometry
- Conclusions

Controlling stoichiometry deviation (1/3)

Approach: Inert atmosphere

→ Decrease availability of oxygen

Controlling stoichiometry deviation (1/3)

Approach: Inert atmosphere

→ Decrease availability of oxygen

Requires large facility with multiple glove boxes



Glove box facilities at SCK•CEN laboratories

Controlling stoichiometry deviation (1/3)

Approach: Inert atmosphere

→ Decrease availability of oxygen

Requires large facility with multiple glove boxes

Sample preparation ✓

Sample analysis ✗

Stoichiometry ✓



Glove box facilities at SCK•CEN laboratories

Controlling stoichiometry deviation (2/3)

Approach: Inert atmosphere

→ **Route abandoned**

Approach: Coarse grained powder


→ Decrease reactivity of powder

Controlling stoichiometry deviation (2/3)

Approach: Coarse grained powder

→ Decrease reactivity of powder

Ideally: Reduction of U_3O_8 to UO_2




Controlling stoichiometry deviation (2/3)

Approach: Coarse grained powder

→ Decrease reactivity of powder

Ideally: Reduction of U_3O_8 to UO_2

Reality: oxidation to UO_{2+x} ✕



Measured mass increase in prepared coarse UO_2 powder upon exposure to lab environment

Controlling stoichiometry deviation (3/3)

Approach: Inert atmosphere

→ **Route abandoned**

Approach: Coarse grained powder

→ **Route abandoned**

Approach: Sintered UO_2 pellet, theoretical density > 95 %

→ Further decrease reactivity of powder

Controlling stoichiometry deviation (3/3)

Approach: Sintered UO_2 pellet, theoretical density $> 95 \%$

→ Further decrease reactivity of powder

Properties:

- No open porosity, S.A. $\ll 1 \text{ m}^2 \text{ g}^{-1}$
- Large, polycrystalline compact body
- Stoichiometry close to $\text{UO}_{2.000}$



Sintered UO_2 pellet

Controlling stoichiometry deviation (3/3)

Approach: Sintered UO_2 pellet, theoretical density > 95 %
→ Further decrease reactivity of powder

Properties:

- No open porosity, S.A. $\ll 1 \text{ m}^2 \text{ g}^{-1}$
- Large, polycrystalline compact body
- Stoichiometry close to $\text{UO}_{2.000}$

No oxygen take-up witnessed after several weeks
Comparable state with real application: fuel pellet
Requires polishing (XRD sample)



Polished, imbedded UO_2 pellet

Question (2/3)

How to prepare a stoichiometric sample?

Controlling stoichiometry deviation (3/3)

Approach: Inert atmosphere

→ **Route abandoned**

Approach: Coarse grained powder

→ **Route abandoned**

Approach: Sintered UO_2 pellet

→ **Chosen route**

Sintering

Sintering: UO_{2+x} green pellets to $\text{UO}_{2.000}$

$$T_{\text{sinter}} = \pm 1750\text{ }^{\circ}\text{C}$$

- T.D. > 95 %

$$t_{\text{dwell}} = 8\text{ h}$$

Atmosphere: reducing

- $\mu_{\text{O}_2} \leq -420\text{ kJ mol}^{-1}$ (at T_{sinter})



Sinter furnace

Sintering

Sintering: UO_{2+x} green pellets to $\text{UO}_{2.000}$

$$T_{\text{sinter}} = \pm 1750\text{ }^{\circ}\text{C}$$

- T.D. > 95 %

$$t_{\text{dwell}} = 8\text{ h}$$

Atmosphere: reducing

- $\mu_{\text{O}_2} \leq -420\text{ kJ mol}^{-1}$ (at T_{sinter})

Accurate control of sintering atmosphere required

→ Mixing high purity gasses: $\text{H}_2 + \text{O}_2$ (in Ar)




Sinter furnace

Sintering atmosphere

Atmosphere: reducing

- $\mu_{\text{O}_2} \leq -420 \text{ kJ mol}^{-1}$ (at T_{sinter})




Ellingham diagram for $\text{UO}_{2\pm x}$

Overview


- Scope of the study
 - Accurate lattice parameter measurement of stoichiometric UO_2
- Background
 - U-O system
- Production of stoichiometric UO_2
 - Sample preparation
- **Verification of stoichiometry**
 - Ignition method with corrections**
- Conclusions

O/U measurement

Most commonly used method: mass difference after oxidation



Mass: y z



Thermogravimetric analysis to determine O/U ratio in sintered UO_2 pellets

O/U measurement

Most commonly used method: mass difference after oxidation



Mass: y z

Not as evident as it may seem

→ Requires high accuracy on mass signal: $y, z \gg x$

Question (3/3)

How to accurately measure (verify) sample stoichiometry?

Ignition method

Main sources of error:

Precision of the (micro-)balance

Ignition method

Main sources of error:

Precision of the (micro-)balance

→ The use of *in-situ* thermogravimetric analysis (TGA) can greatly improve the accuracy of the measurement

Ignition method

Main sources of error:

Precision of the (micro-)balance

Mass difference due to evaporation of volatile impurities

Ignition method

Main sources of error:

Precision of the (micro-)balance

Mass difference due to evaporation of volatile impurities

→ TGA + evolved gas analysis: no measurable volatiles from sintered pellet



→ H₂O release from UO_{2+x} powder

Ignition method

Main sources of error:

Precision of the (micro-)balance

Mass difference due to evaporation of volatile impurities

Mass difference due to reaction of impurities

Ignition method

Main sources of error:

Precision of the (micro-)balance

Mass difference due to evaporation of volatile impurities

Mass difference due to reaction of impurities

→ ICPMS analysis to evaluate impurity content

Stoichiometry measurements

Results:

- Initial mass: analytical balance (lab environment)
- Final mass: *ex-situ* (analytical balance)
No correction for impurities

O/U (in-situ)		O/U (ex-situ)	
Correction	No correction	Corrected	No correction
			1.9934

Stoichiometry measurements

Results:

- Initial mass: analytical balance (lab environment)
- Final mass: *ex-situ* (analytical balance)
Corrected for impurities

O/U (in-situ)		O/U (ex-situ)	
Correction	No correction	Corrected	No correction
		1.9955	1.9934

Stoichiometry measurements

Results:

- Initial mass: analytical balance (lab environment)
- Final mass: *in-situ* (TGA)
No correction for impurities

O/U (in-situ)		O/U (ex-situ)	
Correction	No correction	Corrected	No correction
	1.9975	1.9955	1.9934

Stoichiometry measurements

Results:

- Initial mass: analytical balance (lab environment)
- Final mass: *in-situ* (TGA)
Corrected for impurities

O/U (in-situ)		O/U (ex-situ)	
Correction	No correction	Corrected	No correction
1.9997 ± 0.0006	1.9975	1.9955	1.9934

Underestimation: adsorption

Overview

- Scope of the study

 - Accurate lattice parameter measurement of stoichiometric UO_2

- Background

 - U-O system

- Production of stoichiometric UO_2

 - Sample preparation

- Verification of stoichiometry

 - Ignition method with corrections

- **Conclusions**

Conclusions

Objectives:

Produce a stoichiometric UO_2 sample suitable for analysis

Conclusions

Objectives:

Produce a stoichiometric UO_2 sample suitable for analysis

3 routes considered:

- **Inert atmosphere**
- **Coarse UO_2 powder**
- **Sintered UO_2 pellets**

Conclusions

Objectives:

Produce a stoichiometric UO_2 sample suitable for analysis

Accurately measure the lattice parameter: completed

Accurately measure sample stoichiometry

Conclusions

Objectives:

Produce a stoichiometric UO_2 sample suitable for analysis

Accurately measure the lattice parameter: completed

Accurately measure sample stoichiometry

Stoichiometry verification:

- **High accuracy via *in-situ* TGA ↔ *ex-situ* measurement**
- **No measurable volatile impurities on sintered pellets**
- **Corrected for the presence of impurities**

Conclusions: UO_2 lattice parameter



Overview of published UO_2 lattice parameters

G. Leinders, T. Cardinaels, K. Binnemans, M. Verwerft, *J. Nucl. Mater.* **2015**, 459, 135.

Thanks for your attention



Gregory Leinders

Copyright © 2015 - SCK•CEN

All property rights and copyright are reserved.

Any communication or reproduction of this document, and any communication or use of its content without explicit authorization is prohibited. Any infringement to this rule is illegal and entitles to claim damages from the infringer, without prejudice to any other right in case of granting a patent or registration in the field of intellectual property.

SCK•CEN

Studiecentrum voor Kernenergie
Centre d'Etude de l'Energie Nucléaire
Belgian Nuclear Research Centre

Stichting van Openbaar Nut
Fondation d'Utilité Publique
Foundation of Public Utility

Registered Office: Avenue Herrmann-Debrouxlaan 40 – BE-1160 BRUSSEL
Operational Office: Boeretang 200 – BE-2400 MOL