


AAS High Energy Astrophysics Division Meeting

Monterey, California April 8-11, 2013


Future development trajectories for imaging x-ray spectrometers based on microcalorimeters

Caroline Kilbourne and Simon Bandler

NASA Goddard Space Flight Center




Looking specifically at microcalorimeters (operated at $T < 0.1$ K)




- **The leading microcalorimeter thermometer technologies**
 - Resistance (semiconductor thermistors and superconductors at their phase transition)
 - Magnetically coupled calorimeters
- **What is the state of the art for the leading microcalorimeter sensor and read-out technologies? How far can the limits be pushed?**

Silicon thermistor-based calorimeter array for Astro-H

- Base temperature of 50 mK
- 36 pixels – silicon thermistors on 0.83 mm pitch with HgTe absorbers
- Resolution at 6 keV ranges from 3.6 – 4.6 eV across EM and FM arrays
- Lack of large-scale read-out technology limits arrays to a few hundred pixels
 - Overtaken by TES arrays and SQUID multiplexing
 - Nonetheless, Astro-H is an important pathfinder




SX5 FM
candidate array




Transition-edge sensors (TES) – basic pixels

- The temperature and current dependence of the transition from the zero-resistance to normal-resistance state is used for thermometry
- Consist of thermometer (with superconducting leads and normal-metal features), x-ray absorber, and controlled link to heat sink


(a)



(b)



(c)





- Pixel pitch → thermometer size → transition properties and whether membrane needed for thermal link
 - “small” TES thermometers < 0.05 mm; “standard” ~ 0.14 mm

“Standard” TES pixels –XMS baseline of IXO, Athena, etc.



■ XMS reference design based on GSFC TES design

- Membrane-isolated Mo/Au TES with $T_c \sim 90$ mK, (base temperature at 50 mK)
- Electroplated Bi/Au absorbers, 0.25 – 0.30 mm pitch
- 1.8 eV resolution demonstrated, 2 – 3 eV routine in this design
- Multiplexed SQUID read-out close to requirements for few-thousand pixel array
- 32x32 arrays with microstrip leads successfully fabricated





“Small” TES pixels

- Small pixels suited to shorter focal lengths and/or higher spatial resolution
- In small TES devices, T_c depends sensitively on current – extends linear operating range of pixels
- Don't need membrane isolation; small size limits coupling to solid substrate
 - Heat sinking of solid substrate minimizes thermal crosstalk
- Through choice of T_c , can be optimized for speed (0.03 ms fall time) or resolution (0.9 eV FWHM) (GSFC devices).



Inductive thermometers – using temperature dependence of paramagnetism or magnetic penetration of a superconductor




- Arrays of Nb meanders with layer of magnetic material (Au:Er) or a low- T_c superconductor (Mo/Au), with high-fill-factor absorbers as with TES.
 - change of magnetization measured as change of inductance
- The Heidelberg group has achieved just better than 2.0 eV resolution at 6 keV with a Au:Er metallic magnetic calorimeter (MMC).
- GSFC group has obtained 2.3 eV resolution with Mo/Au magnetic penetration thermometer (MPT).

Magnetically coupled calorimeters (MCC) compared with TES

- **MCCs are intrinsically dissipationless**
 - very large-format focal-plane arrays
- **MCC sensor material is electrically isolated**
 - can be directly connected to metallic heat sink – simplifying reduction of thermal crosstalk
- **Dissipation in TES calorimeters allows electrothermal feedback**
 - stabilizes operating temperature, relaxing temperature stability required at heat sink
- **TES read-out allows easy signal filtering, greatly simplifying multiplexing.**


Each has advantages and disadvantages – continued parallel investment in both TES and MCCs is needed.

Using the non-equilibrium signal in equilibrium devices for position discrimination



- Multiple absorbers connected thermally to the same thermometer via different thermal links
- Demonstrated for TESs and MMCs
 - 2.4 eV resolution obtained in 9-pixel TES device with 0.065 mm pixels
- Ideal “hydra” obtains somewhat worse resolution than for one big pixel of the same area due to thermal fluctuations between the absorbers.

Multiplexed TES read out: switched SQUID multiplexing



- XMS reference design included time-division multiplexing (TDM)
 - Individual TES pixels are coupled (via each pixel's SQUID) to a single amplifier
 - Multiplexed by sequential switching between SQUIDs
 - Used in TRL-4 TES read-out demo in 2008 (2.6 – 3.1 eV across 16 mux'd TESs)
- Code Division Multiplexing (CDM) will soon reach TDM TRL level
 - All pixels ON all the time, polarity of coupling is switched
 - CDM has a \sqrt{N} noise advantage over TDM, where N is the multiplexing scale
 - IXO/XMS noise budget was extremely tight – CDM could provide important margin
 - Facilitates faster pixels with larger slew rates by providing the noise margin to allow the coupling of the TES to the input SQUID to be reduced
- CDM demonstrated: < 3 eV on 16 switched pixels using flux-matrixed CDM

Frequency domain multiplexing (FDM)

■ TES bias modulation

- Different TES pixels AC-biased at different frequencies read out by single SQUID
- X-ray pulses seen in amplitude modulation
- Like CDM, pixels on all the time, imparting a \sqrt{N} advantage over TDM
- However, in identical pixels tested with AC and DC bias, significantly better resolution was obtained in the DC bias case, which may be fundamental

■ Microwave multiplexing


- Pixel electronics form high-Q microwave resonant circuits (GHz scale), hundreds of which can be combined on a single coax
- For TESs, MMCs, and MPTs, an unshunted rf SQUID is incorporated into the read out of each pixel, which is in turn coupled to a resonant circuit
- A successful microwave multiplexing demonstration has recently been completed at NIST on two gamma-ray TES pixels.

Pushing the limits on spectral resolution

▪ Resolving power for soft x-rays

- All microcalorimeters are non-linear. If we set dT_{\max} as the maximum allowed temperature change, then we need to design the TES so that E_{\max} produces dT_{\max} . E_{\max} scales as C/α , but resolution dE scales as $\sqrt{C/\alpha}$. Thus designing for 0.5 keV instead of 6 keV will not preserve the resolving power achieved at 6 keV. Getting to 0.2 eV resolution at 0.5 keV will not be possible without signal processing techniques (under development) that enable analysis of highly non-linear signals with high resolution. Reducing C by more than a factor of ~ 10 will need reductions in the TES size as well as the absorber C .
- In small TES devices, T_c depends sensitively on current – extending the linear operating range of pixels for a given C/α . However, the Johnson noise of a resistor with current dependence fundamentally increases with this current sensitivity, β .
- Paramagnetic calorimeters also have scaling issues. They are more linear, but their sensitivity scales with the heat capacity of the spin system.

➔ $R = 1000$ within reach at 0.5 keV, $R = 3000$ probable, but much higher than that is unlikely.



Pushing the limits on counting rate

- **Limits at the pixel (trade against resolution and array size)**
 - Decreasing the thermal time constant of a pixel starts to degrade resolution when it approaches thermalization time scales in the absorber.
 - Increased thermal conductance requires higher bias current with ramifications for the operating point in the transition and for heat sinking.
 - Faster paramagnetic calorimeters fundamentally have worse resolution than slower ones ($\tau^{0.25}$ scaling).
 - **Limits on the readout (trade against multiplexer scale, array size)**
 - The more bandwidth per pixel, the fewer pixels per multiplexer channel.
 - **Limits on the signal processing**
 - Historically, optimal digital filtering used. Long records containing a single pulse are required in order to have sufficient frequency resolution in the optimal filter as well as to avoid pile up; resolution degraded when shorter records used.
 - Recently, new optimizations specifically for high count rates are being developed (e.g. by B. Alpert, NIST).
- Expect that 1000/s/pixel rates at > 80% live time will be possible in small sub-arrays with new processing techniques.

Pushing the limits on number of pixels



■ Array architecture

- Limit on bringing out wires between the pixels will be reached at the $\sim 10^4$ pixel level (depending on pitch, etc.). Larger arrays will need close integration of the pixels and the multiplexing. NIST is working on integrating CDM with TES arrays.
- Use of Hydras eases demands on heat-sinking, wiring, and electronics, at the expense of resolution and per-pixel count rate.

■ Wiring to room temperature


- Combining integrated CDM with microwave multiplexing holds the promise of reading out 10^5 sensors (pixel pitch > 0.25 mm) with as few as two coaxes (depending on sensor speed).

➔ Expect to get to 10^5 TES in the next 20 years (10^6 with Hydras), though compromises on count rate may be necessary.





Moore's Law for instrumented TES microcalorimeter arrays (courtesy of Kent Irwin)

Doubling time: 2 years



Moore's Law for instrumented microcalorimeter arrays

Doubling time: 2 years



TES with TDM

TES with CDM

TES or MCC with microwave MUX

field of view

TRADE OFF

resolution

speed