


NOVEL MEASUREMENT TECHNIQUES
(DEVELOPMENT AND ANALYSIS OF SILICON SOLAR
CELLS NEAR 20% EFFICIENCY)

UNIVERSITY OF PENNSYLVANIA

M. Wolf and M. Newhouse

Typical High-Efficiency Device

Traditional lifetime measurement techniques have been directed at extracting a single bulk lifetime from rather simple structures in which nonuniformities, drift fields and surface recombination velocities were ignored.



Real devices have multiple unknown recombination and transport parameters

PRECEDING PAGE BLANK NOT FILMED

PRECEDING PAGE BLANK NOT FILMED





HIGH-EFFICIENCY SOLAR CELLS

Objectives

1. REFINE, AUTOMATE, AND APPLY ASLBI METHOD.
2. DEVELOP GENERIC METHOD FOR EVALUATING AVAILABLE METHODS FOR S AND τ DETERMINATION IN COMPLEX DEVICE STRUCTURES (SOLAR CELLS):
 - A. ESTABLISH GENERAL THEORY.
 - B. APPLY TO DETERMINING RELATIVE ADVANTAGES, LIMITATIONS OF CANDIDATE METHODS.
 - C. DERIVE METHODS FOR REDUCING MEASURED DATA FROM THESE METHODS TO MEANINGFUL S, τ VALUES IN RELEVANT PARTS OF COMPLEX DEVICES.
 - D. IF POSSIBLE, APPLY INSIGHTS GAINED TO DEVELOPMENT OF MORE SUITABLE METHODS.
3. ESTABLISH TO WHAT EXTENT S AND AN "EFFECTIVE τ " CAN BE DETERMINED IN THE COMMONLY USED "EMITTER" ($x_j = 0.2 \mu\text{m}$; $N_{D,S} \approx 10^{19} - 10^{20} \text{ cm}^{-3}$).
(EXAMPLE: FSA - COMMITTEE SOLAR CELL DESIGN)


HIGH-EFFICIENCY SOLAR CELLS

Absolute Spectral Light Beam Induced Current (ASLBIC)




HIGH-EFFICIENCY SOLAR CELLS

ASLBIC Facility




ASLBI C Fitting




Two Fitting Methods

1. Steepest Descent
go down steepest hill!
2. Simplex
NEW METHODS
NOT INTUITIVE
WORKS BEST


HIGH-EFFICIENCY SOLAR CELLS



$3\mu\text{m}$ uniform (theor'l)



Spire 4400 20B
 $0.3\mu\text{m}$ SIMS data \rightarrow 3 layers
(same τ)



A-3-1-216/100-2-3, $100\mu\text{m}$ unif'm.




ORIGINAL PAGE IS
OF POOR QUALITY

50



HIGH-EFFICIENCY SOLAR CELLS

Effect of Bias Light Versus Wavelength for a-3-1-216/2-1-2



HIGH-EFFICIENCY SOLAR CELLS

Measurement Types

- Steady State

vs. wavelength
 vs. distance
 vs. voltage

- Relaxation Constant Measurements


- Decay measurements

vs. time



- Modulation measurements

vs. frequency



$$D \frac{\partial^2 n}{\partial x^2} - \frac{\partial n}{\partial t} = \begin{cases} G_n(x) & \text{steady state} \\ \left[G_n(x) + N_{ph} e^{-\alpha x} \right] & \\ \frac{\partial n}{\partial t} & \text{free decay} \\ \frac{\partial n}{\partial t} = G_n(x, t) & \text{forced oscillation} \\ \left[G_n(x, t) = G(x) e^{j\omega t} \right] & \end{cases}$$

$$n(x) = A e^{\frac{x}{L_n}} + B e^{-\frac{x}{L_n}} + C e^{-\alpha x}$$

$$n(x, t) = \sum_{i=1}^{\infty} A_i e^{-\left(\frac{1}{L_n^2} + \lambda_i\right) t} \phi_i(x)$$

$$n(x, \omega) = \sum_{i=1}^{\infty} \frac{D^2 \phi_i(x)}{\frac{1}{L_n^2} + \lambda_i + j\omega} \phi_i(x) G_n(x, \omega)$$




HIGH-EFFICIENCY SOLAR CELLS

The Meaning of the Constants in Decay Modes

- A. $\beta_i = \frac{1}{\tau} + \lambda_i$ ARE THE RELAXATION CONSTANTS OF THE SYSTEM.
THEY ARE OBSERVABLE.
-
- B. $1/\tau$ CHARACTERIZES THE EFFECTIVE MINORITY CARRIER RECOMBINATION RATE
IN THE VOLUME OF THE LAYER AT WHICH THE OBSERVATION IS MADE.
(IF THIS RATE IS UNIFORM IN THE VOLUME, THEN τ IS THE M.C. LIFETIME.)
-
- C. λ_i ARE THE EIGENVALUES WHICH DETERMINE THE DIFFUSIVE DECAY
OF THE M.C. IN THE LAYER UNDER OBSERVATION.
THEY ARE DETERMINED BY:
1. ANY "SINKS" OUTSIDE OF THE LAYER CONSIDERED
(SUCH AS: SURFACE WITH RECOMBINATION;
BOUNDARY TO JUNCTION IN NOT-FLAT-BAND CONDITION;
BULK RECOMBINATION).
 2. THE TRANSPORT PROPERTIES OF THE LAYER AND INTERVENING LAYERS.
-
- D. WHICH, AND HOW MANY, OF THE INFINITELY MANY λ_i ARE OF SIGNIFICANCE,
IS DETERMINED BY THE INITIAL EXCESS MINORITY CARRIER DISTRIBUTION
AND THE PROPERTIES OF THE LAYER.

HIGH-EFFICIENCY SOLAR CELLS



VARIATION CASE	BASELINE CASE: UNIFORM (ONLY 1 LAYER)		DOPING		D		τ		LSA		LSA, BUT LOW τ IN LAYER 2	
	1	2	1	2	1	2	1	2	1	2	1	2
THICKNESS	60	40	→									
DOPING (cm^{-3})	5E16	5E16	5E16	2E18	5E16	5E16	→		5E16	2E18	→	
D (cm^2/s)	15.5	15.5	→		15.5	5.95	15.5	15.5	15.5	5.95	→	
τ (ns)	33	33	→				33	2	33	2	33	0.27
β	2.4			21.6		4.8		2.2		25.3		11.2

ORIGINAL PAGE IS
OF POOR QUALITY

HIGH-EFFICIENCY SOLAR CELLS

Components of $\beta_1 = \lambda_1 + \frac{\mu E^2}{4D} + 1/\tau$
 first relaxation constant

