

CONFIDENCE LEVEL BASED APPROACH TO TOTAL DOSE SPECIFICATION FOR SPACECRAFT ELECTRONICS

M.A. Xapsos¹, C. Stauffer², A. Phan², S.S. McClure³,
R.L. Ladbury¹, J.A. Pellish¹, M.J. Campola¹ and K.A. LaBel¹

¹NASA Goddard Space Flight Center, Greenbelt, MD

²AS&D, Inc., Greenbelt, MD

³Jet Propulsion Laboratory, California Institute of Technology, Pasadena, CA


Supported by the NASA Living With a Star Space Environment Testbed Program



Outline

- **Background**
- **Device Failure Distributions in Total Dose**
- **Total Dose Distributions in Space**
- **Device Failure Probability during a Mission**
- **Conclusions**
 - **Failure Probability (P_{fail}) vs. Radiation Design Margin (RDM)**


Space Environment Model Use in Spacecraft Life Cycle





Radiation Hardness Assurance Overview


- **Starting with mission requirements, methodology consists of 2 branches of analyses that lead to parts categorization**
 - **Parts analysis**
 - **Environment analysis**





Radiation Hardness Assurance Overview


- **Parts are categorized for flight acceptability and possible radiation lot acceptance testing by Radiation Design Margin (RDM).**
- **$RDM = R_{mf} / R_{spec}$**
- **R_{mf} is mean failure level of part**
- **R_{spec} is total dose level of space environment**
- **Difficulties can arise because**
 - **Part failure levels can vary substantially from the mean, especially COTS**
 - **Environment is dynamic and must be predicted years in advance**
- **RDM based approach results from use of deterministic AP8/AE8 trapped particle models**
- **RDM used as a “catch-all” to cover all uncertainties in environment and device variations**
- **Propose modified approach**
 - **Use device failure probability during a mission instead of RDM**



4 stacked MMS spacecraft

Devices Tested



- **Solid State Devices, Inc.**
SFT2907A bipolar transistors
 - Used for high speed, low power applications
 - 10 devices TID tested for MMS project at NASA/GSFC gamma ray facility to 100 krad(Si)
- **Amptek, Inc.** HV801 optocouplers
 - GaAlAs parts manufactured in liquid phase epitaxially grown process
 - 6 devices DDD tested for JUNO project at UC Davis Cyclotron with 50 MeV protons



Credit: <http://mms.gsfc.nasa.gov>




Device Failure Distribution SFT2907A Bipolar Transistors






Total Dose Probability Distribution Calculations

- **TID and DDD probability distributions were calculated for each orbit and mission duration for confidence levels ranging from 1 to 99%**
 - **AP9/AE9 Monte Carlo code used to simulate 99 histories for each case**
 - **ESP solar proton calculations done for 1 to 99% confidence levels**
 - **All energy spectra were transported through shielding levels from 10 to 1000 mils Al using NOVICE code and converted to doses**
 - **TID and DDD for each radiation were separately ranked for confidence levels ranging from 1 to 99% and summed for same confidence and shielding levels**




TID Probability Distributions for 1 Year 10 – 1000 mils Aluminum

Low Inclination LEO



GEO






Failure Probabilities SFT2907A Bipolar Transistor


$$P_{\text{fail}} = \int [1 - H(x)] \cdot g(x) dx$$

$H(x)$ = CDF for environment dose


$g(x)$ = PDF for device failure


Failure probability (P_{fail}) is the probability of a total dose failure during a mission






Confidence Level vs. RDM for 10 years in GEO 200 mils Al shield





Conclusions

- **An approach to total dose radiation hardness assurance was developed that includes variability of the space radiation environment.**
- **Examples showed radiation environment variability is at least as significant as variability of total dose failures in devices measured in the laboratory.**
 - **New approach is more complete**
 - **Uses consistent evaluation of each radiation in the space environment through use of confidence levels**
- **Advantages of using P_{fail} instead of RDM are:**
 - **P_{fail} is an objectively determined parameter because complete probability distributions are used to calculate it; gives designers more trade space**
 - **Better characterization of device radiation performance**
 - **Allows direct comparison of the total dose threats for different devices and missions, regardless of whether degradation is due to TID or DDD**
 - **More amenable to circuit, system and spacecraft reliability analysis**





Acronyms

- **AE9 – Aerospace electron model-9**
- **AP9 – Aerospace proton model-9**
- **CDF – cumulative distribution function**
- **COTS - commercial off the shelf**
- **DDD – displacement damage dose**
- **ESP – Emission of Solar Protons (model)**
- **FP – failure probability**
- **GEO – geostationary Earth orbit**
- **HST – Hubble Space Telescope**
- **JUNO – JUpiter Near-polar Orbiter**
- **LEO – low Earth orbit**
- **MMS – Magnetospheric MultiScale**
- **NOVICE – Numerical Optimizations, Visualizations and Integrations on Computer Aided Design (CAD)/Constructive Solid Geometry (CSG) Edifices**
- **PDF – probability density function**
- **RDM – radiation design margin**
- **TID – total ionizing dose**

BACKUP SLIDES




Device Failure Distribution HV801 Optocoupler




DDD Probability Distributions for 1 Year 10 – 1000 mils Aluminum



Low Inclination LEO



GEO





Failure Probabilities HV801 Optocoupler

$$P_{fail} = \int [1 - H(x)] \cdot g(x) dx$$

$H(x)$ = CDF for environment dose

$g(x)$ = PDF for device failure

Failure probability (P_{fail}) is the probability of a total dose failure during a mission

